

**Where Used: Part Number 0389856**

<b>Model Name</b>	<b>Diagram</b>
10924B 1979	SHORTING SWITCH
10925B 1979	SHORTING SWITCH
10935B 1979	SHORTING SWITCH
10955B 1979	SHORTING SWITCH
10EL79B 1979	SHORTING SWITCH
10R79B 1979	SHORTING SWITCH
10RL79B 1979	SHORTING SWITCH
10SEL79B 1979	SHORTING SWITCH
15904E 1979	SHORTING SWITCH
15905E 1979	SHORTING SWITCH
15954E 1979	SHORTING SWITCH
15955E 1979	SHORTING SWITCH
15E79E 1979	SHORTING SWITCH
15EL79E 1979	SHORTING SWITCH
15R79E 1979	SHORTING SWITCH
15RL79E 1979	SHORTING SWITCH
25904R 1979	SHORTING SWITCH
25905R 1979	SHORTING SWITCH
25952R 1979	SHORTING SWITCH
25953R 1979	SHORTING SWITCH
25E79R 1979	SHORTING SWITCH
25EL79R 1979	SHORTING SWITCH
25R79R 1979	SHORTING SWITCH
25RL79R 1979	SHORTING SWITCH
35902A 1979	SHORTING SWITCH
35903A 1979	SHORTING SWITCH
35952A 1979	SHORTING SWITCH
35953A 1979	SHORTING SWITCH
35E79A 1979	SHORTING SWITCH
35EL79A 1979	SHORTING SWITCH
35R79A 1979	SHORTING SWITCH
35RL79A 1979	SHORTING SWITCH
50902C 1979	SHORTING SWITCH

50903C 1979	SHORTING SWITCH
50R79C 1979	SHORTING SWITCH
50RL79C 1979	SHORTING SWITCH
55974C 1979	SHORTING SWITCH
55975C 1979	SHORTING SWITCH
55E79C 1979	SHORTING SWITCH
55EL79C 1979	SHORTING SWITCH
6904E 1979	MAGNETO
6905E 1979	MAGNETO
6R79E 1979	MAGNETO
6RL79E 1979	MAGNETO
E10ECSE 1980	SHORTING SWITCH
E10ELCID 1981	SHORTING SWITCH
E10ELCNS 1982	SHORTING SWITCH
E10ELCRA 1984	MAGNETO
E10ELCSE 1980	SHORTING SWITCH
E10ELCTC 1983	MAGNETO
E10RCID 1981	SHORTING SWITCH
E10RCNS 1982	SHORTING SWITCH
E10RCRA 1984	MAGNETO
E10RCSE 1980	SHORTING SWITCH
E10RCTC 1983	MAGNETO
E10RCTR 1983	MAGNETO
E10RLCID 1981	SHORTING SWITCH
E10RLCNS 1982	SHORTING SWITCH
E10RLCRA 1984	MAGNETO
E10RLCSE 1980	SHORTING SWITCH
E10RLCTC 1983	MAGNETO
E10SELCID 1981	SHORTING SWITCH
E10SELCNS 1982	SHORTING SWITCH
E10SELCRA 1984	MAGNETO
E10SELCSE 1980	SHORTING SWITCH
E10SELCTC 1983	MAGNETO
E15ECIS 1981	SHORTING SWITCH
E15ECNC 1982	SHORTING SWITCH

E15ECRM 1984	MAGNETO
E15ECSD 1980	SHORTING SWITCH
E15ECTR 1983	MAGNETO
E15ELCRM 1984	MAGNETO
E15ELCSD 1980	SHORTING SWITCH
E15ELCTR 1983	MAGNETO
E15RCIS 1981	SHORTING SWITCH
E15RCNC 1982	SHORTING SWITCH
E15RCRM 1984	MAGNETO
E15RCSD 1980	SHORTING SWITCH
E15RCTA 1983	MAGNETO
E15RCTR 1983	MAGNETO
E15RLCIS 1981	SHORTING SWITCH
E15RLCNC 1982	SHORTING SWITCH
E15RLCRM 1984	MAGNETO
E15RLCSD 1980	SHORTING SWITCH
E15RLCTA 1983	MAGNETO
E15RLCTR 1983	MAGNETO
E25CNE 1982	SHORTING SWITCH
E25ECIB 1981	SHORTING SWITCH
E25ECIM 1981	SHORTING SWITCH
E25ECRS 1984	SHORTING SWITCH
E25ECTD 1983	SHORTING SWITCH
E25ELCIB 1981	SHORTING SWITCH
E25ELCIM 1981	SHORTING SWITCH
E25ELCNE 1982	SHORTING SWITCH
E25ELCRS 1984	SHORTING SWITCH
E25ELCTD 1983	SHORTING SWITCH
E25RCIM 1981	SHORTING SWITCH
E25RCNB 1982	SHORTING SWITCH
E25RCRD 1984	SHORTING SWITCH
E25RCSA 1980	SHORTING SWITCH
E25RCTE 1983	SHORTING SWITCH
E25RLCIM 1981	SHORTING SWITCH
E25RLCNB 1982	SHORTING SWITCH

E25RLCRD 1984	SHORTING SWITCH
E25RLCSA 1980	SHORTING SWITCH
E25RLCTE 1983	SHORTING SWITCH
E25RSA 1981	SHORTING SWITCH
E25RSLA 1981	SHORTING SWITCH
E25RSLS 1983	SHORTING SWITCH
E25RSS 1983	SHORTING SWITCH
E25RW CIM 1981	SHORTING SWITCH
E25RW CRD 1984	SHORTING SWITCH
E25RW CTE 1983	SHORTING SWITCH
E25RWLCIM 1981	SHORTING SWITCH
E25RWLCD 1984	SHORTING SWITCH
E25RWLCTE 1983	SHORTING SWITCH
E25TECIM 1981	SHORTING SWITCH
E25TECNB 1982	SHORTING SWITCH
E25TECRD 1984	SHORTING SWITCH
E25TECSA 1980	SHORTING SWITCH
E25TECTE 1983	SHORTING SWITCH
E25TELCIM 1981	SHORTING SWITCH
E25TELCNB 1982	SHORTING SWITCH
E25TEL CRD 1984	SHORTING SWITCH
E25TEL CSA 1980	SHORTING SWITCH
E25TEL CTE 1983	SHORTING SWITCH
E30ECRR 1984	SHORTING SWITCH
E30ELCRR 1984	SHORTING SWITCH
E35ECIG 1981	SHORTING SWITCH
E35ECND 1982	SHORTING SWITCH
E35ECRR 1984	SHORTING SWITCH
E35ECSM 1980	SHORTING SWITCH
E35ECTS 1983	SHORTING SWITCH
E35ELCIG 1981	SHORTING SWITCH
E35ELCND 1982	SHORTING SWITCH
E35ELCRR 1984	SHORTING SWITCH
E35ELCSM 1980	SHORTING SWITCH
E35ELCTS 1983	SHORTING SWITCH

E35RCIG 1981	SHORTING SWITCH
E35RCND 1982	SHORTING SWITCH
E35RCRR 1984	SHORTING SWITCH
E35RCTS 1983	SHORTING SWITCH
E35RLCIG 1981	SHORTING SWITCH
E35RLCND 1982	SHORTING SWITCH
E35RLCRR 1984	SHORTING SWITCH
E35RLCTS 1983	SHORTING SWITCH
E35TCSM 1980	SHORTING SWITCH
E35TELCNB 1982	SHORTING SWITCH
E35TELCRR 1984	SHORTING SWITCH
E35TELCTS 1983	SHORTING SWITCH
E35TLESM 1980	SHORTING SWITCH
E40RWCR 1984	IGNITION
E40RWLCRA 1984	IGNITION
E55RLCSA 1980	SHORTING SWITCH
E60ECSR 1980	SHORTING SWITCH
E60ELCSR 1980	SHORTING SWITCH
J10ECSE 1980	SHORTING SWITCH
J10ELCID 1981	SHORTING SWITCH
J10ELCNS 1982	SHORTING SWITCH
J10ELCRA 1984	MAGNETO
J10ELCSE 1980	SHORTING SWITCH
J10ELCTC 1983	MAGNETO
J10RCID 1981	SHORTING SWITCH
J10RCNS 1982	SHORTING SWITCH
J10RCRA 1984	MAGNETO
J10RCSE 1980	SHORTING SWITCH
J10RCTC 1983	MAGNETO
J10RCTR 1983	MAGNETO
J10RLCID 1981	SHORTING SWITCH
J10RLCNS 1982	SHORTING SWITCH
J10RLCRA 1984	MAGNETO
J10RLCSE 1980	SHORTING SWITCH
J10RLCTC 1983	MAGNETO

J10RLCTR 1983	MAGNETO
J10SELCID 1981	SHORTING SWITCH
J10SELCNS 1982	SHORTING SWITCH
J10SELCRA 1984	MAGNETO
J10SELCSE 1980	SHORTING SWITCH
J10SELCTC 1983	MAGNETO
J15ECIS 1981	SHORTING SWITCH
J15ECNC 1982	SHORTING SWITCH
J15ECRM 1984	MAGNETO
J15ECS 1980	SHORTING SWITCH
J15ECTR 1983	MAGNETO
J15ELCRM 1984	MAGNETO
J15ELCSD 1980	SHORTING SWITCH
J15ELCTR 1983	MAGNETO
J15RCIS 1981	SHORTING SWITCH
J15RCNC 1982	SHORTING SWITCH
J15RCRM 1984	MAGNETO
J15RCSD 1980	SHORTING SWITCH
J15RCTA 1983	MAGNETO
J15RCTR 1983	MAGNETO
J15RLCIS 1981	SHORTING SWITCH
J15RLCNC 1982	SHORTING SWITCH
J15RLCRM 1984	MAGNETO
J15RLCSD 1980	SHORTING SWITCH
J15RLCTA 1983	MAGNETO
J15RLCTR 1983	MAGNETO
J25ECIB 1981	SHORTING SWITCH
J25ECIM 1981	SHORTING SWITCH
J25ECNE 1982	SHORTING SWITCH
J25ECRS 1984	SHORTING SWITCH
J25ECTD 1983	SHORTING SWITCH
J25ELCIB 1981	SHORTING SWITCH
J25ELCIM 1981	SHORTING SWITCH
J25ELCNE 1982	SHORTING SWITCH
J25ELCRS 1984	SHORTING SWITCH

J25ELCTD 1983	SHORTING SWITCH
J25RCIM 1981	SHORTING SWITCH
J25RCNB 1982	SHORTING SWITCH
J25RCRD 1984	SHORTING SWITCH
J25RCSA 1980	SHORTING SWITCH
J25RCTE 1983	SHORTING SWITCH
J25RELCNB 1982	SHORTING SWITCH
J25RLCIM 1981	SHORTING SWITCH
J25RLCNB 1982	SHORTING SWITCH
J25RLCRD 1984	SHORTING SWITCH
J25RLCSA 1980	SHORTING SWITCH
J25RLCTE 1983	SHORTING SWITCH
J25RSA 1981	SHORTING SWITCH
J25RSLA 1981	SHORTING SWITCH
J25RSLS 1983	SHORTING SWITCH
J25RSS 1983	SHORTING SWITCH
J25RWCIM 1981	SHORTING SWITCH
J25RWCRD 1984	SHORTING SWITCH
J25RWCTE 1983	SHORTING SWITCH
J25RWLCIM 1981	SHORTING SWITCH
J25RWLCRD 1984	SHORTING SWITCH
J25RWLCTE 1983	SHORTING SWITCH
J25TECIM 1981	SHORTING SWITCH
J25TECNB 1982	SHORTING SWITCH
J25TECRD 1984	SHORTING SWITCH
J25TECSA 1980	SHORTING SWITCH
J25TECTE 1983	SHORTING SWITCH
J25TELCIM 1981	SHORTING SWITCH
J25TELIRD 1984	SHORTING SWITCH
J25TELCSA 1980	SHORTING SWITCH
J25TELCTE 1983	SHORTING SWITCH
J30ECRR 1984	SHORTING SWITCH
J30ELCRR 1984	SHORTING SWITCH
J35ECIG 1981	SHORTING SWITCH
J35ECND 1982	SHORTING SWITCH

J35ECRR 1984	SHORTING SWITCH
J35ECSM 1980	SHORTING SWITCH
J35ECTS 1983	SHORTING SWITCH
J35ELCIG 1981	SHORTING SWITCH
J35ELCND 1982	SHORTING SWITCH
J35ELCRR 1984	SHORTING SWITCH
J35ELCSM 1980	SHORTING SWITCH
J35ELCTS 1983	SHORTING SWITCH
J35RCIG 1981	SHORTING SWITCH
J35RCND 1982	SHORTING SWITCH
J35RCRR 1984	SHORTING SWITCH
J35RCSM 1980	SHORTING SWITCH
J35RCTS 1983	SHORTING SWITCH
J35RLCIG 1981	SHORTING SWITCH
J35RLCND 1982	SHORTING SWITCH
J35RLCRR 1984	SHORTING SWITCH
J35RLCSM 1980	SHORTING SWITCH
J35RLCTS 1983	SHORTING SWITCH
J35TELCNB 1982	SHORTING SWITCH
J35TELCRR 1984	SHORTING SWITCH
J35TELCTS 1983	SHORTING SWITCH
J40RWCR 1984	IGNITION
J40RWLCR 1984	IGNITION
J55RLCSA 1980	SHORTING SWITCH
J60ECSR 1980	SHORTING SWITCH
J60ELCSR 1980	SHORTING SWITCH