

Where Used: Part Number 0390680

Model Name	Diagram
E10ECOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10ELCID 1981	EXHAUST HOUSING
E10ELCNS 1982	EXHAUST HOUSING
E10ELCOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10ELCRA 1984	MIDSECTION (10SEL ONLY)
E10ELCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E10ELCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E10ELCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E10RCID 1981	EXHAUST HOUSING
E10RCNS 1982	EXHAUST HOUSING
E10RCOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10RCRA 1984	MIDSECTION (10SEL ONLY)
E10RCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E10RCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E10RCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E10RCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E10RCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E10RLCID 1981	EXHAUST HOUSING
E10RLCNS 1982	EXHAUST HOUSING
E10RLCOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10RLCRA 1984	MIDSECTION (10SEL ONLY)
E10RLCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E10RLCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E10RLCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E10SELCID 1981	EXHAUST HOUSING
E10SELCNS 1982	EXHAUST HOUSING
E10SELCOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10SELCRA 1984	MIDSECTION (10SEL ONLY)
E10SELCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E10SELCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E10SELCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15ECIS 1981	EXHAUST HOUSING
E15ECNC 1982	EXHAUST HOUSING

E15ECOB 1985	STEERING HANDLE & THROTTLE CONTROL
E15ECRM 1984	MIDSECTION (10SEL ONLY)
E15ECRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E15ECTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15ECTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15ELCOB 1985	STEERING HANDLE & THROTTLE CONTROL
E15ELCRM 1984	MIDSECTION (10SEL ONLY)
E15ELCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E15ELCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15ELCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15RCIS 1981	EXHAUST HOUSING
E15RCNC 1982	EXHAUST HOUSING
E15RCOB 1985	STEERING HANDLE & THROTTLE CONTROL
E15RCRM 1984	MIDSECTION (10SEL ONLY)
E15RCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E15RCTA 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15RCTA 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15RCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15RCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15RLCIS 1981	EXHAUST HOUSING
E15RLCNC 1982	EXHAUST HOUSING
E15RLCOB 1985	STEERING HANDLE & THROTTLE CONTROL
E15RLCRM 1984	MIDSECTION (10SEL ONLY)
E15RLCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E15RLCTA 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15RLCTA 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15RLCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15RLCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10ECOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10ELCID 1981	EXHAUST HOUSING
J10ELCNS 1982	EXHAUST HOUSING
J10ELCOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10ELCRA 1984	MIDSECTION (10SEL ONLY)
J10ELCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J10ELCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS

J10ELCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10RCID 1981	EXHAUST HOUSING
J10RCNS 1982	EXHAUST HOUSING
J10RCOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10RCRA 1984	MIDSECTION (10SEL ONLY)
J10RCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J10RCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J10RCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10RCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J10RCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10RLCID 1981	EXHAUST HOUSING
J10RLCNS 1982	EXHAUST HOUSING
J10RLCOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10RLCRA 1984	MIDSECTION (10SEL ONLY)
J10RLCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J10RLCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J10RLCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10RLCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J10RLCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10SELCID 1981	EXHAUST HOUSING
J10SELCNS 1982	EXHAUST HOUSING
J10SELCOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10SELCRA 1984	MIDSECTION (10SEL ONLY)
J10SELCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J10SELCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J10SELCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J15ECIS 1981	EXHAUST HOUSING
J15ECNC 1982	EXHAUST HOUSING
J15ECOB 1985	STEERING HANDLE & THROTTLE CONTROL
J15ECRM 1984	MIDSECTION (10SEL ONLY)
J15ECRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J15ECTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15ECTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J15ELCOB 1985	STEERING HANDLE & THROTTLE CONTROL
J15ELCRM 1984	MIDSECTION (10SEL ONLY)

J15ELCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J15ELCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15ELCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J15RCIS 1981	EXHAUST HOUSING
J15RCNC 1982	EXHAUST HOUSING
J15RCOB 1985	STEERING HANDLE & THROTTLE CONTROL
J15RCRM 1984	MIDSECTION (10SEL ONLY)
J15RCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J15RCTA 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15RCTA 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J15RCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15RCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J15RLCIS 1981	EXHAUST HOUSING
J15RLCNC 1982	EXHAUST HOUSING
J15RLCOB 1985	STEERING HANDLE & THROTTLE CONTROL
J15RLCRM 1984	MIDSECTION (10SEL ONLY)
J15RLCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J15RLCTA 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15RLCTA 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J15RLCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15RLCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS