

Where Used: Part Number 0391105

Model Name	Diagram
10924B 1979	EXHAUST HOUSING
10925B 1979	EXHAUST HOUSING
10935B 1979	EXHAUST HOUSING
10955B 1979	EXHAUST HOUSING
10EL79B 1979	EXHAUST HOUSING
10R79B 1979	EXHAUST HOUSING
10RL79B 1979	EXHAUST HOUSING
10SEL79B 1979	EXHAUST HOUSING
15904E 1979	EXHAUST HOUSING
15905E 1979	EXHAUST HOUSING
15954E 1979	EXHAUST HOUSING
15955E 1979	EXHAUST HOUSING
15E79E 1979	EXHAUST HOUSING
15EL79E 1979	EXHAUST HOUSING
15R79E 1979	EXHAUST HOUSING
15RL79E 1979	EXHAUST HOUSING
E10ECCD 1988	STEERING HANDLE & THROTTLE CONTROL
E10ECDB 1986	STEERING HANDLE & THROTTLE CONTROL
E10ECES 1989	STEERING HANDLE & THROTTLE CONTROL
E10ECOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10ECSE 1980	EXHAUST HOUSING
E10ECUE 1987	STEERING HANDLE & THROTTLE CONTROL
E10EEIR 1991	STEERING HANDLE & THROTTLE CONTROL
E10EENA 1992	STEERING HANDLE & THROTTLE CONTROL
E10EESC 1990	STEERING HANDLE & THROTTLE CONTROL
E10ELCCD 1988	STEERING HANDLE & THROTTLE CONTROL
E10ELCDB 1986	STEERING HANDLE & THROTTLE CONTROL
E10ELCES 1989	STEERING HANDLE & THROTTLE CONTROL
E10ELCID 1981	EXHAUST HOUSING
E10ELCNS 1982	EXHAUST HOUSING
E10ELCOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10ELCRA 1984	MIDSECTION (10SEL ONLY)
E10ELCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)

E10ELCSE 1980	EXHAUST HOUSING
E10ELCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E10ELCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E10ELCUE 1987	STEERING HANDLE & THROTTLE CONTROL
E10ELEIR 1991	STEERING HANDLE & THROTTLE CONTROL
E10ELENA 1992	STEERING HANDLE & THROTTLE CONTROL
E10ELESC 1990	STEERING HANDLE & THROTTLE CONTROL
E10RCCD 1988	STEERING HANDLE & THROTTLE CONTROL
E10RCDB 1986	STEERING HANDLE & THROTTLE CONTROL
E10RCES 1989	STEERING HANDLE & THROTTLE CONTROL
E10RCID 1981	EXHAUST HOUSING
E10RCNS 1982	EXHAUST HOUSING
E10RCOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10RCRA 1984	MIDSECTION (10SEL ONLY)
E10RCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E10RCSE 1980	EXHAUST HOUSING
E10RCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E10RCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E10RCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E10RCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E10RCUE 1987	STEERING HANDLE & THROTTLE CONTROL
E10REIR 1991	STEERING HANDLE & THROTTLE CONTROL
E10RELEIR 1991	STEERING HANDLE & THROTTLE CONTROL
E10RELENA 1992	STEERING HANDLE & THROTTLE CONTROL
E10RELESC 1990	STEERING HANDLE & THROTTLE CONTROL
E10RENA 1992	STEERING HANDLE & THROTTLE CONTROL
E10RESC 1990	STEERING HANDLE & THROTTLE CONTROL
E10RLCCD 1988	STEERING HANDLE & THROTTLE CONTROL
E10RLCDB 1986	STEERING HANDLE & THROTTLE CONTROL
E10RLCES 1989	STEERING HANDLE & THROTTLE CONTROL
E10RLCID 1981	EXHAUST HOUSING
E10RLCNS 1982	EXHAUST HOUSING
E10RLCOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10RLCRA 1984	MIDSECTION (10SEL ONLY)
E10RLCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)

E10RLCSE 1980	EXHAUST HOUSING
E10RLCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E10RLCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E10RLCUE 1987	STEERING HANDLE & THROTTLE CONTROL
E10RLEIR 1991	STEERING HANDLE & THROTTLE CONTROL
E10RLENA 1992	STEERING HANDLE & THROTTLE CONTROL
E10RLESC 1990	STEERING HANDLE & THROTTLE CONTROL
E10SELCCD 1988	STEERING HANDLE & THROTTLE CONTROL
E10SELCDB 1986	STEERING HANDLE & THROTTLE CONTROL
E10SELCEC 1989	STEERING HANDLE & THROTTLE CONTROL
E10SELCID 1981	EXHAUST HOUSING
E10SELCNS 1982	EXHAUST HOUSING
E10SELCOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10SELCRA 1984	MIDSECTION (10SEL ONLY)
E10SELCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E10SELCSE 1980	EXHAUST HOUSING
E10SELCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E10SELCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E10SELCUE 1987	STEERING HANDLE & THROTTLE CONTROL
E10SELEIR 1991	STEERING HANDLE & THROTTLE CONTROL
E10SELENA 1992	STEERING HANDLE & THROTTLE CONTROL
E10SELESC 1990	STEERING HANDLE & THROTTLE CONTROL
E15ECCS 1988	STEERING HANDLE & THROTTLE CONTROL
E15ECDE 1986	STEERING HANDLE & THROTTLE CONTROL
E15ECEC 1989	STEERING HANDLE & THROTTLE CONTROL
E15ECIS 1981	EXHAUST HOUSING
E15ECNC 1982	EXHAUST HOUSING
E15ECOB 1985	STEERING HANDLE & THROTTLE CONTROL
E15ECRM 1984	MIDSECTION (10SEL ONLY)
E15ECRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E15ECSA 1980	EXHAUST HOUSING
E15ECTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15ECTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15ECUD 1987	STEERING HANDLE & THROTTLE CONTROL
E15EEIA 1991	STEERING HANDLE & THROTTLE CONTROL

E15EENM 1992	STEERING HANDLE & THROTTLE CONTROL
E15EESR 1990	STEERING HANDLE & THROTTLE CONTROL
E15ELCCS 1988	STEERING HANDLE & THROTTLE CONTROL
E15ELCDE 1986	STEERING HANDLE & THROTTLE CONTROL
E15ELCEC 1989	STEERING HANDLE & THROTTLE CONTROL
E15ELCOB 1985	STEERING HANDLE & THROTTLE CONTROL
E15ELCRM 1984	MIDSECTION (10SEL ONLY)
E15ELCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E15ELCSD 1980	EXHAUST HOUSING
E15ELCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15ELCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15ELCUD 1987	STEERING HANDLE & THROTTLE CONTROL
E15ELEIA 1991	STEERING HANDLE & THROTTLE CONTROL
E15ELENM 1992	STEERING HANDLE & THROTTLE CONTROL
E15ELESR 1990	STEERING HANDLE & THROTTLE CONTROL
E15RCCS 1988	STEERING HANDLE & THROTTLE CONTROL
E15RCDE 1986	STEERING HANDLE & THROTTLE CONTROL
E15RCEC 1989	STEERING HANDLE & THROTTLE CONTROL
E15RCIS 1981	EXHAUST HOUSING
E15RCNC 1982	EXHAUST HOUSING
E15RCOB 1985	STEERING HANDLE & THROTTLE CONTROL
E15RCRM 1984	MIDSECTION (10SEL ONLY)
E15RCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E15RCSD 1980	EXHAUST HOUSING
E15RCTA 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15RCTA 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15RCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15RCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15RCUD 1987	STEERING HANDLE & THROTTLE CONTROL
E15REIA 1991	STEERING HANDLE & THROTTLE CONTROL
E15RELEIA 1991	STEERING HANDLE & THROTTLE CONTROL
E15RELENM 1992	STEERING HANDLE & THROTTLE CONTROL
E15RELESR 1990	STEERING HANDLE & THROTTLE CONTROL
E15RENM 1992	STEERING HANDLE & THROTTLE CONTROL
E15RESR 1990	STEERING HANDLE & THROTTLE CONTROL

E15RLCCS 1988	STEERING HANDLE & THROTTLE CONTROL
E15RLCDE 1986	STEERING HANDLE & THROTTLE CONTROL
E15RLCEC 1989	STEERING HANDLE & THROTTLE CONTROL
E15RLCIS 1981	EXHAUST HOUSING
E15RLCNC 1982	EXHAUST HOUSING
E15RLCOB 1985	STEERING HANDLE & THROTTLE CONTROL
E15RLCRM 1984	MIDSECTION (10SEL ONLY)
E15RLCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E15RLCSD 1980	EXHAUST HOUSING
E15RLCTA 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15RLCTA 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15RLCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15RLCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15RLCUD 1987	STEERING HANDLE & THROTTLE CONTROL
E15RLEIA 1991	STEERING HANDLE & THROTTLE CONTROL
E15RLENM 1992	STEERING HANDLE & THROTTLE CONTROL
E15RLESR 1990	STEERING HANDLE & THROTTLE CONTROL
J10ECCD 1988	STEERING HANDLE & THROTTLE CONTROL
J10ECDB 1986	STEERING HANDLE & THROTTLE CONTROL
J10ECES 1989	STEERING HANDLE & THROTTLE CONTROL
J10ECOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10ECSE 1980	EXHAUST HOUSING
J10ECUE 1987	STEERING HANDLE & THROTTLE CONTROL
J10EEIR 1991	STEERING HANDLE & THROTTLE CONTROL
J10EENA 1992	STEERING HANDLE & THROTTLE CONTROL
J10EESC 1990	STEERING HANDLE & THROTTLE CONTROL
J10ELCCD 1988	STEERING HANDLE & THROTTLE CONTROL
J10ELCDB 1986	STEERING HANDLE & THROTTLE CONTROL
J10ELCES 1989	STEERING HANDLE & THROTTLE CONTROL
J10ELCID 1981	EXHAUST HOUSING
J10ELCNS 1982	EXHAUST HOUSING
J10ELCOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10ELCRA 1984	MIDSECTION (10SEL ONLY)
J10ELCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J10ELCSE 1980	EXHAUST HOUSING

J10ELCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J10ELCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10ELCUE 1987	STEERING HANDLE & THROTTLE CONTROL
J10ELEIR 1991	STEERING HANDLE & THROTTLE CONTROL
J10ELENA 1992	STEERING HANDLE & THROTTLE CONTROL
J10ELESC 1990	STEERING HANDLE & THROTTLE CONTROL
J10RCCD 1988	STEERING HANDLE & THROTTLE CONTROL
J10RCDB 1986	STEERING HANDLE & THROTTLE CONTROL
J10RCES 1989	STEERING HANDLE & THROTTLE CONTROL
J10RCID 1981	EXHAUST HOUSING
J10RCNS 1982	EXHAUST HOUSING
J10RCOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10RCRA 1984	MIDSECTION (10SEL ONLY)
J10RCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J10RCSE 1980	EXHAUST HOUSING
J10RCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J10RCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10RCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J10RCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10RCUE 1987	STEERING HANDLE & THROTTLE CONTROL
J10REIR 1991	STEERING HANDLE & THROTTLE CONTROL
J10RELEIR 1991	STEERING HANDLE & THROTTLE CONTROL
J10RELENA 1992	STEERING HANDLE & THROTTLE CONTROL
J10RELESC 1990	STEERING HANDLE & THROTTLE CONTROL
J10RENA 1992	STEERING HANDLE & THROTTLE CONTROL
J10RESC 1990	STEERING HANDLE & THROTTLE CONTROL
J10RLCCD 1988	STEERING HANDLE & THROTTLE CONTROL
J10RLCDB 1986	STEERING HANDLE & THROTTLE CONTROL
J10RLCES 1989	STEERING HANDLE & THROTTLE CONTROL
J10RLCID 1981	EXHAUST HOUSING
J10RLCNS 1982	EXHAUST HOUSING
J10RLCOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10RLCRA 1984	MIDSECTION (10SEL ONLY)
J10RLCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J10RLCSE 1980	EXHAUST HOUSING

J10RLCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J10RLCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10RLCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J10RLCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10RLCUE 1987	STEERING HANDLE & THROTTLE CONTROL
J10RLEIR 1991	STEERING HANDLE & THROTTLE CONTROL
J10RLENA 1992	STEERING HANDLE & THROTTLE CONTROL
J10RLESC 1990	STEERING HANDLE & THROTTLE CONTROL
J10SELCCD 1988	STEERING HANDLE & THROTTLE CONTROL
J10SELCDB 1986	STEERING HANDLE & THROTTLE CONTROL
J10SELCEC 1989	STEERING HANDLE & THROTTLE CONTROL
J10SELCID 1981	EXHAUST HOUSING
J10SELCNS 1982	EXHAUST HOUSING
J10SELCOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10SELCRA 1984	MIDSECTION (10SEL ONLY)
J10SELCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J10SELCSE 1980	EXHAUST HOUSING
J10SELCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J10SELCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10SELCUE 1987	STEERING HANDLE & THROTTLE CONTROL
J10SELEIR 1991	STEERING HANDLE & THROTTLE CONTROL
J10SELENA 1992	STEERING HANDLE & THROTTLE CONTROL
J10SELESC 1990	STEERING HANDLE & THROTTLE CONTROL
J15ECCS 1988	STEERING HANDLE & THROTTLE CONTROL
J15ECDE 1986	STEERING HANDLE & THROTTLE CONTROL
J15ECEC 1989	STEERING HANDLE & THROTTLE CONTROL
J15ECIS 1981	EXHAUST HOUSING
J15ECNC 1982	EXHAUST HOUSING
J15ECOB 1985	STEERING HANDLE & THROTTLE CONTROL
J15ECRM 1984	MIDSECTION (10SEL ONLY)
J15ECRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J15ECSO 1980	EXHAUST HOUSING
J15ECTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15ECTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J15ECUD 1987	STEERING HANDLE & THROTTLE CONTROL

J15EEIA 1991	STEERING HANDLE & THROTTLE CONTROL
J15EENM 1992	STEERING HANDLE & THROTTLE CONTROL
J15EESR 1990	STEERING HANDLE & THROTTLE CONTROL
J15ELCCS 1988	STEERING HANDLE & THROTTLE CONTROL
J15ELCDE 1986	STEERING HANDLE & THROTTLE CONTROL
J15ELCEC 1989	STEERING HANDLE & THROTTLE CONTROL
J15ELCOB 1985	STEERING HANDLE & THROTTLE CONTROL
J15ELCRM 1984	MIDSECTION (10SEL ONLY)
J15ELCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J15ELCSD 1980	EXHAUST HOUSING
J15ELCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15ELCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J15ELCUD 1987	STEERING HANDLE & THROTTLE CONTROL
J15ELEIA 1991	STEERING HANDLE & THROTTLE CONTROL
J15ELENM 1992	STEERING HANDLE & THROTTLE CONTROL
J15ELESR 1990	STEERING HANDLE & THROTTLE CONTROL
J15RCCS 1988	STEERING HANDLE & THROTTLE CONTROL
J15RCDE 1986	STEERING HANDLE & THROTTLE CONTROL
J15RCEC 1989	STEERING HANDLE & THROTTLE CONTROL
J15RCIS 1981	EXHAUST HOUSING
J15RCNC 1982	EXHAUST HOUSING
J15RCOB 1985	STEERING HANDLE & THROTTLE CONTROL
J15RCRM 1984	MIDSECTION (10SEL ONLY)
J15RCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J15RCSD 1980	EXHAUST HOUSING
J15RCTA 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15RCTA 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J15RCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15RCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J15RCUD 1987	STEERING HANDLE & THROTTLE CONTROL
J15REIA 1991	STEERING HANDLE & THROTTLE CONTROL
J15RELEIA 1991	STEERING HANDLE & THROTTLE CONTROL
J15RELENM 1992	STEERING HANDLE & THROTTLE CONTROL
J15RELESR 1990	STEERING HANDLE & THROTTLE CONTROL
J15RENM 1992	STEERING HANDLE & THROTTLE CONTROL

J15RESR 1990	STEERING HANDLE & THROTTLE CONTROL
J15RLCCS 1988	STEERING HANDLE & THROTTLE CONTROL
J15RLCDE 1986	STEERING HANDLE & THROTTLE CONTROL
J15RLCEC 1989	STEERING HANDLE & THROTTLE CONTROL
J15RLCIS 1981	EXHAUST HOUSING
J15RLCNC 1982	EXHAUST HOUSING
J15RLCOB 1985	STEERING HANDLE & THROTTLE CONTROL
J15RLCRM 1984	MIDSECTION (10SEL ONLY)
J15RLCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J15RLCSD 1980	EXHAUST HOUSING
J15RLCTA 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15RLCTA 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J15RLCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15RLCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J15RLCUD 1987	STEERING HANDLE & THROTTLE CONTROL
J15RLEIA 1991	STEERING HANDLE & THROTTLE CONTROL
J15RLENM 1992	STEERING HANDLE & THROTTLE CONTROL
J15RLESR 1990	STEERING HANDLE & THROTTLE CONTROL
TE10ELCES 1989	STEERING HANDLE & THROTTLE CONTROL
TE10ELESC 1990	STEERING HANDLE & THROTTLE CONTROL
TE10RELEIR 1991	STEERING HANDLE & THROTTLE CONTROL
TE10RELENA 1992	STEERING HANDLE & THROTTLE CONTROL
TE10RELESC 1990	STEERING HANDLE & THROTTLE CONTROL
TE10RLCES 1989	STEERING HANDLE & THROTTLE CONTROL
TE10RLESC 1990	STEERING HANDLE & THROTTLE CONTROL
TE15RLCEC 1989	STEERING HANDLE & THROTTLE CONTROL
TJ10ELCES 1989	STEERING HANDLE & THROTTLE CONTROL
TJ10ELESC 1990	STEERING HANDLE & THROTTLE CONTROL
TJ10RELEIR 1991	STEERING HANDLE & THROTTLE CONTROL
TJ10RELENA 1992	STEERING HANDLE & THROTTLE CONTROL
TJ10RELESC 1990	STEERING HANDLE & THROTTLE CONTROL
TJ10RLCES 1989	STEERING HANDLE & THROTTLE CONTROL
TJ10RLESC 1990	STEERING HANDLE & THROTTLE CONTROL
TJ15RLCEC 1989	STEERING HANDLE & THROTTLE CONTROL
VE14RCCS 1988	CYLINDER & CRANKCASE

VE14RCEC 1989	CYLINDER & CRANKCASE
VJ14RCCS 1988	CYLINDER & CRANKCASE
VJ14RCEC 1989	CYLINDER & CRANKCASE