

Where Used: Part Number 0391270

Model Name	Diagram
E25CNE 1982	EXHAUST HOUSING- ROPE START ONLY
E25CNE 1982	EXHAUST HOUSING-ELECTRIC START ONLY
E25ECIB 1981	EXHAUST HOUSING - ELECTRIC START ONLY
E25ECIB 1981	EXHAUST HOUSING - ROPE START ONLY
E25ECIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
E25ECIM 1981	EXHAUST HOUSING - ROPE START ONLY
E25ECRS 1984	MIDSECTION - ROPE START
E25ECTD 1983	EXHAUST HOUSING-ROPE START & 25 TE
E25ELCIB 1981	EXHAUST HOUSING - ELECTRIC START ONLY
E25ELCIB 1981	EXHAUST HOUSING - ROPE START ONLY
E25ELCIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
E25ELCIM 1981	EXHAUST HOUSING - ROPE START ONLY
E25ELCNE 1982	EXHAUST HOUSING- ROPE START ONLY
E25ELCNE 1982	EXHAUST HOUSING-ELECTRIC START ONLY
E25ELCRS 1984	MIDSECTION - ROPE START
E25ELCTD 1983	EXHAUST HOUSING-ROPE START & 25 TE
E25RCIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
E25RCIM 1981	EXHAUST HOUSING - ROPE START ONLY
E25RCNB 1982	EXHAUST HOUSING- ROPE START ONLY
E25RCNB 1982	EXHAUST HOUSING-ELECTRIC START ONLY
E25RCRD 1984	MIDSECTION - ROPE START
E25RCTE 1983	EXHAUST HOUSING-ROPE START & 25 TE
E25RLCIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
E25RLCIM 1981	EXHAUST HOUSING - ROPE START ONLY
E25RLCNB 1982	EXHAUST HOUSING- ROPE START ONLY
E25RLCNB 1982	EXHAUST HOUSING-ELECTRIC START ONLY
E25RLCRD 1984	MIDSECTION - ROPE START
E25RLCTE 1983	EXHAUST HOUSING-ROPE START & 25 TE
E25RSA 1981	EXHAUST HOUSING
E25RSLA 1981	EXHAUST HOUSING
E25RSLS 1983	EXHAUST HOUSING
E25RSS 1983	EXHAUST HOUSING
E25RWCIM 1981	EXHAUST HOUSING

E25RWCRD 1984	MIDSECTION
E25RWCTE 1983	EXHAUST HOUSING
E25RWLCIM 1981	EXHAUST HOUSING
E25RWLCRD 1984	MIDSECTION
E25RWLCTE 1983	EXHAUST HOUSING
E25TECIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
E25TECIM 1981	EXHAUST HOUSING - ROPE START ONLY
E25TECNB 1982	EXHAUST HOUSING- ROPE START ONLY
E25TECNB 1982	EXHAUST HOUSING-ELECTRIC START ONLY
E25TECRD 1984	MIDSECTION - ROPE START
E25TECTE 1983	EXHAUST HOUSING-ROPE START & 25 TE
E25TELCIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
E25TELCIM 1981	EXHAUST HOUSING - ROPE START ONLY
E25TELCNB 1982	EXHAUST HOUSING- ROPE START ONLY
E25TELCNB 1982	EXHAUST HOUSING-ELECTRIC START ONLY
E25TELCRD 1984	MIDSECTION - ROPE START
E25TELCTE 1983	EXHAUST HOUSING-ROPE START & 25 TE
J25ECIB 1981	EXHAUST HOUSING - ELECTRIC START ONLY
J25ECIB 1981	EXHAUST HOUSING - ROPE START ONLY
J25ECIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
J25ECIM 1981	EXHAUST HOUSING - ROPE START ONLY
J25ECNE 1982	EXHAUST HOUSING- ROPE START ONLY
J25ECNE 1982	EXHAUST HOUSING-ELECTRIC START ONLY
J25ECRS 1984	MIDSECTION - ROPE START
J25ECTD 1983	EXHAUST HOUSING-ROPE START & 25 TE
J25ELCIB 1981	EXHAUST HOUSING - ELECTRIC START ONLY
J25ELCIB 1981	EXHAUST HOUSING - ROPE START ONLY
J25ELCIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
J25ELCIM 1981	EXHAUST HOUSING - ROPE START ONLY
J25ELCNE 1982	EXHAUST HOUSING- ROPE START ONLY
J25ELCNE 1982	EXHAUST HOUSING-ELECTRIC START ONLY
J25ELCRS 1984	MIDSECTION - ROPE START
J25ELCTD 1983	EXHAUST HOUSING-ROPE START & 25 TE
J25RCIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
J25RCIM 1981	EXHAUST HOUSING - ROPE START ONLY

J25RCNB 1982	EXHAUST HOUSING- ROPE START ONLY
J25RCNB 1982	EXHAUST HOUSING-ELECTRIC START ONLY
J25RCRD 1984	MIDSECTION - ROPE START
J25RCTE 1983	EXHAUST HOUSING-ROPE START & 25 TE
J25RELCNB 1982	EXHAUST HOUSING- ROPE START ONLY
J25RELCNB 1982	EXHAUST HOUSING-ELECTRIC START ONLY
J25RLCIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
J25RLCIM 1981	EXHAUST HOUSING - ROPE START ONLY
J25RLCNB 1982	EXHAUST HOUSING- ROPE START ONLY
J25RLCNB 1982	EXHAUST HOUSING-ELECTRIC START ONLY
J25RLCRD 1984	MIDSECTION - ROPE START
J25RLCTE 1983	EXHAUST HOUSING-ROPE START & 25 TE
J25RSA 1981	EXHAUST HOUSING
J25RSLA 1981	EXHAUST HOUSING
J25RSLS 1983	EXHAUST HOUSING
J25RSS 1983	EXHAUST HOUSING
J25RWCIM 1981	EXHAUST HOUSING
J25RWCRD 1984	MIDSECTION
J25RWCTE 1983	EXHAUST HOUSING
J25RWLCIM 1981	EXHAUST HOUSING
J25RWLCRD 1984	MIDSECTION
J25RWLCTE 1983	EXHAUST HOUSING
J25TECIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
J25TECIM 1981	EXHAUST HOUSING - ROPE START ONLY
J25TECNB 1982	EXHAUST HOUSING- ROPE START ONLY
J25TECNB 1982	EXHAUST HOUSING-ELECTRIC START ONLY
J25TECRD 1984	MIDSECTION - ROPE START
J25TECTE 1983	EXHAUST HOUSING-ROPE START & 25 TE
J25TELCIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
J25TELCIM 1981	EXHAUST HOUSING - ROPE START ONLY
J25TELCRD 1984	MIDSECTION - ROPE START
J25TELCTE 1983	EXHAUST HOUSING-ROPE START & 25 TE