

Where Used: Part Number 0397839

Model Name	Diagram
E10ECCD 1988	FUEL PUMP - ROPE START MODELS
E10ECES 1989	FUEL PUMP - ROPE START MODELS
E10ECUE 1987	FUEL PUMP - EARLY PRODUCTION
E10EEIR 1991	FUEL PUMP - ROPE START MODELS
E10EENA 1992	FUEL PUMP - ROPE START MODELS
E10EESC 1990	FUEL PUMP - ROPE START MODELS
E10ELCCD 1988	FUEL PUMP - ROPE START MODELS
E10ELCES 1989	FUEL PUMP - ROPE START MODELS
E10ELCUE 1987	FUEL PUMP - EARLY PRODUCTION
E10ELEIR 1991	FUEL PUMP - ROPE START MODELS
E10ELENA 1992	FUEL PUMP - ROPE START MODELS
E10ELESC 1990	FUEL PUMP - ROPE START MODELS
E10RCCD 1988	FUEL PUMP - ROPE START MODELS
E10RCES 1989	FUEL PUMP - ROPE START MODELS
E10RCUE 1987	FUEL PUMP - EARLY PRODUCTION
E10REIR 1991	FUEL PUMP - ROPE START MODELS
E10RELEIR 1991	FUEL PUMP - ROPE START MODELS
E10RELENA 1992	FUEL PUMP - ROPE START MODELS
E10RELESC 1990	FUEL PUMP - ROPE START MODELS
E10RENA 1992	FUEL PUMP - ROPE START MODELS
E10RESC 1990	FUEL PUMP - ROPE START MODELS
E10RLCCD 1988	FUEL PUMP - ROPE START MODELS
E10RLCES 1989	FUEL PUMP - ROPE START MODELS
E10RLCUE 1987	FUEL PUMP - EARLY PRODUCTION
E10RLEIR 1991	FUEL PUMP - ROPE START MODELS
E10RLENA 1992	FUEL PUMP - ROPE START MODELS
E10RLESC 1990	FUEL PUMP - ROPE START MODELS
E10SELCCD 1988	FUEL PUMP - ROPE START MODELS
E10SELCES 1989	FUEL PUMP - ROPE START MODELS
E10SELCUE 1987	FUEL PUMP - EARLY PRODUCTION
E10SELEIR 1991	FUEL PUMP - ROPE START MODELS
E10SELENA 1992	FUEL PUMP - ROPE START MODELS
E10SELESC 1990	FUEL PUMP - ROPE START MODELS

E15ECCS 1988	FUEL PUMP - ROPE START MODELS
E15ECEC 1989	FUEL PUMP - ROPE START MODELS
E15ECUD 1987	FUEL PUMP - EARLY PRODUCTION
E15EEIA 1991	FUEL PUMP - ROPE START MODELS
E15EENM 1992	FUEL PUMP - ROPE START MODELS
E15EESR 1990	FUEL PUMP - ROPE START MODELS
E15ELCCS 1988	FUEL PUMP - ROPE START MODELS
E15ELCEC 1989	FUEL PUMP - ROPE START MODELS
E15ELCUD 1987	FUEL PUMP - EARLY PRODUCTION
E15ELEIA 1991	FUEL PUMP - ROPE START MODELS
E15ELENM 1992	FUEL PUMP - ROPE START MODELS
E15ELESR 1990	FUEL PUMP - ROPE START MODELS
E15RCCS 1988	FUEL PUMP - ROPE START MODELS
E15RCEC 1989	FUEL PUMP - ROPE START MODELS
E15RCUD 1987	FUEL PUMP - EARLY PRODUCTION
E15REIA 1991	FUEL PUMP - ROPE START MODELS
E15RELEIA 1991	FUEL PUMP - ROPE START MODELS
E15RELENM 1992	FUEL PUMP - ROPE START MODELS
E15RELESR 1990	FUEL PUMP - ROPE START MODELS
E15RENM 1992	FUEL PUMP - ROPE START MODELS
E15RESR 1990	FUEL PUMP - ROPE START MODELS
E15RLCCS 1988	FUEL PUMP - ROPE START MODELS
E15RLCEC 1989	FUEL PUMP - ROPE START MODELS
E15RLCUD 1987	FUEL PUMP - EARLY PRODUCTION
E15RLEIA 1991	FUEL PUMP - ROPE START MODELS
E15RLENM 1992	FUEL PUMP - ROPE START MODELS
E15RLESR 1990	FUEL PUMP - ROPE START MODELS
J10ECCD 1988	FUEL PUMP - ROPE START MODELS
J10ECES 1989	FUEL PUMP - ROPE START MODELS
J10ECUE 1987	FUEL PUMP - EARLY PRODUCTION
J10EEIR 1991	FUEL PUMP - ROPE START MODELS
J10EENA 1992	FUEL PUMP - ROPE START MODELS
J10EESC 1990	FUEL PUMP - ROPE START MODELS
J10ELCCD 1988	FUEL PUMP - ROPE START MODELS
J10ELCES 1989	FUEL PUMP - ROPE START MODELS

J10ELCUE 1987	FUEL PUMP - EARLY PRODUCTION
J10ELEIR 1991	FUEL PUMP - ROPE START MODELS
J10ELENA 1992	FUEL PUMP - ROPE START MODELS
J10ELESC 1990	FUEL PUMP - ROPE START MODELS
J10RCCD 1988	FUEL PUMP - ROPE START MODELS
J10RCES 1989	FUEL PUMP - ROPE START MODELS
J10RCUE 1987	FUEL PUMP - EARLY PRODUCTION
J10REIR 1991	FUEL PUMP - ROPE START MODELS
J10RELEIR 1991	FUEL PUMP - ROPE START MODELS
J10RELENA 1992	FUEL PUMP - ROPE START MODELS
J10RELESC 1990	FUEL PUMP - ROPE START MODELS
J10RENA 1992	FUEL PUMP - ROPE START MODELS
J10RESC 1990	FUEL PUMP - ROPE START MODELS
J10RLCCD 1988	FUEL PUMP - ROPE START MODELS
J10RLCES 1989	FUEL PUMP - ROPE START MODELS
J10RLCUE 1987	FUEL PUMP - EARLY PRODUCTION
J10RLEIR 1991	FUEL PUMP - ROPE START MODELS
J10RLENA 1992	FUEL PUMP - ROPE START MODELS
J10RLESC 1990	FUEL PUMP - ROPE START MODELS
J10SELCCD 1988	FUEL PUMP - ROPE START MODELS
J10SELCES 1989	FUEL PUMP - ROPE START MODELS
J10SELCUE 1987	FUEL PUMP - EARLY PRODUCTION
J10SELEIR 1991	FUEL PUMP - ROPE START MODELS
J10SELENA 1992	FUEL PUMP - ROPE START MODELS
J10SELESC 1990	FUEL PUMP - ROPE START MODELS
J15ECCS 1988	FUEL PUMP - ROPE START MODELS
J15ECEC 1989	FUEL PUMP - ROPE START MODELS
J15ECUD 1987	FUEL PUMP - EARLY PRODUCTION
J15EEIA 1991	FUEL PUMP - ROPE START MODELS
J15EENM 1992	FUEL PUMP - ROPE START MODELS
J15EESR 1990	FUEL PUMP - ROPE START MODELS
J15ELCCS 1988	FUEL PUMP - ROPE START MODELS
J15ELCEC 1989	FUEL PUMP - ROPE START MODELS
J15ELCUD 1987	FUEL PUMP - EARLY PRODUCTION
J15ELEIA 1991	FUEL PUMP - ROPE START MODELS

J15ELENM 1992	FUEL PUMP - ROPE START MODELS
J15ELESR 1990	FUEL PUMP - ROPE START MODELS
J15RCCS 1988	FUEL PUMP - ROPE START MODELS
J15RCEC 1989	FUEL PUMP - ROPE START MODELS
J15RCUD 1987	FUEL PUMP - EARLY PRODUCTION
J15REIA 1991	FUEL PUMP - ROPE START MODELS
J15RELEIA 1991	FUEL PUMP - ROPE START MODELS
J15RELENM 1992	FUEL PUMP - ROPE START MODELS
J15RELESR 1990	FUEL PUMP - ROPE START MODELS
J15RENM 1992	FUEL PUMP - ROPE START MODELS
J15RESR 1990	FUEL PUMP - ROPE START MODELS
J15RLCCS 1988	FUEL PUMP - ROPE START MODELS
J15RLCEC 1989	FUEL PUMP - ROPE START MODELS
J15RLCUD 1987	FUEL PUMP - EARLY PRODUCTION
J15RLEIA 1991	FUEL PUMP - ROPE START MODELS
J15RLENM 1992	FUEL PUMP - ROPE START MODELS
J15RLESR 1990	FUEL PUMP - ROPE START MODELS
TE10ELCES 1989	FUEL PUMP - ROPE START MODELS
TE10ELESC 1990	FUEL PUMP - ROPE START MODELS
TE10RELEIR 1991	FUEL PUMP - ROPE START MODELS
TE10RELENA 1992	FUEL PUMP - ROPE START MODELS
TE10RELESC 1990	FUEL PUMP - ROPE START MODELS
TE10RLCES 1989	FUEL PUMP - ROPE START MODELS
TE10RLESC 1990	FUEL PUMP - ROPE START MODELS
TE15RLCEC 1989	FUEL PUMP - ROPE START MODELS
TJ10ELCES 1989	FUEL PUMP - ROPE START MODELS
TJ10ELESC 1990	FUEL PUMP - ROPE START MODELS
TJ10RELEIR 1991	FUEL PUMP - ROPE START MODELS
TJ10RELENA 1992	FUEL PUMP - ROPE START MODELS
TJ10RELESC 1990	FUEL PUMP - ROPE START MODELS
TJ10RLCES 1989	FUEL PUMP - ROPE START MODELS
TJ10RLESC 1990	FUEL PUMP - ROPE START MODELS
TJ15RLCEC 1989	FUEL PUMP - ROPE START MODELS