

Where Used: Part Number 0398327

Model Name	Diagram
50FAPLJVB 1993	UPPER INTAKE MANIFOLD
50FAPLJVN 1993	UPPER INTAKE MANIFOLD
50FAPRJVB 1993	UPPER INTAKE MANIFOLD
50FAPRJVN 1993	UPPER INTAKE MANIFOLD
58FAPEJVB 1993	UPPER INTAKE MANIFOLD - 58FAPPJVB & 58FAPEJVB MODELS
58FAPEJVB 1993	UPPER INTAKE MANIFOLD - 58FBPEJVB MODELS
58FAPLJVB 1993	UPPER INTAKE MANIFOLD
58FAPLJVN 1993	UPPER INTAKE MANIFOLD
58FAPPJVB 1993	UPPER INTAKE MANIFOLD - 58FAPPJVB & 58FAPEJVB MODELS
58FAPPJVB 1993	UPPER INTAKE MANIFOLD - 58FBPEJVB MODELS
58FAPRJVB 1993	UPPER INTAKE MANIFOLD
58FAPRJVN 1993	UPPER INTAKE MANIFOLD
58FBPEJVB 1993	UPPER INTAKE MANIFOLD - 58FAPPJVB & 58FAPEJVB MODELS
58FBPEJVB 1993	UPPER INTAKE MANIFOLD - 58FBPEJVB MODELS
BE25ARECA 1998	FUEL SYSTEM
BE25AREDC 1996	FUEL SYSTEM
BE25AREUR 1997	FUEL SYSTEM
BE25ARLECA 1998	FUEL SYSTEM
BE25ARLEDC 1996	FUEL SYSTEM
BE25ARLEUR 1997	FUEL SYSTEM
BE25KECA 1998	FUEL SYSTEM
BE25KEDC 1996	FUEL SYSTEM
BE25KEUR 1997	FUEL SYSTEM
BE25KLECA 1998	FUEL SYSTEM
BE25KLEDC 1996	FUEL SYSTEM
BE25KLEUR 1997	FUEL SYSTEM
BE25QLECA 1998	FUEL SYSTEM
BE25QLEDC 1996	FUEL SYSTEM
BE25QLEUR 1997	FUEL SYSTEM
BE35ARECR 1998	FUEL SYSTEM
BE35AREDS 1996	FUEL SYSTEM
BE35AREEA 1999	FUEL SYSTEM

BE35AREUC 1997	FUEL SYSTEM
BE35ARLECR 1998	FUEL SYSTEM
BE35ARLEDS 1996	FUEL SYSTEM
BE35ARLEUC 1997	FUEL SYSTEM
BE35ARSIB rope start, tiller, 15 in shaft, wht, n/a usa 2001	FUEL SYSTEM
BE35ARSSM 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	FUEL SYSTEM
BE35KECA 1998	FUEL SYSTEM
BE35KEDC 1996	FUEL SYSTEM
BE35KEEM 1999	FUEL SYSTEM
BE35KEUR 1997	FUEL SYSTEM
BE35KECA 1998	FUEL SYSTEM
BE35KLEDC 1996	FUEL SYSTEM
BE35KLEUR 1997	FUEL SYSTEM
BE35KSIE elec start, tiller, 15 in shaft, wht, n/a usa 2001	FUEL SYSTEM
BE35KSSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	FUEL SYSTEM
BE35QLECA 1998	FUEL SYSTEM
BE35QLEDC 1996	FUEL SYSTEM
BE35QLEUR 1997	FUEL SYSTEM
BE50DTLEDC 1996	FUEL PUMP
BE50DTLEUR 1997	FUEL PUMP
BE60ELEDR 1996	FUEL PUMP
BE60ELEUA 1997	FUEL PUMP
BE60TLECM 1998	FUEL PUMP
BE60TLEDR 1996	FUEL PUMP
BE60TLEUA 1997	FUEL PUMP
BE70ELECB 1998	FUEL PUMP
BE70ELEDA 1996	FUEL PUMP
BE70ELEM 1997	FUEL PUMP
BE70TLECB 1998	FUEL PUMP
BE70TLEDA 1996	FUEL PUMP
BE70TLEM 1997	FUEL PUMP
BJ25ARECA 1998	FUEL SYSTEM
BJ25AREDC 1996	FUEL SYSTEM
BJ25AREUR 1997	FUEL SYSTEM

BJ25ARLECA 1998	FUEL SYSTEM
BJ25ARLEDC 1996	FUEL SYSTEM
BJ25ARLEUR 1997	FUEL SYSTEM
BJ25KECA 1998	FUEL SYSTEM
BJ25KEDC 1996	FUEL SYSTEM
BJ25KEUR 1997	FUEL SYSTEM
BJ25KLECA 1998	FUEL SYSTEM
BJ25KLEDC 1996	FUEL SYSTEM
BJ25KLEUR 1997	FUEL SYSTEM
BJ25PL3EEM 1999	FUEL SYSTEM
BJ25PL3SIE elec start, TNT, 20 in shaft 2001	FUEL SYSTEM
BJ25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	FUEL SYSTEM
BJ25QLECA 1998	FUEL SYSTEM
BJ25QLEDC 1996	FUEL SYSTEM
BJ25QLEUR 1997	FUEL SYSTEM
BJ25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	FUEL SYSTEM
BJ35ARECR 1998	FUEL SYSTEM
BJ35AREDS 1996	FUEL SYSTEM
BJ35AREEA 1999	FUEL SYSTEM
BJ35AREUC 1997	FUEL SYSTEM
BJ35ARLECR 1998	FUEL SYSTEM
BJ35ARLEDS 1996	FUEL SYSTEM
BJ35ARLEUC 1997	FUEL SYSTEM
BJ35E3EEM 1999	FUEL SYSTEM
BJ35E3SIE elec start, 15 in shaft, n/a usa 2001	FUEL SYSTEM
BJ35E3SSB 3 Cyl, Elec. Start, 15 IN. shaft, N/A USA 2000	FUEL SYSTEM
BJ35EL3EEM 1999	FUEL SYSTEM
BJ35EL3SIE elec start, 20 in shaft, wht, n/a usa 2001	FUEL SYSTEM
BJ35EL3SSB 3 Cyl, Elec. Start, 20 IN. shaft, N/A USA 2000	FUEL SYSTEM
BJ35EV3SIE elec start, 15 in shaft, wht, n/a usa 2001	FUEL SYSTEM
BJ35EVL3SIE elec start, 20 in shaft, wht, n/a usa 2001	FUEL SYSTEM
BJ35KECA 1998	FUEL SYSTEM
BJ35KEDC 1996	FUEL SYSTEM
BJ35KEEM 1999	FUEL SYSTEM
BJ35KEUR 1997	FUEL SYSTEM

BJ35KLECA 1998	FUEL SYSTEM
BJ35KLEDC 1996	FUEL SYSTEM
BJ35KLEUR 1997	FUEL SYSTEM
BJ35PL3EEM 1999	FUEL SYSTEM
BJ35PL3SIE elec start, TNT, 20 in shaft 2001	FUEL SYSTEM
BJ35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	FUEL SYSTEM
BJ35QLECA 1998	FUEL SYSTEM
BJ35QLEDC 1996	FUEL SYSTEM
BJ35QLEUR 1997	FUEL SYSTEM
BJ35VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	FUEL SYSTEM
BJ50DTLEDC 1996	FUEL PUMP
BJ50DTLEUR 1997	FUEL PUMP
BJ60ELEDR 1996	FUEL PUMP
BJ60ELEUA 1997	FUEL PUMP
BJ60TLECM 1998	FUEL PUMP
BJ60TLEDR 1996	FUEL PUMP
BJ60TLEUA 1997	FUEL PUMP
BJ70ELECB 1998	FUEL PUMP
BJ70ELEDA 1996	FUEL PUMP
BJ70ELEUM 1997	FUEL PUMP
BJ70PLEEE 1999	FUEL PUMP
BJ70PLSIS elec start, TNT, 20 in shaft, n/a usa 2001	FUEL PUMP
BJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	FUEL PUMP
BJ70TLECB 1998	FUEL PUMP
BJ70TLEDA 1996	FUEL PUMP
BJ70TLEUM 1997	FUEL PUMP
E100STLCCA 1988	VRO2 PUMP - 90/110 MODELS
E100STLCEM 1989	VRO2 PUMP - 90/110 MODELS
E100STLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
E100STLEND 1992	VRO2 PUMP - 90/100/115 MODELS
E100STLESB 1990	VRO2 PUMP - 90/100/115 MODELS
E110MLCCA 1988	VRO2 PUMP - 90/110 MODELS
E110MLCEM 1989	VRO2 PUMP - 90/110 MODELS
E110TLCCA 1988	VRO2 PUMP - 90/110 MODELS
E110TLCEM 1989	VRO2 PUMP - 90/110 MODELS

E110TXCCA 1988	VRO2 PUMP - 90/110 MODELS
E110TXCEM 1989	VRO2 PUMP - 90/110 MODELS
E115JLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
E115JLEND 1992	VRO2 PUMP - 90/100/115 MODELS
E115MLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
E115MLEND 1992	VRO2 PUMP - 90/100/115 MODELS
E115MLESB 1990	VRO2 PUMP - 90/100/115 MODELS
E115TLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
E115TLEND 1992	VRO2 PUMP - 90/100/115 MODELS
E115TLESB 1990	VRO2 PUMP - 90/100/115 MODELS
E115TXEIE 1991	VRO2 PUMP - 90/100/115 MODELS
E115TXEND 1992	VRO2 PUMP - 90/100/115 MODELS
E115TXESB 1990	VRO2 PUMP - 90/100/115 MODELS
E150CXCCA 1988	VRO2 PUMP
E150CXCEM 1989	VRO2 PUMP
E150CXEIE 1991	VRO2 PUMP
E150CXESB 1990	VRO2 PUMP
E150JLEIE 1991	VRO2 PUMP
E150STLCCA 1988	VRO2 PUMP
E150STLCEM 1989	VRO2 PUMP
E150STLEIE 1991	VRO2 PUMP
E150STLESB 1990	VRO2 PUMP
E150TLCCA 1988	VRO2 PUMP
E150TLCEM 1989	VRO2 PUMP
E150TLEIE 1991	VRO2 PUMP
E150TLESB 1990	VRO2 PUMP
E150TXCCA 1988	VRO2 PUMP
E150TXCEM 1989	VRO2 PUMP
E150TXEIE 1991	VRO2 PUMP
E150TXESB 1990	VRO2 PUMP
E175STLCCM 1988	VRO2 PUMP
E175STLCEB 1989	VRO2 PUMP
E175STLEID 1991	VRO2 PUMP
E175STLESE 1990	VRO2 PUMP
E175TLCCM 1988	VRO2 PUMP

E175TXCCM 1988	VRO2 PUMP
E175TXCEB 1989	VRO2 PUMP
E175TXEID 1991	VRO2 PUMP
E175TXESE 1990	VRO2 PUMP
E25KLECA 1998	FUEL SYSTEM
E25KLEDC 1996	FUEL SYSTEM
E25KLEUR 1997	FUEL SYSTEM
E25QLECA 1998	FUEL SYSTEM
E25QLEDC 1996	FUEL SYSTEM
E25QLEUR 1997	FUEL SYSTEM
E25RMECA 1998	FUEL SYSTEM
E25RMEDC 1996	FUEL SYSTEM
E25RMEUR 1997	FUEL SYSTEM
E25RMLECA 1998	FUEL SYSTEM
E25RMLEDC 1996	FUEL SYSTEM
E25RMLEUR 1997	FUEL SYSTEM
E25TKECA 1998	FUEL SYSTEM
E25TKEDC 1996	FUEL SYSTEM
E25TKEUR 1997	FUEL SYSTEM
E25TKLECA 1998	FUEL SYSTEM
E25TKLEDC 1996	FUEL SYSTEM
E25TKLEUR 1997	FUEL SYSTEM
E35KLECA 1998	FUEL SYSTEM
E35KLEDC 1996	FUEL SYSTEM
E35KLEUR 1997	FUEL SYSTEM
E35QLECA 1998	FUEL SYSTEM
E35QLEDC 1996	FUEL SYSTEM
E35QLEUR 1997	FUEL SYSTEM
E35RMLEDC 1996	FUEL SYSTEM
E35RMLEUR 1997	FUEL SYSTEM
E35TKLECA 1998	FUEL SYSTEM
E35TKLEDC 1996	FUEL SYSTEM
E35TKLEUR 1997	FUEL SYSTEM
E40AELCCS 1988	VRO2 PUMP
E40ARLCCS 1988	VRO2 PUMP

E40ATLCCS 1988	VRO2 PUMP
E40ECCS 1988	VRO2 PUMP
E40ECEC 1989	VRO2 PUMP
E40EEIA 1991	VRO2 PUMP
E40EENJ 1992	VRO PUMP
E40EENM 1992	VRO PUMP
E40EESR 1990	VRO2 PUMP
E40ELCCS 1988	VRO2 PUMP
E40ELCEC 1989	VRO2 PUMP
E40ELEIA 1991	VRO2 PUMP
E40ELENJ 1992	VRO PUMP
E40ELENM 1992	VRO PUMP
E40ELESR 1990	VRO2 PUMP
E40RCCS 1988	VRO2 PUMP
E40RCEC 1989	VRO2 PUMP
E40REIA 1991	VRO2 PUMP
E40RENM 1992	VRO PUMP
E40RESR 1990	VRO2 PUMP
E40RLCCS 1988	VRO2 PUMP
E40RLCEC 1989	VRO2 PUMP
E40RLEIA 1991	VRO2 PUMP
E40RLENM 1992	VRO PUMP
E40RLESR 1990	VRO2 PUMP
E40TECCS 1988	VRO2 PUMP
E40TECEC 1989	VRO2 PUMP
E40TEEIA 1991	VRO2 PUMP
E40TEENJ 1992	VRO PUMP
E40TEENM 1992	VRO PUMP
E40TEESR 1990	VRO2 PUMP
E40TELCCS 1988	VRO2 PUMP
E40TELCEC 1989	VRO2 PUMP
E40TELEIA 1991	VRO2 PUMP
E40TELENJ 1992	VRO PUMP
E40TELENM 1992	VRO PUMP
E40TELESR 1990	VRO2 PUMP

E40TLCCS 1988	VRO2 PUMP
E40TLCEC 1989	VRO2 PUMP
E40TLEIA 1991	VRO2 PUMP
E40TLENJ 1992	VRO PUMP
E40TLENM 1992	VRO PUMP
E40TLESR 1990	VRO2 PUMP
E40TTLCCS 1988	VRO2 PUMP
E40TTLCEC 1989	VRO2 PUMP
E40TTLEIA 1991	VRO2 PUMP
E40TTLENM 1992	VRO PUMP
E40TTLESR 1990	VRO2 PUMP
E50BECCS 1988	VRO2 PUMP
E50BECEC 1989	VRO2 PUMP
E50BEEIA 1991	VRO2 PUMP
E50BEENJ 1992	VRO PUMP
E50BEENM 1992	VRO PUMP
E50BEESR 1990	VRO2 PUMP
E50BELCCS 1988	VRO2 PUMP
E50BELCEC 1989	VRO2 PUMP
E50BELEIA 1991	VRO2 PUMP
E50BELENJ 1992	VRO PUMP
E50BELENM 1992	VRO PUMP
E50BELESR 1990	VRO2 PUMP
E50DTLECA 1998	FUEL PUMP
E50DTLEDC 1996	FUEL PUMP
E50DTLEOS 1995	FUEL PUMP
E50DTLEUR 1997	FUEL PUMP
E50ELED 1996	FUEL PUMP
E50ELEOS 1995	FUEL PUMP
E50ELEUR 1997	FUEL PUMP
E50JEIA 1991	VRO2 PUMP
E50JENJ 1992	VRO PUMP
E50JENM 1992	VRO PUMP
E50TELCCS 1988	VRO2 PUMP
E50TELCEC 1989	VRO2 PUMP

E50TELEIA 1991	VRO2 PUMP
E50TELENM 1992	VRO PUMP
E50TELESR 1990	VRO2 PUMP
E50TLCCS 1988	VRO2 PUMP
E50TLCEC 1989	VRO2 PUMP
E50TLEIA 1991	VRO2 PUMP
E50TLENJ 1992	VRO PUMP
E50TLENM 1992	VRO PUMP
E50TLESR 1990	VRO2 PUMP
E50TTLECA 1998	FUEL PUMP
E50TTLEDC 1996	FUEL PUMP
E50TTLEOS 1995	FUEL PUMP
E50TTLEUR 1997	FUEL PUMP
E60ELCCR 1988	VRO2 PUMP
E60ELCEA 1989	VRO2 PUMP
E60ELEDR 1996	FUEL PUMP
E60ELEIB 1991	VRO2 PUMP
E60ELENE 1992	VRO2 PUMP
E60ELEOC 1995	FUEL PUMP
E60ELERS 1994	FUEL PUMP
E60ELERV 1994	FUEL PUMP
E60ELES M 1990	VRO2 PUMP
E60ELET D 1993	FUEL PUMP
E60ELEUA 1997	FUEL PUMP
E60TLCCR 1988	VRO2 PUMP
E60TLCEA 1989	VRO2 PUMP
E60TLECM 1998	FUEL PUMP
E60TLEDR 1996	FUEL PUMP
E60TLEIB 1991	VRO2 PUMP
E60TLENE 1992	VRO2 PUMP
E60TLEOC 1995	FUEL PUMP
E60TLERS 1994	FUEL PUMP
E60TLERV 1994	FUEL PUMP
E60TLES M 1990	VRO2 PUMP
E60TLET D 1993	FUEL PUMP

E60TLEUA 1997	FUEL PUMP
E60TTLCCR 1988	VRO2 PUMP
E60TTLCEA 1989	VRO2 PUMP
E60TTLECM 1998	FUEL PUMP
E60TTLEDR 1996	FUEL PUMP
E60TTLEIB 1991	VRO PUMP
E60TTLENE 1992	VRO2 PUMP
E60TTLEOC 1995	FUEL PUMP
E60TTLERS 1994	FUEL PUMP
E60TTLERV 1994	FUEL PUMP
E60TTLESM 1990	VRO2 PUMP
E60TTLETD 1993	FUEL PUMP
E60TLEUA 1997	FUEL PUMP
E70ELCCA 1988	VRO2 PUMP
E70ELCEM 1989	VRO2 PUMP
E70ELEIE 1991	VRO2 PUMP
E70ELEND 1992	VRO2 PUMP
E70ELEOR 1995	FUEL PUMP
E70ELERC 1994	FUEL PUMP
E70ELERV 1994	FUEL PUMP
E70ELESB 1990	VRO2 PUMP
E70ELETS 1993	FUEL PUMP
E70TLCCA 1988	VRO2 PUMP
E70TLCEM 1989	VRO2 PUMP
E70TLECB 1998	FUEL PUMP
E70TLEDA 1996	FUEL PUMP
E70TLEIE 1991	VRO2 PUMP
E70TLEND 1992	VRO2 PUMP
E70TLEOR 1995	FUEL PUMP
E70TLERC 1994	FUEL PUMP
E70TLERV 1994	FUEL PUMP
E70TLESB 1990	VRO2 PUMP
E70TLETS 1993	FUEL PUMP
E70TLEUM 1997	FUEL PUMP
E70TTLEIE 1991	VRO PUMP

E70TTLEND 1992	VRO2 PUMP
E70TTLEOR 1995	FUEL PUMP
E70TTLERC 1994	FUEL PUMP
E70TTLERV 1994	FUEL PUMP
E70TTLETS 1993	FUEL PUMP
E75ECCA 1988	VRO2 PUMP
E85TTLEIE 1991	VRO2 PUMP
E85TTLEND 1992	VRO PUMP
E88MSLCCC 1988	VRO2 PUMP - 90/110 MODELS
E88MSLCER 1989	VRO2 PUMP - 90/110 MODELS
E88MSLEIM 1991	VRO2 PUMP - 90/100/115 MODELS
E88MSLENB 1992	VRO2 PUMP - 90/100/115 MODELS
E88MSLESA 1990	VRO2 PUMP - 90/100/115 MODELS
E90JLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
E90JLEND 1992	VRO2 PUMP - 90/100/115 MODELS
E90TLCCA 1988	VRO2 PUMP - 90/110 MODELS
E90TLCEM 1989	VRO2 PUMP - 90/110 MODELS
E90TLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
E90TLEND 1992	VRO2 PUMP - 90/100/115 MODELS
E90TLESB 1990	VRO2 PUMP - 90/100/115 MODELS
HE35RMLEDC 1996	FUEL SYSTEM
HE35RMLEUR 1997	FUEL SYSTEM
HE70TXEDA 1996	FUEL PUMP
HE70TXEUM 1997	FUEL PUMP
HJ35RMLEDC 1996	FUEL SYSTEM
HJ35RMLEUR 1997	FUEL SYSTEM
HJ70TXEDA 1996	FUEL PUMP
HJ70TXEUM 1997	FUEL PUMP
J100STLCCA 1988	VRO2 PUMP - 90/110 MODELS
J100STLCEM 1989	VRO2 PUMP - 90/110 MODELS
J100STLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
J100STLEND 1992	VRO2 PUMP - 90/100/115 MODELS
J100STLESB 1990	VRO2 PUMP - 90/100/115 MODELS
J110MLCCA 1988	VRO2 PUMP - 90/110 MODELS
J110MLCEM 1989	VRO2 PUMP - 90/110 MODELS

J110TLAEM 1989	VRO2 PUMP - 90/110 MODELS
J110TLCCA 1988	VRO2 PUMP - 90/110 MODELS
J110TLCEM 1989	VRO2 PUMP - 90/110 MODELS
J110TXCCA 1988	VRO2 PUMP - 90/110 MODELS
J110TXCEM 1989	VRO2 PUMP - 90/110 MODELS
J115JLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
J115JLEND 1992	VRO2 PUMP - 90/100/115 MODELS
J115MLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
J115MLEND 1992	VRO2 PUMP - 90/100/115 MODELS
J115MLESB 1990	VRO2 PUMP - 90/100/115 MODELS
J115TLAIE 1991	VRO2 PUMP - 90/100/115 MODELS
J115TLAND 1992	VRO2 PUMP - 90/100/115 MODELS
J115TLASB 1990	VRO2 PUMP - 90/100/115 MODELS
J115TLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
J115TLEND 1992	VRO2 PUMP - 90/100/115 MODELS
J115TLESB 1990	VRO2 PUMP - 90/100/115 MODELS
J115TXEIE 1991	VRO2 PUMP - 90/100/115 MODELS
J115TXEND 1992	VRO2 PUMP - 90/100/115 MODELS
J115TXESB 1990	VRO2 PUMP - 90/100/115 MODELS
J150CXCCA 1988	VRO2 PUMP
J150CXCEM 1989	VRO2 PUMP
J150CXEIE 1991	VRO2 PUMP
J150CXESB 1990	VRO2 PUMP
J150JLEIE 1991	VRO2 PUMP
J150STLACA 1988	VRO2 PUMP
J150STLCCA 1988	VRO2 PUMP
J150STLCEM 1989	VRO2 PUMP
J150STLEIE 1991	VRO2 PUMP
J150STLESB 1990	VRO2 PUMP
J150TLAEM 1989	VRO2 PUMP
J150TLAIE 1991	VRO2 PUMP
J150TLASB 1990	VRO2 PUMP
J150TLCCA 1988	VRO2 PUMP
J150TLCEM 1989	VRO2 PUMP
J150TLEIE 1991	VRO2 PUMP

J150TLESB 1990	VRO2 PUMP
J150TXCCA 1988	VRO2 PUMP
J150TXCEM 1989	VRO2 PUMP
J150TXEIE 1991	VRO2 PUMP
J150TXESB 1990	VRO2 PUMP
J175STLACM 1988	VRO2 PUMP
J175STLCCM 1988	VRO2 PUMP
J175STLCEB 1989	VRO2 PUMP
J175STLEID 1991	VRO2 PUMP
J175STLESE 1990	VRO2 PUMP
J175TLCCM 1988	VRO2 PUMP
J175TXCCM 1988	VRO2 PUMP
J175TXCEB 1989	VRO2 PUMP
J175TXEID 1991	VRO2 PUMP
J175TXESE 1990	VRO2 PUMP
J25KLECA 1998	FUEL SYSTEM
J25KLEDC 1996	FUEL SYSTEM
J25KLEUR 1997	FUEL SYSTEM
J25PL3EEM 1999	FUEL SYSTEM
J25PL3SIE elec start, TNT, 20 in shaft 2001	FUEL SYSTEM
J25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000	FUEL SYSTEM
J25QLECA 1998	FUEL SYSTEM
J25QLEDC 1996	FUEL SYSTEM
J25QLEUR 1997	FUEL SYSTEM
J25R3EEM 1999	FUEL SYSTEM
J25R3SIE rope start, tiller, 15 in shaft 2001	FUEL SYSTEM
J25R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000	FUEL SYSTEM
J25RL3EEM 1999	FUEL SYSTEM
J25RL3SIE rope start, tiller, 20 in shaft 2001	FUEL SYSTEM
J25RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000	FUEL SYSTEM
J25RMECA 1998	FUEL SYSTEM
J25RMEDC 1996	FUEL SYSTEM
J25RMEUR 1997	FUEL SYSTEM
J25RMLECA 1998	FUEL SYSTEM
J25RMLEDC 1996	FUEL SYSTEM

J25RMLEUR 1997	FUEL SYSTEM
J25RV3SIE rope start, tiller, 15 in shaft, wht, n/a usa 2001	FUEL SYSTEM
J25RVL3SIE rope start, tiller, 20 in shaft, wht 2001	FUEL SYSTEM
J25TEL3EEM 1999	FUEL SYSTEM
J25TEL3SIE elec start, tiller, 20 in shaft 2001	FUEL SYSTEM
J25TEL3SSB 3 Cyl, Elec. Start, Tiller, 20 IN. shaft 2000	FUEL SYSTEM
J25TKECA 1998	FUEL SYSTEM
J25TKEDC 1996	FUEL SYSTEM
J25TKEUR 1997	FUEL SYSTEM
J25TKLECA 1998	FUEL SYSTEM
J25TKLEDC 1996	FUEL SYSTEM
J25TKLEUR 1997	FUEL SYSTEM
J25TVL3SIE elec start, tiller, 20 in shaft, wht 2001	FUEL SYSTEM
J25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	FUEL SYSTEM
J35E3EEM 1999	FUEL SYSTEM
J35EL3EEM 1999	FUEL SYSTEM
J35KLECA 1998	FUEL SYSTEM
J35KLEDC 1996	FUEL SYSTEM
J35KLEUR 1997	FUEL SYSTEM
J35PL3EEM 1999	FUEL SYSTEM
J35PL3SIE elec start, TNT, 20 in shaft 2001	FUEL SYSTEM
J35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000	FUEL SYSTEM
J35QLECA 1998	FUEL SYSTEM
J35QLEDC 1996	FUEL SYSTEM
J35QLEUR 1997	FUEL SYSTEM
J35R3EEM 1999	FUEL SYSTEM
J35R3SIE rope start, tiller, 15 in shaft 2001	FUEL SYSTEM
J35R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000	FUEL SYSTEM
J35RL3EEM 1999	FUEL SYSTEM
J35RL3SIE rope start, tiller, 20 in shaft 2001	FUEL SYSTEM
J35RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000	FUEL SYSTEM
J35RMLEDC 1996	FUEL SYSTEM
J35RMLEUR 1997	FUEL SYSTEM
J35RV3SIE rope start, 15 in shaft, wht 2001	FUEL SYSTEM
J35RVL3SIE rope start, 20 in shaft, wht 2001	FUEL SYSTEM

J35TEL3EEM 1999	FUEL SYSTEM
J35TEL3SIE elec start, TNT, 20 in shaft 2001	FUEL SYSTEM
J35TEL3SSB 3 Cyl, Elec. Start, TNT, Tiller, 20 IN. shaft 2000	FUEL SYSTEM
J35TKLECA 1998	FUEL SYSTEM
J35TKLEDC 1996	FUEL SYSTEM
J35TKLEUR 1997	FUEL SYSTEM
J35TVL3SIE elec start, tiller, 20 in shaft, wht 2001	FUEL SYSTEM
J35VL3SIE elec start, TNT, 20 in shaft, wht 2001	FUEL SYSTEM
J40AELCCS 1988	VRO2 PUMP
J40ARLCCS 1988	VRO2 PUMP
J40ATLCCS 1988	VRO2 PUMP
J40ECCS 1988	VRO2 PUMP
J40ECEC 1989	VRO2 PUMP
J40EEIA 1991	VRO2 PUMP
J40EENJ 1992	VRO PUMP
J40EENM 1992	VRO PUMP
J40EESR 1990	VRO2 PUMP
J40ELCCS 1988	VRO2 PUMP
J40ELCEC 1989	VRO2 PUMP
J40ELEIA 1991	VRO2 PUMP
J40ELENJ 1992	VRO PUMP
J40ELENM 1992	VRO PUMP
J40ELESR 1990	VRO2 PUMP
J40JPLEEC 1999	FUEL PUMP
J40JPLSIA jet drive,elec start, TNT, 20 in shaft 2001	FUEL PUMP
J40JPLSSR Jet Drive, Elec Start, TNT, 20 IN. shaft 2000	FUEL PUMP
J40JVLSIA jet drive,elec start, TNT, 20 in shaft, wht 2001	FUEL PUMP
J40RCCS 1988	VRO2 PUMP
J40RCEC 1989	VRO2 PUMP
J40REIA 1991	VRO2 PUMP
J40RENM 1992	VRO PUMP
J40RESR 1990	VRO2 PUMP
J40RLCCS 1988	VRO2 PUMP
J40RLCEC 1989	VRO2 PUMP
J40RLEIA 1991	VRO2 PUMP

J40RLENM 1992	VRO PUMP
J40RLESR 1990	VRO2 PUMP
J40TECCS 1988	VRO2 PUMP
J40TECEC 1989	VRO2 PUMP
J40TEEIA 1991	VRO2 PUMP
J40TEENJ 1992	VRO PUMP
J40TEENM 1992	VRO PUMP
J40TEESR 1990	VRO2 PUMP
J40TELCCS 1988	VRO2 PUMP
J40TELCEC 1989	VRO2 PUMP
J40TELEIA 1991	VRO2 PUMP
J40TELENJ 1992	VRO PUMP
J40TELENM 1992	VRO PUMP
J40TELESR 1990	VRO2 PUMP
J40TLCCS 1988	VRO2 PUMP
J40TLCEC 1989	VRO2 PUMP
J40TLEIA 1991	VRO2 PUMP
J40TLENJ 1992	VRO PUMP
J40TLENM 1992	VRO PUMP
J40TLESR 1990	VRO2 PUMP
J40TTLCCS 1988	VRO2 PUMP
J40TTLCEC 1989	VRO2 PUMP
J40TTLEIA 1991	VRO2 PUMP
J40TTLENM 1992	VRO PUMP
J40TTLESR 1990	VRO2 PUMP
J50BECCS 1988	VRO2 PUMP
J50BECEC 1989	VRO2 PUMP
J50BEEIA 1991	VRO2 PUMP
J50BEENJ 1992	VRO PUMP
J50BEENM 1992	VRO PUMP
J50BEESR 1990	VRO2 PUMP
J50BELCCS 1988	VRO2 PUMP
J50BELCEC 1989	VRO2 PUMP
J50BELEIA 1991	VRO2 PUMP
J50BELENJ 1992	VRO PUMP

J50BELENM 1992	VRO PUMP
J50BELESR 1990	VRO2 PUMP
J50DTLECA 1998	FUEL PUMP
J50DTLEDC 1996	FUEL PUMP
J50DTLEOS 1995	FUEL PUMP
J50DTLEUR 1997	FUEL PUMP
J50ELED 1996	FUEL PUMP
J50ELEOS 1995	FUEL PUMP
J50ELEUR 1997	FUEL PUMP
J50JEIA 1991	VRO2 PUMP
J50JENJ 1992	VRO PUMP
J50JENM 1992	VRO PUMP
J50TELCCS 1988	VRO2 PUMP
J50TELCEC 1989	VRO2 PUMP
J50TELEIA 1991	VRO2 PUMP
J50TELENM 1992	VRO PUMP
J50TELESR 1990	VRO2 PUMP
J50TLCCS 1988	VRO2 PUMP
J50TLCEC 1989	VRO2 PUMP
J50TLEIA 1991	VRO2 PUMP
J50TLENJ 1992	VRO PUMP
J50TLENM 1992	VRO PUMP
J50TLESR 1990	VRO2 PUMP
J50TTLECA 1998	FUEL PUMP
J50TTLEDC 1996	FUEL PUMP
J50TTLEOS 1995	FUEL PUMP
J50TTLEUR 1997	FUEL PUMP
J60ELCCR 1988	VRO2 PUMP
J60ELCEA 1989	VRO2 PUMP
J60ELEDR 1996	FUEL PUMP
J60ELEIB 1991	VRO2 PUMP
J60ELENE 1992	VRO2 PUMP
J60ELEOC 1995	FUEL PUMP
J60ELERS 1994	FUEL PUMP
J60ELERV 1994	FUEL PUMP

J60ELES M 1990	VRO2 PUMP
J60ELETD 1993	FUEL PUMP
J60ELEUA 1997	FUEL PUMP
J60PLEEB 1999	FUEL PUMP
J60PLSID elec start, TNT, 20 in shaft 2001	FUEL PUMP
J60PLSSE Elec Start, TNT, 20 IN. shaft 2000	FUEL PUMP
J60TLCCR 1988	VRO2 PUMP
J60TLCEA 1989	VRO2 PUMP
J60TLECM 1998	FUEL PUMP
J60TLEDR 1996	FUEL PUMP
J60TLEIB 1991	VRO2 PUMP
J60TLENE 1992	VRO2 PUMP
J60TLEOC 1995	FUEL PUMP
J60TLERS 1994	FUEL PUMP
J60TLERV 1994	FUEL PUMP
J60TLES M 1990	VRO2 PUMP
J60TLETD 1993	FUEL PUMP
J60TLEUA 1997	FUEL PUMP
J60TTLCCR 1988	VRO2 PUMP
J60TTLCEA 1989	VRO2 PUMP
J60TTLECM 1998	FUEL PUMP
J60TTLEDR 1996	FUEL PUMP
J60TTLEIB 1991	VRO PUMP
J60TTLENE 1992	VRO2 PUMP
J60TTLEOC 1995	FUEL PUMP
J60TTLERS 1994	FUEL PUMP
J60TTLERV 1994	FUEL PUMP
J60TTLES M 1990	VRO2 PUMP
J60TTLETD 1993	FUEL PUMP
J60TTLEUA 1997	FUEL PUMP
J60VLSID elec start, TNT, 20 in shaft, wht 2001	FUEL PUMP
J70ELCCA 1988	VRO2 PUMP
J70ELCEM 1989	VRO2 PUMP
J70ELEIE 1991	VRO2 PUMP
J70ELEND 1992	VRO2 PUMP

J70ELEOR 1995	FUEL PUMP
J70ELERC 1994	FUEL PUMP
J70ELERV 1994	FUEL PUMP
J70ELESB 1990	VRO2 PUMP
J70ELETS 1993	FUEL PUMP
J70JLEOS 1995	FUEL PUMP
J70PLEEE 1999	FUEL PUMP
J70PLSIS elec start, TNT, 20 in shaft 2001	FUEL PUMP
J70PLSSD Elec Start, TNT, 20 IN. shaft 2000	FUEL PUMP
J70TLCCA 1988	VRO2 PUMP
J70TLCEM 1989	VRO2 PUMP
J70TLECB 1998	FUEL PUMP
J70TLEDA 1996	FUEL PUMP
J70TLEIE 1991	VRO2 PUMP
J70TLEND 1992	VRO2 PUMP
J70TLEOR 1995	FUEL PUMP
J70TLERC 1994	FUEL PUMP
J70TLERV 1994	FUEL PUMP
J70TLESB 1990	VRO2 PUMP
J70TLETS 1993	FUEL PUMP
J70TLEUM 1997	FUEL PUMP
J70TTLEIE 1991	VRO PUMP
J70TTLEND 1992	VRO2 PUMP
J70TTLEOR 1995	FUEL PUMP
J70TTLERC 1994	FUEL PUMP
J70TTLERV 1994	FUEL PUMP
J70TTLETS 1993	FUEL PUMP
J70VLSIS elec start, TNT, 20 in shaft 2001	FUEL PUMP
J75ECCA 1988	VRO2 PUMP
J85TTLEIE 1991	VRO2 PUMP
J85TTLEND 1992	VRO PUMP
J88MSLCCC 1988	VRO2 PUMP - 90/110 MODELS
J88MSLCER 1989	VRO2 PUMP - 90/110 MODELS
J88MSLEIM 1991	VRO2 PUMP - 90/100/115 MODELS
J88MSLENB 1992	VRO2 PUMP - 90/100/115 MODELS

J88MSLESA 1990	VRO2 PUMP - 90/100/115 MODELS
J90JLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
J90JLEND 1992	VRO2 PUMP - 90/100/115 MODELS
J90TLAEM 1989	VRO2 PUMP - 90/110 MODELS
J90TLAIE 1991	VRO2 PUMP - 90/100/115 MODELS
J90TLAND 1992	VRO2 PUMP - 90/100/115 MODELS
J90TLASB 1990	VRO2 PUMP - 90/100/115 MODELS
J90TLCCA 1988	VRO2 PUMP - 90/110 MODELS
J90TLCEM 1989	VRO2 PUMP - 90/110 MODELS
J90TLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
J90TLEND 1992	VRO2 PUMP - 90/100/115 MODELS
J90TLESB 1990	VRO2 PUMP - 90/100/115 MODELS
RJ70PLSIS elec start, TNT, 20 in shaft 2001	FUEL PUMP
RJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	FUEL PUMP
SJ60TLEDR 1996	FUEL PUMP
SJ70TLEDA 1996	FUEL PUMP
TE110TLCEM 1989	VRO2 PUMP - 90/110 MODELS
TE110TLESF 1989	VRO2 PUMP - 90/110 MODELS
TE110TXCEM 1989	VRO2 PUMP - 90/110 MODELS
TE115TLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
TE115TLEND 1992	VRO2 PUMP - 90/100/115 MODELS
TE115TLESB 1990	VRO2 PUMP - 90/100/115 MODELS
TE150SLCEM 1989	VRO2 PUMP
TE150SLEIE 1991	VRO2 PUMP
TE150SLESB 1990	VRO2 PUMP
TE150TXCEM 1989	VRO2 PUMP
TE40ELCEC 1989	VRO2 PUMP
TE40ELEIA 1991	VRO2 PUMP
TE40ELENJ 1992	VRO PUMP
TE40ELENM 1992	VRO PUMP
TE40ELESR 1990	VRO2 PUMP
TE40TELESF 1990	VRO2 PUMP
TE40TELESR 1990	VRO2 PUMP
TE50TLCEC 1989	VRO2 PUMP
TE50TLESF 1989	VRO2 PUMP

TE50TLESF 1990	VRO2 PUMP
TE50TLESR 1990	VRO2 PUMP
TE60TLCEA 1989	VRO2 PUMP
TE60TLEIB 1991	VRO2 PUMP
TE60TLENE 1992	VRO2 PUMP
TE60TLESF 1989	VRO2 PUMP
TE60TLESF 1990	VRO2 PUMP
TE60TLESM 1990	VRO2 PUMP
TE60TLETD 1993	FUEL PUMP
TE70TLCEM 1989	VRO2 PUMP
TE70TLESB 1990	VRO2 PUMP
TE70TLESF 1989	VRO2 PUMP
TE70TLESF 1990	VRO2 PUMP
TE90TLCEM 1989	VRO2 PUMP - 90/110 MODELS
TE90TLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
TE90TLEND 1992	VRO2 PUMP - 90/100/115 MODELS
TE90TLESB 1990	VRO2 PUMP - 90/100/115 MODELS
TE90TLESF 1989	VRO2 PUMP - 90/110 MODELS
TE90TLESF 1990	VRO2 PUMP - 90/100/115 MODELS
TJ110TLCEM 1989	VRO2 PUMP - 90/110 MODELS
TJ110TXCEM 1989	VRO2 PUMP - 90/110 MODELS
TJ115TLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
TJ115TLEND 1992	VRO2 PUMP - 90/100/115 MODELS
TJ115TLESB 1990	VRO2 PUMP - 90/100/115 MODELS
TJ150SLCEM 1989	VRO2 PUMP
TJ150SLEIE 1991	VRO2 PUMP
TJ150SLESB 1990	VRO2 PUMP
TJ150TXCEM 1989	VRO2 PUMP
TJ40ELCEC 1989	VRO2 PUMP
TJ40ELEIA 1991	VRO2 PUMP
TJ40ELENJ 1992	VRO PUMP
TJ40ELENM 1992	VRO PUMP
TJ40ELESF 1990	VRO2 PUMP
TJ40ELESR 1990	VRO2 PUMP
TJ40TELESF 1990	VRO2 PUMP

TJ40TELESR 1990	VRO2 PUMP
TJ50TLCEC 1989	VRO2 PUMP
TJ50TLESF 1989	VRO2 PUMP
TJ50TLESF 1990	VRO2 PUMP
TJ50TLESR 1990	VRO2 PUMP
TJ60TLCEA 1989	VRO2 PUMP
TJ60TLEIB 1991	VRO2 PUMP
TJ60TLENE 1992	VRO2 PUMP
TJ60TLESF 1989	VRO2 PUMP
TJ60TLESF 1990	VRO2 PUMP
TJ60TLESM 1990	VRO2 PUMP
TJ60TLETD 1993	FUEL PUMP
TJ70TLCEM 1989	VRO2 PUMP
TJ70TLESB 1990	VRO2 PUMP
TJ70TLESF 1989	VRO2 PUMP
TJ70TLESF 1990	VRO2 PUMP
TJ90TLCEM 1989	VRO2 PUMP - 90/110 MODELS
TJ90TLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
TJ90TLEND 1992	VRO2 PUMP - 90/100/115 MODELS
TJ90TLESB 1990	VRO2 PUMP - 90/100/115 MODELS
V115SLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
V115SLEND 1992	VRO2 PUMP - 90/100/115 MODELS
V90SLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
V90SLEND 1992	VRO2 PUMP - 90/100/115 MODELS
VE100SLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
VE100SLEND 1992	VRO2 PUMP - 90/100/115 MODELS
VE100SLESB 1990	VRO2 PUMP - 90/100/115 MODELS
VE115TLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
VE115TLESB 1990	VRO2 PUMP - 90/100/115 MODELS
VE115TXEIE 1991	VRO2 PUMP - 90/100/115 MODELS
VE115TXESB 1990	VRO2 PUMP - 90/100/115 MODELS
VE150SLEIE 1991	VRO2 PUMP
VE150SLESB 1990	VRO2 PUMP
VE150TLEIE 1991	VRO2 PUMP
VE150TLESB 1990	VRO2 PUMP

VE150TXEIE 1991	VRO2 PUMP
VE150TXESB 1990	VRO2 PUMP
VE175SLEID 1991	VRO2 PUMP
VE175SLESE 1990	VRO2 PUMP
VE175TXEID 1991	VRO2 PUMP
VE175TXESE 1990	VRO2 PUMP
VE40EEIA 1991	VRO2 PUMP
VE40EENJ 1992	VRO PUMP
VE40EENM 1992	VRO PUMP
VE40EESR 1990	VRO2 PUMP
VE40ELEIA 1991	VRO2 PUMP
VE40ELENJ 1992	VRO PUMP
VE40ELENM 1992	VRO PUMP
VE40ELESR 1990	VRO2 PUMP
VE40TELEIA 1991	VRO2 PUMP
VE40TELENJ 1992	VRO PUMP
VE40TELENM 1992	VRO PUMP
VE40TELESR 1990	VRO2 PUMP
VE40TLEIA 1991	VRO2 PUMP
VE40TLENJ 1992	VRO PUMP
VE40TLENM 1992	VRO PUMP
VE40TLESR 1990	VRO2 PUMP
VE50BEEIA 1991	VRO2 PUMP
VE50BEENJ 1992	VRO PUMP
VE50BEENM 1992	VRO PUMP
VE50BEESR 1990	VRO2 PUMP
VE50BELEIA 1991	VRO2 PUMP
VE50BELENJ 1992	VRO PUMP
VE50BELENM 1992	VRO PUMP
VE50BELESR 1990	VRO2 PUMP
VE50TELENM 1992	VRO PUMP
VE50TLEIA 1991	VRO2 PUMP
VE50TLENJ 1992	VRO PUMP
VE50TLENM 1992	VRO PUMP
VE50TLESR 1990	VRO2 PUMP

VE60ELEIB 1991	VRO2 PUMP
VE60ELENE 1992	VRO2 PUMP
VE60ELES 1990	VRO2 PUMP
VE60ELET 1993	FUEL PUMP
VE60TLEIB 1991	VRO2 PUMP
VE60TLENE 1992	VRO2 PUMP
VE60TLES 1990	VRO2 PUMP
VE70ELEIE 1991	VRO2 PUMP
VE70ELEN 1992	VRO2 PUMP
VE70ELESB 1990	VRO2 PUMP
VE70ELET 1993	FUEL PUMP
VE70TLEIE 1991	VRO2 PUMP
VE70TLEN 1992	VRO2 PUMP
VE70TLESB 1990	VRO2 PUMP
VE70TLET 1993	FUEL PUMP
VE88MSLCCC 1988	VRO2 PUMP - 90/110 MODELS
VE88MSLCER 1989	VRO2 PUMP - 90/110 MODELS
VE88MSLESA 1990	VRO2 PUMP - 90/100/115 MODELS
VE90MLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
VE90MLEN 1992	VRO2 PUMP - 90/100/115 MODELS
VE90MLESB 1990	VRO2 PUMP - 90/100/115 MODELS
VE90TLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
VE90TLEN 1992	VRO2 PUMP - 90/100/115 MODELS
VE90TLESB 1990	VRO2 PUMP - 90/100/115 MODELS
VJ100SLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
VJ100SLEN 1992	VRO2 PUMP - 90/100/115 MODELS
VJ100SLESB 1990	VRO2 PUMP - 90/100/115 MODELS
VJ115TLAIE 1991	VRO2 PUMP - 90/100/115 MODELS
VJ115TLAN 1992	VRO2 PUMP - 90/100/115 MODELS
VJ115TLASB 1990	VRO2 PUMP - 90/100/115 MODELS
VJ115TLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
VJ115TLESB 1990	VRO2 PUMP - 90/100/115 MODELS
VJ115TXEIE 1991	VRO2 PUMP - 90/100/115 MODELS
VJ115TXESB 1990	VRO2 PUMP - 90/100/115 MODELS
VJ150SLEIE 1991	VRO2 PUMP

VJ150SLESB 1990	VRO2 PUMP
VJ150TLEIE 1991	VRO2 PUMP
VJ150TLESB 1990	VRO2 PUMP
VJ150TXEIE 1991	VRO2 PUMP
VJ150TXESB 1990	VRO2 PUMP
VJ175SLEID 1991	VRO2 PUMP
VJ175SLESE 1990	VRO2 PUMP
VJ175TXEID 1991	VRO2 PUMP
VJ175TXESE 1990	VRO2 PUMP
VJ40EEIA 1991	VRO2 PUMP
VJ40EENJ 1992	VRO PUMP
VJ40EENM 1992	VRO PUMP
VJ40EESR 1990	VRO2 PUMP
VJ40ELEIA 1991	VRO2 PUMP
VJ40ELENJ 1992	VRO PUMP
VJ40ELENM 1992	VRO PUMP
VJ40ELESR 1990	VRO2 PUMP
VJ40TELEIA 1991	VRO2 PUMP
VJ40TELENJ 1992	VRO PUMP
VJ40TELENM 1992	VRO PUMP
VJ40TELESR 1990	VRO2 PUMP
VJ40TLEIA 1991	VRO2 PUMP
VJ40TLENJ 1992	VRO PUMP
VJ40TLENM 1992	VRO PUMP
VJ40TLESR 1990	VRO2 PUMP
VJ50BEEIA 1991	VRO2 PUMP
VJ50BEENJ 1992	VRO PUMP
VJ50BEENM 1992	VRO PUMP
VJ50BEESR 1990	VRO2 PUMP
VJ50BELEIA 1991	VRO2 PUMP
VJ50BELENJ 1992	VRO PUMP
VJ50BELENM 1992	VRO PUMP
VJ50BELESR 1990	VRO2 PUMP
VJ50TELENM 1992	VRO PUMP
VJ50TLEIA 1991	VRO2 PUMP

VJ50TLENJ 1992	VRO PUMP
VJ50TLENM 1992	VRO PUMP
VJ50TLESR 1990	VRO2 PUMP
VJ60ELEIB 1991	VRO2 PUMP
VJ60ELENE 1992	VRO2 PUMP
VJ60ELES M 1990	VRO2 PUMP
VJ60ELET D 1993	FUEL PUMP
VJ60TLEIB 1991	VRO2 PUMP
VJ60TLENE 1992	VRO2 PUMP
VJ60TLES M 1990	VRO2 PUMP
VJ70ELEIE 1991	VRO2 PUMP
VJ70ELEND 1992	VRO2 PUMP
VJ70ELESB 1990	VRO2 PUMP
VJ70ELET S 1993	FUEL PUMP
VJ70TLEIE 1991	VRO2 PUMP
VJ70TLEND 1992	VRO2 PUMP
VJ70TLESB 1990	VRO2 PUMP
VJ70TLET S 1993	FUEL PUMP
VJ88MSLCCC 1988	VRO2 PUMP - 90/110 MODELS
VJ88MSLCER 1989	VRO2 PUMP - 90/110 MODELS
VJ88MSLESA 1990	VRO2 PUMP - 90/100/115 MODELS
VJ90MLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
VJ90MLEND 1992	VRO2 PUMP - 90/100/115 MODELS
VJ90MLESB 1990	VRO2 PUMP - 90/100/115 MODELS
VJ90TLAIE 1991	VRO2 PUMP - 90/100/115 MODELS
VJ90TLAND 1992	VRO2 PUMP - 90/100/115 MODELS
VJ90TLASB 1990	VRO2 PUMP - 90/100/115 MODELS
VJ90TLEIE 1991	VRO2 PUMP - 90/100/115 MODELS
VJ90TLEND 1992	VRO2 PUMP - 90/100/115 MODELS
VJ90TLESB 1990	VRO2 PUMP - 90/100/115 MODELS