

Where Used: Part Number 0330092

Model Name	Diagram
D25RWA 1988	FUEL PUMP
D25RWLA 1988	FUEL PUMP
E100STLCCA 1988	FUEL PUMP - 88 MODELS
E100STLCEM 1989	FUEL PUMP - 88 MODELS
E100STLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
E10ECCD 1988	FUEL PUMP - ELECTRIC START MODELS
E10ECES 1989	FUEL PUMP - ELECTRIC START MODELS
E10ECUE 1987	FUEL PUMP - LATE PRODUCTION
E10EESC 1990	FUEL PUMP - ELECTRIC START MODELS
E10ELCCD 1988	FUEL PUMP - ELECTRIC START MODELS
E10ELCES 1989	FUEL PUMP - ELECTRIC START MODELS
E10ELCUE 1987	FUEL PUMP - LATE PRODUCTION
E10ELESC 1990	FUEL PUMP - ELECTRIC START MODELS
E10RCCD 1988	FUEL PUMP - ELECTRIC START MODELS
E10RCES 1989	FUEL PUMP - ELECTRIC START MODELS
E10RCUE 1987	FUEL PUMP - LATE PRODUCTION
E10RELESC 1990	FUEL PUMP - ELECTRIC START MODELS
E10RESC 1990	FUEL PUMP - ELECTRIC START MODELS
E10RLCCD 1988	FUEL PUMP - ELECTRIC START MODELS
E10RLCES 1989	FUEL PUMP - ELECTRIC START MODELS
E10RLCUE 1987	FUEL PUMP - LATE PRODUCTION
E10RLESC 1990	FUEL PUMP - ELECTRIC START MODELS
E10SELCCD 1988	FUEL PUMP - ELECTRIC START MODELS
E10SELCES 1989	FUEL PUMP - ELECTRIC START MODELS
E10SELCUE 1987	FUEL PUMP - LATE PRODUCTION
E10SELESC 1990	FUEL PUMP - ELECTRIC START MODELS
E110MLCCA 1988	FUEL PUMP - 88 MODELS
E110MLCEM 1989	FUEL PUMP - 88 MODELS
E110TLCCA 1988	FUEL PUMP - 88 MODELS
E110TLCEM 1989	FUEL PUMP - 88 MODELS
E110TXCCA 1988	FUEL PUMP - 88 MODELS
E110TXCEM 1989	FUEL PUMP - 88 MODELS
E115MLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION

E115TLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
E115TXESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
E15ECCS 1988	FUEL PUMP - ELECTRIC START MODELS
E15ECEC 1989	FUEL PUMP - ELECTRIC START MODELS
E15ECUD 1987	FUEL PUMP - LATE PRODUCTION
E15EESR 1990	FUEL PUMP - ELECTRIC START MODELS
E15ELCCS 1988	FUEL PUMP - ELECTRIC START MODELS
E15ELCEC 1989	FUEL PUMP - ELECTRIC START MODELS
E15ELCUD 1987	FUEL PUMP - LATE PRODUCTION
E15ELESR 1990	FUEL PUMP - ELECTRIC START MODELS
E15RCCS 1988	FUEL PUMP - ELECTRIC START MODELS
E15RCEC 1989	FUEL PUMP - ELECTRIC START MODELS
E15RCUD 1987	FUEL PUMP - LATE PRODUCTION
E15RELESR 1990	FUEL PUMP - ELECTRIC START MODELS
E15RESR 1990	FUEL PUMP - ELECTRIC START MODELS
E15RLCCS 1988	FUEL PUMP - ELECTRIC START MODELS
E15RLCEC 1989	FUEL PUMP - ELECTRIC START MODELS
E15RLCUD 1987	FUEL PUMP - LATE PRODUCTION
E15RLESR 1990	FUEL PUMP - ELECTRIC START MODELS
E20CRCCA 1988	FUEL PUMP
E20CRCDC 1986	FUEL PUMP
E20CRCEM 1989	FUEL PUMP
E20CRCOS 1985	FUEL PUMP
E20CRCUR 1987	FUEL PUMP
E20CRESB 1990	FUEL PUMP - EARLY PRODUCTION
E20CRLCCA 1988	FUEL PUMP
E20CRLCDC 1986	FUEL PUMP
E20CRLCEM 1989	FUEL PUMP
E20CRLCOS 1985	FUEL PUMP
E20CRLCUR 1987	FUEL PUMP
E20CRLESB 1990	FUEL PUMP - EARLY PRODUCTION
E20ECCA 1988	FUEL PUMP
E20ECDC 1986	FUEL PUMP
E20ECEM 1989	FUEL PUMP
E20ECOS 1985	FUEL PUMP

E20ECUR 1987	FUEL PUMP
E20EESB 1990	FUEL PUMP - EARLY PRODUCTION
E20ELCCA 1988	FUEL PUMP
E20ELCDC 1986	FUEL PUMP
E20ELCEM 1989	FUEL PUMP
E20ELCOS 1985	FUEL PUMP
E20ELCUR 1987	FUEL PUMP
E20ELESB 1990	FUEL PUMP - EARLY PRODUCTION
E20TECDC 1986	FUEL PUMP
E25ECCM 1988	FUEL PUMP
E25ECDR 1986	FUEL PUMP
E25ECEB 1989	FUEL PUMP
E25ECOC 1985	FUEL PUMP
E25ECUA 1987	FUEL PUMP
E25EESE 1990	FUEL PUMP - EARLY PRODUCTION
E25ELCCM 1988	FUEL PUMP
E25ELCDR 1986	FUEL PUMP
E25ELCEB 1989	FUEL PUMP
E25ELCOC 1985	FUEL PUMP
E25ELCUA 1987	FUEL PUMP
E25ELESE 1990	FUEL PUMP - EARLY PRODUCTION
E25RCCA 1988	FUEL PUMP
E25RCDC 1986	FUEL PUMP
E25RCEM 1989	FUEL PUMP
E25RCOS 1985	FUEL PUMP
E25RCUR 1987	FUEL PUMP
E25RESB 1990	FUEL PUMP - EARLY PRODUCTION
E25RLCCA 1988	FUEL PUMP
E25RLCDC 1986	FUEL PUMP
E25RLCEM 1989	FUEL PUMP
E25RLCOS 1985	FUEL PUMP
E25RLCUR 1987	FUEL PUMP
E25RLESB 1990	FUEL PUMP - EARLY PRODUCTION
E25RWDC 1986	FUEL PUMP
E25RWCOS 1985	FUEL PUMP

E25RWCUR 1987	FUEL PUMP
E25RWESA 1990	FUEL PUMP - EARLY PRODUCTION
E25RWK 1989	FUEL PUMP
E25RWLDC 1986	FUEL PUMP
E25RWLCOS 1985	FUEL PUMP
E25RWLCUR 1987	FUEL PUMP
E25RWLESA 1990	FUEL PUMP - EARLY PRODUCTION
E25RWLK 1989	FUEL PUMP
E25TECCA 1988	FUEL PUMP
E25TECDC 1986	FUEL PUMP
E25TECEM 1989	FUEL PUMP
E25TECOS 1985	FUEL PUMP
E25TECUR 1987	FUEL PUMP
E25TEESB 1990	FUEL PUMP - EARLY PRODUCTION
E25TELCCA 1988	FUEL PUMP
E25TELCDC 1986	FUEL PUMP
E25TELCEM 1989	FUEL PUMP
E25TELCOS 1985	FUEL PUMP
E25TELCUR 1987	FUEL PUMP
E25TELESB 1990	FUEL PUMP - EARLY PRODUCTION
E28ELCDS 1986	FUEL PUMP
E28ESLCCR 1988	FUEL PUMP
E28ESLCEA 1989	FUEL PUMP
E28ESLCUC 1987	FUEL PUMP
E28ESLESM 1990	FUEL PUMP - EARLY PRODUCTION
E30ECCE 1988	FUEL PUMP
E30ECDM 1986	FUEL PUMP
E30ECED 1989	FUEL PUMP
E30EOA 1985	FUEL PUMP
E30ECUB 1987	FUEL PUMP
E30EES 1990	FUEL PUMP - EARLY PRODUCTION
E30ELCCE 1988	FUEL PUMP
E30ELCDM 1986	FUEL PUMP
E30ELCED 1989	FUEL PUMP
E30ELCOA 1985	FUEL PUMP

E30ELCUB 1987	FUEL PUMP
E30ELESS 1990	FUEL PUMP - EARLY PRODUCTION
E30RCCE 1988	FUEL PUMP
E30RCDM 1986	FUEL PUMP
E30RCED 1989	FUEL PUMP
E30RCOA 1985	FUEL PUMP
E30RCUB 1987	FUEL PUMP
E30RESS 1990	FUEL PUMP - EARLY PRODUCTION
E30RLCCE 1988	FUEL PUMP
E30RLCDM 1986	FUEL PUMP
E30RLCED 1989	FUEL PUMP
E30RLCOA 1985	FUEL PUMP
E30RLCUB 1987	FUEL PUMP
E30RLESS 1990	FUEL PUMP - EARLY PRODUCTION
E30TECCE 1988	FUEL PUMP
E30TECDM 1986	FUEL PUMP
E30TECED 1989	FUEL PUMP
E30TECOA 1985	FUEL PUMP
E30TECUB 1987	FUEL PUMP
E30TEESS 1990	FUEL PUMP - EARLY PRODUCTION
E30TELCCE 1988	FUEL PUMP
E30TELCDM 1986	FUEL PUMP
E30TELCED 1989	FUEL PUMP
E30TELCOA 1985	FUEL PUMP
E30TELCUB 1987	FUEL PUMP
E30TELESS 1990	FUEL PUMP - EARLY PRODUCTION
E35AELCDE 1986	FUEL PUMP AND FILTER
E35AELCUD 1987	FUEL PUMP AND FILTER
E35ARLCDE 1986	FUEL PUMP AND FILTER
E35ARLCUD 1987	FUEL PUMP AND FILTER
E35RCCE 1988	FUEL PUMP
E35RCDM 1986	FUEL PUMP
E35RCED 1989	FUEL PUMP
E35RCUB 1987	FUEL PUMP
E35RESS 1990	FUEL PUMP - EARLY PRODUCTION

E35RLCCE 1988	FUEL PUMP
E35RLCDM 1986	FUEL PUMP
E35RLCED 1989	FUEL PUMP
E35RLCUB 1987	FUEL PUMP
E35RLESS 1990	FUEL PUMP - EARLY PRODUCTION
E40AELCCS 1988	FUEL PUMP AND FILTER
E40ARLCCS 1988	FUEL PUMP AND FILTER
E40ATLCCS 1988	FUEL PUMP AND FILTER
E40ECCS 1988	FUEL PUMP AND FILTER
E40ECDE 1986	FUEL PUMP AND FILTER
E40ECEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
E40ECOB 1985	FUEL PUMP AND FILTER
E40ECUD 1987	FUEL PUMP AND FILTER
E40EESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
E40ELCCS 1988	FUEL PUMP AND FILTER
E40ELCDE 1986	FUEL PUMP AND FILTER
E40ELCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
E40ELCOB 1985	FUEL PUMP AND FILTER
E40ELCUD 1987	FUEL PUMP AND FILTER
E40ELESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
E40RCCS 1988	FUEL PUMP AND FILTER
E40RCDE 1986	FUEL PUMP AND FILTER
E40RCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
E40RCOB 1985	FUEL PUMP AND FILTER
E40RCUD 1987	FUEL PUMP AND FILTER
E40RESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
E40RLCCS 1988	FUEL PUMP AND FILTER
E40RLCDE 1986	FUEL PUMP AND FILTER
E40RLCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
E40RLCOB 1985	FUEL PUMP AND FILTER
E40RLCUD 1987	FUEL PUMP AND FILTER
E40RLESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
E40RWCDDB 1986	FUEL PUMP
E40RWCOM 1985	FUEL PUMP
E40RWLCDB 1986	FUEL PUMP

E40RWLCOM 1985	FUEL PUMP
E40TECCS 1988	FUEL PUMP AND FILTER
E40TECDE 1986	FUEL PUMP AND FILTER
E40TECEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
E40TECOB 1985	FUEL PUMP AND FILTER
E40TECUD 1987	FUEL PUMP AND FILTER
E40TEESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
E40TELCCS 1988	FUEL PUMP AND FILTER
E40TELCDE 1986	FUEL PUMP AND FILTER
E40TELCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
E40TELCOB 1985	FUEL PUMP AND FILTER
E40TELESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
E40TLCCS 1988	FUEL PUMP AND FILTER
E40TLCDE 1986	FUEL PUMP AND FILTER
E40TLCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
E40TLCUD 1987	FUEL PUMP AND FILTER
E40TLESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
E40TTLCCS 1988	FUEL PUMP AND FILTER
E40TTLCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
E40TTLESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
E45RCCDS 1986	FUEL PUMP AND FILTER
E45RCCUC 1987	FUEL PUMP AND FILTER
E45RCE 1989	FUEL PUMP AND FILTER - ROPE START
E45RCESR 1990	FUEL PUMP AND FILTER - ROPE START
E45RCLCDS 1986	FUEL PUMP AND FILTER
E45RCLCUC 1987	FUEL PUMP AND FILTER
E45RCLE 1989	FUEL PUMP AND FILTER - ROPE START
E45RCLESR 1990	FUEL PUMP AND FILTER - ROPE START
E45WMLE 1989	FUEL PUMP AND FILTER - ROPE START
E45WMLESR 1990	FUEL PUMP AND FILTER - ROPE START
E48ESLCCC 1988	FUEL PUMP AND FILTER
E48ESLCER 1989	FUEL PUMP
E48ESLCUS 1987	FUEL PUMP AND FILTER
E48ESLESA 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
E50BECCS 1988	FUEL PUMP AND FILTER

E50BECDE 1986	FUEL PUMP AND FILTER
E50BECEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
E50BECOB 1985	FUEL PUMP AND FILTER
E50BECUD 1987	FUEL PUMP AND FILTER
E50BEESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
E50BELCCS 1988	FUEL PUMP AND FILTER
E50BELCDE 1986	FUEL PUMP AND FILTER
E50BELCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
E50BELCOB 1985	FUEL PUMP AND FILTER
E50BELCUD 1987	FUEL PUMP AND FILTER
E50BEESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
E50RNLIA 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
E50TELCCS 1988	FUEL PUMP AND FILTER
E50TELCDE 1986	FUEL PUMP AND FILTER
E50TELCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
E50TELCOB 1985	FUEL PUMP AND FILTER
E50TELCUD 1987	FUEL PUMP AND FILTER
E50TELESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
E50TLCCS 1988	FUEL PUMP AND FILTER
E50TLCDE 1986	FUEL PUMP AND FILTER
E50TLCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
E50TLCOB 1985	FUEL PUMP AND FILTER
E50TLCUD 1987	FUEL PUMP AND FILTER
E50TLESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
E55RWLDCD 1986	FUEL PUMP AND FILTER
E55RWLCOS 1985	FUEL PUMP AND FILTER
E55RWLCUC 1987	FUEL PUMP AND FILTER
E55RWLE 1989	FUEL PUMP AND FILTER - ROPE START
E55RWLESR 1990	FUEL PUMP AND FILTER - ROPE START
E60ELCCR 1988	FUEL PUMP
E60ELCOD 1985	FUEL PUMP AND FILTER
E60TLCCR 1988	FUEL PUMP
E60TLCOD 1985	FUEL PUMP AND FILTER
E60TTLCCR 1988	FUEL PUMP
E65RWLCDR 1986	FUEL PUMP AND FILTER

E65RWLCOC 1985	FUEL PUMP AND FILTER
E65TELCDR 1986	FUEL PUMP AND FILTER
E65TELCOC 1985	FUEL PUMP AND FILTER
E65WMLCOC 1985	FUEL PUMP & FILTER - WMLP & WMYP MODELS ONLY
E65WMLZ 1989	FUEL PUMP & FILTER
E65WTLCOG 1985	FUEL PUMP & FILTER - WMLP & WMYP MODELS ONLY
E6RCUD 1987	FUEL PUMP - LATE PRODUCTION
E6RLCUD 1987	FUEL PUMP - LATE PRODUCTION
E6SLCUD 1987	FUEL PUMP - LATE PRODUCTION
E88MSLCCC 1988	FUEL PUMP - 88 MODELS
E88MSLCER 1989	FUEL PUMP - 88 MODELS
E88MSLCUS 1987	CARBURETOR, FUEL PUMP AND FILTER
E88MSLESA 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
E8RCUD 1987	FUEL PUMP - LATE PRODUCTION
E8RLCUD 1987	FUEL PUMP - LATE PRODUCTION
E8SRLCUD 1987	FUEL PUMP - LATE PRODUCTION
E90TLCCA 1988	FUEL PUMP - 88 MODELS
E90TLCEM 1989	FUEL PUMP - 88 MODELS
E90TLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
FUEL SYSTEMS 1988	ACCUMIX FUEL PUMP KIT - 5, 6, 6.5 & 8
FUEL SYSTEMS 1988	ACCUMIX FUEL PUMP KIT 9.9,15 R AC LIGHT,TE,REM. ELEC. & SAIL
FUEL SYSTEMS 1988	ACCUMIX FUEL PUMP KIT 9.9 15 ROPE START (W/O AC LIGHT)
FUEL SYSTEMS 1989	ACCUMIX FUEL PUMP KIT - 5, 6, 6.5 & 8
FUEL SYSTEMS 1989	ACCUMIX FUEL PUMP KIT 9.9,15 R AC LIGHT,TE,REM. ELEC. & SAIL
FUEL SYSTEMS 1989	ACCUMIX FUEL PUMP KIT 9.9 15 ROPE START (W/O AC LIGHT)
FUEL SYSTEMS 1990	ACCUMIX FUEL PUMP KIT - 5, 6, 6.5 & 8
FUEL SYSTEMS 1990	ACCUMIX FUEL PUMP KIT - 9.9, 15 ROPE START MODELS
J100STLCCA 1988	FUEL PUMP - 88 MODELS
J100STLCEM 1989	FUEL PUMP - 88 MODELS
J100STLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
J10ECCD 1988	FUEL PUMP - ELECTRIC START MODELS
J10ECES 1989	FUEL PUMP - ELECTRIC START MODELS
J10ECUE 1987	FUEL PUMP - LATE PRODUCTION
J10EESC 1990	FUEL PUMP - ELECTRIC START MODELS
J10ELCCD 1988	FUEL PUMP - ELECTRIC START MODELS

J10ELCES 1989	FUEL PUMP - ELECTRIC START MODELS
J10ELCUE 1987	FUEL PUMP - LATE PRODUCTION
J10ELESC 1990	FUEL PUMP - ELECTRIC START MODELS
J10RCCD 1988	FUEL PUMP - ELECTRIC START MODELS
J10RCES 1989	FUEL PUMP - ELECTRIC START MODELS
J10RCUE 1987	FUEL PUMP - LATE PRODUCTION
J10RELESC 1990	FUEL PUMP - ELECTRIC START MODELS
J10RESC 1990	FUEL PUMP - ELECTRIC START MODELS
J10RLCCD 1988	FUEL PUMP - ELECTRIC START MODELS
J10RLCES 1989	FUEL PUMP - ELECTRIC START MODELS
J10RLCUE 1987	FUEL PUMP - LATE PRODUCTION
J10RLESC 1990	FUEL PUMP - ELECTRIC START MODELS
J10SELCCD 1988	FUEL PUMP - ELECTRIC START MODELS
J10SELCES 1989	FUEL PUMP - ELECTRIC START MODELS
J10SELCUE 1987	FUEL PUMP - LATE PRODUCTION
J10SELESC 1990	FUEL PUMP - ELECTRIC START MODELS
J110MLCCA 1988	FUEL PUMP - 88 MODELS
J110MLCEM 1989	FUEL PUMP - 88 MODELS
J110TLAEM 1989	FUEL PUMP - 88 MODELS
J110TLCCA 1988	FUEL PUMP - 88 MODELS
J110TLCEM 1989	FUEL PUMP - 88 MODELS
J110TXCCA 1988	FUEL PUMP - 88 MODELS
J110TXCEM 1989	FUEL PUMP - 88 MODELS
J115MLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
J115TLASB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
J115TLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
J115TXESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
J15ECCS 1988	FUEL PUMP - ELECTRIC START MODELS
J15ECEC 1989	FUEL PUMP - ELECTRIC START MODELS
J15ECUD 1987	FUEL PUMP - LATE PRODUCTION
J15EESR 1990	FUEL PUMP - ELECTRIC START MODELS
J15ELCCS 1988	FUEL PUMP - ELECTRIC START MODELS
J15ELCEC 1989	FUEL PUMP - ELECTRIC START MODELS
J15ELCUD 1987	FUEL PUMP - LATE PRODUCTION
J15ELESR 1990	FUEL PUMP - ELECTRIC START MODELS

J15RCCS 1988	FUEL PUMP - ELECTRIC START MODELS
J15RCEC 1989	FUEL PUMP - ELECTRIC START MODELS
J15RCUD 1987	FUEL PUMP - LATE PRODUCTION
J15RELSR 1990	FUEL PUMP - ELECTRIC START MODELS
J15RESR 1990	FUEL PUMP - ELECTRIC START MODELS
J15RLCCS 1988	FUEL PUMP - ELECTRIC START MODELS
J15RLCEC 1989	FUEL PUMP - ELECTRIC START MODELS
J15RLCUD 1987	FUEL PUMP - LATE PRODUCTION
J15RLESR 1990	FUEL PUMP - ELECTRIC START MODELS
J20CRCCA 1988	FUEL PUMP
J20CRCDC 1986	FUEL PUMP
J20CRCEM 1989	FUEL PUMP
J20CRCOS 1985	FUEL PUMP
J20CRCUR 1987	FUEL PUMP
J20CRESB 1990	FUEL PUMP - EARLY PRODUCTION
J20CRLCCA 1988	FUEL PUMP
J20CRLCDC 1986	FUEL PUMP
J20CRLCEM 1989	FUEL PUMP
J20CRLCOS 1985	FUEL PUMP
J20CRLCUR 1987	FUEL PUMP
J20CRLESB 1990	FUEL PUMP - EARLY PRODUCTION
J20ECCA 1988	FUEL PUMP
J20ECDC 1986	FUEL PUMP
J20ECEM 1989	FUEL PUMP
J20ECOS 1985	FUEL PUMP
J20ECUR 1987	FUEL PUMP
J20EESB 1990	FUEL PUMP - EARLY PRODUCTION
J20ELCCA 1988	FUEL PUMP
J20ELCDC 1986	FUEL PUMP
J20ELCEM 1989	FUEL PUMP
J20ELCOS 1985	FUEL PUMP
J20ELCUR 1987	FUEL PUMP
J20ELESB 1990	FUEL PUMP - EARLY PRODUCTION
J20TECDC 1986	FUEL PUMP
J25ECCM 1988	FUEL PUMP

J25ECDR 1986	FUEL PUMP
J25ECEB 1989	FUEL PUMP
J25ECOC 1985	FUEL PUMP
J25ECUA 1987	FUEL PUMP
J25EESE 1990	FUEL PUMP - EARLY PRODUCTION
J25ELCCM 1988	FUEL PUMP
J25ELCDR 1986	FUEL PUMP
J25ELCEB 1989	FUEL PUMP
J25ELCOC 1985	FUEL PUMP
J25ELCUA 1987	FUEL PUMP
J25ELESE 1990	FUEL PUMP - EARLY PRODUCTION
J25RCCA 1988	FUEL PUMP
J25RCDC 1986	FUEL PUMP
J25RCEM 1989	FUEL PUMP
J25RCOS 1985	FUEL PUMP
J25RCUR 1987	FUEL PUMP
J25RESB 1990	FUEL PUMP - EARLY PRODUCTION
J25RLCCA 1988	FUEL PUMP
J25RLCDC 1986	FUEL PUMP
J25RLCEM 1989	FUEL PUMP
J25RLCOS 1985	FUEL PUMP
J25RLCUR 1987	FUEL PUMP
J25RLESB 1990	FUEL PUMP - EARLY PRODUCTION
J25RWDC 1986	FUEL PUMP
J25RWCOS 1985	FUEL PUMP
J25RWCUR 1987	FUEL PUMP
J25RWESA 1990	FUEL PUMP - EARLY PRODUCTION
J25RWK 1989	FUEL PUMP
J25RWLDC 1986	FUEL PUMP
J25RWLCOS 1985	FUEL PUMP
J25RWLCUR 1987	FUEL PUMP
J25RWLESA 1990	FUEL PUMP - EARLY PRODUCTION
J25RWLK 1989	FUEL PUMP
J25TECCA 1988	FUEL PUMP
J25TECDC 1986	FUEL PUMP

J25TECEM 1989	FUEL PUMP
J25TECOS 1985	FUEL PUMP
J25TECUR 1987	FUEL PUMP
J25TEESB 1990	FUEL PUMP - EARLY PRODUCTION
J25TELCCA 1988	FUEL PUMP
J25TELCDC 1986	FUEL PUMP
J25TELCEM 1989	FUEL PUMP
J25TELCOS 1985	FUEL PUMP
J25TELCUR 1987	FUEL PUMP
J25TELESB 1990	FUEL PUMP - EARLY PRODUCTION
J28ELCDS 1986	FUEL PUMP
J28ESLCCR 1988	FUEL PUMP
J28ESLCEA 1989	FUEL PUMP
J28ESLCUC 1987	FUEL PUMP
J28ESLESM 1990	FUEL PUMP - EARLY PRODUCTION
J30ECCE 1988	FUEL PUMP
J30ECDM 1986	FUEL PUMP
J30ECED 1989	FUEL PUMP
J30EOA 1985	FUEL PUMP
J30ECUB 1987	FUEL PUMP
J30EES 1990	FUEL PUMP - EARLY PRODUCTION
J30ELCCE 1988	FUEL PUMP
J30ELCDM 1986	FUEL PUMP
J30ELCED 1989	FUEL PUMP
J30ELCOA 1985	FUEL PUMP
J30ELCUB 1987	FUEL PUMP
J30ELESS 1990	FUEL PUMP - EARLY PRODUCTION
J30RCCE 1988	FUEL PUMP
J30RCDM 1986	FUEL PUMP
J30RCED 1989	FUEL PUMP
J30ROA 1985	FUEL PUMP
J30RCUB 1987	FUEL PUMP
J30RESS 1990	FUEL PUMP - EARLY PRODUCTION
J30RLCCE 1988	FUEL PUMP
J30RLCDM 1986	FUEL PUMP

J30RLCED 1989	FUEL PUMP
J30RLCOA 1985	FUEL PUMP
J30RLCUB 1987	FUEL PUMP
J30RLESS 1990	FUEL PUMP - EARLY PRODUCTION
J30TECCE 1988	FUEL PUMP
J30TECDM 1986	FUEL PUMP
J30TECED 1989	FUEL PUMP
J30TECOA 1985	FUEL PUMP
J30TECUB 1987	FUEL PUMP
J30TEESS 1990	FUEL PUMP - EARLY PRODUCTION
J30TELCCE 1988	FUEL PUMP
J30TELCDM 1986	FUEL PUMP
J30TELCED 1989	FUEL PUMP
J30TELCOA 1985	FUEL PUMP
J30TELCUB 1987	FUEL PUMP
J30TELESS 1990	FUEL PUMP - EARLY PRODUCTION
J35AELCDE 1986	FUEL PUMP AND FILTER
J35AELCUD 1987	FUEL PUMP AND FILTER
J35ARLCDE 1986	FUEL PUMP AND FILTER
J35ARLCUD 1987	FUEL PUMP AND FILTER
J35RCCE 1988	FUEL PUMP
J35RCDM 1986	FUEL PUMP
J35RCED 1989	FUEL PUMP
J35RCUB 1987	FUEL PUMP
J35RESS 1990	FUEL PUMP - EARLY PRODUCTION
J35RLCCE 1988	FUEL PUMP
J35RLCDM 1986	FUEL PUMP
J35RLCED 1989	FUEL PUMP
J35RLCUB 1987	FUEL PUMP
J35RLESS 1990	FUEL PUMP - EARLY PRODUCTION
J40AELCCS 1988	FUEL PUMP AND FILTER
J40ARLCCS 1988	FUEL PUMP AND FILTER
J40ATLCCS 1988	FUEL PUMP AND FILTER
J40ECCS 1988	FUEL PUMP AND FILTER
J40ECDE 1986	FUEL PUMP AND FILTER

J40ECEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
J40ECOB 1985	FUEL PUMP AND FILTER
J40ECUD 1987	FUEL PUMP AND FILTER
J40EESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
J40ELCCS 1988	FUEL PUMP AND FILTER
J40ELCDE 1986	FUEL PUMP AND FILTER
J40ELCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
J40ELCOB 1985	FUEL PUMP AND FILTER
J40ELCUD 1987	FUEL PUMP AND FILTER
J40ELESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
J40RCCS 1988	FUEL PUMP AND FILTER
J40RCDE 1986	FUEL PUMP AND FILTER
J40RCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
J40RCOB 1985	FUEL PUMP AND FILTER
J40RCUD 1987	FUEL PUMP AND FILTER
J40RESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
J40RLCCS 1988	FUEL PUMP AND FILTER
J40RLCDE 1986	FUEL PUMP AND FILTER
J40RLCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
J40RLCOB 1985	FUEL PUMP AND FILTER
J40RLCUD 1987	FUEL PUMP AND FILTER
J40RLESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
J40RWADB 1986	FUEL PUMP
J40RWCOM 1985	FUEL PUMP
J40RWLCDB 1986	FUEL PUMP
J40RWLCOM 1985	FUEL PUMP
J40TECCS 1988	FUEL PUMP AND FILTER
J40TECDE 1986	FUEL PUMP AND FILTER
J40TECEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
J40TECOB 1985	FUEL PUMP AND FILTER
J40TECUD 1987	FUEL PUMP AND FILTER
J40TEESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
J40TELCCS 1988	FUEL PUMP AND FILTER
J40TELCDE 1986	FUEL PUMP AND FILTER
J40TELCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL

J40TELCOB 1985	FUEL PUMP AND FILTER
J40TELESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
J40TLCCS 1988	FUEL PUMP AND FILTER
J40TLCDE 1986	FUEL PUMP AND FILTER
J40TLCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
J40TLCUD 1987	FUEL PUMP AND FILTER
J40TLESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
J40TTLCCS 1988	FUEL PUMP AND FILTER
J40TTLCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
J40TTLESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
J45RCCDS 1986	FUEL PUMP AND FILTER
J45RCCUC 1987	FUEL PUMP AND FILTER
J45RCE 1989	FUEL PUMP AND FILTER - ROPE START
J45RCESR 1990	FUEL PUMP AND FILTER - ROPE START
J45RCLCDS 1986	FUEL PUMP AND FILTER
J45RCLCUC 1987	FUEL PUMP AND FILTER
J45RCLE 1989	FUEL PUMP AND FILTER - ROPE START
J45RCLESR 1990	FUEL PUMP AND FILTER - ROPE START
J45WMLE 1989	FUEL PUMP AND FILTER - ROPE START
J45WMLESR 1990	FUEL PUMP AND FILTER - ROPE START
J48ESLCCC 1988	FUEL PUMP AND FILTER
J48ESLCER 1989	FUEL PUMP
J48ESLCUS 1987	FUEL PUMP AND FILTER
J48ESLESA 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
J50BECCS 1988	FUEL PUMP AND FILTER
J50BECDE 1986	FUEL PUMP AND FILTER
J50BECEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
J50BECOB 1985	FUEL PUMP AND FILTER
J50BECUD 1987	FUEL PUMP AND FILTER
J50BEESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
J50BELCCS 1988	FUEL PUMP AND FILTER
J50BELCDE 1986	FUEL PUMP AND FILTER
J50BELCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
J50BELCOB 1985	FUEL PUMP AND FILTER
J50BELCUD 1987	FUEL PUMP AND FILTER

J50BELESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
J50TELCCS 1988	FUEL PUMP AND FILTER
J50TELCDE 1986	FUEL PUMP AND FILTER
J50TELCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
J50TELCOB 1985	FUEL PUMP AND FILTER
J50TELCUD 1987	FUEL PUMP AND FILTER
J50TELESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
J50TLCCS 1988	FUEL PUMP AND FILTER
J50TLCDE 1986	FUEL PUMP AND FILTER
J50TLCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
J50TLCOB 1985	FUEL PUMP AND FILTER
J50TLCUD 1987	FUEL PUMP AND FILTER
J50TLESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
J55RWLDC 1986	FUEL PUMP AND FILTER
J55RWLCOS 1985	FUEL PUMP AND FILTER
J55RWLCUC 1987	FUEL PUMP AND FILTER
J55RWLE 1989	FUEL PUMP AND FILTER - ROPE START
J55RWLESR 1990	FUEL PUMP AND FILTER - ROPE START
J60ELCCR 1988	FUEL PUMP
J60ELCOD 1985	FUEL PUMP AND FILTER
J60TLCCR 1988	FUEL PUMP
J60TLCOD 1985	FUEL PUMP AND FILTER
J60TTLCCR 1988	FUEL PUMP
J65RWLCDR 1986	FUEL PUMP AND FILTER
J65RWLCOC 1985	FUEL PUMP AND FILTER
J65TELCDR 1986	FUEL PUMP AND FILTER
J65TELCOC 1985	FUEL PUMP AND FILTER
J65WMLCOC 1985	FUEL PUMP & FILTER - WMLP & WMYP MODELS ONLY
J65WMLZ 1989	FUEL PUMP & FILTER
J65WTLCOC 1985	FUEL PUMP & FILTER - WMLP & WMYP MODELS ONLY
J6RCUD 1987	FUEL PUMP - LATE PRODUCTION
J6RLCUD 1987	FUEL PUMP - LATE PRODUCTION
J6SLCUD 1987	FUEL PUMP - LATE PRODUCTION
J88MSLCCC 1988	FUEL PUMP - 88 MODELS
J88MSLCER 1989	FUEL PUMP - 88 MODELS

J88MSLCUS 1987	CARBURETOR, FUEL PUMP AND FILTER
J88MSLESA 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
J8RCUD 1987	FUEL PUMP - LATE PRODUCTION
J8RLCUD 1987	FUEL PUMP - LATE PRODUCTION
J8SRLCUD 1987	FUEL PUMP - LATE PRODUCTION
J90TLAEM 1989	FUEL PUMP - 88 MODELS
J90TLASB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
J90TLCCA 1988	FUEL PUMP - 88 MODELS
J90TLCEM 1989	FUEL PUMP - 88 MODELS
J90TLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
M55RWLR 1988	FUEL PUMP AND FILTER
R45RCLR 1988	FUEL PUMP AND FILTER
R45RCR 1988	FUEL PUMP AND FILTER
R55RWLR 1988	FUEL PUMP AND FILTER
S45RCLR 1988	FUEL PUMP AND FILTER
S45RCR 1988	FUEL PUMP AND FILTER
TE10ELCES 1989	FUEL PUMP - ELECTRIC START MODELS
TE10ELESC 1990	FUEL PUMP - ELECTRIC START MODELS
TE10RELESC 1990	FUEL PUMP - ELECTRIC START MODELS
TE10RLCES 1989	FUEL PUMP - ELECTRIC START MODELS
TE10RLESC 1990	FUEL PUMP - ELECTRIC START MODELS
TE110TLCEM 1989	FUEL PUMP - 88 MODELS
TE110TLESF 1989	FUEL PUMP - 88 MODELS
TE110TXCEM 1989	FUEL PUMP - 88 MODELS
TE115TLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
TE15RLCEC 1989	FUEL PUMP - ELECTRIC START MODELS
TE20CRCEM 1989	FUEL PUMP
TE20CRESB 1990	FUEL PUMP - EARLY PRODUCTION
TE20CRLCEM 1989	FUEL PUMP
TE20CRLESB 1990	FUEL PUMP - EARLY PRODUCTION
TE20CRLESF 1989	FUEL PUMP
TE25ELCEB 1989	FUEL PUMP
TE25ELESE 1990	FUEL PUMP - EARLY PRODUCTION
TE25ELESF 1989	FUEL PUMP
TE30ELCED 1989	FUEL PUMP

TE30ELESF 1989	FUEL PUMP
TE30ELESS 1990	FUEL PUMP - EARLY PRODUCTION
TE40ELCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
TE40ELESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
TE40TELESF 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
TE40TELESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
TE50TLCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
TE50TLESF 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
TE50TLESF 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
TE50TLESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
TE90TLCEM 1989	FUEL PUMP - 88 MODELS
TE90TLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
TE90TLESF 1989	FUEL PUMP - 88 MODELS
TE90TLESF 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
TJ10ELCES 1989	FUEL PUMP - ELECTRIC START MODELS
TJ10ELESC 1990	FUEL PUMP - ELECTRIC START MODELS
TJ10RELESC 1990	FUEL PUMP - ELECTRIC START MODELS
TJ10RLCES 1989	FUEL PUMP - ELECTRIC START MODELS
TJ10RLESC 1990	FUEL PUMP - ELECTRIC START MODELS
TJ110TLCEM 1989	FUEL PUMP - 88 MODELS
TJ110TXCEM 1989	FUEL PUMP - 88 MODELS
TJ115TLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
TJ15RLCEC 1989	FUEL PUMP - ELECTRIC START MODELS
TJ20CRCEM 1989	FUEL PUMP
TJ20CRESB 1990	FUEL PUMP - EARLY PRODUCTION
TJ20CRLCEM 1989	FUEL PUMP
TJ20CRLESB 1990	FUEL PUMP - EARLY PRODUCTION
TJ20CRLESF 1989	FUEL PUMP
TJ25ELCEB 1989	FUEL PUMP
TJ25ELESE 1990	FUEL PUMP - EARLY PRODUCTION
TJ25ELESF 1989	FUEL PUMP
TJ30ELCED 1989	FUEL PUMP
TJ30ELESF 1989	FUEL PUMP
TJ30ELESS 1990	FUEL PUMP - EARLY PRODUCTION
TJ40ELCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL

TJ40ELESF 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
TJ40ELESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
TJ40TELESF 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
TJ40TELESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
TJ50TLCEC 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
TJ50TLESF 1989	FUEL PUMP AND FILTER ROPE - TE - TTL
TJ50TLESF 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
TJ50TLESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
TJ90TLCEM 1989	FUEL PUMP - 88 MODELS
TJ90TLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
U25RWA 1988	FUEL PUMP
U25RWLA 1988	FUEL PUMP
VE100SLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
VE115TLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
VE115TXESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
VE25ELESE 1990	FUEL PUMP - EARLY PRODUCTION
VE25RESB 1990	FUEL PUMP - EARLY PRODUCTION
VE28ESLCCR 1988	FUEL PUMP
VE28ESLCEA 1989	FUEL PUMP
VE28ESLESM 1990	FUEL PUMP - EARLY PRODUCTION
VE30EES 1990	FUEL PUMP - EARLY PRODUCTION
VE30ELESS 1990	FUEL PUMP - EARLY PRODUCTION
VE40EESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
VE40ELESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
VE40TELESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
VE40TLESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
VE48ESLCCC 1988	FUEL PUMP AND FILTER
VE48ESLCER 1989	FUEL PUMP
VE48ESLESA 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
VE50BEESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
VE50BELESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
VE50TLESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
VE88MSLCCC 1988	FUEL PUMP - 88 MODELS
VE88MSLCER 1989	FUEL PUMP - 88 MODELS
VE88MSLESA 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION

VE90MLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
VE90TLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
VJ100SLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
VJ115TLASB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
VJ115TLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
VJ115TXESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
VJ25ELESE 1990	FUEL PUMP - EARLY PRODUCTION
VJ25RESB 1990	FUEL PUMP - EARLY PRODUCTION
VJ28ESLCCR 1988	FUEL PUMP
VJ28ESLCEA 1989	FUEL PUMP
VJ28ESLESM 1990	FUEL PUMP - EARLY PRODUCTION
VJ30EESS 1990	FUEL PUMP - EARLY PRODUCTION
VJ30ELESS 1990	FUEL PUMP - EARLY PRODUCTION
VJ40EESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
VJ40ELESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
VJ40TELESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
VJ40TLESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
VJ48ESLCCC 1988	FUEL PUMP AND FILTER
VJ48ESLCER 1989	FUEL PUMP
VJ48ESLESA 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
VJ50BEESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
VJ50BELESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
VJ50TLESR 1990	FUEL PUMP AND FILTER EARLY PRODUCTION
VJ88MSLCCC 1988	FUEL PUMP - 88 MODELS
VJ88MSLCER 1989	FUEL PUMP - 88 MODELS
VJ88MSLESA 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
VJ90MLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
VJ90TLASB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION
VJ90TLESB 1990	FUEL PUMP - 88 MODELS EARLY PRODUCTION