

## Where Used: Part Number 0436972

Model Name	Diagram
BE40EECR 1998	CRANKSHAFT & PISTON
BE40EEDS 1996	CRANKSHAFT & PISTON
BE40EEUC 1997	CRANKSHAFT & PISTON
BE40ELECR 1998	CRANKSHAFT & PISTON
BE40ELEDs 1996	CRANKSHAFT & PISTON
BE40ELEUC 1997	CRANKSHAFT & PISTON
BE40TLECR 1998	CRANKSHAFT & PISTON
BE40TLEDs 1996	CRANKSHAFT & PISTON
BE40TLEUC 1997	CRANKSHAFT & PISTON
BE50BEEDs 1996	CRANKSHAFT & PISTON
BE50BELEDs 1996	CRANKSHAFT & PISTON
BE50DTLEDC 1996	CRANKSHAFT & PISTON
BE50DTLEUR 1997	CRANKSHAFT & PISTON
BE50ESECC 1998	CRANKSHAFT & PISTON
BE50RLECR 1998	CRANKSHAFT & PISTON
BE50RLEUC 1997	CRANKSHAFT & PISTON
BE50TLECR 1998	CRANKSHAFT & PISTON
BE50TLEDs 1996	CRANKSHAFT & PISTON
BE50TLEUC 1997	CRANKSHAFT & PISTON
BE50TSLECC 1998	CRANKSHAFT & PISTON
BE50TSLEUS 1997	CRANKSHAFT & PISTON
BE60ELEDR 1996	CRANKSHAFT & PISTON
BE60ELEUA 1997	CRANKSHAFT & PISTON
BE60TLECM 1998	CRANKSHAFT & PISTON
BE60TLEDR 1996	CRANKSHAFT & PISTON
BE60TLEUA 1997	CRANKSHAFT & PISTON
BE70ELECB 1998	CRANKSHAFT & PISTON
BE70ELEDa 1996	CRANKSHAFT & PISTON
BE70ELEUM 1997	CRANKSHAFT & PISTON
BE70TLECB 1998	CRANKSHAFT & PISTON
BE70TLEDA 1996	CRANKSHAFT & PISTON
BE70TLEUM 1997	CRANKSHAFT & PISTON
BJ40EECR 1998	CRANKSHAFT & PISTON

BJ40EEDS 1996	CRANKSHAFT & PISTON
BJ40EEEE 1999	CRANKSHAFT & PISTON
BJ40EEUC 1997	CRANKSHAFT & PISTON
BJ40ELECR 1998	CRANKSHAFT & PISTON
BJ40ELEDs 1996	CRANKSHAFT & PISTON
BJ40ELEEA 1999	CRANKSHAFT & PISTON
BJ40ELEUC 1997	CRANKSHAFT & PISTON
BJ40ELSIF elec start, 20 in shaft, n/a usa 2001	CRANKSHAFT & PISTON
BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000	CRANKSHAFT & PISTON
BJ40ESIF elec start, 15 in shaft, n/a usa 2001	CRANKSHAFT & PISTON
BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000	CRANKSHAFT & PISTON
BJ40PLEEA 1999	CRANKSHAFT & PISTON
BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	CRANKSHAFT & PISTON
BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000	CRANKSHAFT & PISTON
BJ40TLECR 1998	CRANKSHAFT & PISTON
BJ40TLEDs 1996	CRANKSHAFT & PISTON
BJ40TLEUC 1997	CRANKSHAFT & PISTON
BJ50BEEDs 1996	CRANKSHAFT & PISTON
BJ50BELEDs 1996	CRANKSHAFT & PISTON
BJ50DTLEDC 1996	CRANKSHAFT & PISTON
BJ50DTLEUR 1997	CRANKSHAFT & PISTON
BJ50EEER 1999	CRANKSHAFT & PISTON
BJ50ELEER 1999	CRANKSHAFT & PISTON
BJ50ELSIF elec start, 20 in shaft, n/a usa 2001	CRANKSHAFT & PISTON
BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000	CRANKSHAFT & PISTON
BJ50ESECC 1998	CRANKSHAFT & PISTON
BJ50ESIF elec start, 15 in shaft, n/a usa 2001	CRANKSHAFT & PISTON
BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000	CRANKSHAFT & PISTON
BJ50PLEEA 1999	CRANKSHAFT & PISTON
BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	CRANKSHAFT & PISTON
BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000	CRANKSHAFT & PISTON
BJ50RLECR 1998	CRANKSHAFT & PISTON
BJ50RLEEA 1999	CRANKSHAFT & PISTON
BJ50RLEUC 1997	CRANKSHAFT & PISTON
BJ50RLSIF elec start, 20 in shaft, n/a usa 2001	CRANKSHAFT & PISTON

BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000	CRANKSHAFT & PISTON
BJ50TLECR 1998	CRANKSHAFT & PISTON
BJ50TLEDS 1996	CRANKSHAFT & PISTON
BJ50TLEUC 1997	CRANKSHAFT & PISTON
BJ50TSLECC 1998	CRANKSHAFT & PISTON
BJ50TSLEUS 1997	CRANKSHAFT & PISTON
BJ60ELEDR 1996	CRANKSHAFT & PISTON
BJ60ELEUA 1997	CRANKSHAFT & PISTON
BJ60TLECM 1998	CRANKSHAFT & PISTON
BJ60TLEDR 1996	CRANKSHAFT & PISTON
BJ60TLEUA 1997	CRANKSHAFT & PISTON
BJ70ELECB 1998	CRANKSHAFT & PISTON
BJ70ELEDA 1996	CRANKSHAFT & PISTON
BJ70ELEUM 1997	CRANKSHAFT & PISTON
BJ70PLEEE 1999	CRANKSHAFT & PISTON
BJ70PLSIS elec start, TNT, 20 in shaft, n/a usa 2001	CRANKSHAFT & PISTON
BJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	CRANKSHAFT & PISTON
BJ70TLECB 1998	CRANKSHAFT & PISTON
BJ70TLEDA 1996	CRANKSHAFT & PISTON
BJ70TLEUM 1997	CRANKSHAFT & PISTON
E40EEOD 1995	CRANKSHAFT & PISTON
E40ELECR 1998	CRANKSHAFT & PISTON
E40ELED 1996	CRANKSHAFT & PISTON
E40ELEOD 1995	CRANKSHAFT & PISTON
E40ELEUC 1997	CRANKSHAFT & PISTON
E40JRECA 1998	CRANKSHAFT & PISTON
E40JREDC 1996	CRANKSHAFT & PISTON
E40JREOS 1995	CRANKSHAFT & PISTON
E40JREUR 1997	CRANKSHAFT & PISTON
E40RECR 1998	CRANKSHAFT & PISTON
E40REDS 1996	CRANKSHAFT & PISTON
E40REOD 1995	CRANKSHAFT & PISTON
E40REUC 1997	CRANKSHAFT & PISTON
E40RLECR 1998	CRANKSHAFT & PISTON
E40RLEDS 1996	CRANKSHAFT & PISTON

E40RLEOD 1995	CRANKSHAFT & PISTON
E40RLEUC 1997	CRANKSHAFT & PISTON
E40TEECR 1998	CRANKSHAFT & PISTON
E40TEEDS 1996	CRANKSHAFT & PISTON
E40TEEOD 1995	CRANKSHAFT & PISTON
E40TEEUC 1997	CRANKSHAFT & PISTON
E40TELECR 1998	CRANKSHAFT & PISTON
E40TELEDS 1996	CRANKSHAFT & PISTON
E40TELEOD 1995	CRANKSHAFT & PISTON
E40TELEUC 1997	CRANKSHAFT & PISTON
E40TLECR 1998	CRANKSHAFT & PISTON
E40TLEDS 1996	CRANKSHAFT & PISTON
E40TLEOD 1995	CRANKSHAFT & PISTON
E40TLEUC 1997	CRANKSHAFT & PISTON
E40TTLECR 1998	CRANKSHAFT & PISTON
E40TTLEDS 1996	CRANKSHAFT & PISTON
E40TTLEOD 1995	CRANKSHAFT & PISTON
E40TTLEUC 1997	CRANKSHAFT & PISTON
E48ESLEDC 1996	CRANKSHAFT & PISTON
E48ESLEOS 1995	CRANKSHAFT & PISTON
E50BEEOD 1995	CRANKSHAFT & PISTON
E50BELEOD 1995	CRANKSHAFT & PISTON
E50DTLECA 1998	CRANKSHAFT & PISTON
E50DTLEDC 1996	CRANKSHAFT & PISTON
E50DTLEOS 1995	CRANKSHAFT & PISTON
E50DTLEUR 1997	CRANKSHAFT & PISTON
E50ELED 1996	CRANKSHAFT & PISTON
E50ELEOS 1995	CRANKSHAFT & PISTON
E50ELEUR 1997	CRANKSHAFT & PISTON
E50ESLECC 1998	CRANKSHAFT & PISTON
E50ESLEUR 1997	CRANKSHAFT & PISTON
E50JEDS 1996	CRANKSHAFT & PISTON
E50JEOD 1995	CRANKSHAFT & PISTON
E50JEUC 1997	CRANKSHAFT & PISTON
E50TELEOD 1995	CRANKSHAFT & PISTON

E50TLECR 1998	CRANKSHAFT & PISTON
E50TLEDS 1996	CRANKSHAFT & PISTON
E50TLEOD 1995	CRANKSHAFT & PISTON
E50TLEUC 1997	CRANKSHAFT & PISTON
E50TSLECC 1998	CRANKSHAFT & PISTON
E50TSLEUS 1997	CRANKSHAFT & PISTON
E50TTLECA 1998	CRANKSHAFT & PISTON
E50TTLEDC 1996	CRANKSHAFT & PISTON
E50TTLEOS 1995	CRANKSHAFT & PISTON
E50TTLEUR 1997	CRANKSHAFT & PISTON
E60ELEDR 1996	CRANKSHAFT & PISTON
E60ELEOC 1995	CRANKSHAFT & PISTON
E60ELERS 1994	CRANKSHAFT & PISTON
E60ELERV 1994	CRANKSHAFT & PISTON
E60ELEUA 1997	CRANKSHAFT & PISTON
E60TLECM 1998	CRANKSHAFT & PISTON
E60TLEDR 1996	CRANKSHAFT & PISTON
E60TLEOC 1995	CRANKSHAFT & PISTON
E60TLERS 1994	CRANKSHAFT & PISTON
E60TLERV 1994	CRANKSHAFT & PISTON
E60TLEUA 1997	CRANKSHAFT & PISTON
E60TTLECM 1998	CRANKSHAFT & PISTON
E60TTLEDR 1996	CRANKSHAFT & PISTON
E60TTLEOC 1995	CRANKSHAFT & PISTON
E60TTLERS 1994	CRANKSHAFT & PISTON
E60TTLERV 1994	CRANKSHAFT & PISTON
E60TTLEUA 1997	CRANKSHAFT & PISTON
E70ELEOR 1995	CRANKSHAFT & PISTON
E70ELERC 1994	CRANKSHAFT & PISTON
E70ELERV 1994	CRANKSHAFT & PISTON
E70TLECB 1998	CRANKSHAFT & PISTON
E70TLEDA 1996	CRANKSHAFT & PISTON
E70TLEOR 1995	CRANKSHAFT & PISTON
E70TLERC 1994	CRANKSHAFT & PISTON
E70TLERV 1994	CRANKSHAFT & PISTON

E70TLEUM 1997	CRANKSHAFT & PISTON
E70TTLEOR 1995	CRANKSHAFT & PISTON
E70TTLERC 1994	CRANKSHAFT & PISTON
E70TTLERV 1994	CRANKSHAFT & PISTON
HE40REDS 1996	CRANKSHAFT & PISTON
HE40REUC 1997	CRANKSHAFT & PISTON
HE40RLEDS 1996	CRANKSHAFT & PISTON
HE40RLEUC 1997	CRANKSHAFT & PISTON
HE70TXEDA 1996	CRANKSHAFT & PISTON
HE70TXEUM 1997	CRANKSHAFT & PISTON
HJ40REDS 1996	CRANKSHAFT & PISTON
HJ40REUC 1997	CRANKSHAFT & PISTON
HJ40RLEDS 1996	CRANKSHAFT & PISTON
HJ40RLEUC 1997	CRANKSHAFT & PISTON
HJ70TXEDA 1996	CRANKSHAFT & PISTON
HJ70TXEUM 1997	CRANKSHAFT & PISTON
J25JRTSSS Jet Drive, Rope Start, Tiller, 15 IN. shaft 2000	CRANKSHAFT & PISTON
J30JREEM 1999	CRANKSHAFT & PISTON
J30JRSIE jet drive, rope start, 15 in shaft 2001	CRANKSHAFT & PISTON
J30JRSSB Jet Drive, Rope Start, Tiller, 15 IN. shaft 2000	CRANKSHAFT & PISTON
J40EEOD 1995	CRANKSHAFT & PISTON
J40ELECR 1998	CRANKSHAFT & PISTON
J40ELEDS 1996	CRANKSHAFT & PISTON
J40ELEOD 1995	CRANKSHAFT & PISTON
J40ELEUC 1997	CRANKSHAFT & PISTON
J40JPLEEC 1999	CRANKSHAFT & PISTON
J40JPLSIA jet drive,elec start, TNT, 20 in shaft 2001	CRANKSHAFT & PISTON
J40JPLSSR Jet Drive, Elec Start, TNT, 20 IN. shaft 2000	CRANKSHAFT & PISTON
J40JRECA 1998	CRANKSHAFT & PISTON
J40JREDC 1996	CRANKSHAFT & PISTON
J40JREOS 1995	CRANKSHAFT & PISTON
J40JREUR 1997	CRANKSHAFT & PISTON
J40JVLSIA jet drive,elec start, TNT, 20 in shaft, wht 2001	CRANKSHAFT & PISTON
J40PLEEA 1999	CRANKSHAFT & PISTON
J40PLSIF elec start, TNT, 20 in shaft 2001	CRANKSHAFT & PISTON

J40PLSNF - FR	25-2_VILEBREQUIN ET PISTONS
J40PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	CRANKSHAFT & PISTON
J40PLSOC	CRANKSHAFT & PISTON
J40PLSOC - FR	25-2_VILEBREQUIN ET PISTONS
J40PLSRS	CRANKSHAFT & PISTON
J40PLSRS - FR	25-2_VILEBREQUIN ET PISTONS
J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000	CRANKSHAFT & PISTON
J40PLSTD	CRANKSHAFT & PISTON
J40PLSTD - FR	25-2_VILEBREQUIN ET PISTONS
J40RECR 1998	CRANKSHAFT & PISTON
J40REDS 1996	CRANKSHAFT & PISTON
J40REEA 1999	CRANKSHAFT & PISTON
J40REOD 1995	CRANKSHAFT & PISTON
J40REUC 1997	CRANKSHAFT & PISTON
J40RLECR 1998	CRANKSHAFT & PISTON
J40RLEDS 1996	CRANKSHAFT & PISTON
J40RLEEA 1999	CRANKSHAFT & PISTON
J40RLEOD 1995	CRANKSHAFT & PISTON
J40RLEUC 1997	CRANKSHAFT & PISTON
J40RLSIF rope start, 20 in shaft 2001	CRANKSHAFT & PISTON
J40RLSNF - FR	25-2_VILEBREQUIN ET PISTONS
J40RLSNF 20 in. shaft, White, Tiller, Rope, Touch Trim 2002	CRANKSHAFT & PISTON
J40RLSOC	CRANKSHAFT & PISTON
J40RLSOC - FR	25-2_VILEBREQUIN ET PISTONS
J40RLSRS	CRANKSHAFT & PISTON
J40RLSRS - FR	25-2_VILEBREQUIN ET PISTONS
J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000	CRANKSHAFT & PISTON
J40RLSTD	CRANKSHAFT & PISTON
J40RLSTD - FR	25-2_VILEBREQUIN ET PISTONS
J40RSIF rope start, 15 in shaft 2001	CRANKSHAFT & PISTON
J40RSNF - FR	25-2_VILEBREQUIN ET PISTONS
J40RSNF 15 in. shaft, White, Tiller, Rope, Touch Trim 2002	CRANKSHAFT & PISTON
J40RSOC	CRANKSHAFT & PISTON
J40RSOC - FR	25-2_VILEBREQUIN ET PISTONS
J40RSRS	CRANKSHAFT & PISTON

J40RSRS - FR	25-2_VILEBREQUIN ET PISTONS
J40RSSM Rope Start, Tiller, 15 IN. shaft 2000	CRANKSHAFT & PISTON
J40RSTD	CRANKSHAFT & PISTON
J40RSTD - FR	25-2_VILEBREQUIN ET PISTONS
J40TEECR 1998	CRANKSHAFT & PISTON
J40TEEDS 1996	CRANKSHAFT & PISTON
J40TEEOD 1995	CRANKSHAFT & PISTON
J40TEEUC 1997	CRANKSHAFT & PISTON
J40TELECR 1998	CRANKSHAFT & PISTON
J40TELEDS 1996	CRANKSHAFT & PISTON
J40TELEOD 1995	CRANKSHAFT & PISTON
J40TELEUC 1997	CRANKSHAFT & PISTON
J40TLECR 1998	CRANKSHAFT & PISTON
J40TLEDS 1996	CRANKSHAFT & PISTON
J40TLEOD 1995	CRANKSHAFT & PISTON
J40TLEUC 1997	CRANKSHAFT & PISTON
J40TPLEEA 1999	CRANKSHAFT & PISTON
J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001	CRANKSHAFT & PISTON
J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	CRANKSHAFT & PISTON
J40TTLECR 1998	CRANKSHAFT & PISTON
J40TTLEDS 1996	CRANKSHAFT & PISTON
J40TTLEOD 1995	CRANKSHAFT & PISTON
J40TTLEUC 1997	CRANKSHAFT & PISTON
J48ESLEDC 1996	CRANKSHAFT & PISTON
J48ESLEOS 1995	CRANKSHAFT & PISTON
J50BEEOD 1995	CRANKSHAFT & PISTON
J50BELEOD 1995	CRANKSHAFT & PISTON
J50DTLECA 1998	CRANKSHAFT & PISTON
J50DTLEDC 1996	CRANKSHAFT & PISTON
J50DTLEOS 1995	CRANKSHAFT & PISTON
J50DTLEUR 1997	CRANKSHAFT & PISTON
J50ELED 1996	CRANKSHAFT & PISTON
J50ELEER 1999	CRANKSHAFT & PISTON
J50ELEOS 1995	CRANKSHAFT & PISTON
J50ELEUR 1997	CRANKSHAFT & PISTON



J50ELSIF elec start, 20 in shaft 2001	CRANKSHAFT & PISTON
J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000	CRANKSHAFT & PISTON
J50ESLECC 1998	CRANKSHAFT & PISTON
J50ESLEUR 1997	CRANKSHAFT & PISTON
J50JEDS 1996	CRANKSHAFT & PISTON
J50JEOD 1995	CRANKSHAFT & PISTON
J50JEUC 1997	CRANKSHAFT & PISTON
J50PLEEA 1999	CRANKSHAFT & PISTON
J50PLSIF elec start, TNT, 20 in shaft 2001	CRANKSHAFT & PISTON
J50PLSNF - FR	25-2_VILEBREQUIN ET PISTONS
J50PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	CRANKSHAFT & PISTON
J50PLSOC	CRANKSHAFT & PISTON
J50PLSOC - FR	25-2_VILEBREQUIN ET PISTONS
J50PLSRS	CRANKSHAFT & PISTON
J50PLSRS - FR	25-2_VILEBREQUIN ET PISTONS
J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	CRANKSHAFT & PISTON
J50PLSTD	CRANKSHAFT & PISTON
J50PLSTD - FR	25-2_VILEBREQUIN ET PISTONS
J50TELEOD 1995	CRANKSHAFT & PISTON
J50TLECR 1998	CRANKSHAFT & PISTON
J50TLEDS 1996	CRANKSHAFT & PISTON
J50TLEOD 1995	CRANKSHAFT & PISTON
J50TLEUC 1997	CRANKSHAFT & PISTON
J50TSLECC 1998	CRANKSHAFT & PISTON
J50TSLEUS 1997	CRANKSHAFT & PISTON
J50TTLECA 1998	CRANKSHAFT & PISTON
J50TTLEDC 1996	CRANKSHAFT & PISTON
J50TTLEOS 1995	CRANKSHAFT & PISTON
J50TTLEUR 1997	CRANKSHAFT & PISTON
J60ELEDR 1996	CRANKSHAFT & PISTON
J60ELEOC 1995	CRANKSHAFT & PISTON
J60ELERS 1994	CRANKSHAFT & PISTON
J60ELERV 1994	CRANKSHAFT & PISTON
J60ELEUA 1997	CRANKSHAFT & PISTON
J60PLEEB 1999	CRANKSHAFT & PISTON

J60PLSID elec start, TNT, 20 in shaft 2001	CRANKSHAFT & PISTON
J60PLSSE Elec Start, TNT, 20 IN. shaft 2000	CRANKSHAFT & PISTON
J60TLECM 1998	CRANKSHAFT & PISTON
J60TLEDR 1996	CRANKSHAFT & PISTON
J60TLEOC 1995	CRANKSHAFT & PISTON
J60TLERS 1994	CRANKSHAFT & PISTON
J60TLERV 1994	CRANKSHAFT & PISTON
J60TLEUA 1997	CRANKSHAFT & PISTON
J60TTLECM 1998	CRANKSHAFT & PISTON
J60TTLEDR 1996	CRANKSHAFT & PISTON
J60TTLEOC 1995	CRANKSHAFT & PISTON
J60TTLERS 1994	CRANKSHAFT & PISTON
J60TTLERV 1994	CRANKSHAFT & PISTON
J60TTLEUA 1997	CRANKSHAFT & PISTON
J60VLSID elec start, TNT, 20 in shaft, wht 2001	CRANKSHAFT & PISTON
J70ELEOR 1995	CRANKSHAFT & PISTON
J70ELERC 1994	CRANKSHAFT & PISTON
J70ELERV 1994	CRANKSHAFT & PISTON
J70JLEOS 1995	CRANKSHAFT & PISTON
J70PLEEE 1999	CRANKSHAFT & PISTON
J70PLSIS elec start, TNT, 20 in shaft 2001	CRANKSHAFT & PISTON
J70PLSSD Elec Start, TNT, 20 IN. shaft 2000	CRANKSHAFT & PISTON
J70TLECB 1998	CRANKSHAFT & PISTON
J70TLEDA 1996	CRANKSHAFT & PISTON
J70TLEOR 1995	CRANKSHAFT & PISTON
J70TLERC 1994	CRANKSHAFT & PISTON
J70TLERV 1994	CRANKSHAFT & PISTON
J70TLEUM 1997	CRANKSHAFT & PISTON
J70TTLEOR 1995	CRANKSHAFT & PISTON
J70TTLERC 1994	CRANKSHAFT & PISTON
J70TTLERV 1994	CRANKSHAFT & PISTON
J70VLSIS elec start, TNT, 20 in shaft 2001	CRANKSHAFT & PISTON
RJ50ELSIF elec start, TNT, 20 in shaft 2001	CRANKSHAFT & PISTON
RJ70PLSIS elec start, TNT, 20 in shaft 2001	CRANKSHAFT & PISTON
RJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	CRANKSHAFT & PISTON

SE50TLEDS 1996	CRANKSHAFT & PISTON
SJ40EEDS 1996	CRANKSHAFT & PISTON
SJ40REDS 1996	CRANKSHAFT & PISTON
SJ40RLEDS 1996	CRANKSHAFT & PISTON
SJ60TLEDR 1996	CRANKSHAFT & PISTON
SJ70TLEDA 1996	CRANKSHAFT & PISTON
X50ESLECC 1998	CRANKSHAFT & PISTON