

Where Used: Part Number 0445128

Model Name	Diagram
BE5FRBECC 1998	IGNITION
BE5FRBLECC 1998	IGNITION
BE8FRBECA 1998	IGNITION -- ELECTRIC
BE8FRBECA 1998	IGNITION -- ROPE
BE8FRBLECA 1998	IGNITION -- ELECTRIC
BE8FRBLECA 1998	IGNITION -- ROPE
BJ5FRBECC 1998	IGNITION
BJ5FRBLECC 1998	IGNITION
BJ8FRBECA 1998	IGNITION -- ELECTRIC
BJ8FRBECA 1998	IGNITION -- ROPE
BJ8FRBLECA 1998	IGNITION -- ELECTRIC
BJ8FRBLECA 1998	IGNITION -- ROPE
E10FOECA 1998	IGNITION -- ELECTRIC
E10FOECA 1998	IGNITION -- ROPE
E10FOLECA 1998	IGNITION -- ELECTRIC
E10FOLECA 1998	IGNITION -- ROPE
E5R4EEM 1999	IGNITION
E5R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	IGNITION
E5R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. Shaft 2000	IGNITION
E5RB4EER 1999	IGNITION
E5RBL4EER 1999	IGNITION
E5RL4EEM 1999	IGNITION
E5RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	IGNITION
E5RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. Shaft 2000	IGNITION
E6R4EEM 1999	IGNITION
E6R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	IGNITION
E6R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. Shaft 2000	IGNITION
E6RL4EEM 1999	IGNITION
E6RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	IGNITION
E6RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. Shaft 2000	IGNITION
E8FRECA 1998	IGNITION -- ELECTRIC
E8FRECA 1998	IGNITION -- ROPE
E8FRLECA 1998	IGNITION -- ELECTRIC

E8FRLECA 1998	IGNITION -- ROPE
E8FRXECA 1998	IGNITION -- ELECTRIC
E8FRXECA 1998	IGNITION -- ROPE
E8R4EEM 1999	IGNITION
E8R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	IGNITION
E8R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
E8RB4EEM 1999	IGNITION
E8RBL4EEM 1999	IGNITION
E8RL4EEM 1999	IGNITION
E8RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	IGNITION
E8RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
E8RVL4SIC 4-stroke, rope start, tiller, 20 in shaft, wht 2001	IGNITION
E8RVL4SSB 4-Stroke, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
HE10FELECA 1998	IGNITION -- ELECTRIC
HE10FELECA 1998	IGNITION -- ROPE
HE5FRECA 1998	IGNITION
HE5FRLECA 1998	IGNITION
HE6FRECA 1998	IGNITION
HE6FRLECA 1998	IGNITION
HJ10FELECA 1998	IGNITION -- ELECTRIC
HJ10FELECA 1998	IGNITION -- ROPE
HJ5FRECA 1998	IGNITION
HJ5FRLECA 1998	IGNITION
HJ6FRECA 1998	IGNITION
HJ6FRLECA 1998	IGNITION
J10FOECA 1998	IGNITION -- ELECTRIC
J10FOECA 1998	IGNITION -- ROPE
J10FOLECA 1998	IGNITION -- ELECTRIC
J10FOLECA 1998	IGNITION -- ROPE
J6R4SRC	IGNITION
J6R4SRC - FR	12-5_SYSTÈME D'ALLUMAGE
J6R4STS	IGNITION
J6R4STS - FR	12-5_SYSTÈME D'ALLUMAGE
J6RL4SRC	IGNITION
J6RL4SRC - FR	12-5_SYSTÈME D'ALLUMAGE

J6RL4STS	IGNITION
J6RL4STS - FR	12-5_SYSTÈME D'ALLUMAGE
J8FRECA 1998	IGNITION -- ELECTRIC
J8FRECA 1998	IGNITION -- ROPE
J8FRLECA 1998	IGNITION -- ELECTRIC
J8FRLECA 1998	IGNITION -- ROPE
J8FRXECA 1998	IGNITION -- ELECTRIC
J8FRXECA 1998	IGNITION -- ROPE
J8R4SRC	IGNITION
J8R4SRC - FR	12-5_SYSTÈME D'ALLUMAGE
J8R4STS	IGNITION
J8R4STS - FR	12-5_SYSTÈME D'ALLUMAGE
J8RL4SRC	IGNITION
J8RL4SRC - FR	12-5_SYSTÈME D'ALLUMAGE
J8RL4STS	IGNITION
J8RL4STS - FR	12-5_SYSTÈME D'ALLUMAGE