

Where Used: Part Number 0446074

Model Name	Diagram
BE10FAEDC 1996	CYLINDER & CRANKCASE
BE10FAEUR 1997	CYLINDER & CRANKCASE
BE10FCLEDC 1996	CYLINDER & CRANKCASE
BE10FCLEUR 1997	CYLINDER & CRANKCASE
BE10FWEDC 1996	CYLINDER & CRANKCASE
BE10FWEUR 1997	CYLINDER & CRANKCASE
BE10FWLEDC 1996	CYLINDER & CRANKCASE
BE10FWLEUR 1997	CYLINDER & CRANKCASE
BE5FRBECC 1998	CYLINDER & CRANKCASE
BE5FRBEUS 1997	CYLINDER & CRANKCASE
BE5FRBLECC 1998	CYLINDER & CRANKCASE
BE5FRBLEUS 1997	CYLINDER & CRANKCASE
BE8FRBECA 1998	CYLINDER & CRANKCASE
BE8FRBEDC 1996	CYLINDER & CRANKCASE
BE8FRBEUR 1997	CYLINDER & CRANKCASE
BE8FRBLECA 1998	CYLINDER & CRANKCASE
BE8FRBLEDC 1996	CYLINDER & CRANKCASE
BE8FRBLEUR 1997	CYLINDER & CRANKCASE
BE8FRBXEDC 1996	CYLINDER & CRANKCASE
BE8FRBXEUR 1997	CYLINDER & CRANKCASE
BJ10FAEDC 1996	CYLINDER & CRANKCASE
BJ10FAEUR 1997	CYLINDER & CRANKCASE
BJ10FCLEDC 1996	CYLINDER & CRANKCASE
BJ10FCLEUR 1997	CYLINDER & CRANKCASE
BJ10FWEDC 1996	CYLINDER & CRANKCASE
BJ10FWEUR 1997	CYLINDER & CRANKCASE
BJ10FWLEDC 1996	CYLINDER & CRANKCASE
BJ10FWLEUR 1997	CYLINDER & CRANKCASE
BJ5FRBECC 1998	CYLINDER & CRANKCASE
BJ5FRBEUS 1997	CYLINDER & CRANKCASE
BJ5FRBLECC 1998	CYLINDER & CRANKCASE
BJ5FRBLEUS 1997	CYLINDER & CRANKCASE
BJ8FRBECA 1998	CYLINDER & CRANKCASE

BJ8FRBEDC 1996	CYLINDER & CRANKCASE
BJ8FRBEUR 1997	CYLINDER & CRANKCASE
BJ8FRBLECA 1998	CYLINDER & CRANKCASE
BJ8FRBLEDC 1996	CYLINDER & CRANKCASE
BJ8FRBLEUR 1997	CYLINDER & CRANKCASE
BJ8FRBXEDC 1996	CYLINDER & CRANKCASE
BJ8FRBXEUR 1997	CYLINDER & CRANKCASE
E10FOECA 1998	CYLINDER & CRANKCASE
E10FOLECA 1998	CYLINDER & CRANKCASE
E5R4EEM 1999	CYLINDER & CRANKCASE
E5R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	CYLINDER & CRANKCASE
E5R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. Shaft 2000	CYLINDER AND CRANKCASE
E5RB4EER 1999	CYLINDER & CRANKCASE
E5RBL4EER 1999	CYLINDER & CRANKCASE
E5RL4EEM 1999	CYLINDER & CRANKCASE
E5RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	CYLINDER & CRANKCASE
E5RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. Shaft 2000	CYLINDER AND CRANKCASE
E6R4EEM 1999	CYLINDER & CRANKCASE
E6R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	CYLINDER & CRANKCASE
E6R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. Shaft 2000	CYLINDER AND CRANKCASE
E6RL4EEM 1999	CYLINDER & CRANKCASE
E6RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	CYLINDER & CRANKCASE
E6RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. Shaft 2000	CYLINDER AND CRANKCASE
E8FRECA 1998	CYLINDER & CRANKCASE
E8FREDC 1996	CYLINDER & CRANKCASE
E8FREUR 1997	CYLINDER & CRANKCASE
E8FRLECA 1998	CYLINDER & CRANKCASE
E8FRXECA 1998	CYLINDER & CRANKCASE
E8FRXEDC 1996	CYLINDER & CRANKCASE
E8FRXEUR 1997	CYLINDER & CRANKCASE
E8R4EEM 1999	CYLINDER & CRANKCASE
E8R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	CYLINDER HEAD & CRANKSHAFT
E8R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. shaft 2000	CYLINDER AND CRANKCASE
E8RB4EEM 1999	CYLINDER & CRANKCASE
E8RBL4EEM 1999	CYLINDER & CRANKCASE

E8RL4EEM 1999	CYLINDER & CRANKCASE
E8RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	CYLINDER HEAD & CRANKSHAFT
E8RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. shaft 2000	CYLINDER AND CRANKCASE
E8RVL4SIC 4-stroke, rope start, tiller, 20 in shaft, wht 2001	CYLINDER HEAD & CRANKSHAFT
E8RVL4SSB 4-Stroke, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	CYLINDER AND CRANKCASE
HE10FDEDC 1996	CYLINDER & CRANKCASE
HE10FDLEDC 1996	CYLINDER & CRANKCASE
HE10FELECA 1998	CYLINDER & CRANKCASE
HE10FELEDC 1996	CYLINDER & CRANKCASE
HE10FELEUR 1997	CYLINDER & CRANKCASE
HE10FOEUR 1997	CYLINDER & CRANKCASE
HE10FOLEUR 1997	CYLINDER & CRANKCASE
HE10FTEDC 1996	CYLINDER & CRANKCASE
HE10FTEUR 1997	CYLINDER & CRANKCASE
HE10FTLEDC 1996	CYLINDER & CRANKCASE
HE10FTLEUR 1997	CYLINDER & CRANKCASE
HE5FRECA 1998	CYLINDER & CRANKCASE
HE5FREUR 1997	CYLINDER & CRANKCASE
HE5FRLECA 1998	CYLINDER & CRANKCASE
HE5FRLEUR 1997	CYLINDER & CRANKCASE
HE6FRECA 1998	CYLINDER & CRANKCASE
HE6FREUR 1997	CYLINDER & CRANKCASE
HE6FRLECA 1998	CYLINDER & CRANKCASE
HE6FRLEUR 1997	CYLINDER & CRANKCASE
HE8FREDC 1996	CYLINDER & CRANKCASE
HE8FREUR 1997	CYLINDER & CRANKCASE
HE8FRLEDC 1996	CYLINDER & CRANKCASE
HE8FRLEUR 1997	CYLINDER & CRANKCASE
HJ10FDEDC 1996	CYLINDER & CRANKCASE
HJ10FDLEDC 1996	CYLINDER & CRANKCASE
HJ10FELECA 1998	CYLINDER & CRANKCASE
HJ10FELEDC 1996	CYLINDER & CRANKCASE
HJ10FELEUR 1997	CYLINDER & CRANKCASE
HJ10FOEUR 1997	CYLINDER & CRANKCASE
HJ10FOLEUR 1997	CYLINDER & CRANKCASE

HJ10FTEDC 1996	CYLINDER & CRANKCASE
HJ10FTEUR 1997	CYLINDER & CRANKCASE
HJ10FTLEDC 1996	CYLINDER & CRANKCASE
HJ10FTLEUR 1997	CYLINDER & CRANKCASE
HJ5FRECA 1998	CYLINDER & CRANKCASE
HJ5FREUR 1997	CYLINDER & CRANKCASE
HJ5FRLECA 1998	CYLINDER & CRANKCASE
HJ5FRLEUR 1997	CYLINDER & CRANKCASE
HJ6FRECA 1998	CYLINDER & CRANKCASE
HJ6FREUR 1997	CYLINDER & CRANKCASE
HJ6FRLECA 1998	CYLINDER & CRANKCASE
HJ6FRLEUR 1997	CYLINDER & CRANKCASE
HJ8FREDC 1996	CYLINDER & CRANKCASE
HJ8FREUR 1997	CYLINDER & CRANKCASE
HJ8FRLEDC 1996	CYLINDER & CRANKCASE
HJ8FRLEUR 1997	CYLINDER & CRANKCASE
J10FOECA 1998	CYLINDER & CRANKCASE
J10FOLECA 1998	CYLINDER & CRANKCASE
J6R4SRC	CYLINDER HEAD & CRANKCASE
J6R4SRC - FR	15-7_CULASSE ET CARTER-MOTEUR
J6R4STS	CYLINDER HEAD & CRANKCASE
J6R4STS - FR	15-7_CULASSE ET CARTER-MOTEUR
J6RL4SRC	CYLINDER HEAD & CRANKCASE
J6RL4SRC - FR	15-7_CULASSE ET CARTER-MOTEUR
J6RL4STS	CYLINDER HEAD & CRANKCASE
J6RL4STS - FR	15-7_CULASSE ET CARTER-MOTEUR
J8FRECA 1998	CYLINDER & CRANKCASE
J8FREDC 1996	CYLINDER & CRANKCASE
J8FREUR 1997	CYLINDER & CRANKCASE
J8FRLECA 1998	CYLINDER & CRANKCASE
J8FRXECA 1998	CYLINDER & CRANKCASE
J8FRXEDC 1996	CYLINDER & CRANKCASE
J8FRXEUR 1997	CYLINDER & CRANKCASE
J8R4SRC	CYLINDER HEAD & CRANKCASE
J8R4SRC - FR	15-7_CULASSE ET CARTER-MOTEUR

J8R4STS	CYLINDER & CRANKCASE
J8R4STS - FR	15-6_CYLINDRES ET CARTER-MOTEUR
J8RL4SRC	CYLINDER HEAD & CRANKCASE
J8RL4SRC - FR	15-7_CULASSE ET CARTER-MOTEUR
J8RL4STS	CYLINDER & CRANKCASE
J8RL4STS - FR	15-6_CYLINDRES ET CARTER-MOTEUR