

Where Used: Part Number 5001036

Model Name	Diagram
BJ200CXSS ELEC. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	CYLINDER & CRANKCASE
BJ200PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	CYLINDER & CRANKCASE
BJ200PLSSC ELEC. Start, TNT, 20 IN. shaft, N/A USA 2000	CYLINDER & CRANKCASE
BJ200PXSSC ELEC. Start, TNT, 25 IN. shaft, N/A USA 2000	CYLINDER & CRANKCASE
BJ200VCSIF elec start, TNT, 25 in , wht, cntr rotate, n/a usa 2001	CYLINDER & CRANKCASE
BJ200VCSSE ELEC. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	CYLINDER & CRANKCASE
BJ200VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	CYLINDER & CRANKCASE
BJ200VXSSS ELEC. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	CYLINDER & CRANKCASE
BJ225CXSSR ELEC Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	CYLINDER & CRANKCASE
BJ225PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	CYLINDER & CRANKCASE
BJ225PLSSR ELEC. Start, TNT, 20 IN. shaft, N/A USA 2000	CYLINDER & CRANKCASE
BJ225PXSSR ELEC. Start, TNT, 25 IN. shaft, N/A USA 2000	CYLINDER & CRANKCASE
BJ225VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
BJ225VCSSE ELEC. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
BJ225VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	CYLINDER & CRANKCASE
BJ225VXSSS ELEC. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	CYLINDER & CRANKCASE
E200FCSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
E200FCSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
E200FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
E200FCXSNF - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E200FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002	CYLINDER & CRANKCASE
E200FCXSOE	CYLINDER & CRANKCASE
E200FCXSOE - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E200FCXSRB	CYLINDER & CRANKCASE
E200FCXSRB - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E200FCXSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
E200FCXSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
E200FCXSTM	CYLINDER & CRANKCASE
E200FHLSOR	CYLINDER & CRANKCASE
E200FHLSOR - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E200FHLSRC	CYLINDER & CRANKCASE
E200FHLSRC - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E200FHLSTS	CYLINDER & CRANKCASE

E200FPLSIF FFI, elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
E200FPLSNF - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E200FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002	CYLINDER & CRANKCASE
E200FPLSOE	CYLINDER & CRANKCASE
E200FPLSOE - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E200FPLSRB	CYLINDER & CRANKCASE
E200FPLSRB - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E200FPLSSC FFI, Elec Start, TNT, 20 IN shaft 2000	CYLINDER & CRANKCASE
E200FPLSSH FFI, Elec Start, TNT, 20 IN shaft 2000	CYLINDER & CRANKCASE
E200FPLSTM	CYLINDER & CRANKCASE
E200FPXSIF FFI, elec start, TNT, 25 in shaft 2001	CYLINDER & CRANKCASE
E200FPXSNF - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E200FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002	CYLINDER & CRANKCASE
E200FPXSOE	CYLINDER & CRANKCASE
E200FPXSOE - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E200FPXSRB	CYLINDER & CRANKCASE
E200FPXSRB - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E200FPXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	CYLINDER & CRANKCASE
E200FPXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	CYLINDER & CRANKCASE
E200FPXSTM	CYLINDER & CRANKCASE
E200FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	CYLINDER & CRANKCASE
E200FSLSOE	CYLINDER & CRANKCASE
E200FSLSOE - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E200FSLSRB	CYLINDER & CRANKCASE
E200FSLSRB - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E200FSLSSC FFI, Elec Start, TNT, 20 IN shaft, wht 2000	CYLINDER & CRANKCASE
E200FSLSSH FFI, Elec Start, TNT, 20 IN shaft, wht 2000	CYLINDER & CRANKCASE
E200FSLSTM	CYLINDER & CRANKCASE
E225FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
E225FCXSNF - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002	CYLINDER & CRANKCASE
E225FCXSOE	CYLINDER & CRANKCASE
E225FCXSOE - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FCXSRB	CYLINDER & CRANKCASE
E225FCXSRB - FR	05-3_CYLINDRES ET CARTER-MOTEUR

E225FCXSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
E225FCXSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
E225FCXSTM	CYLINDER & CRANKCASE
E225FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
E225FCZSNF - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002	CYLINDER & CRANKCASE
E225FCZSOE	CYLINDER & CRANKCASE
E225FCZSOE - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FCZSRB	CYLINDER & CRANKCASE
E225FCZSRB - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FCZSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
E225FCZSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
E225FCZSTM	CYLINDER & CRANKCASE
E225FGLSSC FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000	CYLINDER & CRANKCASE
E225FGLSSH FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000	CYLINDER & CRANKCASE
E225FHLSIF FFI, elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
E225FHLSNF - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FHLSNF Ficht RAM Injection, H.O., 20 in. shaft, Blue 2002	CYLINDER & CRANKCASE
E225FHLSOB	CYLINDER & CRANKCASE
E225FHLSOB - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FHLSRM	CYLINDER & CRANKCASE
E225FHLSRM - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FHLSSS FFI, Elec Start, TNT, 20 IN shaft, hs gc, HO 2000	CYLINDER & CRANKCASE
E225FHLSTA	CYLINDER & CRANKCASE
E225FHXSOC	CYLINDER & CRANKCASE
E225FHXSOC - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FHXSRS	CYLINDER & CRANKCASE
E225FHXSRS - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FPLSIF FFI	CYLINDER & CRANKCASE
E225FPLSNF - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002	CYLINDER & CRANKCASE
E225FPLSOE	CYLINDER & CRANKCASE
E225FPLSOE - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FPLSRB	CYLINDER & CRANKCASE
E225FPLSRB - FR	05-3_CYLINDRES ET CARTER-MOTEUR

E225FPLSSC FFI, Elec Start, TNT, 20 IN shaft 2000	CYLINDER & CRANKCASE
E225FPLSSH FFI, Elec Start, TNT, 20 IN shaft 2000	CYLINDER & CRANKCASE
E225FPLSTM	CYLINDER & CRANKCASE
E225FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	CYLINDER & CRANKCASE
E225FPXSNF - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002	CYLINDER & CRANKCASE
E225FPXSOE	CYLINDER & CRANKCASE
E225FPXSOE - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FPXSRB	CYLINDER & CRANKCASE
E225FPXSRB - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FPXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	CYLINDER & CRANKCASE
E225FPXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	CYLINDER & CRANKCASE
E225FPXSTM	CYLINDER & CRANKCASE
E225FPZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	CYLINDER & CRANKCASE
E225FPZSNF - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002	CYLINDER & CRANKCASE
E225FPZSOE	CYLINDER & CRANKCASE
E225FPZSOE - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FPZSRB	CYLINDER & CRANKCASE
E225FPZSRB - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E225FPZSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	CYLINDER & CRANKCASE
E225FPZSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	CYLINDER & CRANKCASE
E225FPZSTM	CYLINDER & CRANKCASE
E250FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
E250FCXSNF - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E250FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002	CYLINDER & CRANKCASE
E250FCXSOB	CYLINDER & CRANKCASE
E250FCXSOB - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E250FCXSRM	CYLINDER & CRANKCASE
E250FCXSRM - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E250FCXSSS FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
E250FCXSTA	CYLINDER & CRANKCASE
E250FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
E250FCZSNF - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E250FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002	CYLINDER & CRANKCASE

E250FCZSOB	CYLINDER & CRANKCASE
E250FCZSOB - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E250FCZSRM	CYLINDER & CRANKCASE
E250FCZSRM - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E250FCZSSS FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
E250FCZSTA	CYLINDER & CRANKCASE
E250FGLSSS FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000	CYLINDER & CRANKCASE
E250FPLSOM	CYLINDER & CRANKCASE
E250FPLSOM - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E250FPLSRA	CYLINDER & CRANKCASE
E250FPLSRA - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E250FPLSSS FFI, Elec Start, TNT, 20 IN shaft 2000	CYLINDER & CRANKCASE
E250FPLSTR	CYLINDER & CRANKCASE
E250FPXSIF FFI, elec start, TNT, 25 in shaft 2001	CYLINDER & CRANKCASE
E250FPXSNF - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E250FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002	CYLINDER & CRANKCASE
E250FPXSOB	CYLINDER & CRANKCASE
E250FPXSOB - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E250FPXSRM	CYLINDER & CRANKCASE
E250FPXSRM - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E250FPXSSS FFI, Elec Start, TNT, 25 IN shaft, wht 2000	CYLINDER & CRANKCASE
E250FPXSTA	CYLINDER & CRANKCASE
E250FPZSIF FFI, elec start, TNT, 30 in shaft 2001	CYLINDER & CRANKCASE
E250FPZSNF - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E250FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002	CYLINDER & CRANKCASE
E250FPZSOB	CYLINDER & CRANKCASE
E250FPZSOB - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E250FPZSRM	CYLINDER & CRANKCASE
E250FPZSRM - FR	05-3_CYLINDRES ET CARTER-MOTEUR
E250FPZSSS FFI, Elec Start, TNT, 30 IN shaft, wht 2000	CYLINDER & CRANKCASE
E250FPZSTA	CYLINDER & CRANKCASE
J200CXSE Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000	CYLINDER & CRANKCASE
J200PLSIF elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	CYLINDER & CRANKCASE
J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	CYLINDER & CRANKCASE

J200VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
J200VLSIF elec start, TNT, 20 in shaft, wht 2001	CYLINDER & CRANKCASE
J200VXSIF elec start, TNT, 25 in shaft, wht 2001	CYLINDER & CRANKCASE
J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	CYLINDER & CRANKCASE
J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	CYLINDER & CRANKCASE
J225HGLSIF elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	CYLINDER & CRANKCASE
J225HPLSIF elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	CYLINDER & CRANKCASE
J225PLSIF elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	CYLINDER & CRANKCASE
J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	CYLINDER & CRANKCASE
J225VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
J225VLSIF elec start, TNT, 20 in shaft, wht 2001	CYLINDER & CRANKCASE
J225VXSIF elec start, TNT, 25 in shaft, wht 2001	CYLINDER & CRANKCASE
J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	CYLINDER & CRANKCASE
J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000	CYLINDER & CRANKCASE
J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000	CYLINDER & CRANKCASE
J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
J250VCZSIF elec start, TNT, 30 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
J250VXSIF elec start, TNT, 25 in shaft, wht 2001	CYLINDER & CRANKCASE
J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	CYLINDER & CRANKCASE
J250VZSSIF elec start, TNT, 30 in shaft, wht 2001	CYLINDER & CRANKCASE
J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	CYLINDER & CRANKCASE
RE200FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
RE200FLSIF FFI, elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
RE200FLSSC FFI, Elec Start, TNT, 20 IN shaft 2000	CYLINDER & CRANKCASE
RE200FLSSH FFI, Elec Start, TNT, 20 IN shaft 2000	CYLINDER & CRANKCASE
RE200FSSH FFI, Elec Start, TNT, 20 IN shaft, wht 2000	CYLINDER & CRANKCASE
RE200FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	CYLINDER & CRANKCASE

RE200FXSIF FFI, elec start, TNT, 25 in shaft 2001	CYLINDER & CRANKCASE
RE200FXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	CYLINDER & CRANKCASE
RE200FXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	CYLINDER & CRANKCASE
RE225FCSSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
RE225FCSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
RE225FCSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
RE225FGSSC FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000	CYLINDER & CRANKCASE
RE225FGSSH FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000	CYLINDER & CRANKCASE
RE225FHSIF FFI, elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
RE225FHSSC FFI, Elec Start, TNT, 20 IN shaft, hs gc, HO 2000	CYLINDER & CRANKCASE
RE225FLSSC FFI, Elec Start, TNT, 20 IN shaft 2000	CYLINDER & CRANKCASE
RE225FLSSH FFI, Elec Start, TNT, 20 IN shaft 2000	CYLINDER & CRANKCASE
RE225FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	CYLINDER & CRANKCASE
RE225FXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	CYLINDER & CRANKCASE
RE225FXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	CYLINDER & CRANKCASE
RE225FZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	CYLINDER & CRANKCASE
RE225FZSSH FFI, Elec Start, TNT, 30 IN shaft, wht 2000	CYLINDER & CRANKCASE
RJ200PLSIF elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	CYLINDER & CRANKCASE
RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	CYLINDER & CRANKCASE
RJ200VXSIF elec start, TNT, 25 in shaft, wht 2001	CYLINDER & CRANKCASE
RJ200VXSSC Elec. Start, TNT, 25 IN. shaft, wht 2000	CYLINDER & CRANKCASE
RJ225CXSSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
RJ225CXSSC Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	CYLINDER & CRANKCASE
RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	CYLINDER & CRANKCASE
RJ225HLSIF elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	CYLINDER & CRANKCASE
RJ225PLSIF elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	CYLINDER & CRANKCASE
RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	CYLINDER & CRANKCASE
RJ225VXSIF elec start, TNT, 25 in shaft, wht 2001	CYLINDER & CRANKCASE
RJ225VXSSC Elec. Start, TNT, 25 IN. shaft, wht 2000	CYLINDER & CRANKCASE
RJ250CXSSC Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
RJ250VXSIF elec start, TNT, 25 in shaft, wht 2001	CYLINDER & CRANKCASE
RJ250VXSSC Elec. Start, TNT, 25 IN. shaft, wht 2000	CYLINDER & CRANKCASE

RJ250VZSSIF elec start, TNT, 30 in shaft, wht 2001

CYLINDER & CRANKCASE

RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000

CYLINDER & CRANKCASE