

Where Used: Part Number 0436979

Model Name	Diagram
BE50DTLEDC 1996	CRANKSHAFT & PISTON
BE50DTLEUR 1997	CRANKSHAFT & PISTON
BE60ELEDR 1996	CRANKSHAFT & PISTON
BE60ELEUA 1997	CRANKSHAFT & PISTON
BE60TLECM 1998	CRANKSHAFT & PISTON
BE60TLEDR 1996	CRANKSHAFT & PISTON
BE60TLEUA 1997	CRANKSHAFT & PISTON
BE70ELECB 1998	CRANKSHAFT & PISTON
BE70ELEDA 1996	CRANKSHAFT & PISTON
BE70ELEUM 1997	CRANKSHAFT & PISTON
BE70TLECB 1998	CRANKSHAFT & PISTON
BE70TLEDA 1996	CRANKSHAFT & PISTON
BE70TLEUM 1997	CRANKSHAFT & PISTON
BJ50DTLEDC 1996	CRANKSHAFT & PISTON
BJ50DTLEUR 1997	CRANKSHAFT & PISTON
BJ60ELEDR 1996	CRANKSHAFT & PISTON
BJ60ELEUA 1997	CRANKSHAFT & PISTON
BJ60TLECM 1998	CRANKSHAFT & PISTON
BJ60TLEDR 1996	CRANKSHAFT & PISTON
BJ60TLEUA 1997	CRANKSHAFT & PISTON
BJ70ELECB 1998	CRANKSHAFT & PISTON
BJ70ELEDA 1996	CRANKSHAFT & PISTON
BJ70ELEUM 1997	CRANKSHAFT & PISTON
BJ70PLEEE 1999	CRANKSHAFT & PISTON
BJ70PLSIS elec start, TNT, 20 in shaft, n/a usa 2001	CRANKSHAFT & PISTON
BJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	CRANKSHAFT & PISTON
BJ70TLECB 1998	CRANKSHAFT & PISTON
BJ70TLEDA 1996	CRANKSHAFT & PISTON
BJ70TLEUM 1997	CRANKSHAFT & PISTON
E50DTLECA 1998	CRANKSHAFT & PISTON
E50DTLEDC 1996	CRANKSHAFT & PISTON
E50DTLEOS 1995	CRANKSHAFT & PISTON
E50DTLEUR 1997	CRANKSHAFT & PISTON

E50ELED 1996	CRANKSHAFT & PISTON
E50ELEOS 1995	CRANKSHAFT & PISTON
E50ELEUR 1997	CRANKSHAFT & PISTON
E50TTLECA 1998	CRANKSHAFT & PISTON
E50TTLEDC 1996	CRANKSHAFT & PISTON
E50TTLEOS 1995	CRANKSHAFT & PISTON
E50TTLEUR 1997	CRANKSHAFT & PISTON
E60ELEDR 1996	CRANKSHAFT & PISTON
E60ELEOC 1995	CRANKSHAFT & PISTON
E60ELERS 1994	CRANKSHAFT & PISTON
E60ELERV 1994	CRANKSHAFT & PISTON
E60ELEUA 1997	CRANKSHAFT & PISTON
E60TLECM 1998	CRANKSHAFT & PISTON
E60TLEDR 1996	CRANKSHAFT & PISTON
E60TLEOC 1995	CRANKSHAFT & PISTON
E60TLERS 1994	CRANKSHAFT & PISTON
E60TLERV 1994	CRANKSHAFT & PISTON
E60TLEUA 1997	CRANKSHAFT & PISTON
E60TTLECM 1998	CRANKSHAFT & PISTON
E60TTLEDR 1996	CRANKSHAFT & PISTON
E60TTLEOC 1995	CRANKSHAFT & PISTON
E60TTLERS 1994	CRANKSHAFT & PISTON
E60TTLERV 1994	CRANKSHAFT & PISTON
E60TTLEUA 1997	CRANKSHAFT & PISTON
E70ELEOR 1995	CRANKSHAFT & PISTON
E70ELERC 1994	CRANKSHAFT & PISTON
E70ELERV 1994	CRANKSHAFT & PISTON
E70TLECB 1998	CRANKSHAFT & PISTON
E70TLEDA 1996	CRANKSHAFT & PISTON
E70TLEOR 1995	CRANKSHAFT & PISTON
E70TLERC 1994	CRANKSHAFT & PISTON
E70TLERV 1994	CRANKSHAFT & PISTON
E70TLEUM 1997	CRANKSHAFT & PISTON
E70TTLEOR 1995	CRANKSHAFT & PISTON
E70TTLERC 1994	CRANKSHAFT & PISTON

E70TTLERV 1994	CRANKSHAFT & PISTON
HE70TXEDA 1996	CRANKSHAFT & PISTON
HE70TXEUM 1997	CRANKSHAFT & PISTON
HJ70TXEDA 1996	CRANKSHAFT & PISTON
HJ70TXEUM 1997	CRANKSHAFT & PISTON
J40JPLEEC 1999	CRANKSHAFT & PISTON
J40JPLSIA jet drive,elec start, TNT, 20 in shaft 2001	CRANKSHAFT & PISTON
J40JPLSSR Jet Drive, Elec Start, TNT, 20 IN. shaft 2000	CRANKSHAFT & PISTON
J40JVLSIA jet drive,elec start, TNT, 20 in shaft, wht 2001	CRANKSHAFT & PISTON
J50DTLECA 1998	CRANKSHAFT & PISTON
J50DTLEDC 1996	CRANKSHAFT & PISTON
J50DTLEOS 1995	CRANKSHAFT & PISTON
J50DTLEUR 1997	CRANKSHAFT & PISTON
J50ELED 1996	CRANKSHAFT & PISTON
J50ELEOS 1995	CRANKSHAFT & PISTON
J50ELEUR 1997	CRANKSHAFT & PISTON
J50TTLECA 1998	CRANKSHAFT & PISTON
J50TTLEDC 1996	CRANKSHAFT & PISTON
J50TTLEOS 1995	CRANKSHAFT & PISTON
J50TTLEUR 1997	CRANKSHAFT & PISTON
J60ELEDR 1996	CRANKSHAFT & PISTON
J60ELEOC 1995	CRANKSHAFT & PISTON
J60ELERS 1994	CRANKSHAFT & PISTON
J60ELERV 1994	CRANKSHAFT & PISTON
J60ELEUA 1997	CRANKSHAFT & PISTON
J60PLEEB 1999	CRANKSHAFT & PISTON
J60PLSID elec start, TNT, 20 in shaft 2001	CRANKSHAFT & PISTON
J60PLSSE Elec Start, TNT, 20 IN. shaft 2000	CRANKSHAFT & PISTON
J60TLECM 1998	CRANKSHAFT & PISTON
J60TLEDR 1996	CRANKSHAFT & PISTON
J60TLEOC 1995	CRANKSHAFT & PISTON
J60TLERS 1994	CRANKSHAFT & PISTON
J60TLERV 1994	CRANKSHAFT & PISTON
J60TLEUA 1997	CRANKSHAFT & PISTON
J60TTLECM 1998	CRANKSHAFT & PISTON

J60TTLEDR 1996	CRANKSHAFT & PISTON
J60TTLEOC 1995	CRANKSHAFT & PISTON
J60TTLERS 1994	CRANKSHAFT & PISTON
J60TTLERV 1994	CRANKSHAFT & PISTON
J60TTLEUA 1997	CRANKSHAFT & PISTON
J60VLSID elec start, TNT, 20 in shaft, wht 2001	CRANKSHAFT & PISTON
J70ELEOR 1995	CRANKSHAFT & PISTON
J70ELERC 1994	CRANKSHAFT & PISTON
J70ELERV 1994	CRANKSHAFT & PISTON
J70JLEOS 1995	CRANKSHAFT & PISTON
J70PLEEE 1999	CRANKSHAFT & PISTON
J70PLSIS elec start, TNT, 20 in shaft 2001	CRANKSHAFT & PISTON
J70PLSSD Elec Start, TNT, 20 IN. shaft 2000	CRANKSHAFT & PISTON
J70TLECB 1998	CRANKSHAFT & PISTON
J70TLEDA 1996	CRANKSHAFT & PISTON
J70TLEOR 1995	CRANKSHAFT & PISTON
J70TLERC 1994	CRANKSHAFT & PISTON
J70TLERV 1994	CRANKSHAFT & PISTON
J70TLEUM 1997	CRANKSHAFT & PISTON
J70TTLEOR 1995	CRANKSHAFT & PISTON
J70TTLERC 1994	CRANKSHAFT & PISTON
J70TTLERV 1994	CRANKSHAFT & PISTON
J70VLSIS elec start, TNT, 20 in shaft 2001	CRANKSHAFT & PISTON
RJ70PLSIS elec start, TNT, 20 in shaft 2001	CRANKSHAFT & PISTON
RJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	CRANKSHAFT & PISTON
SJ60TTLEDR 1996	CRANKSHAFT & PISTON
SJ70TLEDA 1996	CRANKSHAFT & PISTON