

Where Used: Part Number 5030600

Model Name	Diagram
BJ60PL4SDM	CYLINDER HEAD
BJ60PL4SDM - FR	15-7_CULASSE
BJ60PL4SOA	CYLINDER HEAD
BJ60PL4SOA - FR	15-7_CULASSE
BJ60PL4SRR	CYLINDER HEAD
BJ60PL4SRR - FR	15-7_CULASSE
BJ60PL4STC	CYLINDER HEAD
BJ60PL4STC - FR	15-7_CULASSE
BJ70PL4SDM	CYLINDER HEAD
BJ70PL4SDM - FR	15-7_CULASSE
BJ70PL4SOA	CYLINDER HEAD
BJ70PL4SOA - FR	15-7_CULASSE
BJ70PL4SRR	CYLINDER HEAD
BJ70PL4SRR - FR	15-7_CULASSE
BJ70PL4STC	CYLINDER HEAD
BJ70PL4STC - FR	15-7_CULASSE
E70 PL4SSR 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2000	CYLINDER & CRANKCASE
E70FLTLECS 1998	CYLINDER & CRANKCASE
E70PL4EEC 1999	CYLINDER & CRANKCASE
E70PL4SIA 4-Stroke, Elec. Start, TNT, Blue, 20 IN. shaft 2001	CYLINDER & CRANKCASE
J4R4SDA	CYLINDER HEAD
J4R4SDA - FR	15-7_CULASSE
J4R4SOR	CYLINDER HEAD
J4R4SOR - FR	15-7_CULASSE
J4R4SRC	CYLINDER HEAD
J4R4SRC - FR	15-7_CULASSE
J4R4STS	CYLINDER HEAD
J4R4STS - FR	15-7_CULASSE
J4R4SUM	CYLINDER HEAD
J4R4SUM - FR	15-7_CULASSE
J4RL4SDA	CYLINDER HEAD
J4RL4SDA - FR	15-7_CULASSE
J4RL4SOR	CYLINDER HEAD

J4RL4SOR - FR	15-7_CULASSE
J4RL4SRC	CYLINDER HEAD
J4RL4SRC - FR	15-7_CULASSE
J4RL4STS	CYLINDER HEAD
J4RL4STS - FR	15-7_CULASSE
J4RL4SUM	CYLINDER HEAD
J4RL4SUM - FR	15-7_CULASSE
J5R4SDA	CYLINDER HEAD
J5R4SDA - FR	15-7_CULASSE
J5R4SOR	CYLINDER HEAD
J5R4SOR - FR	15-7_CULASSE
J5R4SRC	CYLINDER HEAD
J5R4SRC - FR	15-7_CULASSE
J5R4STS	CYLINDER HEAD
J5R4STS - FR	15-7_CULASSE
J5R4SUM	CYLINDER HEAD
J5R4SUM - FR	15-7_CULASSE
J5RL4SDA	CYLINDER HEAD
J5RL4SDA - FR	15-7_CULASSE
J5RL4SOR	CYLINDER HEAD
J5RL4SOR - FR	15-7_CULASSE
J5RL4SRC	CYLINDER HEAD
J5RL4SRC - FR	15-7_CULASSE
J5RL4STS	CYLINDER HEAD
J5RL4STS - FR	15-7_CULASSE
J5RL4SUM	CYLINDER HEAD
J5RL4SUM - FR	15-7_CULASSE
J60PL4SDM	CYLINDER HEAD
J60PL4SDM - FR	15-7_CULASSE
J60PL4SNF - FR	15-7_CULASSE
J60PL4SNF 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2002	CYLINDER HEAD
J60PL4SOA	CYLINDER HEAD
J60PL4SOA - FR	15-7_CULASSE
J60PL4SRR	CYLINDER HEAD
J60PL4SRR - FR	15-7_CULASSE

J60PL4STC	CYLINDER HEAD
J60PL4STC - FR	15-7_CULASSE
J6R4SDC	CYLINDER HEAD
J6R4SDC - FR	15-7_CULASSE
J6R4SOS	CYLINDER HEAD
J6R4SOS - FR	15-7_CULASSE
J6R4SUR	CYLINDER HEAD
J6R4SUR - FR	15-7_CULASSE
J6RL4SDC	CYLINDER HEAD
J6RL4SDC - FR	15-7_CULASSE
J6RL4SOS	CYLINDER HEAD
J6RL4SOS - FR	15-7_CULASSE
J6RL4SUR	CYLINDER HEAD
J6RL4SUR - FR	15-7_CULASSE
J70FLTLECS 1998	CYLINDER & CRANKCASE
J70PL4SDM	CYLINDER HEAD
J70PL4SDM - FR	15-7_CULASSE
J70PL4SNF - FR	15-7_CULASSE
J70PL4SNF 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2002	CYLINDER HEAD
J70PL4SOA	CYLINDER HEAD
J70PL4SOA - FR	15-7_CULASSE
J70PL4SRR	CYLINDER HEAD
J70PL4SRR - FR	15-7_CULASSE
J70PL4STC	CYLINDER HEAD
J70PL4STC - FR	15-7_CULASSE