

Where Used: Part Number 5030635

Model Name	Diagram
BJ60PL4SDM	OIL PAN
BJ60PL4SDM - FR	15-5_CARTER D'HUILE
BJ60PL4SOA	OIL PAN
BJ60PL4SOA - FR	15-5_CARTER D'HUILE
BJ60PL4SRR	OIL PAN
BJ60PL4SRR - FR	15-5_CARTER D'HUILE
BJ60PL4STC	OIL PAN
BJ60PL4STC - FR	15-5_CARTER D'HUILE
BJ70PL4SDM	OIL PAN
BJ70PL4SDM - FR	15-5_CARTER D'HUILE
BJ70PL4SOA	OIL PAN
BJ70PL4SOA - FR	15-5_CARTER D'HUILE
BJ70PL4SRR	OIL PAN
BJ70PL4SRR - FR	15-5_CARTER D'HUILE
BJ70PL4STC	OIL PAN
BJ70PL4STC - FR	15-5_CARTER D'HUILE
E70 PL4SSR 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2000	MIDSECTION & OIL SYSTEM
E70FLTLECS 1998	MIDSECTION & OIL SYSTEM
E70PL4EEC 1999	MIDSECTION & OIL SYSTEM
E70PL4SIA 4-Stroke, Elec. Start, TNT, Blue, 20 IN. shaft 2001	MIDSECTION & OIL SYSTEM
J60PL4SDM	OIL PAN
J60PL4SDM - FR	15-5_CARTER D'HUILE
J60PL4SNF - FR	15-5_CARTER D'HUILE
J60PL4SNF 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2002	OIL PAN
J60PL4SOA	OIL PAN
J60PL4SOA - FR	15-5_CARTER D'HUILE
J60PL4SRR	OIL PAN
J60PL4SRR - FR	15-5_CARTER D'HUILE
J60PL4STC	OIL PAN
J60PL4STC - FR	15-5_CARTER D'HUILE
J70FLTLECS 1998	MIDSECTION & OIL SYSTEM
J70PL4SDM	OIL PAN
J70PL4SDM - FR	15-5_CARTER D'HUILE

J70PL4SNF - FR	15-5_CARTER D'HUILE
J70PL4SNF 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2002	OIL PAN
J70PL4SOA	OIL PAN
J70PL4SOA - FR	15-5_CARTER D'HUILE
J70PL4SRR	OIL PAN
J70PL4SRR - FR	15-5_CARTER D'HUILE
J70PL4STC	OIL PAN
J70PL4STC - FR	15-5_CARTER D'HUILE