

Where Used: Part Number 5030826

Model Name	Diagram
BJ115L4SRC	SENSOR GROUP
BJ115L4SRC - FR	12-6_CAPTEURS
BJ115L4STS	SENSOR GROUP
BJ115L4STS - FR	12-6_CAPTEURS
BJ115PL4SDA	SENSOR GROUP
BJ115PL4SDA - FR	12-6_CAPTEURS
BJ115PX4SDA	SENSOR GROUP
BJ115PX4SDA - FR	12-6_CAPTEURS
BJ115X4SRC	SENSOR GROUP
BJ115X4SRC - FR	12-6_CAPTEURS
BJ115X4STS	SENSOR GROUP
BJ115X4STS - FR	12-6_CAPTEURS
BJ140CX4DR	SENSORS
BJ140CX4DR - FR	12-6_CAPTEURS
BJ140CX4SRS	SENSOR GROUP
BJ140CX4SRS - FR	12-6_CAPTEURS
BJ140L4SDR	SENSORS
BJ140L4SDR - FR	12-6_CAPTEURS
BJ140PL4SRS	SENSOR GROUP
BJ140PL4SRS - FR	12-6_CAPTEURS
BJ140PX4SRS	SENSOR GROUP
BJ140PX4SRS - FR	12-6_CAPTEURS
BJ140X4SDR	SENSORS
BJ140X4SDR - FR	12-6_CAPTEURS
BJ200CX4DC	SENSORS
BJ200CX4DC - FR	12-6_CAPTEURS
BJ200CX4SO	SENSORS
BJ200CX4SO - FR	12-6_CAPTEURS
BJ200PX4SO	SENSORS
BJ200PX4SO - FR	12-6_CAPTEURS
BJ200X4SDC	SENSORS
BJ200X4SDC - FR	12-6_CAPTEURS
BJ225CX4DC	SENSORS

BJ225CX4DC - FR	12-6_CAPTEURS
BJ225CX4SO	SENSORS
BJ225CX4SO - FR	12-6_CAPTEURS
BJ225PX4SO - FR	12-6_CAPTEURS
BJ225X4SDC	SENSORS
BJ225X4SDC - FR	12-6_CAPTEURS
BJ225X4SO	SENSORS
BJ40PL4SDR	SENSOR GROUP
BJ40PL4SDR - FR	12-6_CAPTEURS
BJ40PL4SOC	SENSOR GROUP
BJ40PL4SOC - FR	12-6_CAPTEURS
BJ40PL4SRS	SENSOR GROUP
BJ40PL4SRS - FR	12-6_CAPTEURS
BJ50PL4SDR	SENSOR GROUP
BJ50PL4SDR - FR	12-6_CAPTEURS
BJ50PL4SOC	SENSOR GROUP
BJ50PL4SOC - FR	12-6_CAPTEURS
BJ50PL4SRS	SENSOR GROUP
BJ50PL4SRS - FR	12-6_CAPTEURS
BJ60PL4SDM	SENSOR GROUP
BJ60PL4SDM - FR	12-6_CAPTEURS
BJ60PL4SOA	SENSOR GROUP
BJ60PL4SOA - FR	12-6_CAPTEURS
BJ60PL4SRR	SENSOR GROUP
BJ60PL4SRR - FR	12-6_CAPTEURS
BJ60PL4STC	SENSOR GROUP
BJ60PL4STC - FR	12-6_CAPTEURS
BJ70PL4SDM	SENSOR GROUP
BJ70PL4SDM - FR	12-6_CAPTEURS
BJ70PL4SOA	SENSOR GROUP
BJ70PL4SOA - FR	12-6_CAPTEURS
BJ70PL4SRR	SENSOR GROUP
BJ70PL4SRR - FR	12-6_CAPTEURS
BJ70PL4STC	SENSOR GROUP
BJ70PL4STC - FR	12-6_CAPTEURS

BJ90PL4SDA	SENSOR GROUP
BJ90PL4SDA - FR	12-6_CAPTEURS
BJ90PL4SRC	SENSOR GROUP
BJ90PL4SRC - FR	12-6_CAPTEURS
BJ90PL4STS	SENSOR GROUP
BJ90PL4STS - FR	12-6_CAPTEURS
BJ90PX4SDA	SENSOR GROUP
BJ90PX4SDA - FR	12-6_CAPTEURS
BJ90PX4SRC	SENSOR GROUP
BJ90PX4SRC - FR	12-6_CAPTEURS
BJ90PX4STS	SENSOR GROUP
BJ90PX4STS - FR	12-6_CAPTEURS
E40PL4EES 1999	ELECTRICAL SYSTEM
E40PL4SIR 4-Stroke, Elec Start, TNT, 20 IN. shaft 2001	ELECTRICAL SYSTEM
E40PL4SSC 4-Stroke, Elec Start, TNT, 20 IN. shaft 2000	ELECTRICAL SYSTEM
E50PL4EES 1999	ELECTRICAL SYSTEM
E50PL4SIR 4-Stroke, Elec Start, TNT, 20 IN. shaft 2001	ELECTRICAL SYSTEM
E50PL4SSC 4-Stroke, Elec Start, TNT, 20 IN. shaft 2000	ELECTRICAL SYSTEM
E70 PL4SSR 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2000	ELECTRICAL SYSTEM
E70FLTLECS 1998	ELECTRICAL SYSTEM
E70PL4EEC 1999	ELECTRICAL SYSTEM
E70PL4SIA 4-Stroke, Elec. Start, TNT, Blue, 20 IN. shaft 2001	ELECTRICAL SYSTEM
J115PL4SDA	SENSOR GROUP
J115PL4SDA - FR	12-6_CAPTEURS
J115PL4SOR, BJ115PL4SOR	SENSOR GROUP
J115PL4SOR, BJ115PL4SOR - FR	12-6_CAPTEURS
J115PL4SRC	SENSOR GROUP
J115PL4SRC - FR	12-6_CAPTEURS
J115PL4STS	SENSOR GROUP
J115PL4STS - FR	12-6_CAPTEURS
J115PX4SDA	SENSOR GROUP
J115PX4SDA - FR	12-6_CAPTEURS
J115PX4SOR, BJ115PX4SOR	SENSOR GROUP
J115PX4SOR, BJ115PX4SOR - FR	12-6_CAPTEURS
J115PX4SRC	SENSOR GROUP

J115PX4SRC - FR	12-6_CAPTEURS
J115PX4STS	SENSOR GROUP
J115PX4STS - FR	12-6_CAPTEURS
J140CX4SDA	SENSORS
J140CX4SDA - FR	12-6_CAPTEURS
J140CX4SOR, BJ140CX4SOC	SENSOR GROUP
J140CX4SOR, BJ140CX4SOC - FR	12-6_CAPTEURS
J140CX4SRC	SENSOR GROUP
J140CX4SRC - FR	12-6_CAPTEURS
J140CX4STS	SENSOR GROUP
J140CX4STS - FR	12-6_CAPTEURS
J140PL4SDA	SENSORS
J140PL4SDA - FR	12-6_CAPTEURS
J140PL4SOR, BJ140PL4SOC	SENSOR GROUP
J140PL4SOR, BJ140PL4SOC - FR	12-6_CAPTEURS
J140PL4SRC	SENSOR GROUP
J140PL4SRC - FR	12-6_CAPTEURS
J140PL4STS	SENSOR GROUP
J140PL4STS - FR	12-6_CAPTEURS
J140PX4SDA	SENSORS
J140PX4SDA - FR	12-6_CAPTEURS
J140PX4SOR, BJ140PX4SOC	SENSOR GROUP
J140PX4SOR, BJ140PX4SOC - FR	12-6_CAPTEURS
J140PX4SRS	SENSOR GROUP
J140PX4SRS - FR	12-6_CAPTEURS
J140PX4STS	SENSOR GROUP
J140PX4STS - FR	12-6_CAPTEURS
J200CX4SOC	SENSORS
J200CX4SOC - FR	12-6_CAPTEURS
J200CX4SRS	SENSORS
J200CX4SRS - FR	12-6_CAPTEURS
J200PX4SOC	SENSORS
J200PX4SOC - FR	12-6_CAPTEURS
J200PX4SRS	SENSORS
J200PX4SRS - FR	12-6_CAPTEURS

J225CX4SOC	SENSORS
J225CX4SOC - FR	12-6_CAPTEURS
J225CX4SRS	SENSORS
J225CX4SRS - FR	12-6_CAPTEURS
J225CZ4SOS	SENSORS
J225CZ4SOS - FR	12-6_CAPTEURS
J225PX4SOC	SENSORS
J225PX4SOC - FR	12-6_CAPTEURS
J225PX4SRS	SENSORS
J225PX4SRS - FR	12-6_CAPTEURS
J225PZ4SOS	SENSORS
J225PZ4SOS - FR	12-6_CAPTEURS
J40PL4SDE	SENSOR GROUP
J40PL4SDE - FR	12-6_CAPTEURS
J40PL4SNF - FR	12-6_CAPTEURS
J40PL4SNF 4-Stroke, Remote, White, 20 in. shaft, Power Trim&Tilt 2002	SENSOR GROUP
J40PL4SOB	SENSOR GROUP
J40PL4SOB - FR	12-6_CAPTEURS
J40PL4SRM	SENSOR GROUP
J40PL4SRM - FR	12-6_CAPTEURS
J40PL4STC	SENSOR GROUP
J40PL4STC - FR	12-6_CAPTEURS
J50PL4SDE	SENSOR GROUP
J50PL4SDE - FR	12-6_CAPTEURS
J50PL4SNF - FR	12-6_CAPTEURS
J50PL4SNF 4-Stroke, Remote, White, 20 in. shaft, Power Trim&Tilt 2002	SENSOR GROUP
J50PL4SOB	SENSOR GROUP
J50PL4SOB - FR	12-6_CAPTEURS
J50PL4SRM	SENSOR GROUP
J50PL4SRM - FR	12-6_CAPTEURS
J50PL4STC	SENSOR GROUP
J50PL4STC - FR	12-6_CAPTEURS
J60PL4SDM	SENSOR GROUP
J60PL4SDM - FR	12-6_CAPTEURS
J60PL4SNF - FR	12-6_CAPTEURS

J60PL4SNF 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2002	SENSOR GROUP
J60PL4SOA	SENSOR GROUP
J60PL4SOA - FR	12-6_CAPTEURS
J60PL4SRR	SENSOR GROUP
J60PL4SRR - FR	12-6_CAPTEURS
J60PL4STC	SENSOR GROUP
J60PL4STC - FR	12-6_CAPTEURS
J70FLTLECS 1998	ELECTRICAL SYSTEM
J70PL4SDM	SENSOR GROUP
J70PL4SDM - FR	12-6_CAPTEURS
J70PL4SNF - FR	12-6_CAPTEURS
J70PL4SNF 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2002	SENSOR GROUP
J70PL4SOA	SENSOR GROUP
J70PL4SOA - FR	12-6_CAPTEURS
J70PL4SRR	SENSOR GROUP
J70PL4SRR - FR	12-6_CAPTEURS
J70PL4STC	SENSOR GROUP
J70PL4STC - FR	12-6_CAPTEURS
J90PL4SDA	SENSOR GROUP
J90PL4SDA - FR	12-6_CAPTEURS
J90PL4SOR, BJ90PL4SOR	SENSOR GROUP
J90PL4SOR, BJ90PL4SOR - FR	12-6_CAPTEURS
J90PL4SRC	SENSOR GROUP
J90PL4SRC - FR	12-6_CAPTEURS
J90PL4STS	SENSOR GROUP
J90PL4STS - FR	12-6_CAPTEURS
J90PX4SDA	SENSOR GROUP
J90PX4SDA - FR	12-6_CAPTEURS
J90PX4SOR, BJ90PX4SOR	SENSOR GROUP
J90PX4SOR, BJ90PX4SOR - FR	12-6_CAPTEURS
J90PX4SRC	SENSOR GROUP
J90PX4SRC - FR	12-6_CAPTEURS
J90PX4STS	SENSOR GROUP
J90PX4STS - FR	12-6_CAPTEURS