

Where Used: Part Number 5030927

Model Name	Diagram
BJ60PL4SDM	LOWER ENGINE COVER
BJ60PL4SDM - FR	11-3_CAPOT MOTEUR INFÉRIEUR
BJ60PL4SOA	LOWER ENGINE COVER
BJ60PL4SOA - FR	11-3_CAPOT MOTEUR INFÉRIEUR
BJ60PL4SRR	LOWER ENGINE COVER
BJ60PL4SRR - FR	11-3_CAPOT MOTEUR INFÉRIEUR
BJ60PL4STC	LOWER ENGINE COVER
BJ60PL4STC - FR	11-3_CAPOT MOTEUR INFÉRIEUR
BJ70PL4SDM	LOWER ENGINE COVER
BJ70PL4SDM - FR	11-3_CAPOT MOTEUR INFÉRIEUR
BJ70PL4SOA	LOWER ENGINE COVER
BJ70PL4SOA - FR	11-3_CAPOT MOTEUR INFÉRIEUR
BJ70PL4SRR	LOWER ENGINE COVER
BJ70PL4SRR - FR	11-3_CAPOT MOTEUR INFÉRIEUR
BJ70PL4STC	LOWER ENGINE COVER
BJ70PL4STC - FR	11-3_CAPOT MOTEUR INFÉRIEUR
E70 PL4SSR 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2000	LOWER ENGINE COVER
E70FLTLECS 1998	LOWER ENGINE COVER
E70PL4EEC 1999	LOWER ENGINE COVER
E70PL4SIA 4-Stroke, Elec. Start, TNT, Blue, 20 IN. shaft 2001	LOWER ENGINE COVER
J60PL4SDM	LOWER ENGINE COVER
J60PL4SDM - FR	11-3_CAPOT MOTEUR INFÉRIEUR
J60PL4SNF - FR	11-3_CAPOT MOTEUR INFÉRIEUR
J60PL4SNF 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2002	LOWER ENGINE COVER
J60PL4SOA	LOWER ENGINE COVER
J60PL4SOA - FR	11-3_CAPOT MOTEUR INFÉRIEUR
J60PL4SRR	LOWER ENGINE COVER
J60PL4SRR - FR	11-3_CAPOT MOTEUR INFÉRIEUR
J60PL4STC	LOWER ENGINE COVER
J60PL4STC - FR	11-3_CAPOT MOTEUR INFÉRIEUR
J70FLTLECS 1998	LOWER ENGINE COVER
J70PL4SDM	LOWER ENGINE COVER
J70PL4SDM - FR	11-3_CAPOT MOTEUR INFÉRIEUR

J70PL4SNF - FR	11-3_CAPOT MOTEUR INFÉRIEUR
J70PL4SNF 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2002	LOWER ENGINE COVER
J70PL4SOA	LOWER ENGINE COVER
J70PL4SOA - FR	11-3_CAPOT MOTEUR INFÉRIEUR
J70PL4SRR	LOWER ENGINE COVER
J70PL4SRR - FR	11-3_CAPOT MOTEUR INFÉRIEUR
J70PL4STC	LOWER ENGINE COVER
J70PL4STC - FR	11-3_CAPOT MOTEUR INFÉRIEUR