

Where Used: Part Number 5031216

| Model Name       | Diagram                                  |
|------------------|--|
| BJ115L4SRC       | GEARS                                    |
| BJ115L4SRC - FR  | 17-3_ENGRENAGES                          |
| BJ115L4STS       | GEARS                                    |
| BJ115L4STS - FR  | 17-3_ENGRENAGES                          |
| BJ115PL4SDA      | GEARS                                    |
| BJ115PL4SDA - FR | 17-3_ENGRENAGES                          |
| BJ115PX4SDA      | GEARS                                    |
| BJ115PX4SDA - FR | 17-3_ENGRENAGES                          |
| BJ115X4SRC       | GEARS                                    |
| BJ115X4SRC - FR  | 17-3_ENGRENAGES                          |
| BJ115X4STS       | GEARS                                    |
| BJ115X4STS - FR  | 17-3_ENGRENAGES                          |
| BJ140CX4DR       | GEARS, COUNTER ROTATION                  |
| BJ140CX4DR - FR  | 17-3_ENGRENAGES, Modèles contre rotation |
| BJ140CX4SRS      | GEARS, COUNTER ROTATION                  |
| BJ140CX4SRS - FR | 17-3_ENGRENAGES, Modèles contre rotation |
| BJ140L4SDR       | GEARS, STANDARD                          |
| BJ140L4SDR - FR  | 17-3_ENGRENAGES                          |
| BJ140PL4SRS      | GEARS, STANDARD                          |
| BJ140PL4SRS - FR | 17-3_ENGRENAGES                          |
| BJ140PX4SRS      | GEARS, STANDARD                          |
| BJ140PX4SRS - FR | 17-3_ENGRENAGES                          |
| BJ140X4SDR       | GEARS, STANDARD                          |
| BJ140X4SDR - FR  | 17-3_ENGRENAGES                          |
| BJ40PL4SDR       | GEARS                                    |
| BJ40PL4SDR - FR  | 17-3_ENGRENAGES                          |
| BJ40PL4SOC       | TRANSMISSION                             |
| BJ40PL4SOC - FR  | 17-3_ENGRENAGES                          |
| BJ40PL4SRS       | TRANSMISSION                             |
| BJ40PL4SRS - FR  | 17-3_ENGRENAGES                          |
| BJ50PL4SDR       | GEARS                                    |
| BJ50PL4SDR - FR  | 17-3_ENGRENAGES                          |
| BJ50PL4SOC       | TRANSMISSION                             |

|  |                              |
|--|------------------------------|
| BJ50PL4SOC - FR  | 17-3_ENGRENAGES              |
| BJ50PL4SRS   | TRANSMISSION                 |
| BJ50PL4SRS - FR  | 17-3_ENGRENAGES              |
| BJ60PL4SDM   | DRIVESHAFT & PROPELLER SHAFT |
| BJ60PL4SDM - FR  | 17-3_ENGRENAGES              |
| BJ60PL4SOA   | DRIVESHAFT & PROPELLER SHAFT |
| BJ60PL4SOA - FR  | 17-3_ENGRENAGES              |
| BJ60PL4SRR   | DRIVESHAFT & PROPELLER SHAFT |
| BJ60PL4SRR - FR  | 17-3_ENGRENAGES              |
| BJ60PL4STC   | DRIVESHAFT & PROPELLER SHAFT |
| BJ60PL4STC - FR  | 17-3_ENGRENAGES              |
| BJ70PL4SDM   | DRIVESHAFT & PROPELLER SHAFT |
| BJ70PL4SDM - FR  | 17-3_ENGRENAGES              |
| BJ70PL4SOA   | DRIVESHAFT & PROPELLER SHAFT |
| BJ70PL4SOA - FR  | 17-3_ENGRENAGES              |
| BJ70PL4SRR   | DRIVESHAFT & PROPELLER SHAFT |
| BJ70PL4SRR - FR  | 17-3_ENGRENAGES              |
| BJ70PL4STC   | DRIVESHAFT & PROPELLER SHAFT |
| BJ70PL4STC - FR  | 17-3_ENGRENAGES              |
| BJ90PL4SDA   | GEARS                        |
| BJ90PL4SDA - FR  | 17-3_ENGRENAGES              |
| BJ90PL4SRC   | GEARS                        |
| BJ90PL4SRC - FR  | 17-3_ENGRENAGES              |
| BJ90PL4STS   | GEARS                        |
| BJ90PL4STS - FR  | 17-3_ENGRENAGES              |
| BJ90PX4SDA   | GEARS                        |
| BJ90PX4SDA - FR  | 17-3_ENGRENAGES              |
| BJ90PX4SRC   | GEARS                        |
| BJ90PX4SRC - FR  | 17-3_ENGRENAGES              |
| BJ90PX4STS   | GEARS                        |
| BJ90PX4STS - FR  | 17-3_ENGRENAGES              |
| E40PL4EES 1999   | DRIVESHAFT & PROPELLER SHAFT |
| E40PL4SIR 4-Stroke, Elec Start, TNT, 20 IN. shaft 2001 | DRIVESHAFT & PROPELLER SHAFT |
| E40PL4SSC 4-Stroke, Elec Start, TNT, 20 IN. shaft 2000 | DRIVESHAFT & PROPELLER SHAFT |
| E50PL4EES 1999   | DRIVESHAFT & PROPELLER SHAFT |

|  |                                    |
|--|------------------------------------|
| E50PL4SIR 4-Stroke, Elec Start, TNT, 20 IN. shaft 2001             | DRIVESHAFT & PROPELLER SHAFT       |
| E50PL4SSC 4-Stroke, Elec Start, TNT, 20 IN. shaft 2000             | DRIVESHAFT & PROPELLER SHAFT       |
| E70PL4SIA 4-Stroke, Elec. Start, TNT, Blue, 20 IN. shaft 2001      | DRIVESHAFT & PROPELLER SHAFT       |
| J10BL4SUM  | GEARCASE                           |
| J10BL4SUM - FR - Modeles 4 temps                                   | 17-1_BOÎTIER D'ENGRENAGES          |
| J10EL4SDA  | GEARCASE                           |
| J10EL4SDA - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J10EL4SOR  | GEARCASE                           |
| J10EL4SOR - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J10EL4SRC  | GEARCASE                           |
| J10EL4SRC - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J10EL4SUM  | GEARCASE                           |
| J10EL4SUM - FR - Modeles 4 temps                                   | 17-1_BOÎTIER D'ENGRENAGES          |
| J10R4SDM   | GEARCASE                           |
| J10R4SDM - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J10R4SNF - FR  | 16-0_CARTER D'ARBRE D'ENTRAÎNEMENT |
| J10R4SNF - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J10R4SNF 4-Stroke, Tiller, Rope, Carburetor, White, 15" Shaft 2002 | DRIVESHAFT HOUSING                 |
| J10R4SNF 4-Stroke, Tiller, Rope, Carburetor, White, 15" Shaft 2002 | GEARCASE                           |
| J10R4SOA   | GEARCASE                           |
| J10R4SOA - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J10R4SR (R and F)  | GEARCASE                           |
| J10R4SR (R et F) - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J10R4STC   | DRIVESHAFT HOUSING                 |
| J10R4STC   | GEARCASE                           |
| J10R4STC - FR  | 16-0_CARTER D'ARBRE D'ENTRAÎNEMENT |
| J10R4STC - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J10R4SUB   | GEARCASE                           |
| J10R4SUB - FR - Modeles 4 temps                                    | 17-1_BOÎTIER D'ENGRENAGES          |
| J10RBL4STS   | DRIVESHAFT HOUSING                 |
| J10RBL4STS   | GEARCASE                           |
| J10RBL4STS - FR  | 16-0_CARTER D'ARBRE D'ENTRAÎNEMENT |
| J10RBL4STS - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J10REL4STS   | DRIVESHAFT HOUSING                 |
| J10REL4STS   | GEARCASE                           |

|  |                                    |
|--|------------------------------------|
| J10REL4STS - FR  | 16-0_CARTER D'ARBRE D'ENTRAÎNEMENT |
| J10REL4STS - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J10RL4SDM  | GEARCASE                           |
| J10RL4SDM - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J10RL4SNF - FR   | 16-0_CARTER D'ARBRE D'ENTRAÎNEMENT |
| J10RL4SNF - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J10RL4SNF 4-Stroke, Tiller, Rope, Carburetor, White, 20" Shaft 2002  | DRIVESHAFT HOUSING                 |
| J10RL4SNF 4-Stroke, Tiller, Rope, Carburetor, White, 20" Shaft 2002  | GEARCASE                           |
| J10RL4SOA  | GEARCASE                           |
| J10RL4SOA - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J10RL4SR (R and F)   | GEARCASE                           |
| J10RL4SR (R et F) - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J10RL4STC  | DRIVESHAFT HOUSING                 |
| J10RL4STC  | GEARCASE                           |
| J10RL4STC - FR   | 16-0_CARTER D'ARBRE D'ENTRAÎNEMENT |
| J10RL4STC - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J10RL4SUB  | GEARCASE                           |
| J10RL4SUB - FR - Modeles 4 temps                                     | 17-1_BOÎTIER D'ENGRENAGES          |
| J10TBL4SDE   | GEARCASE                           |
| J10TBL4SDE - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J10TBL4SOB   | GEARCASE                           |
| J10TBL4SOB - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J10TBL4SR (M and F)  | GEARCASE                           |
| J10TBL4SR (M et F) - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J10TBL4STC   | DRIVESHAFT HOUSING                 |
| J10TBL4STC   | GEARCASE                           |
| J10TBL4STC - FR  | 16-0_CARTER D'ARBRE D'ENTRAÎNEMENT |
| J10TBL4STC - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J10TBL4SUD   | GEARCASE                           |
| J10TBL4SUD - FR - Modeles 4 temps                                    | 17-1_BOÎTIER D'ENGRENAGES          |
| J10TE4SDM  | GEARCASE                           |
| J10TE4SDM - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J10TE4SNF - FR   | 16-0_CARTER D'ARBRE D'ENTRAÎNEMENT |
| J10TE4SNF - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J10TE4SNF 4-Stroke, Tiller electric, Carburetor, White, 15 in., 2002 | DRIVESHAFT HOUSING                 |

|   |                                    |
|---|------------------------------------|
| J10TE4SNF 4-Stroke, Tiller electric, Carburetor, White, 15 in., 2002  | GEARCASE                           |
| J10TE4SOA   | GEARCASE                           |
| J10TE4SOA - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J10TE4SR (R and F)  | GEARCASE                           |
| J10TE4SR (R et F) - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J10TE4STC   | DRIVESHAFT HOUSING                 |
| J10TE4STC   | GEARCASE                           |
| J10TE4STC - FR  | 16-0_CARTER D'ARBRE D'ENTRAÎNEMENT |
| J10TE4STC - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J10TE4SUB   | GEARCASE                           |
| J10TE4SUB - FR - Modeles 4 temps                                      | 17-1_BOÎTIER D'ENGRENAGES          |
| J10TEL4SDM  | GEARCASE                           |
| J10TEL4SDM - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J10TEL4SNF - FR   | 16-0_CARTER D'ARBRE D'ENTRAÎNEMENT |
| J10TEL4SNF - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J10TEL4SNF 4-Stroke, Tiller electric, Carburetor, White, 20 in., 2002 | DRIVESHAFT HOUSING                 |
| J10TEL4SNF 4-Stroke, Tiller electric, Carburetor, White, 20 in., 2002 | GEARCASE                           |
| J10TEL4SOA  | GEARCASE                           |
| J10TEL4SOA - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J10TEL4SR (R and F)   | GEARCASE                           |
| J10TEL4SR (R et F) - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J10TEL4STC  | DRIVESHAFT HOUSING                 |
| J10TEL4STC  | GEARCASE                           |
| J10TEL4STC - FR   | 16-0_CARTER D'ARBRE D'ENTRAÎNEMENT |
| J10TEL4STC - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J10TEL4SUB  | GEARCASE                           |
| J10TEL4SUB - FR - Modeles 4 temps                                     | 17-1_BOÎTIER D'ENGRENAGES          |
| J115PL4SDA  | GEARS                              |
| J115PL4SDA - FR   | 17-3_ENGRENAGES                    |
| J115PL4SOR, BJ115PL4SOR   | GEARS                              |
| J115PL4SOR, BJ115PL4SOR - FR  | 17-3_ENGRENAGES                    |
| J115PL4SRC  | GEARS                              |
| J115PL4SRC - FR   | 17-3_ENGRENAGES                    |
| J115PL4STS  | GEARS                              |
| J115PL4STS - FR   | 17-3_ENGRENAGES                    |

|                              |  |
|------------------------------|--|
| J115PX4SDA                   | GEARS                                    |
| J115PX4SDA - FR              | 17-3_ENGRENAGES                          |
| J115PX4SOR, BJ115PX4SOR      | GEARS                                    |
| J115PX4SOR, BJ115PX4SOR - FR | 17-3_ENGRENAGES                          |
| J115PX4SRC                   | GEARS                                    |
| J115PX4SRC - FR              | 17-3_ENGRENAGES                          |
| J115PX4STS                   | GEARS                                    |
| J115PX4STS - FR              | 17-3_ENGRENAGES                          |
| J140CX4SDA                   | GEARS, COUNTER ROTATION                  |
| J140CX4SDA - FR              | 17-3_ENGRENAGES, Modèles contre rotation |
| J140CX4SOR, BJ140CX4SOC      | GEARS, COUNTER ROTATION                  |
| J140CX4SOR, BJ140CX4SOC - FR | 17-3_ENGRENAGES, Modèles contre rotation |
| J140CX4SRC                   | GEARS, COUNTER ROTATION                  |
| J140CX4SRC - FR              | 17-3_ENGRENAGES, Modèles contre rotation |
| J140CX4STS                   | GEARS, COUNTER ROTATION                  |
| J140CX4STS - FR              | 17-3_ENGRENAGES, Modèles contre rotation |
| J140PL4SDA                   | GEARS, STANDARD                          |
| J140PL4SDA - FR              | 17-3_ENGRENAGES                          |
| J140PL4SOR, BJ140PL4SOC      | GEARS, STANDARD                          |
| J140PL4SOR, BJ140PL4SOC - FR | 17-3_ENGRENAGES                          |
| J140PL4SRC                   | GEARS, STANDARD                          |
| J140PL4SRC - FR              | 17-3_ENGRENAGES                          |
| J140PL4STS                   | GEARS, STANDARD                          |
| J140PL4STS - FR              | 17-3_ENGRENAGES                          |
| J140PX4SDA                   | GEARS, STANDARD                          |
| J140PX4SDA - FR              | 17-3_ENGRENAGES                          |
| J140PX4SOR, BJ140PX4SOC      | GEARS, STANDARD                          |
| J140PX4SOR, BJ140PX4SOC - FR | 17-3_ENGRENAGES                          |
| J140PX4SRS                   | GEARS, STANDARD                          |
| J140PX4SRS - FR              | 17-3_ENGRENAGES                          |
| J140PX4STS                   | GEARS, STANDARD                          |
| J140PX4STS - FR              | 17-3_ENGRENAGES                          |
| J15EL4SDC                    | GEARCASE                                 |
| J15EL4SDC - FR               | 17-1_BOÎTIER D'ENGRENAGES                |
| J15EL4SOS                    | GEARCASE                                 |

|   |                                    |
|---|------------------------------------|
| J15EL4SOS - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J15EL4SUR   | GEARCASE                           |
| J15EL4SUR - FR - Modeles 4 temps                                    | 17-1_BOÎTIER D'ENGRENAGES          |
| J15R4SDM  | GEARCASE                           |
| J15R4SDM - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J15R4SNF - FR   | 16-0_CARTER D'ARBRE D'ENTRAÎNEMENT |
| J15R4SNF - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J15R4SNF 4-Stroke, Tiller, Rope, Carburetor, White, 15" Shaft 2002  | DRIVESHAFT HOUSING                 |
| J15R4SNF 4-Stroke, Tiller, Rope, Carburetor, White, 15" Shaft 2002  | GEARCASE                           |
| J15R4SOA  | GEARCASE                           |
| J15R4SOA - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J15R4SR (R and F)   | GEARCASE                           |
| J15R4SR (R et F) - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J15R4STC  | DRIVESHAFT HOUSING                 |
| J15R4STC  | GEARCASE                           |
| J15R4SUB  | GEARCASE                           |
| J15R4SUB - FR - Modeles 4 temps                                     | 17-1_BOÎTIER D'ENGRENAGES          |
| J15RL4SDM   | GEARCASE                           |
| J15RL4SDM - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J15RL4SNF - FR  | 16-0_CARTER D'ARBRE D'ENTRAÎNEMENT |
| J15RL4SNF - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J15RL4SNF 4-Stroke, Tiller, Rope, Carburetor, White, 20" Shaft 2002 | DRIVESHAFT HOUSING                 |
| J15RL4SNF 4-Stroke, Tiller, Rope, Carburetor, White, 20" Shaft 2002 | GEARCASE                           |
| J15RL4SOA   | GEARCASE                           |
| J15RL4SOA - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J15RL4SR (R and F)  | GEARCASE                           |
| J15RL4SR (R et F) - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J15RL4STC   | DRIVESHAFT HOUSING                 |
| J15RL4STC   | GEARCASE                           |
| J15RL4SUB   | GEARCASE                           |
| J15RL4SUB - FR - Modeles 4 temps                                    | 17-1_BOÎTIER D'ENGRENAGES          |
| J15TE4SDM   | GEARCASE                           |
| J15TE4SDM - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J15TE4SNF - FR  | 16-0_CARTER D'ARBRE D'ENTRAÎNEMENT |
| J15TE4SNF - FR  | 17-1_BOÎTIER D'ENGRENAGES          |

|   |                                    |
|---|------------------------------------|
| J15TE4SNF 4-Stroke, Tiller electric, Carburetor, White, 15 in., 2002  | DRIVESHAFT HOUSING                 |
| J15TE4SNF 4-Stroke, Tiller electric, Carburetor, White, 15 in., 2002  | GEARCASE                           |
| J15TE4SOA   | GEARCASE                           |
| J15TE4SOA - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J15TE4SR (R and F)  | GEARCASE                           |
| J15TE4SR (R et F) - FR  | 17-1_BOÎTIER D'ENGRENAGES          |
| J15TE4STC   | DRIVESHAFT HOUSING                 |
| J15TE4STC   | GEARCASE                           |
| J15TE4SUB   | GEARCASE                           |
| J15TE4SUB - FR - Modeles 4 temps                                      | 17-1_BOÎTIER D'ENGRENAGES          |
| J15TEL4SDM  | GEARCASE                           |
| J15TEL4SDM - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J15TEL4SNF - FR   | 16-0_CARTER D'ARBRE D'ENTRAÎNEMENT |
| J15TEL4SNF - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J15TEL4SNF 4-Stroke, Tiller electric, Carburetor, White, 20 in., 2002 | DRIVESHAFT HOUSING                 |
| J15TEL4SNF 4-Stroke, Tiller electric, Carburetor, White, 20 in., 2002 | GEARCASE                           |
| J15TEL4SOA  | GEARCASE                           |
| J15TEL4SOA - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J15TEL4SR (R and F)   | GEARCASE                           |
| J15TEL4SR (R et F) - FR   | 17-1_BOÎTIER D'ENGRENAGES          |
| J15TEL4STC  | DRIVESHAFT HOUSING                 |
| J15TEL4STC  | GEARCASE                           |
| J15TEL4SUB  | GEARCASE                           |
| J15TEL4SUB - FR - Modeles 4 temps                                     | 17-1_BOÎTIER D'ENGRENAGES          |
| J40PL4SDE   | GEARS                              |
| J40PL4SDE - FR  | 17-3_ENGRENAGES                    |
| J40PL4SNF - FR  | 17-3_ENGRENAGES                    |
| J40PL4SNF 4-Stroke, Remote, White, 20 in. shaft, Power Trim&Tilt 2002 | TRANSMISSION                       |
| J40PL4SOB   | TRANSMISSION                       |
| J40PL4SOB - FR  | 17-3_ENGRENAGES                    |
| J40PL4SRM   | TRANSMISSION                       |
| J40PL4SRM - FR  | 17-3_ENGRENAGES                    |
| J40PL4STC   | TRANSMISSION                       |
| J40PL4STC - FR  | 17-3_ENGRENAGES                    |
| J50PL4SDE   | GEARS                              |

|   |                              |
|---|------------------------------|
| J50PL4SDE - FR  | 17-3_ENGRENAGES              |
| J50PL4SNF - FR  | 17-3_ENGRENAGES              |
| J50PL4SNF 4-Stroke, Remote, White, 20 in. shaft, Power Trim&Tilt 2002 | TRANSMISSION                 |
| J50PL4SOB   | TRANSMISSION                 |
| J50PL4SOB - FR  | 17-3_ENGRENAGES              |
| J50PL4SRM   | TRANSMISSION                 |
| J50PL4SRM - FR  | 17-3_ENGRENAGES              |
| J50PL4STC   | TRANSMISSION                 |
| J50PL4STC - FR  | 17-3_ENGRENAGES              |
| J60PL4SDM   | DRIVESHAFT & PROPELLER SHAFT |
| J60PL4SDM - FR  | 17-3_ENGRENAGES              |
| J60PL4SNF - FR  | 17-3_ENGRENAGES              |
| J60PL4SNF 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2002               | DRIVESHAFT & PROPELLER SHAFT |
| J60PL4SOA   | DRIVESHAFT & PROPELLER SHAFT |
| J60PL4SOA - FR  | 17-3_ENGRENAGES              |
| J60PL4SRR   | DRIVESHAFT & PROPELLER SHAFT |
| J60PL4SRR - FR  | 17-3_ENGRENAGES              |
| J60PL4STC   | DRIVESHAFT & PROPELLER SHAFT |
| J60PL4STC - FR  | 17-3_ENGRENAGES              |
| J70PL4SDM   | DRIVESHAFT & PROPELLER SHAFT |
| J70PL4SDM - FR  | 17-3_ENGRENAGES              |
| J70PL4SNF - FR  | 17-3_ENGRENAGES              |
| J70PL4SNF 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2002               | DRIVESHAFT & PROPELLER SHAFT |
| J70PL4SOA   | DRIVESHAFT & PROPELLER SHAFT |
| J70PL4SOA - FR  | 17-3_ENGRENAGES              |
| J70PL4SRR   | DRIVESHAFT & PROPELLER SHAFT |
| J70PL4SRR - FR  | 17-3_ENGRENAGES              |
| J70PL4STC   | DRIVESHAFT & PROPELLER SHAFT |
| J70PL4STC - FR  | 17-3_ENGRENAGES              |
| J90PL4SDA   | GEARS                        |
| J90PL4SDA - FR  | 17-3_ENGRENAGES              |
| J90PL4SOR, BJ90PL4SOR   | GEARS                        |
| J90PL4SOR, BJ90PL4SOR - FR  | 17-3_ENGRENAGES              |
| J90PL4SRC   | GEARS                        |
| J90PL4SRC - FR  | 17-3_ENGRENAGES              |

|                            |                 |
|----------------------------|-----------------|
| J90PL4STS                  | GEARS           |
| J90PL4STS - FR             | 17-3_ENGRENAGES |
| J90PX4SDA                  | GEARS           |
| J90PX4SDA - FR             | 17-3_ENGRENAGES |
| J90PX4SOR, BJ90PX4SOR      | GEARS           |
| J90PX4SOR, BJ90PX4SOR - FR | 17-3_ENGRENAGES |
| J90PX4SRC                  | GEARS           |
| J90PX4SRC - FR             | 17-3_ENGRENAGES |
| J90PX4STS                  | GEARS           |
| J90PX4STS - FR             | 17-3_ENGRENAGES |