

Where Used: Part Number 5031538

Model Name	Diagram
BJ40PL4SDR	GEARCASE
BJ40PL4SDR - FR	17-1_BOÎTIER D'ENGRENAGES
BJ40PL4SOC	GEARCASE
BJ40PL4SOC - FR	17-1_BOÎTIER D'ENGRENAGES
BJ50PL4SDR	GEARCASE
BJ50PL4SDR - FR	17-1_BOÎTIER D'ENGRENAGES
BJ50PL4SOC	GEARCASE
BJ50PL4SOC - FR	17-1_BOÎTIER D'ENGRENAGES
E25EL4SIC 4-Stroke, Elec. Start, 20 IN. shaft 2001	GEARCASE
E25EL4SSS 4-Stroke, Elec. Start, 20 IN. shaft 2000	GEARCASE
E25PL4SIC 4-Stroke, Elec. Start, TNT, 15 IN. shaft 2001	GEARCASE
E25PL4SSS 4-Stroke, Elec. Start, TNT, 15 IN. shaft 2000	GEARCASE
E25R4SIC 4-Stroke, Rope Start, Tiller, 15 IN. shaft 2001	GEARCASE
E25R4SSS 4-Stroke, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
E25RL4SIC 4-Stroke, Rope Start, Tiller, 20 IN. shaft 2001	GEARCASE
E25RL4SSS 4-Stroke, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
E25TE4SIC 4-Stroke, Elec. Start, Tiller, 15 IN. shaft 2001	GEARCASE
E25TE4SSS 4-Stroke, Elec. Start, Tiller, 15 IN. shaft 2000	GEARCASE
E25TEL4SIC 4-Stroke, Elec. Start, Tiller, 20 IN. shaft 2001	GEARCASE
E25TEL4SSS 4-Stroke, Elec. Start, Tiller, 20 IN. shaft 2000	GEARCASE
E30EL4SIC 4-Stroke, Elec. Start, 20 IN. shaft 2001	GEARCASE
E30EL4SSS 4-Stroke, Elec. Start, 20 IN. shaft 2000	GEARCASE
E30PL4SIC 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2001	GEARCASE
E30PL4SSS 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
E30R4SIC 4-Stroke, Rope Start, Tiller, 15 IN. shaft 2001	GEARCASE
E30R4SSS 4-Stroke, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
E30RL4SIC 4-Stroke, Rope Start, Tiller, 20 IN. shaft 2001	GEARCASE
E30RL4SSS 4-Stroke, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
E30TE4SIC 4-Stroke, Elec. Start, Tiller, 15 IN. shaft 2001	GEARCASE
E30TE4SSS 4-Stroke, Elec. Start, Tiller, 15 IN. shaft 2000	GEARCASE
E30TEL4SIC 4-Stroke, Elec. Start, Tiller, 20 IN. shaft 2001	GEARCASE
E30TEL4SSS 4-Stroke, Elec. Start, Tiller, 20 IN. shaft 2000	GEARCASE
E40PL4EES 1999	GEARCASE

E40PL4SIR 4-Stroke, Elec Start, TNT, 20 IN. shaft 2001	GEARCASE
E40PL4SSC 4-Stroke, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
E50PL4EES 1999	GEARCASE
E50PL4SIR 4-Stroke, Elec Start, TNT, 20 IN. shaft 2001	GEARCASE
E50PL4SSC 4-Stroke, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
J10BL4SUM	GEARCASE
J10BL4SUM - FR - Modeles 4 temps	17-1_BOÎTIER D'ENGRENAGES
J10EL4SDA	GEARCASE
J10EL4SDA - FR	17-1_BOÎTIER D'ENGRENAGES
J10EL4SOR	GEARCASE
J10EL4SOR - FR	17-1_BOÎTIER D'ENGRENAGES
J10EL4SRC	GEARCASE
J10EL4SRC - FR	17-1_BOÎTIER D'ENGRENAGES
J10EL4SUM	GEARCASE
J10EL4SUM - FR - Modeles 4 temps	17-1_BOÎTIER D'ENGRENAGES
J10R4SDM	GEARCASE
J10R4SDM - FR	17-1_BOÎTIER D'ENGRENAGES
J10R4SNF - FR	17-1_BOÎTIER D'ENGRENAGES
J10R4SNF 4-Stroke, Tiller, Rope, Carburetor, White, 15" Shaft 2002	GEARCASE
J10R4SOA	GEARCASE
J10R4SOA - FR	17-1_BOÎTIER D'ENGRENAGES
J10R4SR (R and F)	GEARCASE
J10R4SR (R et F) - FR	17-1_BOÎTIER D'ENGRENAGES
J10R4STC	GEARCASE
J10R4STC - FR	17-1_BOÎTIER D'ENGRENAGES
J10R4SUB	GEARCASE
J10R4SUB - FR - Modeles 4 temps	17-1_BOÎTIER D'ENGRENAGES
J10RBL4STS	GEARCASE
J10RBL4STS - FR	17-1_BOÎTIER D'ENGRENAGES
J10REL4STS	GEARCASE
J10REL4STS - FR	17-1_BOÎTIER D'ENGRENAGES
J10RL4SDM	GEARCASE
J10RL4SDM - FR	17-1_BOÎTIER D'ENGRENAGES
J10RL4SNF - FR	17-1_BOÎTIER D'ENGRENAGES
J10RL4SNF 4-Stroke, Tiller, Rope, Carburetor, White, 20" Shaft 2002	GEARCASE

J10RL4SOA	GEARCASE
J10RL4SOA - FR	17-1_BOÎTIER D'ENGRENAGES
J10RL4SR (R and F)	GEARCASE
J10RL4SR (R et F) - FR	17-1_BOÎTIER D'ENGRENAGES
J10RL4STC	GEARCASE
J10RL4STC - FR	17-1_BOÎTIER D'ENGRENAGES
J10RL4SUB	GEARCASE
J10RL4SUB - FR - Modeles 4 temps	17-1_BOÎTIER D'ENGRENAGES
J10TBL4SDE	GEARCASE
J10TBL4SDE - FR	17-1_BOÎTIER D'ENGRENAGES
J10TBL4SOB	GEARCASE
J10TBL4SOB - FR	17-1_BOÎTIER D'ENGRENAGES
J10TBL4SR (M and F)	GEARCASE
J10TBL4SR (M et F) - FR	17-1_BOÎTIER D'ENGRENAGES
J10TBL4STC	GEARCASE
J10TBL4STC - FR	17-1_BOÎTIER D'ENGRENAGES
J10TBL4SUD	GEARCASE
J10TBL4SUD - FR - Modeles 4 temps	17-1_BOÎTIER D'ENGRENAGES
J10TE4SDM	GEARCASE
J10TE4SDM - FR	17-1_BOÎTIER D'ENGRENAGES
J10TE4SNF - FR	17-1_BOÎTIER D'ENGRENAGES
J10TE4SNF 4-Stroke, Tiller electric, Carburetor, White, 15 in., 2002	GEARCASE
J10TE4SOA	GEARCASE
J10TE4SOA - FR	17-1_BOÎTIER D'ENGRENAGES
J10TE4SR (R and F)	GEARCASE
J10TE4SR (R et F) - FR	17-1_BOÎTIER D'ENGRENAGES
J10TE4STC	GEARCASE
J10TE4STC - FR	17-1_BOÎTIER D'ENGRENAGES
J10TE4SUB	GEARCASE
J10TE4SUB - FR - Modeles 4 temps	17-1_BOÎTIER D'ENGRENAGES
J10TEL4SDM	GEARCASE
J10TEL4SDM - FR	17-1_BOÎTIER D'ENGRENAGES
J10TEL4SNF - FR	17-1_BOÎTIER D'ENGRENAGES
J10TEL4SNF 4-Stroke, Tiller electric, Carburetor, White, 20 in., 2002	GEARCASE
J10TEL4SOA	GEARCASE

J10TEL4SOA - FR	17-1_BOÎTIER D'ENGRENAGES
J10TEL4SR (R and F)	GEARCASE
J10TEL4SR (R et F) - FR	17-1_BOÎTIER D'ENGRENAGES
J10TEL4STC	GEARCASE
J10TEL4STC - FR	17-1_BOÎTIER D'ENGRENAGES
J10TEL4SUB	GEARCASE
J10TEL4SUB - FR - Modeles 4 temps	17-1_BOÎTIER D'ENGRENAGES
J15EL4SDC	GEARCASE
J15EL4SDC - FR	17-1_BOÎTIER D'ENGRENAGES
J15EL4SOS	GEARCASE
J15EL4SOS - FR	17-1_BOÎTIER D'ENGRENAGES
J15EL4SUR	GEARCASE
J15EL4SUR - FR - Modeles 4 temps	17-1_BOÎTIER D'ENGRENAGES
J15R4SDM	GEARCASE
J15R4SDM - FR	17-1_BOÎTIER D'ENGRENAGES
J15R4SNF - FR	17-1_BOÎTIER D'ENGRENAGES
J15R4SNF 4-Stroke, Tiller, Rope, Carburetor, White, 15" Shaft 2002	GEARCASE
J15R4SOA	GEARCASE
J15R4SOA - FR	17-1_BOÎTIER D'ENGRENAGES
J15R4SR (R and F)	GEARCASE
J15R4SR (R et F) - FR	17-1_BOÎTIER D'ENGRENAGES
J15R4STC	GEARCASE
J15R4SUB	GEARCASE
J15R4SUB - FR - Modeles 4 temps	17-1_BOÎTIER D'ENGRENAGES
J15RL4SDM	GEARCASE
J15RL4SDM - FR	17-1_BOÎTIER D'ENGRENAGES
J15RL4SNF - FR	17-1_BOÎTIER D'ENGRENAGES
J15RL4SNF 4-Stroke, Tiller, Rope, Carburetor, White, 20" Shaft 2002	GEARCASE
J15RL4SOA	GEARCASE
J15RL4SOA - FR	17-1_BOÎTIER D'ENGRENAGES
J15RL4SR (R and F)	GEARCASE
J15RL4SR (R et F) - FR	17-1_BOÎTIER D'ENGRENAGES
J15RL4STC	GEARCASE
J15RL4SUB	GEARCASE
J15RL4SUB - FR - Modeles 4 temps	17-1_BOÎTIER D'ENGRENAGES

J15TE4SDM	GEARCASE
J15TE4SDM - FR	17-1_BOÎTIER D'ENGRENAGES
J15TE4SNF - FR	17-1_BOÎTIER D'ENGRENAGES
J15TE4SNF 4-Stroke, Tiller electric, Carburetor, White, 15 in., 2002	GEARCASE
J15TE4SOA	GEARCASE
J15TE4SOA - FR	17-1_BOÎTIER D'ENGRENAGES
J15TE4SR (R and F)	GEARCASE
J15TE4SR (R et F) - FR	17-1_BOÎTIER D'ENGRENAGES
J15TE4STC	GEARCASE
J15TE4SUB	GEARCASE
J15TE4SUB - FR - Modeles 4 temps	17-1_BOÎTIER D'ENGRENAGES
J15TEL4SDM	GEARCASE
J15TEL4SDM - FR	17-1_BOÎTIER D'ENGRENAGES
J15TEL4SNF - FR	17-1_BOÎTIER D'ENGRENAGES
J15TEL4SNF 4-Stroke, Tiller electric, Carburetor, White, 20 in., 2002	GEARCASE
J15TEL4SOA	GEARCASE
J15TEL4SOA - FR	17-1_BOÎTIER D'ENGRENAGES
J15TEL4SR (R and F)	GEARCASE
J15TEL4SR (R et F) - FR	17-1_BOÎTIER D'ENGRENAGES
J15TEL4STC	GEARCASE
J15TEL4SUB	GEARCASE
J15TEL4SUB - FR - Modeles 4 temps	17-1_BOÎTIER D'ENGRENAGES
J25PL4SOC	GEARCASE
J25PL4SOC - FR	17-1_BOÎTIER D'ENGRENAGES
J25PL4SRS, J25TEL4SRS	GEARCASE
J25PL4SRS, J25TEL4SRS - FR	17-1_BOÎTIER D'ENGRENAGES
J25TEL4SOC	GEARCASE
J25TEL4SOC - FR	17-1_BOÎTIER D'ENGRENAGES
J30PL4SDR	GEARCASE
J30PL4SDR - FR	17-1_BOÎTIER D'ENGRENAGES
J30PL4SOC	GEARCASE
J30PL4SOC - FR	17-1_BOÎTIER D'ENGRENAGES
J30PL4SRS, J30TEL4SRS	GEARCASE
J30PL4SRS, J30TEL4SRS - FR	17-1_BOÎTIER D'ENGRENAGES
J30PL4SUA	GEARCASE

J30PL4SUA	17-1_BOÎTIER D'ENGRENAGES
J30TEL4SDR	GEARCASE
J30TEL4SDR - FR	17-1_BOÎTIER D'ENGRENAGES
J30TEL4SOC	GEARCASE
J30TEL4SOC - FR	17-1_BOÎTIER D'ENGRENAGES
J30TEL4SUA	GEARCASE
J30TEL4SUA	17-1_BOÎTIER D'ENGRENAGES
J40PL4SDE	GEARCASE
J40PL4SDE - FR	17-1_BOÎTIER D'ENGRENAGES
J40PL4SNF - FR	17-1_BOÎTIER D'ENGRENAGES
J40PL4SNF 4-Stroke, Remote, White, 20 in. shaft, Power Trim&Tilt 2002	GEARCASE
J40PL4SOB	GEARCASE
J40PL4SOB - FR	17-1_BOÎTIER D'ENGRENAGES
J40PL4STC	GEARCASE
J40PL4STC - FR	17-1_BOÎTIER D'ENGRENAGES
J50PL4SDE	GEARCASE
J50PL4SDE - FR	17-1_BOÎTIER D'ENGRENAGES
J50PL4SNF - FR	17-1_BOÎTIER D'ENGRENAGES
J50PL4SNF 4-Stroke, Remote, White, 20 in. shaft, Power Trim&Tilt 2002	GEARCASE
J50PL4SOB	GEARCASE
J50PL4SOB - FR	17-1_BOÎTIER D'ENGRENAGES
J50PL4STC	GEARCASE
J50PL4STC - FR	17-1_BOÎTIER D'ENGRENAGES