

Where Used: Part Number 5032341

Model Name	Diagram
E25EL4SIC 4-Stroke, Elec. Start, 20 IN. shaft 2001	ELECTRICAL SYSTEM
E25EL4SSS 4-Stroke, Elec. Start, 20 IN. shaft 2000	ELECTRICAL SYSTEM
E25PL4SIC 4-Stroke, Elec. Start, TNT, 15 IN. shaft 2001	ELECTRICAL SYSTEM
E25PL4SSS 4-Stroke, Elec. Start, TNT, 15 IN. shaft 2000	ELECTRICAL SYSTEM
E25R4SIC 4-Stroke, Rope Start, Tiller, 15 IN. shaft 2001	ELECTRICAL SYSTEM
E25R4SSS 4-Stroke, Rope Start, Tiller, 15 IN. shaft 2000	ELECTRICAL SYSTEM
E25RL4SIC 4-Stroke, Rope Start, Tiller, 20 IN. shaft 2001	ELECTRICAL SYSTEM
E25RL4SSS 4-Stroke, Rope Start, Tiller, 20 IN. shaft 2000	ELECTRICAL SYSTEM
E25TE4SIC 4-Stroke, Elec. Start, Tiller, 15 IN. shaft 2001	ELECTRICAL SYSTEM
E25TE4SSS 4-Stroke, Elec. Start, Tiller, 15 IN. shaft 2000	ELECTRICAL SYSTEM
E25TEL4SIC 4-Stroke, Elec. Start, Tiller, 20 IN. shaft 2001	ELECTRICAL SYSTEM
E25TEL4SSS 4-Stroke, Elec. Start, Tiller, 20 IN. shaft 2000	ELECTRICAL SYSTEM
E30EL4SIC 4-Stroke, Elec. Start, 20 IN. shaft 2001	ELECTRICAL SYSTEM
E30EL4SSS 4-Stroke, Elec. Start, 20 IN. shaft 2000	ELECTRICAL SYSTEM
E30PL4SIC 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2001	ELECTRICAL SYSTEM
E30PL4SSS 4-Stroke, Elec. Start, TNT, 20 IN. shaft 2000	ELECTRICAL SYSTEM
E30R4SIC 4-Stroke, Rope Start, Tiller, 15 IN. shaft 2001	ELECTRICAL SYSTEM
E30R4SSS 4-Stroke, Rope Start, Tiller, 15 IN. shaft 2000	ELECTRICAL SYSTEM
E30RL4SIC 4-Stroke, Rope Start, Tiller, 20 IN. shaft 2001	ELECTRICAL SYSTEM
E30RL4SSS 4-Stroke, Rope Start, Tiller, 20 IN. shaft 2000	ELECTRICAL SYSTEM
E30TE4SIC 4-Stroke, Elec. Start, Tiller, 15 IN. shaft 2001	ELECTRICAL SYSTEM
E30TE4SSS 4-Stroke, Elec. Start, Tiller, 15 IN. shaft 2000	ELECTRICAL SYSTEM
E30TEL4SIC 4-Stroke, Elec. Start, Tiller, 20 IN. shaft 2001	ELECTRICAL SYSTEM
E30TEL4SSS 4-Stroke, Elec. Start, Tiller, 20 IN. shaft 2000	ELECTRICAL SYSTEM
J10EL4SRC	STARTER MOTOR
J10EL4SRC - FR	12-1_DÉMARREUR
J10R4SNF - FR	12-1_DÉMARREUR
J10R4SNF 4-Stroke, Tiller, Rope, Carburetor, White, 15" Shaft 2002	STARTER MOTOR
J10R4SR (R and F)	STARTER MOTOR
J10R4SR (R et F) - FR	12-1_DÉMARREUR
J10R4STC	STARTER MOTOR
J10R4STC - FR	12-1_DÉMARREUR
J10RBL4STS	STARTER MOTOR

J10RBL4STS - FR	12-1_DÉMARREUR
J10REL4STS	STARTER MOTOR
J10REL4STS - FR	12-1_DÉMARREUR
J10RL4SNF - FR	12-1_DÉMARREUR
J10RL4SNF 4-Stroke, Tiller, Rope, Carburetor, White, 20" Shaft 2002	STARTER MOTOR
J10RL4SR (R and F)	STARTER MOTOR
J10RL4SR (R et F) - FR	12-1_DÉMARREUR
J10RL4STC	STARTER MOTOR
J10RL4STC - FR	12-1_DÉMARREUR
J10TBL4SR (M and F)	STARTER MOTOR
J10TBL4SR (M et F) - FR	12-1_DÉMARREUR
J10TBL4STC	STARTER MOTOR
J10TBL4STC - FR	12-1_DÉMARREUR
J10TE4SNF - FR	12-1_DÉMARREUR
J10TE4SNF 4-Stroke, Tiller electric, Carburetor, White, 15 in., 2002	STARTER MOTOR
J10TE4SR (R and F)	STARTER MOTOR
J10TE4SR (R et F) - FR	12-1_DÉMARREUR
J10TE4STC	STARTER MOTOR
J10TE4STC - FR	12-1_DÉMARREUR
J10TEL4SNF - FR	12-1_DÉMARREUR
J10TEL4SNF 4-Stroke, Tiller electric, Carburetor, White, 20 in., 2002	STARTER MOTOR
J10TEL4SR (R and F)	STARTER MOTOR
J10TEL4SR (R et F) - FR	12-1_DÉMARREUR
J10TEL4STC	STARTER MOTOR
J10TEL4STC - FR	12-1_DÉMARREUR
J15R4SNF - FR	12-1_DÉMARREUR
J15R4SNF 4-Stroke, Tiller, Rope, Carburetor, White, 15" Shaft 2002	STARTER MOTOR
J15R4SR (R and F)	STARTER MOTOR
J15R4SR (R et F) - FR	12-1_DÉMARREUR
J15R4STC	STARTER MOTOR
J15RL4SNF - FR	12-1_DÉMARREUR
J15RL4SNF 4-Stroke, Tiller, Rope, Carburetor, White, 20" Shaft 2002	STARTER MOTOR
J15RL4SR (R and F)	STARTER MOTOR
J15RL4SR (R et F) - FR	12-1_DÉMARREUR
J15RL4STC	STARTER MOTOR

J15TE4SNF - FR	12-1_DÉMARREUR
J15TE4SNF 4-Stroke, Tiller electric, Carburetor, White, 15 in., 2002	STARTER MOTOR
J15TE4SR (R and F)	STARTER MOTOR
J15TE4SR (R et F) - FR	12-1_DÉMARREUR
J15TE4STC	STARTER MOTOR
J15TEL4SNF - FR	12-1_DÉMARREUR
J15TEL4SNF 4-Stroke, Tiller electric, Carburetor, White, 20 in., 2002	STARTER MOTOR
J15TEL4SR (R and F)	STARTER MOTOR
J15TEL4SR (R et F) - FR	12-1_DÉMARREUR
J15TEL4STC	STARTER MOTOR
J25PL4SOC	ELECTRIC STARTER
J25PL4SOC - FR	12-1_DÉMARREUR
J25PL4SRS, J25TEL4SRS	ELECTRIC STARTER
J25PL4SRS, J25TEL4SRS - FR	12-1_DÉMARREUR
J25TEL4SOC	ELECTRIC STARTER
J25TEL4SOC - FR	12-1_DÉMARREUR
J30PL4SDR	ELECTRIC STARTER
J30PL4SDR - FR	12-1_DÉMARREUR
J30PL4SOC	ELECTRIC STARTER
J30PL4SOC - FR	12-1_DÉMARREUR
J30PL4SRS, J30TEL4SRS	ELECTRIC STARTER
J30PL4SRS, J30TEL4SRS - FR	12-1_DÉMARREUR
J30PL4SUA	ELECTRIC STARTER
J30PL4SUA	12-1_MOTEUR DE DÉMARREUR
J30TEL4SDR	ELECTRIC STARTER
J30TEL4SDR - FR	12-1_DÉMARREUR
J30TEL4SOC	ELECTRIC STARTER
J30TEL4SOC - FR	12-1_DÉMARREUR
J30TEL4SUA	ELECTRIC STARTER
J30TEL4SUA	12-1_MOTEUR DE DÉMARREUR