

## Where Used: Part Number 5034137

| Model Name       | Diagram         |
|------------------|-----------------|
| BJ115L4SRC       | GEARS           |
| BJ115L4SRC - FR  | 17-3_ENGRENAGES |
| BJ115L4STS       | GEARS           |
| BJ115L4STS - FR  | 17-3_ENGRENAGES |
| BJ115PL4SDA      | GEARS           |
| BJ115PL4SDA - FR | 17-3_ENGRENAGES |
| BJ115PX4SDA      | GEARS           |
| BJ115PX4SDA - FR | 17-3_ENGRENAGES |
| BJ115X4SRC       | GEARS           |
| BJ115X4SRC - FR  | 17-3_ENGRENAGES |
| BJ115X4STS       | GEARS           |
| BJ115X4STS - FR  | 17-3_ENGRENAGES |
| BJ140L4SDR       | GEARS, STANDARD |
| BJ140L4SDR - FR  | 17-3_ENGRENAGES |
| BJ140PL4SRS      | GEARS, STANDARD |
| BJ140PL4SRS - FR | 17-3_ENGRENAGES |
| BJ140PX4SRS      | GEARS, STANDARD |
| BJ140PX4SRS - FR | 17-3_ENGRENAGES |
| BJ140X4SDR       | GEARS, STANDARD |
| BJ140X4SDR - FR  | 17-3_ENGRENAGES |
| BJ90PL4SDA       | GEARS           |
| BJ90PL4SDA - FR  | 17-3_ENGRENAGES |
| BJ90PL4SRC       | GEARS           |
| BJ90PL4SRC - FR  | 17-3_ENGRENAGES |
| BJ90PL4STS       | GEARS           |
| BJ90PL4STS - FR  | 17-3_ENGRENAGES |
| BJ90PX4SDA       | GEARS           |
| BJ90PX4SDA - FR  | 17-3_ENGRENAGES |
| BJ90PX4SRC       | GEARS           |
| BJ90PX4SRC - FR  | 17-3_ENGRENAGES |
| BJ90PX4STS       | GEARS           |
| BJ90PX4STS - FR  | 17-3_ENGRENAGES |
| J115PL4SDA       | GEARS           |

|                              |                 |
|------------------------------|-----------------|
| J115PL4SDA - FR              | 17-3_ENGRENAGES |
| J115PL4SOR, BJ115PL4SOR      | GEARS           |
| J115PL4SOR, BJ115PL4SOR - FR | 17-3_ENGRENAGES |
| J115PL4SRC                   | GEARS           |
| J115PL4SRC - FR              | 17-3_ENGRENAGES |
| J115PL4STS                   | GEARS           |
| J115PL4STS - FR              | 17-3_ENGRENAGES |
| J115PX4SDA                   | GEARS           |
| J115PX4SDA - FR              | 17-3_ENGRENAGES |
| J115PX4SOR, BJ115PX4SOR      | GEARS           |
| J115PX4SOR, BJ115PX4SOR - FR | 17-3_ENGRENAGES |
| J115PX4SRC                   | GEARS           |
| J115PX4SRC - FR              | 17-3_ENGRENAGES |
| J115PX4STS                   | GEARS           |
| J115PX4STS - FR              | 17-3_ENGRENAGES |
| J140PL4SDA                   | GEARS, STANDARD |
| J140PL4SDA - FR              | 17-3_ENGRENAGES |
| J140PL4SOR, BJ140PL4SOC      | GEARS, STANDARD |
| J140PL4SOR, BJ140PL4SOC - FR | 17-3_ENGRENAGES |
| J140PL4SRC                   | GEARS, STANDARD |
| J140PL4SRC - FR              | 17-3_ENGRENAGES |
| J140PL4STS                   | GEARS, STANDARD |
| J140PL4STS - FR              | 17-3_ENGRENAGES |
| J140PX4SDA                   | GEARS, STANDARD |
| J140PX4SDA - FR              | 17-3_ENGRENAGES |
| J140PX4SOR, BJ140PX4SOC      | GEARS, STANDARD |
| J140PX4SOR, BJ140PX4SOC - FR | 17-3_ENGRENAGES |
| J140PX4SRS                   | GEARS, STANDARD |
| J140PX4SRS - FR              | 17-3_ENGRENAGES |
| J140PX4STS                   | GEARS, STANDARD |
| J140PX4STS - FR              | 17-3_ENGRENAGES |
| J90PL4SDA                    | GEARS           |
| J90PL4SDA - FR               | 17-3_ENGRENAGES |
| J90PL4SOR, BJ90PL4SOR        | GEARS           |
| J90PL4SOR, BJ90PL4SOR - FR   | 17-3_ENGRENAGES |

|                            |                 |
|----------------------------|-----------------|
| J90PL4SRC                  | GEARS           |
| J90PL4SRC - FR             | 17-3_ENGRENAGES |
| J90PL4STS                  | GEARS           |
| J90PL4STS - FR             | 17-3_ENGRENAGES |
| J90PX4SDA                  | GEARS           |
| J90PX4SDA - FR             | 17-3_ENGRENAGES |
| J90PX4SOR, BJ90PX4SOR      | GEARS           |
| J90PX4SOR, BJ90PX4SOR - FR | 17-3_ENGRENAGES |
| J90PX4SRC                  | GEARS           |
| J90PX4SRC - FR             | 17-3_ENGRENAGES |
| J90PX4STS                  | GEARS           |
| J90PX4STS - FR             | 17-3_ENGRENAGES |