

Where Used: Part Number 5041163

Model Name	Diagram
B4R4AAA	15-0_RECOIL STARTER
B4R4AAA, AAB & AAC - FR	15-0_LANCEUR MANUEL
B4R4AAB & AAC	15-0_RECOIL STARTER
B4R4INS	15-0_RECOIL STARTER
B4R4INS - FR	15-0_LANCEUR MANUEL
B4RG4ABA	15-0_RECOIL STARTER
B4RG4ABB	15-0_RECOIL STARTER
B4RGL4ABA	15-0_RECOIL STARTER
B4RGL4ABB	15-0_RECOIL STARTER
B4RL4AAA	15-0_RECOIL STARTER
B4RL4AAA, AAB & AAC - FR	15-0_LANCEUR MANUEL
B4RL4AAB & AAC	15-0_RECOIL STARTER
B4RL4INS	15-0_RECOIL STARTER
B4RL4INS - FR	15-0_LANCEUR MANUEL
B6R4AAA	15-0_RECOIL STARTER
B6R4AAA, AAB & AAC - FR	15-0_LANCEUR MANUEL
B6R4AAB & AAC	15-0_RECOIL STARTER
B6R4INS	15-0_RECOIL STARTER
B6R4INS - FR	15-0_LANCEUR MANUEL
B6RG4ABA	15-0_RECOIL STARTER
B6RG4ABB	15-0_RECOIL STARTER
B6RGL4ABA	15-0_RECOIL STARTER
B6RGL4ABB	15-0_RECOIL STARTER
B6RL4AAA	15-0_RECOIL STARTER
B6RL4AAA, AAB & AAC - FR	15-0_LANCEUR MANUEL
B6RL4AAB & AAC	15-0_RECOIL STARTER
B6RL4INS	15-0_RECOIL STARTER
B6RL4INS - FR	15-0_LANCEUR MANUEL
B6RX4AAA	15-0_RECOIL STARTER
B6RX4AAA, AAB & AAC - FR	15-0_LANCEUR MANUEL
B6RX4AAB & AAC	15-0_RECOIL STARTER
B6RX4INS	15-0_RECOIL STARTER
B6RX4INS - FR	15-0_LANCEUR MANUEL

E4R4AAA	15-0_RECOIL STARTER
E4R4AAA, AAB & AAC - FR	15-0_LANCEUR MANUEL
E4R4AAB & AAC	15-0_RECOIL STARTER
E4R4INS	15-0_RECOIL STARTER
E4R4INS - FR	15-0_LANCEUR MANUEL
E4RL4AAA	15-0_RECOIL STARTER
E4RL4AAA, AAB & AAC - FR	15-0_LANCEUR MANUEL
E4RL4AAB & AAC	15-0_RECOIL STARTER
E4RL4INS	15-0_RECOIL STARTER
E4RL4INS - FR	15-0_LANCEUR MANUEL
E6R4AAA	15-0_RECOIL STARTER
E6R4AAA, AAB & AAC - FR	15-0_LANCEUR MANUEL
E6R4AAB & AAC	15-0_RECOIL STARTER
E6R4INS	15-0_RECOIL STARTER
E6R4INS - FR	15-0_LANCEUR MANUEL
E6RG4ABA	15-0_RECOIL STARTER
E6RG4ABB	15-0_RECOIL STARTER
E6RGL4ABA	15-0_RECOIL STARTER
E6RGLABB	15-0_RECOIL STARTER
E6RL4AAA	15-0_RECOIL STARTER
E6RL4AAA, AAB & AAC - FR	15-0_LANCEUR MANUEL
E6RL4AAB & AAC	15-0_RECOIL STARTER
E6RL4INS	15-0_RECOIL STARTER
E6RL4INS - FR	15-0_LANCEUR MANUEL
E6RX4AAA	15-0_RECOIL STARTER
E6RX4AAA, AAB & AAC - FR	15-0_LANCEUR MANUEL
E6RX4AAB & AAC	15-0_RECOIL STARTER
E6RX4INS	15-0_RECOIL STARTER
E6RX4INS - FR	15-0_LANCEUR MANUEL