

Where Used: Part Number 0580148

Model Name	Diagram
1002R 1970	MAGNETO GROUP
18002C 1970	MAGNETO GROUP
18002E 1970	MAGNETO GROUP
18003C 1970	MAGNETO GROUP
18003E 1970	MAGNETO GROUP
1802S 1968	MAGNETO GROUP
18102S 1971	MAGNETO
18103S 1971	MAGNETO
18202R 1972	MAGNETO
18203R 1972	MAGNETO
18304A 1973	MAGNETO
18305A 1973	MAGNETO
18802A 1968	MAGNETO GROUP
18802E 1968	MAGNETO GROUP
18802M 1968	MAGNETO GROUP
18803A 1968	MAGNETO GROUP
18803E 1968	MAGNETO GROUP
18803M 1968	MAGNETO GROUP
18902B 1969	MAGNETO GROUP
18902D 1969	MAGNETO GROUP
18903B 1969	MAGNETO GROUP
18903D 1969	MAGNETO GROUP
1902C 1969	MAGNETO GROUP
1R69C 1969	MAGNETO GROUP
1R70R 1970	MAGNETO GROUP
20R69B 1969	MAGNETO GROUP
20R69D 1969	MAGNETO GROUP
20R70C 1970	MAGNETO GROUP
20R70E 1970	MAGNETO GROUP
20R71S 1971	MAGNETO
20R72R 1972	MAGNETO
20R73A 1973	MAGNETO
20RL69B 1969	MAGNETO GROUP

20RL69D 1969	MAGNETO GROUP
20RL70C 1970	MAGNETO GROUP
20RL70E 1970	MAGNETO GROUP
20RL71S 1971	MAGNETO
20RL72R 1972	MAGNETO
20RL73A 1973	MAGNETO
2102A 1971	MAGNETO
2202M 1972	MAGNETO
2302B 1973	MAGNETO
2402E 1974	MAGNETO
25002C 1970	MAGNETO GROUP
25002E 1970	MAGNETO GROUP
25003C 1970	MAGNETO GROUP
25003E 1970	MAGNETO GROUP
2502D 1975	MAGNETO
25102S 1971	MAGNETO
25103S 1971	MAGNETO
25202R 1972	MAGNETO
25203R 1972	MAGNETO
25252R 1972	MAGNETO
25253R 1972	MAGNETO
25302A 1973	MAGNETO
25303A 1973	MAGNETO
25352A 1973	MAGNETO
25353A 1973	MAGNETO
25402M 1974	MAGNETO
25403M 1974	MAGNETO
25452M 1974	MAGNETO
25453M 1974	MAGNETO
25502B 1975	MAGNETO
25503B 1975	MAGNETO
25552B 1975	MAGNETO
25553B 1975	MAGNETO
25602E 1976	MAGNETO
25603E 1976	MAGNETO

25652E 1976	MAGNETO
25653E 1976	MAGNETO
25902B 1969	MAGNETO GROUP
25902D 1969	MAGNETO GROUP
25903B 1969	MAGNETO GROUP
25903D 1969	MAGNETO GROUP
25E72R 1972	MAGNETO
25E73A 1973	MAGNETO
25E74M 1974	MAGNETO
25E75B 1975	MAGNETO
25E76E 1976	MAGNETO
25EL72R 1972	MAGNETO
25EL73A 1973	MAGNETO
25EL74M 1974	MAGNETO
25EL75B 1975	MAGNETO
25EL76E 1976	MAGNETO
25R69B 1969	MAGNETO GROUP
25R69D 1969	MAGNETO GROUP
25R70C 1970	MAGNETO GROUP
25R70E 1970	MAGNETO GROUP
25R71S 1971	MAGNETO
25R72R 1972	MAGNETO
25R73A 1973	MAGNETO
25R74M 1974	MAGNETO
25R75B 1975	MAGNETO
25R76E 1976	MAGNETO
25RL69B 1969	MAGNETO GROUP
25RL69D 1969	MAGNETO GROUP
25RL70C 1970	MAGNETO GROUP
25RL70E 1970	MAGNETO GROUP
25RL71S 1971	MAGNETO
25RL72R 1972	MAGNETO
25RL73A 1973	MAGNETO
25RL74M 1974	MAGNETO
25RL75B 1975	MAGNETO

25RL76E 1976	MAGNETO
2602S 1976	MAGNETO
2702C 1977	MAGNETO
2802R 1978	MAGNETO
2902A 1979	MAGNETO
2R71A 1971	MAGNETO
2R72M 1972	MAGNETO
2R73B 1973	MAGNETO
2R74E 1974	MAGNETO
2R75D 1975	MAGNETO
2R76S 1976	MAGNETO
2R77C 1977	MAGNETO
2R78R 1978	AGNETO
2R79A 1979	MAGNETO
33002M 1970	MAGNETO GROUP
33003M 1970	MAGNETO GROUP
33052M 1970	MAGNETO GROUP
33053M 1970	MAGNETO GROUP
33802M 1968	MAGNETO GROUP
33802R 1968	MAGNETO GROUP
33803M 1968	MAGNETO GROUP
33803R 1968	MAGNETO GROUP
33852M 1968	MAGNETO GROUP
33852R 1968	MAGNETO GROUP
33853M 1968	MAGNETO GROUP
33853R 1968	MAGNETO GROUP
33902A 1969	MAGNETO GROUP
33903A 1969	MAGNETO GROUP
33952A 1969	MAGNETO GROUP
33953A 1969	MAGNETO GROUP
33E69A 1969	MAGNETO GROUP
33E70M 1970	MAGNETO GROUP
33EL69A 1969	MAGNETO GROUP
33EL70M 1970	MAGNETO GROUP
33R69A 1969	MAGNETO GROUP

33R70M 1970	MAGNETO GROUP
33RL69A 1969	MAGNETO GROUP
33RL70M 1970	MAGNETO GROUP
3802A 1968	MAGNETO GROUP
3802M 1968	MAGNETO GROUP
3803A 1968	MAGNETO GROUP
3803M 1968	MAGNETO GROUP
3806A 1968	MAGNETO GROUP
3806M 1968	MAGNETO GROUP
3807A 1968	MAGNETO GROUP
3807M 1968	MAGNETO GROUP
3832A 1968	MAGNETO GROUP
3832M 1968	MAGNETO GROUP
3833A 1968	MAGNETO GROUP
3833M 1968	MAGNETO GROUP
3836A 1968	MAGNETO GROUP
3836M 1968	MAGNETO GROUP
3837A 1968	MAGNETO GROUP
3837M 1968	MAGNETO GROUP
40002A 1970	MAGNETO GROUP
40003A 1970	MAGNETO GROUP
40052A 1970	MAGNETO GROUP
40053A 1970	MAGNETO GROUP
4006E 1970	MAGNETO GROUP
40072A 1970	MAGNETO GROUP ELECTRIC SHIFT
40073A 1970	MAGNETO GROUP ELECTRIC SHIFT
4007E 1970	MAGNETO GROUP
40102B 1971	MAGNETO
40102G 1971	MAGNETO
40103B 1971	MAGNETO
40103G 1971	MAGNETO
40152B 1971	MAGNETO
40152G 1971	MAGNETO
40153B 1971	MAGNETO
40153G 1971	MAGNETO

40202E 1972	MAGNETO
40203E 1972	MAGNETO
40252E 1972	MAGNETO
40253E 1972	MAGNETO
40304D 1973	MAGNETO
40305D 1973	MAGNETO
40354D 1973	MAGNETO
40355D 1973	MAGNETO
4036E 1970	MAGNETO GROUP
4037E 1970	MAGNETO GROUP
40802A 1968	MAGNETO GROUP
40802D 1968	MAGNETO GROUP
40802S 1968	MAGNETO GROUP
40803A 1968	MAGNETO GROUP
40803D 1968	MAGNETO GROUP
40803S 1968	MAGNETO GROUP
40852A 1968	MAGNETO GROUP ELECTRIC START
40852C 1968	MAGNETO GROUP ELECTRIC START
40852D 1968	MAGNETO GROUP ELECTRIC START
40852S 1968	MAGNETO GROUP ELECTRIC START
40853A 1968	MAGNETO GROUP ELECTRIC START
40853C 1968	MAGNETO GROUP ELECTRIC START
40853D 1968	MAGNETO GROUP ELECTRIC START
40853S 1968	MAGNETO GROUP ELECTRIC START
40872A 1968	MAGNETO GROUP ELECTRIC SHIFT
40872C 1968	MAGNETO GROUP ELECTRIC SHIFT
40872D 1968	MAGNETO GROUP ELECTRIC SHIFT
40873A 1968	MAGNETO GROUP ELECTRIC SHIFT
40873C 1968	MAGNETO GROUP ELECTRIC SHIFT
40873D 1968	MAGNETO GROUP ELECTRIC SHIFT
40902R 1969	MAGNETO GROUP
40903R 1969	MAGNETO GROUP
40952R 1969	MAGNETO GROUP
40953R 1969	MAGNETO GROUP
40972R 1969	MAGNETO GROUP ELECTRIC SHIFT

40973R 1969	MAGNETO GROUP ELECTRIC SHIFT
40E69R 1969	MAGNETO GROUP ELECTRIC START
40E70A 1970	MAGNETO GROUP
40E71B 1971	MAGNETO
40E71G 1971	MAGNETO
40E72E 1972	MAGNETO
40E73D 1973	MAGNETO
40EL69R 1969	MAGNETO GROUP ELECTRIC START
40EL70A 1970	MAGNETO GROUP
40EL71B 1971	MAGNETO
40EL71G 1971	MAGNETO
40EL72E 1972	MAGNETO
40EL73D 1973	MAGNETO
40ES69R 1969	MAGNETO GROUP ELECTRIC SHIFT
40ES70A 1970	MAGNETO GROUP ELECTRIC SHIFT
40ESL69R 1969	MAGNETO GROUP ELECTRIC SHIFT
40ESL70A 1970	MAGNETO GROUP ELECTRIC SHIFT
40R69R 1969	MAGNETO GROUP
40R70A 1970	MAGNETO GROUP
40R71B 1971	MAGNETO
40R71G 1971	MAGNETO
40R72E 1972	MAGNETO
40R73D 1973	MAGNETO
40RL69R 1969	MAGNETO GROUP
40RL70A 1970	MAGNETO GROUP
40RL71B 1971	MAGNETO
40RL71G 1971	MAGNETO
40RL72E 1972	MAGNETO
40RL73D 1973	MAGNETO
4106D 1971	MAGNETO
4107D 1971	MAGNETO
4136D 1971	MAGNETO
4137D 1971	MAGNETO
4206S 1972	MAGNETO
4236S 1972	MAGNETO

4306C 1973	MAGNETO
4336C 1973	MAGNETO
4406R 1974	MAGNETO
4436R 1974	MAGNETO
4506A 1975	MAGNETO
4536A 1975	MAGNETO
4606M 1976	MAGNETO
4636M 1976	MAGNETO
4902B 1969	MAGNETO GROUP
4906B 1969	MAGNETO GROUP
4936B 1969	MAGNETO GROUP
4R69B 1969	MAGNETO GROUP
4R70E 1970	MAGNETO GROUP
4R71D 1971	MAGNETO
4R72S 1972	MAGNETO
4R73C 1973	MAGNETO
4R74R 1974	MAGNETO
4R75A 1975	MAGNETO
4R76M 1976	MAGNETO
4RL70E 1970	MAGNETO GROUP
4RL71D 1971	MAGNETO
4W69B 1969	MAGNETO GROUP
4W70E 1970	MAGNETO GROUP
4W71D 1971	MAGNETO
4W72S 1972	MAGNETO
4W73C 1973	MAGNETO
4W74R 1974	MAGNETO
4W75A 1975	MAGNETO
4W76M 1976	MAGNETO
4WF69B 1969	MAGNETO GROUP
4WL70E 1970	MAGNETO GROUP
4WL71D 1971	MAGNETO
5802B 1968	MAGNETO GROUP
5802E 1968	MAGNETO GROUP
5802M 1968	MAGNETO GROUP

5803B 1968	MAGNETO GROUP
5803E 1968	MAGNETO GROUP
5803M 1968	MAGNETO GROUP
6002B 1970	MAGNETO GROUP
6003B 1970	MAGNETO GROUP
6102E 1971	MAGNETO
6102G 1971	MAGNETO
6103E 1971	MAGNETO
6103G 1971	MAGNETO
6202D 1972	MAGNETO
6203D 1972	MAGNETO
6302S 1973	MAGNETO
6303S 1973	MAGNETO
6402C 1974	MAGNETO
6403C 1974	MAGNETO
6504R 1975	MAGNETO
6505R 1975	MAGNETO
6604A 1976	MAGNETO
6605A 1976	MAGNETO
6802A 1968	MAGNETO GROUP
6802C 1968	MAGNETO GROUP
6802R 1968	MAGNETO GROUP
6803A 1968	MAGNETO GROUP
6803C 1968	MAGNETO GROUP
6803R 1968	MAGNETO GROUP
6902M 1969	MAGNETO GROUP
6903M 1969	MAGNETO GROUP
6R69M 1969	MAGNETO GROUP
6R70B 1970	MAGNETO GROUP
6R71E 1971	MAGNETO
6R71G 1971	MAGNETO
6R72D 1972	MAGNETO
6R73S 1973	MAGNETO
6R74C 1974	MAGNETO
6R75R 1975	MAGNETO

6R76A 1976	MAGNETO
6RL69M 1969	MAGNETO GROUP
6RL70B 1970	MAGNETO GROUP
6RL71E 1971	MAGNETO
6RL71G 1971	MAGNETO
6RL72 1972	MAGNETO
6RL73S 1973	MAGNETO
6RL74C 1974	MAGNETO
6RL75R 1975	MAGNETO
6RL76A 1976	MAGNETO
9022A 1970	MAGNETO GROUP
9022C 1970	MAGNETO GROUP
9023A 1970	MAGNETO GROUP
9023C 1970	MAGNETO GROUP
9122R 1971	MAGNETO
9123R 1971	MAGNETO
9222M 1972	MAGNETO
9223M 1972	MAGNETO
9322B 1973	MAGNETO
9323B 1973	MAGNETO
9822D 1968	MAGNETO GROUP
9822E 1968	MAGNETO GROUP
9823D 1968	MAGNETO GROUP
9823E 1968	MAGNETO GROUP
9922S 1969	MAGNETO GROUP
9923S 1969	MAGNETO GROUP
9R70A 1970	MAGNETO GROUP
9R70C 1970	MAGNETO GROUP
9R71R 1971	MAGNETO
9R72M 1972	MAGNETO
9R73B 1973	MAGNETO
9RL70A 1970	MAGNETO GROUP
9RL70C 1970	MAGNETO GROUP
9RL71R 1971	MAGNETO
9RL72M 1972	MAGNETO

9RL73B 1973	MAGNETO
CD-25A 1968	MAGNETO GROUP
CD-25C 1968	MAGNETO GROUP
CD-25R 1968	MAGNETO GROUP
CDL-25A 1968	MAGNETO GROUP
CDL-25C 1968	MAGNETO GROUP
CDL-25R 1968	MAGNETO GROUP
E2RCIB 1981	MAGNETO
E2RCNE 1982	MAGNETO
E2RCOC 1985	MAGNETO
E2RCRS 1984	MAGNETO
E2RCSM 1980	MAGNETO
E2RCTD 1983	MAGNETO
E3BRCEC 1989	IGNITION
E3BRESR 1990	IGNITION
E4BRCICI 1981	MAGNETO
E4BRHCCS 1988	IGNITION
E4BRHCDE 1986	IGNITION
E4BRHCNR 1982	MAGNETO
E4BRHCOB 1985	IGNITION
E4BRHCRM 1984	IGNITION
E4BRHCTA 1983	MAGNETO
E4BRHCUD 1987	IGNITION
E4BRHLCCS 1988	IGNITION
E4BRHLCDE 1986	IGNITION
E4BRHLCNR 1982	MAGNETO
E4BRHLCOB 1985	IGNITION
E4BRHLCRM 1984	IGNITION
E4BRHLCTA 1983	MAGNETO
E4BRHLCUD 1987	IGNITION
E4BRLCIC 1981	MAGNETO
E4WCIC 1981	MAGNETO
E4WCNR 1982	MAGNETO
EJR-CCM 1988	MAGNETO
EJR-CDR 1986	MAGNETO

EJR-CEB 1989	MAGNETO
EJR-CUA 1987	MAGNETO
EJR-ESE 1990	MAGNETO
FD-22A 1968	MAGNETO GROUP
FD-22E 1968	MAGNETO GROUP
FD-22M 1968	MAGNETO GROUP
FDL-22A 1968	MAGNETO GROUP
FDL-22E 1968	MAGNETO GROUP
FDL-22M 1968	MAGNETO GROUP
J2RCIB 1981	MAGNETO
J2RCNE 1982	MAGNETO
J2RCOC 1985	MAGNETO
J2RCRS 1984	MAGNETO
J2RCSM 1980	MAGNETO
J2RCTD 1983	MAGNETO
J3BRCEC 1989	IGNITION
J3BRESR 1990	IGNITION
J4BRCIC 1981	MAGNETO
J4BRHCCS 1988	IGNITION
J4BRHCDE 1986	IGNITION
J4BRHCNR 1982	MAGNETO
J4BRHCOB 1985	IGNITION
J4BRHCRM 1984	IGNITION
J4BRHCTA 1983	MAGNETO
J4BRHCUD 1987	IGNITION
J4BRHLCCS 1988	IGNITION
J4BRHLCDE 1986	IGNITION
J4BRHLCNR 1982	MAGNETO
J4BRHLCOB 1985	IGNITION
J4BRHLCRM 1984	IGNITION
J4BRHLCTA 1983	MAGNETO
J4BRHLCUD 1987	IGNITION
J4BRLCIC 1981	MAGNETO
J4WCIC 1981	MAGNETO
J4WCNR 1982	MAGNETO

JCO-CCM 1988	MAGNETO
JCO-CDR 1986	MAGNETO
JCO-CEB 1989	MAGNETO
JCO-CUA 1987	MAGNETO
JCO-ESE 1990	MAGNETO
JH-23A 1968	MAGNETO GROUP
JH-23M 1968	MAGNETO GROUP
JHF-23A 1968	MAGNETO GROUP
JHF-23M 1968	MAGNETO GROUP
JHFL-23A 1968	MAGNETO GROUP
JHFL-23M 1968	MAGNETO GROUP
JHL-23A 1968	MAGNETO GROUP
JHL-23M 1968	MAGNETO GROUP
JW-23A 1968	MAGNETO GROUP
JW-23M 1968	MAGNETO GROUP
JWF-23A 1968	MAGNETO GROUP
JWF-23M 1968	MAGNETO GROUP
JWFL-23A 1968	MAGNETO GROUP
JWFL-23M 1968	MAGNETO GROUP
JWL-23A 1968	MAGNETO GROUP
JWL-23M 1968	MAGNETO GROUP
LD-13B 1968	MAGNETO
LD-13E 1968	MAGNETO
LD-13M 1968	MAGNETO
LDL-13B 1968	MAGNETO
LDL-13E 1968	MAGNETO
LDL-13M 1968	MAGNETO
MQ-14D 1968	MAGNETO GROUP
MQ-14E 1968	MAGNETO GROUP
MQL-14D 1968	MAGNETO GROUP
MQL-14E 1968	MAGNETO GROUP
RD-30A 1968	MAGNETO GROUP MANUAL START
RD-30D 1968	MAGNETO GROUP MANUAL START
RD-30S 1968	MAGNETO GROUP MANUAL START
RDL-30A 1968	MAGNETO GROUP MANUAL START

RDL-30D 1968	MAGNETO GROUP MANUAL START
RDL-30S 1968	MAGNETO GROUP MANUAL START
RDS-30A 1968	MAGNETO GROUP
RDS-30C 1968	MAGNETO GROUP
RDS-30D 1968	MAGNETO GROUP
RDS-30S 1968	MAGNETO GROUP
RDSL-30A 1968	MAGNETO GROUP
RDSL-30C 1968	MAGNETO GROUP
RDSL-30D 1968	MAGNETO GROUP
RDSL-30S 1968	MAGNETO GROUP
RK-30A 1968	MAGNETO GROUP ELECTRIC SHIFT
RK-30C 1968	MAGNETO GROUP ELECTRIC SHIFT
RK-30D 1968	MAGNETO GROUP ELECTRIC SHIFT
RKL-30A 1968	MAGNETO GROUP ELECTRIC SHIFT
RKL-30C 1968	MAGNETO GROUP ELECTRIC SHIFT
RKL-30D 1968	MAGNETO GROUP ELECTRIC SHIFT
RX-16M 1968	MAGNETO GROUP
RX-16R 1968	MAGNETO GROUP
RXE-16M 1968	MAGNETO GROUP
RXE-16R 1968	MAGNETO GROUP
RXEL-16M 1968	MAGNETO GROUP
RXEL-16R 1968	MAGNETO GROUP
RXL-16M 1968	MAGNETO GROUP
RXL-16R 1968	MAGNETO GROUP
SC-10S 1968	MAGNETO GROUP