

Where Used: Part Number 0581027

Model Name	Diagram
100293R 1972	IGNITION SYSTEM
100990S 1979	IGNITION SYSTEM
100993S 1979	IGNITION SYSTEM
100999S 1979	IGNITION SYSTEM
100ESL72R 1972	IGNITION SYSTEM
100ML79S 1979	IGNITION SYSTEM
100TLR79S 1979	IGNITION SYSTEM
100TXLR79S 1979	IGNITION SYSTEM
10424G 1974	MAGNETO
10424S 1974	MAGNETO
10425G 1974	MAGNETO
10425S 1974	MAGNETO
10454G 1974	MAGNETO
10454S 1974	MAGNETO
10455G 1974	MAGNETO
10455S 1974	MAGNETO
10524C 1975	MAGNETO
10525C 1975	MAGNETO
10554C 1975	MAGNETO
10555C 1975	MAGNETO
10624G 1976	MAGNETO
10624H 1976	MAGNETO
10624R 1976	MAGNETO
10625G 1976	MAGNETO
10625H 1976	MAGNETO
10625R 1976	MAGNETO
10654G 1976	MAGNETO
10654H 1976	MAGNETO
10654R 1976	MAGNETO
10655G 1976	MAGNETO
10655H 1976	MAGNETO
10655R 1976	MAGNETO
10724A 1977	MAGNETO

10725A 1977	MAGNETO
10754A 1977	MAGNETO
10755A 1977	MAGNETO
10824M 1978	MAGNETO
10825M 1978	MAGNETO
10835M 1978	MAGNETO
10854M 1978	MAGNETO
10855M 1978	MAGNETO
10924B 1979	MAGNETO
10925B 1979	MAGNETO
10935B 1979	MAGNETO
10955B 1979	MAGNETO
10E74G 1974	MAGNETO
10E74S 1974	MAGNETO
10E75C 1975	MAGNETO
10E76G 1976	MAGNETO
10E76H 1976	MAGNETO
10E76R 1976	MAGNETO
10E77A 1977	MAGNETO
10E78M 1978	MAGNETO
10EL74G 1974	MAGNETO
10EL75C 1975	MAGNETO
10EL76G 1976	MAGNETO
10EL76H 1976	MAGNETO
10EL76R 1976	MAGNETO
10EL77A 1977	MAGNETO
10EL78M 1978	MAGNETO
10EL79B 1979	MAGNETO
10ELT4S 1974	MAGNETO
10R74G 1974	MAGNETO
10R74S 1974	MAGNETO
10R75C 1975	MAGNETO
10R76G 1976	MAGNETO
10R76H 1976	MAGNETO
10R76R 1976	MAGNETO

10R77A 1977	MAGNETO
10R78M 1978	MAGNETO
10R79B 1979	MAGNETO
10RL74G 1974	MAGNETO
10RL74S 1974	MAGNETO
10RL75C 1975	MAGNETO
10RL76G 1976	MAGNETO
10RL76H 1976	MAGNETO
10RL76R 1976	MAGNETO
10RL77A 1977	MAGNETO
10RL78M 1978	MAGNETO
10RL79B 1979	MAGNETO
10SEL78M 1978	MAGNETO
10SEL79B 1979	MAGNETO
115393M 1973	IGNITION SYSTEM
115493B 1974	IGNITION SYSTEM
115593 1975	IGNITION SYSTEM
115693D 1976	IGNITION SYSTEM
115693G 1976	IGNITION SYSTEM
115699D 1976	IGNITION SYSTEM
115699G 1976	IGNITION SYSTEM
115790S 1977	IGNITION SYSTEM
115793S 1977	IGNITION SYSTEM
115799S 1977	IGNITION SYSTEM
115890C 1978	IGNITION SYSTEM
115893C 1978	IGNITION SYSTEM
115899C 1978	IGNITION SYSTEM
115990R 1979	IGNITION SYSTEM
115993R 1979	IGNITION SYSTEM
115999R 1979	IGNITION SYSTEM
115EL77S 1977	IGNITION SYSTEM
115ESL73M 1973	IGNITION SYSTEM
115ESL74B 1974	IGNITION SYSTEM
115ESL75E 1975	IGNITION SYSTEM
115ETL74B 1974	IGNITION SYSTEM

115ETL75E 1975	IGNITION SYSTEM
115ETL77 1977	IGNITION SYSTEM
115ETZ78C 1978	IGNITION SYSTEM
115JEEOB 1995	IGNITION SYSTEM
115JEERA 1994	IGNITION SYSTEM
115ML78C 1978	IGNITION SYSTEM
115ML79R 1979	IGNITION SYSTEM
115TJEDB 1996	IGNITION SYSTEM
115TJEOA 1995	IGNITION SYSTEM
115TJEUC 1997	IGNITION SYSTEM
115TL79R 1979	IGNITION SYSTEM
115TXL77S 1977	IGNITION SYSTEM
115TXL78C 1978	IGNITION SYSTEM
115TXL79R 1979	IGNITION SYSTEM
125283R 1972	IGNITION SYSTEM
125ESL72R 1972	IGNITION SYSTEM
135383M 1973	IGNITION SYSTEM
135443B 1974	IGNITION SYSTEM
135483B 1974	IGNITION SYSTEM
135489B 1974	IGNITION SYSTEM
135543E 1975	IGNITION SYSTEM
135583E 1975	IGNITION SYSTEM
135589E 1975	IGNITION SYSTEM
135643D 1976	IGNITION SYSTEM
135643G 1976	IGNITION SYSTEM
135683D 1976	IGNITION SYSTEM
135683G 1976	IGNITION SYSTEM
135ESL73M 1973	IGNITION SYSTEM
135ESL74B 1974	IGNITION SYSTEM
135ESL75E 1975	IGNITION SYSTEM
135ETL74B 1974	IGNITION SYSTEM
135ETL75E 1975	IGNITION SYSTEM
140740S 1977	IGNITION SYSTEM
140743S 1977	IGNITION SYSTEM
140783S 1977	IGNITION SYSTEM

140840C 1978	IGNITION SYSTEM
140843C 1978	IGNITION SYSTEM
140883C 1978	IGNITION SYSTEM
140940R 1979	IGNITION SYSTEM
140943R 1979	IGNITION SYSTEM
140983R 1979	IGNITION SYSTEM
140ML77S 1977	IGNITION SYSTEM
140ML78C 1978	IGNITION SYSTEM
140ML79R 1979	IGNITION SYSTEM
140TL77S 1977	IGNITION SYSTEM
140TL78C 1978	IGNITION SYSTEM
140TL79R 1979	IGNITION SYSTEM
140TX78C 1978	IGNITION SYSTEM
140TXL77S 1977	IGNITION SYSTEM
140TXL79R 1979	IGNITION SYSTEM
150840S 1978	IGNITION SYSTEM
150849S 1978	IGNITION SYSTEM
150940C 1979	IGNITION SYSTEM
150949C 1979	IGNITION SYSTEM
150TL78S 1978	IGNITION SYSTEM
150TL79C 1979	IGNITION SYSTEM
150TXL78S 1978	IGNITION SYSTEM
150TXL79C 1979	IGNITION SYSTEM
15404G 1974	MAGNETO
15404S 1974	MAGNETO
15405G 1974	MAGNETO
15405S 1974	MAGNETO
15454G 1974	MAGNETO
15454S 1974	MAGNETO
15455G 1974	MAGNETO
15455S 1974	MAGNETO
15504C 1975	MAGNETO
15505C 1975	MAGNETO
15554C 1975	MAGNETO
15555C 1975	MAGNETO

15604A 1976	MAGNETO
15604R 1976	MAGNETO
15605A 1976	MAGNETO
15605R 1976	MAGNETO
15654A 1976	MAGNETO
15654R 1976	MAGNETO
15655A 1976	MAGNETO
15655R 1976	MAGNETO
15704M 1977	MAGNETO
15705M 1977	MAGNETO
15754M 1977	MAGNETO
15804B 1978	MAGNETO
15805B 1978	MAGNETO
15854B 1978	MAGNETO
15855B 1978	MAGNETO
15904E 1979	MAGNETO
15905E 1979	MAGNETO
15954E 1979	MAGNETO
15955E 1979	MAGNETO
15E74G 1974	MAGNETO
15E74S 1974	MAGNETO
15E75C 1975	MAGNETO
15E76A 1976	MAGNETO
15E76R 1976	MAGNETO
15E77M 1977	MAGNETO
15E78B 1978	MAGNETO
15E79E 1979	MAGNETO
15EL74G 1974	MAGNETO
15EL74S 1974	MAGNETO
15EL75C 1975	MAGNETO
15EL76A 1976	MAGNETO
15EL76R 1976	MAGNETO
15EL77M 1977	MAGNETO
15EL78B 1978	MAGNETO
15EL79E 1979	MAGNETO

15R74G 1974	MAGNETO
15R74S 1974	MAGNETO
15R75C 1975	MAGNETO
15R76A 1976	MAGNETO
15R76R 1976	MAGNETO
15R77M 1977	MAGNETO
15R78B 1978	MAGNETO
15R79E 1979	MAGNETO
15RL74G 1974	MAGNETO
15RL74S 1974	MAGNETO
15RL75C 1975	MAGNETO
15RL76A 1976	MAGNETO
15RL76R 1976	MAGNETO
15RL77M 1977	MAGNETO
15RL78B 1978	MAGNETO
15RL79E 1979	MAGNETO
175740S 1977	IGNITION SYSTEM
175749S 1977	IGNITION SYSTEM
175840C 1978	IGNITION SYSTEM
175840S 1978	IGNITION SYSTEM
175940R 1979	IGNITION SYSTEM
175949R 1979	IGNITION SYSTEM
175TL77S 1977	IGNITION SYSTEM
175TL78C 1978	IGNITION SYSTEM
175TL79R 1979	IGNITION SYSTEM
175TX78C 1978	IGNITION SYSTEM
175TXL77S 1977	IGNITION SYSTEM
175TXL79R 1979	IGNITION SYSTEM
18202R 1972	MAGNETO
18203R 1972	MAGNETO
18304A 1973	MAGNETO
18305A 1973	MAGNETO
200490A 1979	IGNITION SYSTEM
200640S 1976	IGNITION SYSTEM
200649S 1976	IGNITION SYSTEM

200740C 1977	IGNITION SYSTEM
200749C 1977	IGNITION SYSTEM
200840R 1978	IGNITION SYSTEM
200849R 1978	IGNITION SYSTEM
200940A 1979	IGNITION SYSTEM
200949A 1979	IGNITION SYSTEM
200TL76S 1976	IGNITION SYSTEM
200TL77C 1977	IGNITION SYSTEM
200TL78R 1978	IGNITION SYSTEM
200TL79A 1979	IGNITION SYSTEM
200TX78R 1978	IGNITION SYSTEM
200TXL76S 1976	IGNITION SYSTEM
200TXL77C 1977	IGNITION SYSTEM
200TXL79A 1979	IGNITION SYSTEM
20R72R 1972	MAGNETO
20R73A 1973	MAGNETO
20RL72R 1972	MAGNETO
20RL73A 1973	MAGNETO
2202M 1972	MAGNETO
2302B 1973	MAGNETO
235840R 1978	IGNITION SYSTEM
235849R 1978	IGNITION SYSTEM
235940A 1979	IGNITION SYSTEM
235949A 1979	IGNITION SYSTEM
235TL70A 1979	IGNITION SYSTEM
235TL78R 1978	IGNITION SYSTEM
235TX78R 1978	IGNITION SYSTEM
235TXL79A 1979	IGNITION SYSTEM
2402E 1974	MAGNETO
2502D 1975	MAGNETO
25202R 1972	MAGNETO
25203R 1972	MAGNETO
25252R 1972	MAGNETO
25253R 1972	MAGNETO
25302A 1973	MAGNETO

25303A 1973	MAGNETO
25352A 1973	MAGNETO
25353A 1973	MAGNETO
25402M 1974	MAGNETO
25403M 1974	MAGNETO
25452M 1974	MAGNETO
25453M 1974	MAGNETO
25502B 1975	MAGNETO
25503B 1975	MAGNETO
25552B 1975	MAGNETO
25553B 1975	MAGNETO
25602E 1976	MAGNETO
25603E 1976	MAGNETO
25652E 1976	MAGNETO
25653E 1976	MAGNETO
25702H 1977	MAGNETO
25702S 1977	MAGNETO
25703H 1977	MAGNETO
25703S 1977	MAGNETO
25752H 1977	MAGNETO
25752S 1977	MAGNETO
25753H 1977	MAGNETO
25753S 1977	MAGNETO
25802C 1978	MAGNETO
25803C 1978	MAGNETO
25852C 1978	MAGNETO
25853C 1978	MAGNETO
25904R 1979	MAGNETO
25905R 1979	MAGNETO
25952R 1979	MAGNETO
25953R 1979	MAGNETO
25E72R 1972	MAGNETO
25E73A 1973	MAGNETO
25E74M 1974	MAGNETO
25E75B 1975	MAGNETO

25E76E 1976	MAGNETO
25E77S 1977	MAGNETO
25E78C 1978	MAGNETO
25E79R 1979	MAGNETO
25EL72R 1972	MAGNETO
25EL73A 1973	MAGNETO
25EL74M 1974	MAGNETO
25EL75B 1975	MAGNETO
25EL76E 1976	MAGNETO
25EL77H 1977	MAGNETO
25EL77S 1977	MAGNETO
25EL78C 1978	MAGNETO
25EL79R 1979	MAGNETO
25R72R 1972	MAGNETO
25R73A 1973	MAGNETO
25R74M 1974	MAGNETO
25R75B 1975	MAGNETO
25R76E 1976	MAGNETO
25R77H 1977	MAGNETO
25R77S 1977	MAGNETO
25R78C 1978	MAGNETO
25R79R 1979	MAGNETO
25RL72R 1972	MAGNETO
25RL73A 1973	MAGNETO
25RL74M 1974	MAGNETO
25RL75B 1975	MAGNETO
25RL76E 1976	MAGNETO
25RL77H 1977	MAGNETO
25RL77S 1977	MAGNETO
25RL78C 1978	MAGNETO
25RL79R 1979	MAGNETO
2602S 1976	MAGNETO
2702C 1977	MAGNETO
2802R 1978	MAGNETO
2902A 1979	MAGNETO

2R72M 1972	MAGNETO
2R73B 1973	MAGNETO
2R74E 1974	MAGNETO
2R75D 1975	MAGNETO
2R76S 1976	MAGNETO
2R77C 1977	MAGNETO
2R78R 1978	AGNETO
2R79A 1979	MAGNETO
35602G 1976	MAGNETO
35602S 1976	MAGNETO
35603G 1976	MAGNETO
35603S 1976	MAGNETO
35652G 1976	MAGNETO
35652S 1976	MAGNETO
35653G 1976	MAGNETO
35653S 1976	MAGNETO
35702C 1977	MAGNETO
35702H 1977	MAGNETO
35703C 1977	MAGNETO
35703H 1977	MAGNETO
35752C 1977	MAGNETO
35752H 1977	MAGNETO
35753C 1977	MAGNETO
35753H 1977	MAGNETO
35802R 1978	MAGNETO
35803R 1978	MAGNETO
35852R 1978	MAGNETO
35853R 1978	MAGNETO
35902A 1979	MAGNETO
35903A 1979	MAGNETO
35952A 1979	MAGNETO
35953A 1979	MAGNETO
35E76G 1976	MAGNETO
35E76S 1976	MAGNETO
35E77C 1977	MAGNETO

35E77H 1977	MAGNETO
35E78R 1978	MAGNETO
35E79A 1979	MAGNETO
35EL76G 1976	MAGNETO
35EL76S 1976	MAGNETO
35EL77C 1977	MAGNETO
35EL77H 1977	MAGNETO
35EL78R 1978	MAGNETO
35EL79A 1979	MAGNETO
35R76G 1976	MAGNETO
35R76S 1976	MAGNETO
35R77C 1977	MAGNETO
35R77H 1977	MAGNETO
35R78R 1978	MAGNETO
35R79A 1979	MAGNETO
35RL76G 1976	MAGNETO
35RL76S 1976	MAGNETO
35RL77C 1977	MAGNETO
35RL77H 1977	MAGNETO
35RL78R 1978	MAGNETO
35RL79A 1979	MAGNETO
40202E 1972	MAGNETO
40203E 1972	MAGNETO
40252E 1972	MAGNETO
40253E 1972	MAGNETO
40304D 1973	MAGNETO
40305D 1973	MAGNETO
40354D 1973	MAGNETO
40355D 1973	MAGNETO
40404S 1974	MAGNETO
40405S 1974	MAGNETO
40454S 1974	MAGNETO
40455S 1974	MAGNETO
40504C 1975	MAGNETO
40505C 1975	MAGNETO

40554C 1975	MAGNETO
40555C 1975	MAGNETO
40604A 1976	MAGNETO
40604R 1976	MAGNETO
40605A 1976	MAGNETO
40605R 1976	MAGNETO
40654A 1976	MAGNETO
40654R 1976	MAGNETO
40655A 1976	MAGNETO
40655R 1976	MAGNETO
40E72E 1972	MAGNETO
40E73D 1973	MAGNETO
40E74S 1974	MAGNETO
40E75C 1975	MAGNETO
40E76A 1976	MAGNETO
40E76R 1976	MAGNETO
40EL72E 1972	MAGNETO
40EL73D 1973	MAGNETO
40EL74S 1974	MAGNETO
40EL75C 1975	MAGNETO
40EL76A 1976	MAGNETO
40EL76R 1976	MAGNETO
40R72E 1972	MAGNETO
40R73D 1973	MAGNETO
40R74S 1974	MAGNETO
40R75C 1975	MAGNETO
40R76A 1976	MAGNETO
40R76R 1976	MAGNETO
40RL72E 1972	MAGNETO
40RL73D 1973	MAGNETO
40RL74S 1974	MAGNETO
40RL75C 1975	MAGNETO
40RL76A 1976	MAGNETO
40RL76R 1976	MAGNETO
4206S 1972	MAGNETO

4236S 1972	MAGNETO
4306C 1973	MAGNETO
4336C 1973	MAGNETO
4406R 1974	MAGNETO
4436R 1974	MAGNETO
4506A 1975	MAGNETO
4536A 1975	MAGNETO
4606M 1976	MAGNETO
4636M 1976	MAGNETO
4706B 1977	MAGNETO
4736B 1977	MAGNETO
4806E 1978	MAGNETO
4836E 1978	MAGNETO
4837E 1978	MAGNETO
4904D 1979	MAGNETO
4932D 1979	MAGNETO
4933D 1979	MAGNETO
4R72S 1972	MAGNETO
4R73C 1973	MAGNETO
4R74R 1974	MAGNETO
4R75A 1975	MAGNETO
4R76M 1976	MAGNETO
4R77B 1977	MAGNETO
4R78E 1978	MAGNETO
4R79D 1979	MAGNETO
4RL78E 1978	MAGNETO
4RL79D 1979	MAGNETO
4W72S 1972	MAGNETO
4W73C 1973	MAGNETO
4W74R 1974	MAGNETO
4W75A 1975	MAGNETO
4W76M 1976	MAGNETO
4W77B 1977	MAGNETO
4W78E 1978	MAGNETO
4W79D 1979	MAGNETO

50202C 1972	IGNITION SYSTEM
50203C 1972	IGNITION SYSTEM
50272C 1972	IGNITION SYSTEM
50273C 1972	IGNITION SYSTEM
50302R 1973	IGNITION SYSTEM
50303R 1973	IGNITION SYSTEM
50372R 1973	IGNITION SYSTEM
50373R 1973	IGNITION SYSTEM
50442M 1974	IGNITION SYSTEM
50443M 1974	IGNITION SYSTEM
50472M 1974	IGNITION SYSTEM
50473M 1974	IGNITION SYSTEM
50542B 1975	IGNITION SYSTEM
50543B 1975	IGNITION SYSTEM
50572B 1975	IGNITION SYSTEM
50573B 1975	IGNITION SYSTEM
50902C 1979	IGNITION SYSTEM
50903C 1979	IGNITION SYSTEM
50ES72C 1972	IGNITION SYSTEM
50ES73R 1973	IGNITION SYSTEM
50ES74M 1974	IGNITION SYSTEM
50ES75B 1975	IGNITION SYSTEM
50ESL72C 1972	IGNITION SYSTEM
50ESL73R 1973	IGNITION SYSTEM
50ESL74M 1974	IGNITION SYSTEM
50ESL75B 1975	IGNITION SYSTEM
50R72C 1972	IGNITION SYSTEM
50R73R 1973	IGNITION SYSTEM
50R79C 1979	IGNITION SYSTEM
50RL72C 1972	IGNITION SYSTEM
50RL73R 1973	IGNITION SYSTEM
50RL79C 1979	IGNITION SYSTEM
55642E 1976	IGNITION SYSTEM
55643E 1976	IGNITION SYSTEM
55672E 1976	IGNITION SYSTEM

55673E 1976	IGNITION SYSTEM
55772D 1977	IGNITION SYSTEM
55773D 1977	IGNITION SYSTEM
55874S 1978	IGNITION SYSTEM
55875S 1978	IGNITION SYSTEM
55974C 1979	IGNITION SYSTEM
55975C 1979	IGNITION SYSTEM
55E76E 1976	IGNITION SYSTEM
55E77D 1977	IGNITION SYSTEM
55E78S 1978	IGNITION SYSTEM
55E79C 1979	IGNITION SYSTEM
55EL76E 1976	IGNITION SYSTEM
55EL77D 1977	IGNITION SYSTEM
55EL78S 1978	IGNITION SYSTEM
55EL79C 1979	IGNITION SYSTEM
6202D 1972	MAGNETO
6203D 1972	MAGNETO
6302S 1973	MAGNETO
6303S 1973	MAGNETO
6402C 1974	MAGNETO
6403C 1974	MAGNETO
6504R 1975	MAGNETO
6505R 1975	MAGNETO
65272S 1972	IGNITION SYSTEM
65273S 1972	IGNITION SYSTEM
65372R 1973	IGNITION SYSTEM
65373R 1973	IGNITION SYSTEM
65ES72S 1972	IGNITION SYSTEM
65ES73R 1973	IGNITION SYSTEM
65ESL72S 1972	IGNITION SYSTEM
65ESL73R 1973	IGNITION SYSTEM
6604A 1976	MAGNETO
6605A 1976	MAGNETO
6704M 1977	MAGNETO
6705M 1977	MAGNETO

6804B 1978	MAGNETO
6805B 1978	MAGNETO
6904E 1979	MAGNETO
6905E 1979	MAGNETO
6R72D 1972	MAGNETO
6R73S 1973	MAGNETO
6R74C 1974	MAGNETO
6R75R 1975	MAGNETO
6R76A 1976	MAGNETO
6R77M 1977	MAGNETO
6R78B 1978	MAGNETO
6R79E 1979	MAGNETO
6RL72 1972	MAGNETO
6RL73S 1973	MAGNETO
6RL74C 1974	MAGNETO
6RL75R 1975	MAGNETO
6RL76A 1976	MAGNETO
6RL77M 1977	MAGNETO
6RL78B 1978	MAGNETO
6RL79E 1979	MAGNETO
70442M 1974	IGNITION SYSTEM
70443M 1974	IGNITION SYSTEM
70472M 1974	IGNITION SYSTEM
70473M 1974	IGNITION SYSTEM
70572B 1975	IGNITION SYSTEM
70572E 1975	IGNITION SYSTEM
70573B 1975	IGNITION SYSTEM
70573E 1975	IGNITION SYSTEM
70673D 1976	IGNITION SYSTEM
70773S 1977	IGNITION SYSTEM
70873C 1978	IGNITION SYSTEM
70973R 1979	IGNITION SYSTEM
70EL76D 1976	IGNITION SYSTEM
70EL77S 1977	IGNITION SYSTEM
70EL78C 1978	IGNITION SYSTEM

70EL79R 1979	IGNITION SYSTEM
70ES74M 1974	IGNITION SYSTEM
70ES75B 1975	IGNITION SYSTEM
70ES75E 1975	IGNITION SYSTEM
70ESL74M 1974	IGNITION SYSTEM
70ESL75B 1975	IGNITION SYSTEM
70ESL75E 1975	IGNITION SYSTEM
70ESLR74M 1974	IGNITION SYSTEM
75542B 1975	IGNITION SYSTEM
75543B 1975	IGNITION SYSTEM
75642D 1976	IGNITION SYSTEM
75643D 1976	IGNITION SYSTEM
75742S 1977	IGNITION SYSTEM
75743S 1977	IGNITION SYSTEM
75842C 1978	IGNITION SYSTEM
75843C 1978	IGNITION SYSTEM
75942R 1979	IGNITION SYSTEM
75943R 1979	IGNITION SYSTEM
75ELR76D 1976	IGNITION SYSTEM
75ELR77S 1977	IGNITION SYSTEM
75ELR78C 1978	IGNITION SYSTEM
75ELR79R 1979	IGNITION SYSTEM
75ER76D 1976	IGNITION SYSTEM
75ER77S 1977	IGNITION SYSTEM
75ER78C 1978	IGNITION SYSTEM
75ER79R 1979	IGNITION SYSTEM
75ESLR75B 1975	IGNITION SYSTEM
75ESR75B 1975	IGNITION SYSTEM
85293R 1972	IGNITION SYSTEM
85393M 1973	IGNITION SYSTEM
85493B 1974	IGNITION SYSTEM
85593E 1975	IGNITION SYSTEM
85693D 1976	IGNITION SYSTEM
85693G 1976	IGNITION SYSTEM
85699G 1976	IGNITION SYSTEM

85790S 1977	IGNITION SYSTEM
85793S 1977	IGNITION SYSTEM
85799S 1977	IGNITION SYSTEM
85890C 1978	IGNITION SYSTEM
85895C 1978	IGNITION SYSTEM
85899C 1978	IGNITION SYSTEM
85990R 1979	IGNITION SYSTEM
85995R 1979	IGNITION SYSTEM
85999R 1979	IGNITION SYSTEM
85EL76D 1976	IGNITION SYSTEM
85EL76G 1976	IGNITION SYSTEM
85EL77S 1977	IGNITION SYSTEM
85ESL72R 1972	IGNITION SYSTEM
85ESL73M 1973	IGNITION SYSTEM
85ESL74B 1974	IGNITION SYSTEM
85ESL75E 1975	IGNITION SYSTEM
85ETLR76D 1976	IGNITION SYSTEM
85ETLR76G 1976	IGNITION SYSTEM
85ETLR77S 1977	IGNITION SYSTEM
85ETLR78C 1978	IGNITION SYSTEM
85ML78C 1978	IGNITION SYSTEM
85ML79R 1979	IGNITION SYSTEM
85TL79R 1979	IGNITION SYSTEM
85TXL79R 1979	IGNITION SYSTEM
85TXLR77S 1977	IGNITION SYSTEM
85TXLR78C 1978	IGNITION SYSTEM
90JEEOB 1995	IGNITION SYSTEM
90JEERA 1994	IGNITION SYSTEM
9222M 1972	MAGNETO
9223M 1972	MAGNETO
9322B 1973	MAGNETO
9323B 1973	MAGNETO
9R72M 1972	MAGNETO
9R73B 1973	MAGNETO
9RL72M 1972	MAGNETO

9RL73B 1973	MAGNETO
AM55RSLD 1999	IGNITION SYSTEM
B25JREUR 1997	IGNITION
BE10EEDD 1996	IGNITION - ELECTRIC
BE10EEDD 1996	IGNITION - ROPE
BE10ELEDD 1996	IGNITION - ELECTRIC
BE10ELEDD 1996	IGNITION - ROPE
BE10FAEDC 1996	IGNITION - ELECTRIC
BE10FAEDC 1996	IGNITION - ROPE
BE10FAEUR 1997	IGNITION - ELECTRIC
BE10FAEUR 1997	IGNITION - ROPE
BE10FCLEDC 1996	IGNITION - ELECTRIC
BE10FCLEDC 1996	IGNITION - ROPE
BE10FCLEUR 1997	IGNITION - ELECTRIC
BE10FCLEUR 1997	IGNITION - ROPE
BE10FWEDC 1996	IGNITION - ELECTRIC
BE10FWEDC 1996	IGNITION - ROPE
BE10FWEUR 1997	IGNITION - ELECTRIC
BE10FWEUR 1997	IGNITION - ROPE
BE10FWLEDC 1996	IGNITION - ELECTRIC
BE10FWLEDC 1996	IGNITION - ROPE
BE10FWLEUR 1997	IGNITION - ELECTRIC
BE10FWLEUR 1997	IGNITION - ROPE
BE10REDD 1996	IGNITION - ELECTRIC
BE10REDD 1996	IGNITION - ROPE
BE10RELEDD 1996	IGNITION - ELECTRIC
BE10RELEDD 1996	IGNITION - ROPE
BE10RELEUS 1997	IGNITION - ELECTRIC
BE10RELEUS 1997	IGNITION - ROPE
BE10RLEDD 1996	IGNITION - ELECTRIC
BE10RLEDD 1996	IGNITION - ROPE
BE10SELEDD 1996	IGNITION - ELECTRIC
BE10SELEDD 1996	IGNITION - ROPE
BE115TLEDA 1996	IGNITION SYSTEM
BE130TLECE 1998	IGNITION SYSTEM

BE130TLEDM 1996	IGNITION SYSTEM
BE130TLEUB 1997	IGNITION SYSTEM
BE150ELEDB 1996	IGNITION SYSTEM
BE150ELEUC 1997	IGNITION SYSTEM
BE150ELEUE 1997	IGNITION SYSTEM
BE150EXEDB 1996	IGNITION SYSTEM
BE150XEUC 1997	IGNITION SYSTEM
BE150XEUE 1997	IGNITION SYSTEM
BE150GLEDB 1996	IGNITION SYSTEM
BE150GLEUC 1997	IGNITION SYSTEM
BE150GLEUE 1997	IGNITION SYSTEM
BE150NXEDB 1996	IGNITION SYSTEM
BE150NXEUC 1997	IGNITION SYSTEM
BE150NXEUE 1997	IGNITION SYSTEM
BE15EEDS 1996	IGNITION - ELECTRIC
BE15EEDS 1996	IGNITION - ROPE
BE15ELEDS 1996	IGNITION - ELECTRIC
BE15ELEDS 1996	IGNITION - ROPE
BE15REDS 1996	IGNITION - ELECTRIC
BE15REDS 1996	IGNITION - ROPE
BE15RELEUC 1997	IGNITION - ELECTRIC
BE15RELEUC 1997	IGNITION - ROPE
BE15RLEDS 1996	IGNITION - ELECTRIC
BE15RLEDS 1996	IGNITION - ROPE
BE175EXEDB 1996	IGNITION SYSTEM
BE175XEUC 1997	IGNITION SYSTEM
BE175XEUE 1997	IGNITION SYSTEM
BE175GLEDB 1996	IGNITION SYSTEM
BE175GLEUC 1997	IGNITION SYSTEM
BE175GLEUE 1997	IGNITION SYSTEM
BE175NXEDB 1996	IGNITION SYSTEM
BE175NXEUC 1997	IGNITION SYSTEM
BE175NXEUE 1997	IGNITION SYSTEM
BE200CXECM 1998	IGNITION SYSTEM
BE200CXEDR 1996	IGNITION SYSTEM

BE200CXEUA 1997	IGNITION SYSTEM
BE200TXECM 1998	IGNITION SYSTEM
BE200TXEDR 1996	IGNITION SYSTEM
BE200TXEUA 1997	IGNITION SYSTEM
BE20SEECB 1998	IGNITION
BE20SEEDA 1996	IGNITION
BE20SEEUM 1997	IGNITION
BE20SELECB 1998	IGNITION
BE20SELEDA 1996	IGNITION
BE20SELEUM 1997	IGNITION
BE20SRECB 1998	IGNITION
BE20SREDA 1996	IGNITION
BE20SREUM 1997	IGNITION
BE20SRLECB 1998	IGNITION
BE20SRLEDA 1996	IGNITION
BE20SRLEUM 1997	IGNITION
BE225CXECS 1998	IGNITION SYSTEM
BE225CXEDE 1996	IGNITION SYSTEM
BE225CXEUD 1997	IGNITION SYSTEM
BE225PXEDE 1996	IGNITION SYSTEM
BE225SLECS 1998	IGNITION SYSTEM
BE225SLEDE 1996	IGNITION SYSTEM
BE225SLEUD 1997	IGNITION SYSTEM
BE225TXECS 1998	IGNITION SYSTEM
BE225TXEDE 1996	IGNITION SYSTEM
BE225TXEUD 1997	IGNITION SYSTEM
BE250CXECB 1998	IGNITION SYSTEM & STARTER MOTOR
BE250CXEDA 1996	IGNITION SYSTEM & STARTER MOTOR
BE250CXEUM 1997	IGNITION SYSTEM & STARTER MOTOR
BE250TXECB 1998	IGNITION SYSTEM & STARTER MOTOR
BE250TXEDA 1996	IGNITION SYSTEM & STARTER MOTOR
BE250TXEUM 1997	IGNITION SYSTEM & STARTER MOTOR
BE25BAECM 1998	IGNITION
BE25BAEDR 1996	IGNITION
BE25BAEUA 1997	IGNITION

BE25BALECM 1998	IGNITION
BE25BALEDR 1996	IGNITION
BE25BALEUA 1997	IGNITION
BE25BREDC 1996	IGNITION
BE25BRLEDC 1996	IGNITION
BE25EECE 1998	IGNITION
BE25EEDM 1996	IGNITION
BE25EEUB 1997	IGNITION
BE25ELECE 1998	IGNITION
BE25ELEDM 1996	IGNITION
BE25ELEUB 1997	IGNITION
BE25EREDC 1996	IGNITION
BE25ERLEDC 1996	IGNITION
BE30BAECS 1998	IGNITION
BE30BAEDE 1996	IGNITION
BE30BAEEC 1999	IGNITION
BE30BAEEN 1999	IGNITION
BE30BAEUD 1997	IGNITION
BE30BALECS 1998	IGNITION
BE30BALEDE 1996	IGNITION
BE30BALEUD 1997	IGNITION
BE30BASIA rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION
BE30BASSR Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
BE30EECS 1998	IGNITION
BE30EEDE 1996	IGNITION
BE30EEUD 1997	IGNITION
BE30ELECS 1998	IGNITION
BE30ELEDE 1996	IGNITION
BE30ELEUD 1997	IGNITION
BE3REDS 1996	IGNITION
BE40EECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
BE40EECR 1998	IGNITION SYSTEM -- ROPE START
BE40EEDS 1996	IGNITION SYSTEM - 40 ROPE START
BE40EEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS

BE40EEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
BE40EEUC 1997	IGNITION SYSTEM - ROPE START
BE40EEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
BE40ELECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
BE40ELECR 1998	IGNITION SYSTEM -- ROPE START
BE40ELEDs 1996	IGNITION SYSTEM - 40 ROPE START
BE40ELEDs 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
BE40ELEDs 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
BE40ELEUC 1997	IGNITION SYSTEM - ROPE START
BE40ELEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
BE40TLECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
BE40TLECR 1998	IGNITION SYSTEM -- ROPE START
BE40TLEDs 1996	IGNITION SYSTEM - 40 ROPE START
BE40TLEDs 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
BE40TLEDs 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
BE40TLEUC 1997	IGNITION SYSTEM - ROPE START
BE40TLEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
BE4BREDS 1996	IGNITION
BE4BREUC 1997	IGNITION
BE4BRLEDs 1996	IGNITION
BE4BRLEUC 1997	IGNITION
BE4RDHEDs 1996	MAGNETO
BE4RDHLEDs 1996	MAGNETO
BE4REDS 1996	IGNITION
BE4RLEDs 1996	IGNITION
BE50BEEDs 1996	IGNITION SYSTEM - 40 ROPE START
BE50BEEDs 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
BE50BEEDs 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
BE50BELEDs 1996	IGNITION SYSTEM - 40 ROPE START
BE50BELEDs 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
BE50BELEDs 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
BE50DTLEDc 1996	IGNITION SYSTEM
BE50DTLEDc 1996	IGNITION SYSTEM - E70RNLIB ONLY

BE50DTLEUR 1997	IGNITION SYSTEM
BE50ESECC 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
BE50ESECC 1998	IGNITION SYSTEM -- ROPE START
BE50RLECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
BE50RLECR 1998	IGNITION SYSTEM -- ROPE START
BE50RLEUC 1997	IGNITION SYSTEM - ROPE START
BE50RLEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
BE50TLECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
BE50TLECR 1998	IGNITION SYSTEM -- ROPE START
BE50TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
BE50TLEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
BE50TLEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
BE50TLEUC 1997	IGNITION SYSTEM - ROPE START
BE50TLEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
BE50TSLECC 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
BE50TSLECC 1998	IGNITION SYSTEM -- ROPE START
BE50TSLEUS 1997	IGNITION SYSTEM - ROPE START
BE50TSLEUS 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
BE5DREDS 1996	IGNITION
BE5DREUC 1997	IGNITION
BE5DRLEDS 1996	IGNITION
BE5DRLEUC 1997	IGNITION
BE5FRBECC 1998	IGNITION
BE5FRBEUS 1997	IGNITION
BE5FRBLECC 1998	IGNITION
BE5FRBLEUS 1997	IGNITION
BE60ELEDR 1996	IGNITION SYSTEM
BE60ELEDR 1996	IGNITION SYSTEM - E70RNLIB ONLY
BE60ELEUA 1997	IGNITION SYSTEM
BE60TLECM 1998	IGNITION SYSTEM
BE60TLEDR 1996	IGNITION SYSTEM
BE60TLEDR 1996	IGNITION SYSTEM - E70RNLIB ONLY
BE60TLEUA 1997	IGNITION SYSTEM
BE6DRECR 1998	IGNITION

BE6DREDS 1996	IGNITION
BE6DREUC 1997	IGNITION
BE6DRLECR 1998	IGNITION
BE6DRLEDS 1996	IGNITION
BE6DRLEUC 1997	IGNITION
BE6REDS 1996	IGNITION
BE6RLEDS 1996	IGNITION
BE70ELECB 1998	IGNITION SYSTEM
BE70ELEDA 1996	IGNITION SYSTEM
BE70ELEDA 1996	IGNITION SYSTEM - E70RNLIB ONLY
BE70ELEUM 1997	IGNITION SYSTEM
BE70TLECB 1998	IGNITION SYSTEM
BE70TLEDA 1996	IGNITION SYSTEM
BE70TLEDA 1996	IGNITION SYSTEM - E70RNLIB ONLY
BE70TLEUM 1997	IGNITION SYSTEM
BE8FRBECA 1998	IGNITION -- ELECTRIC
BE8FRBECA 1998	IGNITION -- ROPE
BE8FRBEDC 1996	IGNITION - ELECTRIC
BE8FRBEDC 1996	IGNITION - ROPE
BE8FRBEUR 1997	IGNITION - ELECTRIC
BE8FRBEUR 1997	IGNITION - ROPE
BE8FRBLECA 1998	IGNITION -- ELECTRIC
BE8FRBLECA 1998	IGNITION -- ROPE
BE8FRBLEDC 1996	IGNITION - ELECTRIC
BE8FRBLEDC 1996	IGNITION - ROPE
BE8FRBLEUR 1997	IGNITION - ELECTRIC
BE8FRBLEUR 1997	IGNITION - ROPE
BE8FRBXEDC 1996	IGNITION - ELECTRIC
BE8FRBXEDC 1996	IGNITION - ROPE
BE8FRBXEUR 1997	IGNITION - ELECTRIC
BE8FRBXEUR 1997	IGNITION - ROPE
BE8RCB 1997	IGNITION
BE8RCH 1996	IGNITION
BE8RCLB 1997	IGNITION
BE8RCLH 1996	IGNITION

BE8RCLT 1998	IGNITION
BE8RCT 1998	IGNITION
BE8REDS 1996	IGNITION
BE8RLEDS 1996	IGNITION
BE8SRLEDS 1996	IGNITION
BE90TLEDA 1996	IGNITION SYSTEM
BJ10EEDD 1996	IGNITION - ELECTRIC
BJ10EEDD 1996	IGNITION - ROPE
BJ10ELEDD 1996	IGNITION - ELECTRIC
BJ10ELEDD 1996	IGNITION - ROPE
BJ10FAEDC 1996	IGNITION - ELECTRIC
BJ10FAEDC 1996	IGNITION - ROPE
BJ10FAEUR 1997	IGNITION - ELECTRIC
BJ10FAEUR 1997	IGNITION - ROPE
BJ10FCLEDC 1996	IGNITION - ELECTRIC
BJ10FCLEDC 1996	IGNITION - ROPE
BJ10FCLEUR 1997	IGNITION - ELECTRIC
BJ10FCLEUR 1997	IGNITION - ROPE
BJ10FWEDC 1996	IGNITION - ELECTRIC
BJ10FWEDC 1996	IGNITION - ROPE
BJ10FWEUR 1997	IGNITION - ELECTRIC
BJ10FWEUR 1997	IGNITION - ROPE
BJ10FWLEDC 1996	IGNITION - ELECTRIC
BJ10FWLEDC 1996	IGNITION - ROPE
BJ10FWLEUR 1997	IGNITION - ELECTRIC
BJ10FWLEUR 1997	IGNITION - ROPE
BJ10REDD 1996	IGNITION - ELECTRIC
BJ10REDD 1996	IGNITION - ROPE
BJ10RELEDD 1996	IGNITION - ELECTRIC
BJ10RELEDD 1996	IGNITION - ROPE
BJ10RELEUS 1997	IGNITION - ELECTRIC
BJ10RELEUS 1997	IGNITION - ROPE
BJ10RHLSDA	IGNITION
BJ10RHLSDA - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHLSOR	IGNITION

BJ10RHLSOR - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHLSRC	IGNITION
BJ10RHLSRC - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHLSTS	IGNITION
BJ10RHLSTS - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSDA	IGNITION
BJ10RHSDA - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSOR	IGNITION
BJ10RHSOR - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSRC	IGNITION
BJ10RHSRC - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSTS	IGNITION
BJ10RHSTS - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RLEDD 1996	IGNITION - ELECTRIC
BJ10RLEDD 1996	IGNITION - ROPE
BJ10SELEDD 1996	IGNITION - ELECTRIC
BJ10SELEDD 1996	IGNITION - ROPE
BJ115TLEDA 1996	IGNITION SYSTEM
BJ130PLEED 1999	IGNITION SYSTEM
BJ130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM
BJ130PXED 1999	IGNITION SYSTEM
BJ130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	IGNITION SYSTEM
BJ130TLECE 1998	IGNITION SYSTEM
BJ130TLEDM 1996	IGNITION SYSTEM
BJ130TLEUB 1997	IGNITION SYSTEM
BJ135PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	IGNITION
BJ135VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	IGNITION
BJ150ELEDB 1996	IGNITION SYSTEM
BJ150ELEUC 1997	IGNITION SYSTEM
BJ150ELEUE 1997	IGNITION SYSTEM
BJ150EXEDB 1996	IGNITION SYSTEM
BJ150EXEUC 1997	IGNITION SYSTEM
BJ150EXEUE 1997	IGNITION SYSTEM
BJ150GLEDB 1996	IGNITION SYSTEM
BJ150GLEUC 1997	IGNITION SYSTEM

BJ150GLEUE 1997	IGNITION SYSTEM
BJ150NXEDB 1996	IGNITION SYSTEM
BJ150XEUC 1997	IGNITION SYSTEM
BJ150XEUE 1997	IGNITION SYSTEM
BJ15EEDS 1996	IGNITION - ELECTRIC
BJ15EEDS 1996	IGNITION - ROPE
BJ15ELEDs 1996	IGNITION - ELECTRIC
BJ15ELEDs 1996	IGNITION - ROPE
BJ15REDS 1996	IGNITION - ELECTRIC
BJ15REDS 1996	IGNITION - ROPE
BJ15RELEUC 1997	IGNITION - ELECTRIC
BJ15RELEUC 1997	IGNITION - ROPE
BJ15RLEDs 1996	IGNITION - ELECTRIC
BJ15RLEDs 1996	IGNITION - ROPE
BJ175EXEDB 1996	IGNITION SYSTEM
BJ175XEUC 1997	IGNITION SYSTEM
BJ175XEUE 1997	IGNITION SYSTEM
BJ175GLEDB 1996	IGNITION SYSTEM
BJ175GLEUC 1997	IGNITION SYSTEM
BJ175GLEUE 1997	IGNITION SYSTEM
BJ175NXEDB 1996	IGNITION SYSTEM
BJ175NXEUC 1997	IGNITION SYSTEM
BJ175NXEUE 1997	IGNITION SYSTEM
BJ200CXEDR 1996	IGNITION SYSTEM
BJ200CXEEB 1999	IGNITION SYSTEM
BJ200CXEEN 1999	IGNITION SYSTEM
BJ200CXSSC Elec. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	IGNITION SYSTEM
BJ200PLEEB 1999	IGNITION SYSTEM
BJ200PLEEN 1999	IGNITION SYSTEM
BJ200PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	IGNITION SYSTEM
BJ200PLSSC Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM
BJ200PXEEB 1999	IGNITION SYSTEM
BJ200PXEEB 1999	IGNITION SYSTEM
BJ200PXSSC Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	IGNITION SYSTEM

BJ200TXEDR 1996	IGNITION SYSTEM
BJ200VCSIF elec start, TNT, 25 in , wht, cntr rotate, n/a usa 2001	IGNITION SYSTEM
BJ200VCSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	IGNITION SYSTEM
BJ200VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	IGNITION SYSTEM
BJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	IGNITION SYSTEM
BJ20SEECB 1998	IGNITION
BJ20SEEDA 1996	IGNITION
BJ20SEEUM 1997	IGNITION
BJ20SELECB 1998	IGNITION
BJ20SELEDA 1996	IGNITION
BJ20SELEUM 1997	IGNITION
BJ20SRECB 1998	IGNITION
BJ20SREDA 1996	IGNITION
BJ20SREUM 1997	IGNITION
BJ20SRLECB 1998	IGNITION
BJ20SRLEDA 1996	IGNITION
BJ20SRLEUM 1997	IGNITION
BJ225CXEEC 1999	IGNITION SYSTEM
BJ225CXEEN 1999	IGNITION SYSTEM
BJ225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	IGNITION SYSTEM
BJ225PLEEC 1999	IGNITION SYSTEM
BJ225PLEEN 1999	IGNITION SYSTEM
BJ225PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	IGNITION SYSTEM
BJ225PLSSR Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM
BJ225PXEEC 1999	IGNITION SYSTEM
BJ225PXEEN 1999	IGNITION SYSTEM
BJ225PXSSR Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	IGNITION SYSTEM
BJ225VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	IGNITION SYSTEM
BJ225VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	IGNITION SYSTEM
BJ225VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	IGNITION SYSTEM
BJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	IGNITION SYSTEM
BJ250CXECB 1998	IGNITION SYSTEM & STARTER MOTOR
BJ250CXEDA 1996	IGNITION SYSTEM & STARTER MOTOR
BJ250CXEUM 1997	IGNITION SYSTEM & STARTER MOTOR

BJ250TXECB 1998	IGNITION SYSTEM & STARTER MOTOR
BJ250TXEDA 1996	IGNITION SYSTEM & STARTER MOTOR
BJ250TXEUM 1997	IGNITION SYSTEM & STARTER MOTOR
BJ25BAECM 1998	IGNITION
BJ25BAEDR 1996	IGNITION
BJ25BAEUA 1997	IGNITION
BJ25BALECM 1998	IGNITION
BJ25BALEDR 1996	IGNITION
BJ25BALEUA 1997	IGNITION
BJ25BREDC 1996	IGNITION
BJ25BRLEDC 1996	IGNITION
BJ25EECE 1998	IGNITION
BJ25EEDM 1996	IGNITION
BJ25EEED 1999	IGNITION
BJ25EEEN 1999	IGNITION
BJ25EEUB 1997	IGNITION
BJ25ELECE 1998	IGNITION
BJ25ELEDM 1996	IGNITION
BJ25ELEED 1999	IGNITION
BJ25ELEEN 1999	IGNITION
BJ25ELEUB 1997	IGNITION
BJ25ELSIC elec start, remote, 20 in shaft, n/a usa 2001	IGNITION
BJ25ELSSS Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION
BJ25EREDC 1996	IGNITION
BJ25ERLEDC 1996	IGNITION
BJ25ESIC elec start, remote, 15 in shaft, n/a usa 2001	IGNITION
BJ25ESSS Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION
BJ25EVLSIC elec start, remote, 20 in shaft, wht, n/a usa 2001	IGNITION
BJ25EVSIC elec start, remote, 15 in shaft, wht, n/a usa 2001	IGNITION
BJ30BAECS 1998	IGNITION
BJ30BAEDE 1996	IGNITION
BJ30BAEEC 1999	IGNITION
BJ30BAEEN 1999	IGNITION
BJ30BAEUD 1997	IGNITION
BJ30BALECS 1998	IGNITION

BJ30BALEDE 1996	IGNITION
BJ30BALEUD 1997	IGNITION
BJ30EECS 1998	IGNITION
BJ30EEDE 1996	IGNITION
BJ30EEEC 1999	IGNITION
BJ30EEEN 1999	IGNITION
BJ30EEUD 1997	IGNITION
BJ30ELECS 1998	IGNITION
BJ30ELEDE 1996	IGNITION
BJ30ELEEC 1999	IGNITION
BJ30ELEEN 1999	IGNITION
BJ30ELEUD 1997	IGNITION
BJ30ELSIA elec start, remote, 20 in shaft, n/a usa 2001	IGNITION
BJ30ELSSR Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION
BJ30ESIA elec start, remote, 15 in shaft, n/a usa 2001	IGNITION
BJ30ESSR Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION
BJ30EVLSIA elec start, remote, 20 in shaft, wht, n/a usa 2001	IGNITION
BJ30EVSIA elec start, remote, 15 in shaft, wht, n/a usa 2001	IGNITION
BJ3REDS 1996	IGNITION
BJ40EECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
BJ40EECR 1998	IGNITION SYSTEM -- ROPE START
BJ40EEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ40EEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
BJ40EEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
BJ40EEEA 1999	IGNITION SYSTEM -- ELECTRIC START
BJ40EEEA 1999	IGNITION SYSTEM -- ROPE START
BJ40EEUC 1997	IGNITION SYSTEM - ROPE START
BJ40EEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
BJ40ELECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
BJ40ELECR 1998	IGNITION SYSTEM -- ROPE START
BJ40ELEDs 1996	IGNITION SYSTEM - 40 ROPE START
BJ40ELEDs 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
BJ40ELEDs 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
BJ40ELEEA 1999	IGNITION SYSTEM -- ELECTRIC START

BJ40ELEEA 1999	IGNITION SYSTEM -- ROPE START
BJ40ELEUC 1997	IGNITION SYSTEM - ROPE START
BJ40ELEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
BJ40ELSIF elec start, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ELECTRIC START
BJ40ELSIF elec start, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ELECTRIC START
BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ40ESIF elec start, 15 in shaft, n/a usa 2001	IGNITION SYSTEM - ELECTRIC START
BJ40ESIF elec start, 15 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ELECTRIC START
BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ40PLEEA 1999	IGNITION SYSTEM -- ELECTRIC START
BJ40PLEEA 1999	IGNITION SYSTEM -- ROPE START
BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ELECTRIC START
BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ELECTRIC START
BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ40TLECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
BJ40TLECR 1998	IGNITION SYSTEM -- ROPE START
BJ40TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ40TLEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
BJ40TLEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
BJ40TLEUC 1997	IGNITION SYSTEM - ROPE START
BJ40TLEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
BJ4BREDS 1996	IGNITION
BJ4BREUC 1997	IGNITION
BJ4BRLEDS 1996	IGNITION
BJ4BRLEUC 1997	IGNITION
BJ4RDHEDS 1996	MAGNETO
BJ4RDHLEDs 1996	MAGNETO
BJ4REDS 1996	IGNITION
BJ4RLEDs 1996	IGNITION
BJ50BEEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ50BEEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS

BJ50BEEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
BJ50BELEDs 1996	IGNITION SYSTEM - 40 ROPE START
BJ50BELEDs 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
BJ50BELEDs 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
BJ50DTLEDC 1996	IGNITION SYSTEM
BJ50DTLEDC 1996	IGNITION SYSTEM - E70RNLIB ONLY
BJ50DTLEUR 1997	IGNITION SYSTEM
BJ50EEER 1999	IGNITION SYSTEM -- ELECTRIC START
BJ50EEER 1999	IGNITION SYSTEM -- ROPE START
BJ50ELEER 1999	IGNITION SYSTEM -- ELECTRIC START
BJ50ELEER 1999	IGNITION SYSTEM -- ROPE START
BJ50ELSIF elec start, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ELECTRIC START
BJ50ELSIF elec start, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ELECTRIC START
BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ50ESECC 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
BJ50ESECC 1998	IGNITION SYSTEM -- ROPE START
BJ50ESIF elec start, 15 in shaft, n/a usa 2001	IGNITION SYSTEM - ELECTRIC START
BJ50ESIF elec start, 15 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ELECTRIC START
BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ50PLEEA 1999	IGNITION SYSTEM -- ELECTRIC START
BJ50PLEEA 1999	IGNITION SYSTEM -- ROPE START
BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ELECTRIC START
BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ELECTRIC START
BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ50RLECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
BJ50RLECR 1998	IGNITION SYSTEM -- ROPE START
BJ50RLEEA 1999	IGNITION SYSTEM -- ELECTRIC START
BJ50RLEEA 1999	IGNITION SYSTEM -- ROPE START
BJ50RLEUC 1997	IGNITION SYSTEM - ROPE START
BJ50RLEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
BJ50RLSIF elec start, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ELECTRIC START

BJ50RLSIF elec start, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ELECTRIC START
BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ50TLECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
BJ50TLECR 1998	IGNITION SYSTEM -- ROPE START
BJ50TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ50TLEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
BJ50TLEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
BJ50TLEUC 1997	IGNITION SYSTEM - ROPE START
BJ50TLEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
BJ50TSLECC 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
BJ50TSLECC 1998	IGNITION SYSTEM -- ROPE START
BJ50TSLEUS 1997	IGNITION SYSTEM - ROPE START
BJ50TSLEUS 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
BJ5DREDS 1996	IGNITION
BJ5DREUC 1997	IGNITION
BJ5DRLEDS 1996	IGNITION
BJ5DRLEUC 1997	IGNITION
BJ5FRBECC 1998	IGNITION
BJ5FRBEUS 1997	IGNITION
BJ5FRBLECC 1998	IGNITION
BJ5FRBLEUS 1997	IGNITION
BJ60ELEDR 1996	IGNITION SYSTEM
BJ60ELEDR 1996	IGNITION SYSTEM - E70RNLIB ONLY
BJ60ELEUA 1997	IGNITION SYSTEM
BJ60TLECM 1998	IGNITION SYSTEM
BJ60TLEDR 1996	IGNITION SYSTEM
BJ60TLEDR 1996	IGNITION SYSTEM - E70RNLIB ONLY
BJ60TLEUA 1997	IGNITION SYSTEM
BJ6DRECR 1998	IGNITION
BJ6DREDS 1996	IGNITION
BJ6DREUC 1997	IGNITION
BJ6DRLECR 1998	IGNITION
BJ6DRLEDS 1996	IGNITION

BJ6DRLEUC 1997	IGNITION
BJ6REDS 1996	IGNITION
BJ6RLEDS 1996	IGNITION
BJ70ELECB 1998	IGNITION SYSTEM
BJ70ELED A 1996	IGNITION SYSTEM
BJ70ELED A 1996	IGNITION SYSTEM - E70RNLIB ONLY
BJ70ELEUM 1997	IGNITION SYSTEM
BJ70PLEEE 1999	IGNITION SYSTEM
BJ70PLSIS elec start, TNT, 20 in shaft, n/a usa 2001	IGNITION SYSTEM
BJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM
BJ70TLECB 1998	IGNITION SYSTEM
BJ70TLEDA 1996	IGNITION SYSTEM
BJ70TLEDA 1996	IGNITION SYSTEM - E70RNLIB ONLY
BJ70TLEUM 1997	IGNITION SYSTEM
BJ8FRBECA 1998	IGNITION -- ELECTRIC
BJ8FRBECA 1998	IGNITION -- ROPE
BJ8FRBEDC 1996	IGNITION - ELECTRIC
BJ8FRBEDC 1996	IGNITION - ROPE
BJ8FRBEUR 1997	IGNITION - ELECTRIC
BJ8FRBEUR 1997	IGNITION - ROPE
BJ8FRBLECA 1998	IGNITION -- ELECTRIC
BJ8FRBLECA 1998	IGNITION -- ROPE
BJ8FRBLEDC 1996	IGNITION - ELECTRIC
BJ8FRBLEDC 1996	IGNITION - ROPE
BJ8FRBLEUR 1997	IGNITION - ELECTRIC
BJ8FRBLEUR 1997	IGNITION - ROPE
BJ8FRBXEDC 1996	IGNITION - ELECTRIC
BJ8FRBXEDC 1996	IGNITION - ROPE
BJ8FRBXEUR 1997	IGNITION - ELECTRIC
BJ8FRBXEUR 1997	IGNITION - ROPE
BJ8RCB 1997	IGNITION
BJ8RCH 1996	IGNITION
BJ8RCLB 1997	IGNITION
BJ8RCLH 1996	IGNITION
BJ8RCLT 1998	IGNITION

BJ8RCT 1998	IGNITION
BJ8REDS 1996	IGNITION
BJ8RLEDS 1996	IGNITION
BJ8SRLEDS 1996	IGNITION
BJ90TLEDA 1996	IGNITION SYSTEM
C155WTLM 1988	IGNITION SYSTEM - 35 AMP
C155WTXM 1988	IGNITION SYSTEM - 35 AMP
CE275TLCDC 1986	IGNITION SYSTEM - 35 AMP
CE275TLCOS 1985	IGNITION SYSTEM - 35 AMP
CE275TXCDC 1986	IGNITION SYSTEM - 35 AMP
CE275TXCOS 1985	IGNITION SYSTEM - 35 AMP
CE300TLCDC 1986	IGNITION SYSTEM - 35 AMP
CE300TLCOS 1985	IGNITION SYSTEM - 35 AMP
CE300TXCDC 1986	IGNITION SYSTEM - 35 AMP
CE300TXCOS 1985	IGNITION SYSTEM - 35 AMP
CJ275TLCDC 1986	IGNITION SYSTEM - 35 AMP
CJ275TLCOS 1985	IGNITION SYSTEM - 35 AMP
CJ275TXCDC 1986	IGNITION SYSTEM - 35 AMP
CJ275TXCOS 1985	IGNITION SYSTEM - 35 AMP
CJ300TLCDC 1986	IGNITION SYSTEM - 35 AMP
CJ300TLCOS 1985	IGNITION SYSTEM - 35 AMP
CJ300TXCDC 1986	IGNITION SYSTEM - 35 AMP
CJ300TXCOS 1985	IGNITION SYSTEM - 35 AMP
D100WTLM 1988	IGNITION SYSTEM
D100WTXM 1988	IGNITION SYSTEM
D25RWA 1988	MAGNETO
D25RWLA 1988	MAGNETO
E100MLCSC 1980	IGNITION SYSTEM
E100STLCCA 1988	IGNITION SYSTEM
E100STLCEM 1989	IGNITION SYSTEM
E100STLEIE 1991	IGNITION SYSTEM
E100STLEND 1992	IGNITION SYSTEM
E100STLERC 1994	IGNITION SYSTEM
E100STLESB 1990	IGNITION SYSTEM
E100STLETS 1993	IGNITION SYSTEM

E100TLCSC 1980	IGNITION SYSTEM
E100TXCSC 1980	IGNITION SYSTEM
E100WMLCDR 1986	IGNITION SYSTEM
E100WMLCOC 1985	IGNITION SYSTEM
E100WMLCRS 1984	IGNITION SYSTEM
E100WTLCDR 1986	IGNITION SYSTEM
E100WTLCOG 1985	IGNITION SYSTEM
E100WTLCRS 1984	IGNITION SYSTEM
E100WTLCUA 1987	IGNITION SYSTEM
E100WTLEDR 1996	IGNITION SYSTEM
E100WTLEIB 1991	IGNITION SYSTEM
E100WTLENE 1992	IGNITION SYSTEM
E100WTLEOC 1995	IGNITION SYSTEM
E100WTLERS 1994	IGNITION SYSTEM
E100WTLESM 1990	IGNITION SYSTEM
E100WTLETD 1993	IGNITION SYSTEM
E100WTLEUA 1997	IGNITION SYSTEM
E100WTLZ 1989	IGNITION SYSTEM
E100WTXCDCR 1986	IGNITION SYSTEM
E100WTXCUA 1987	IGNITION SYSTEM
E100WTXEDR 1996	IGNITION SYSTEM
E100WTXEIB 1991	IGNITION SYSTEM
E100WTXENE 1992	IGNITION SYSTEM
E100WTXEOG 1995	IGNITION SYSTEM
E100WTXERS 1994	IGNITION SYSTEM
E100WTXESM 1990	IGNITION SYSTEM
E100WTXETD 1993	IGNITION SYSTEM
E100WTXEUA 1997	IGNITION SYSTEM
E100WTXZ 1989	IGNITION SYSTEM
E10ECCD 1988	IGNITION
E10ECDB 1986	IGNITION
E10ECES 1989	IGNITION
E10ECOM 1985	IGNITION
E10ECSE 1980	MAGNETO
E10ECUE 1987	IGNITION

E10EECC 1998	IGNITION -- ELECTRIC
E10EECC 1998	IGNITION -- ROPE
E10EEDD 1996	IGNITION - ELECTRIC
E10EEDD 1996	IGNITION - ROPE
E10EEIR 1991	IGNITION
E10EENA 1992	IGNITION
E10EEOE 1995	IGNITION - ELECTRIC
E10EEOE 1995	IGNITION - ROPE
E10EERB 1994	IGNITION - ELECTRIC
E10EERB 1994	IGNITION - ROPE
E10EESC 1990	IGNITION
E10EETM 1993	IGNITION - ELECTRIC
E10EETM 1993	IGNITION - ROPE
E10EEUS 1997	IGNITION - ELECTRIC
E10EEUS 1997	IGNITION - ROPE
E10ELCCD 1988	IGNITION
E10ELCDB 1986	IGNITION
E10ELCES 1989	IGNITION
E10ELCID 1981	MAGNETO
E10ELCNS 1982	MAGNETO
E10ELCOM 1985	IGNITION
E10ELCRA 1984	MAGNETO
E10ELCSE 1980	MAGNETO
E10ELCTC 1983	MAGNETO
E10ELCUE 1987	IGNITION
E10ELECC 1998	IGNITION -- ELECTRIC
E10ELECC 1998	IGNITION -- ROPE
E10ELEDD 1996	IGNITION - ELECTRIC
E10ELEDD 1996	IGNITION - ROPE
E10ELEIR 1991	IGNITION
E10ELENA 1992	IGNITION
E10ELEOE 1995	IGNITION - ELECTRIC
E10ELEOE 1995	IGNITION - ROPE
E10ELERB 1994	IGNITION - ELECTRIC
E10ELERB 1994	IGNITION - ROPE

E10ELESC 1990	IGNITION
E10ELETM 1993	IGNITION - ELECTRIC
E10ELETM 1993	IGNITION - ROPE
E10ELEUS 1997	IGNITION - ELECTRIC
E10ELEUS 1997	IGNITION - ROPE
E10FOECA 1998	IGNITION -- ELECTRIC
E10FOECA 1998	IGNITION -- ROPE
E10FOLECA 1998	IGNITION -- ELECTRIC
E10FOLECA 1998	IGNITION -- ROPE
E10RCCD 1988	IGNITION
E10RCDB 1986	IGNITION
E10RCES 1989	IGNITION
E10RCID 1981	MAGNETO
E10RCNS 1982	MAGNETO
E10RCOM 1985	IGNITION
E10RCRA 1984	MAGNETO
E10RCSE 1980	MAGNETO
E10RCTC 1983	MAGNETO
E10RCTR 1983	MAGNETO
E10RCUE 1987	IGNITION
E10RECC 1998	IGNITION -- ELECTRIC
E10RECC 1998	IGNITION -- ROPE
E10REDD 1996	IGNITION - ELECTRIC
E10REDD 1996	IGNITION - ROPE
E10REIR 1991	IGNITION
E10RELECC 1998	IGNITION -- ELECTRIC
E10RELECC 1998	IGNITION -- ROPE
E10RELEDD 1996	IGNITION - ELECTRIC
E10RELEDD 1996	IGNITION - ROPE
E10RELEIR 1991	IGNITION
E10RELENA 1992	IGNITION
E10RELEOE 1995	IGNITION - ELECTRIC
E10RELEOE 1995	IGNITION - ROPE
E10RELERB 1994	IGNITION - ELECTRIC
E10RELERB 1994	IGNITION - ROPE

E10RELESC 1990	IGNITION
E10RELETM 1993	IGNITION - ELECTRIC
E10RELETM 1993	IGNITION - ROPE
E10RELEUS 1997	IGNITION - ELECTRIC
E10RELEUS 1997	IGNITION - ROPE
E10RENA 1992	IGNITION
E10REOE 1995	IGNITION - ELECTRIC
E10REOE 1995	IGNITION - ROPE
E10RERB 1994	IGNITION - ELECTRIC
E10RERB 1994	IGNITION - ROPE
E10RESC 1990	IGNITION
E10RETM 1993	IGNITION - ELECTRIC
E10RETM 1993	IGNITION - ROPE
E10REUS 1997	IGNITION - ELECTRIC
E10REUS 1997	IGNITION - ROPE
E10RLCCD 1988	IGNITION
E10RLCDB 1986	IGNITION
E10RLCES 1989	IGNITION
E10RLCID 1981	MAGNETO
E10RLCNS 1982	MAGNETO
E10RLCOM 1985	IGNITION
E10RLCRA 1984	MAGNETO
E10RLCSE 1980	MAGNETO
E10RLCTC 1983	MAGNETO
E10RLCUE 1987	IGNITION
E10RLECC 1998	IGNITION -- ELECTRIC
E10RLECC 1998	IGNITION -- ROPE
E10RLEDD 1996	IGNITION - ELECTRIC
E10RLEDD 1996	IGNITION - ROPE
E10RLEIR 1991	IGNITION
E10RLENA 1992	IGNITION
E10RLEOE 1995	IGNITION - ELECTRIC
E10RLEOE 1995	IGNITION - ROPE
E10RLERB 1994	IGNITION - ELECTRIC
E10RLERB 1994	IGNITION - ROPE

E10RLESC 1990	IGNITION
E10RLETM 1993	IGNITION - ELECTRIC
E10RLETM 1993	IGNITION - ROPE
E10RLEUS 1997	IGNITION - ELECTRIC
E10RLEUS 1997	IGNITION - ROPE
E10SELCCD 1988	IGNITION
E10SELCDB 1986	IGNITION
E10SELCES 1989	IGNITION
E10SELCID 1981	MAGNETO
E10SELCNS 1982	MAGNETO
E10SELCOM 1985	IGNITION
E10SELCRA 1984	MAGNETO
E10SELCSE 1980	MAGNETO
E10SELCTC 1983	MAGNETO
E10SELCUE 1987	IGNITION
E10SELECC 1998	IGNITION -- ELECTRIC
E10SELECC 1998	IGNITION -- ROPE
E10SELEDD 1996	IGNITION - ELECTRIC
E10SELEDD 1996	IGNITION - ROPE
E10SELEIR 1991	IGNITION
E10SELENA 1992	IGNITION
E10SELEOE 1995	IGNITION - ELECTRIC
E10SELEOE 1995	IGNITION - ROPE
E10SELERB 1994	IGNITION - ELECTRIC
E10SELERB 1994	IGNITION - ROPE
E10SELESC 1990	IGNITION
E10SELETM 1993	IGNITION - ELECTRIC
E10SELETM 1993	IGNITION - ROPE
E10SELEUS 1997	IGNITION - ELECTRIC
E10SELEUS 1997	IGNITION - ROPE
E110MLCCA 1988	IGNITION SYSTEM
E110MLCDC 1986	IGNITION SYSTEM
E110MLCEM 1989	IGNITION SYSTEM
E110MLCUR 1987	IGNITION SYSTEM
E110TLCCA 1988	IGNITION SYSTEM

E110TLCDC 1986	IGNITION SYSTEM
E110TLCDF 1986	IGNITION SYSTEM
E110TLCEM 1989	IGNITION SYSTEM
E110TLCUR 1987	IGNITION SYSTEM
E110TXCCA 1988	IGNITION SYSTEM
E110TXCEM 1989	IGNITION SYSTEM
E110TXCUR 1987	IGNITION SYSTEM
E112TSLEDR 1996	IGNITION SYSTEM
E112TSLEOC 1995	IGNITION SYSTEM
E112TSLERS 1994	IGNITION SYSTEM
E112TSXEDR 1996	IGNITION SYSTEM
E112TSXEOC 1995	IGNITION SYSTEM
E112TSXERS 1994	IGNITION SYSTEM
E115JKLEOC 1995	IGNITION SYSTEM
E115JKLERS 1994	IGNITION SYSTEM
E115JLEDA 1996	IGNITION SYSTEM
E115JLEIE 1991	IGNITION SYSTEM
E115JLEND 1992	IGNITION SYSTEM
E115JLEOR 1995	IGNITION SYSTEM
E115JLERC 1994	IGNITION SYSTEM
E115JLETS 1993	IGNITION SYSTEM
E115JLEUM 1997	IGNITION SYSTEM
E115MLCIH 1981	IGNITION SYSTEM
E115MLCIM 1981	IGNITION SYSTEM
E115MLCNB 1982	IGNITION SYSTEM
E115MLCOS 1985	IGNITION SYSTEM
E115MLCRD 1984	IGNITION SYSTEM
E115MLCSA 1980	IGNITION SYSTEM
E115MLCTE 1983	IGNITION SYSTEM
E115MLEIE 1991	IGNITION SYSTEM
E115MLEND 1992	IGNITION SYSTEM
E115MLEOR 1995	IGNITION SYSTEM
E115MLERS 1994	IGNITION SYSTEM
E115MLESB 1990	IGNITION SYSTEM
E115MLETS 1993	IGNITION SYSTEM

E115TLCIH 1981	IGNITION SYSTEM
E115TLCIM 1981	IGNITION SYSTEM
E115TLCNB 1982	IGNITION SYSTEM
E115TLCOS 1985	IGNITION SYSTEM
E115TLCRD 1984	IGNITION SYSTEM
E115TLCSA 1980	IGNITION SYSTEM
E115TLCTE 1983	IGNITION SYSTEM
E115TLEDA 1996	IGNITION SYSTEM
E115TLEIE 1991	IGNITION SYSTEM
E115TLEND 1992	IGNITION SYSTEM
E115TLEOR 1995	IGNITION SYSTEM
E115TLERC 1994	IGNITION SYSTEM
E115TLESB 1990	IGNITION SYSTEM
E115TLETS 1993	IGNITION SYSTEM
E115TSLECM 1998	IGNITION SYSTEM
E115TSLEUA 1997	IGNITION SYSTEM
E115TSXECM 1998	IGNITION SYSTEM
E115TSXEUA 1997	IGNITION SYSTEM
E115TXADA 1996	IGNITION SYSTEM
E115TXAOR 1995	IGNITION SYSTEM
E115TXARS 1994	IGNITION SYSTEM
E115TXATS 1993	IGNITION SYSTEM
E115TXCIH 1981	IGNITION SYSTEM
E115TXCIM 1981	IGNITION SYSTEM
E115TXCNB 1982	IGNITION SYSTEM
E115TXCRD 1984	IGNITION SYSTEM
E115TXCSA 1980	IGNITION SYSTEM
E115TXCTE 1983	IGNITION SYSTEM
E115TXEIE 1991	IGNITION SYSTEM
E115TXEND 1992	IGNITION SYSTEM
E115TXESB 1990	IGNITION SYSTEM
E120TLCCA 1988	IGNITION SYSTEM & STARTER MOTOR
E120TLCDC 1986	IGNITION SYSTEM
E120TLCEM 1989	IGNITION SYSTEM & STARTER MOTOR
E120TLCOS 1985	IGNITION SYSTEM

E120TLCUR 1987	IGNITION SYSTEM
E120TLEIE 1991	IGNITION SYSTEM & STARTER MOTOR
E120TLEND 1992	IGNITION SYSTEM & STARTER MOTOR
E120TLERC 1994	IGNITION SYSTEM
E120TLERK 1994	IGNITION SYSTEM
E120TLESB 1990	IGNITION SYSTEM & STARTER MOTOR
E120TLETF 1993	IGNITION SYSTEM & STARTER MOTOR
E120TLETS 1993	IGNITION SYSTEM & STARTER MOTOR
E120TXARC 1994	IGNITION SYSTEM
E120TXARK 1994	IGNITION SYSTEM
E120TXATF 1993	IGNITION SYSTEM & STARTER MOTOR
E120TXATS 1993	IGNITION SYSTEM & STARTER MOTOR
E120TXCCA 1988	IGNITION SYSTEM & STARTER MOTOR
E120TXCDC 1986	IGNITION SYSTEM
E120TXCEM 1989	IGNITION SYSTEM & STARTER MOTOR
E120XCCOS 1985	IGNITION SYSTEM
E120TXCUR 1987	IGNITION SYSTEM
E120TXEIE 1991	IGNITION SYSTEM & STARTER MOTOR
E120TXEND 1992	IGNITION SYSTEM & STARTER MOTOR
E120TXERC 1994	IGNITION SYSTEM
E120TXERK 1994	IGNITION SYSTEM
E120TXESB 1990	IGNITION SYSTEM & STARTER MOTOR
E120TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
E120TXETS 1993	IGNITION SYSTEM & STARTER MOTOR
E125ESXENR 1992	IGNITION SYSTEM & STARTER MOTOR
E125ESXERK 1994	IGNITION SYSTEM
E125ESXESS 1990	IGNITION SYSTEM & STARTER MOTOR
E125ESXETA 1993	IGNITION SYSTEM & STARTER MOTOR
E125ESXETF 1993	IGNITION SYSTEM & STARTER MOTOR
E125ESXW 1989	IGNITION SYSTEM & STARTER MOTOR
E125WTPLE 1995	IGNITION SYSTEM
E130CXAOR 1995	IGNITION SYSTEM
E130TLECE 1998	IGNITION SYSTEM
E130TLEDM 1996	IGNITION SYSTEM
E130TLEOA 1995	IGNITION SYSTEM

E130TLEUB 1997	IGNITION SYSTEM
E130TXACB 1998	IGNITION SYSTEM
E130TXADA 1996	IGNITION SYSTEM
E130TXAOR 1995	IGNITION SYSTEM
E130TXAUM 1997	IGNITION SYSTEM
E140CXARC 1994	IGNITION SYSTEM
E140CXARK 1994	IGNITION SYSTEM
E140CXATF 1993	IGNITION SYSTEM & STARTER MOTOR
E140CXATS 1993	IGNITION SYSTEM & STARTER MOTOR
E140CXCCS 1988	IGNITION SYSTEM & STARTER MOTOR
E140CXCEC 1989	IGNITION SYSTEM & STARTER MOTOR
E140CXEIA 1991	IGNITION SYSTEM & STARTER MOTOR
E140CXENM 1992	IGNITION SYSTEM & STARTER MOTOR
E140CXERE 1994	IGNITION SYSTEM
E140CXERK 1994	IGNITION SYSTEM
E140CXESR 1990	IGNITION SYSTEM & STARTER MOTOR
E140CXETB 1993	IGNITION SYSTEM & STARTER MOTOR
E140CXETF 1993	IGNITION SYSTEM & STARTER MOTOR
E140MLCIH 1981	IGNITION SYSTEM
E140MLCIM 1981	IGNITION SYSTEM
E140MLCNB 1982	IGNITION SYSTEM
E140MLCSA 1980	IGNITION SYSTEM
E140MLCTE 1983	IGNITION SYSTEM
E140TLATC 1993	IGNITION SYSTEM & STARTER MOTOR
E140TLATF 1993	IGNITION SYSTEM & STARTER MOTOR
E140TLCCM 1988	IGNITION SYSTEM & STARTER MOTOR
E140TLCDC 1986	IGNITION SYSTEM
E140TLCEB 1989	IGNITION SYSTEM & STARTER MOTOR
E140TLCOS 1985	IGNITION SYSTEM
E140TLCRD 1984	IGNITION SYSTEM
E140TLCUA 1987	IGNITION SYSTEM
E140TLEID 1991	IGNITION SYSTEM & STARTER MOTOR
E140TLENS 1992	IGNITION SYSTEM & STARTER MOTOR
E140TLERK 1994	IGNITION SYSTEM
E140TLERR 1994	IGNITION SYSTEM

E140TLESE 1990	IGNITION SYSTEM & STARTER MOTOR
E140TLETC 1993	IGNITION SYSTEM & STARTER MOTOR
E140TLETF 1993	IGNITION SYSTEM & STARTER MOTOR
E140TRLCIH 1981	IGNITION SYSTEM
E140TRLCIM 1981	IGNITION SYSTEM
E140TRLCNB 1982	IGNITION SYSTEM
E140TRLCSA 1980	IGNITION SYSTEM
E140TRLCTE 1983	IGNITION SYSTEM
E140TRXCIH 1981	IGNITION SYSTEM
E140TRXCIM 1981	IGNITION SYSTEM
E140TRXCNB 1982	IGNITION SYSTEM
E140TRXCSA 1980	IGNITION SYSTEM
E140TRXCTE 1983	IGNITION SYSTEM
E140TXARC 1994	IGNITION SYSTEM
E140TXARK 1994	IGNITION SYSTEM
E140TXATF 1993	IGNITION SYSTEM & STARTER MOTOR
E140TXATS 1993	IGNITION SYSTEM & STARTER MOTOR
E140TXCCM 1988	IGNITION SYSTEM & STARTER MOTOR
E140TXCDC 1986	IGNITION SYSTEM
E140TXCEB 1989	IGNITION SYSTEM & STARTER MOTOR
E140TXCOS 1985	IGNITION SYSTEM
E140TXCRD 1984	IGNITION SYSTEM
E140TXCUA 1987	IGNITION SYSTEM
E140TXEID 1991	IGNITION SYSTEM & STARTER MOTOR
E140TXENS 1992	IGNITION SYSTEM & STARTER MOTOR
E140TXERK 1994	IGNITION SYSTEM
E140TXERR 1994	IGNITION SYSTEM
E140TXESE 1990	IGNITION SYSTEM & STARTER MOTOR
E140TXETC 1993	IGNITION SYSTEM & STARTER MOTOR
E140TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
E150ANCRS 1984	IGNITION SYSTEM
E150CXCCA 1988	IGNITION SYSTEM
E150CXCEM 1989	IGNITION SYSTEM - 150 MODELS
E150CXCEM 1989	IGNITION SYSTEM - 175 MODELS
E150CXEIE 1991	IGNITION SYSTEM - 150 MODELS

E150CXEIE 1991	IGNITION SYSTEM - 175 MODELS
E150CXESB 1990	IGNITION SYSTEM - 150 MODELS
E150CXESB 1990	IGNITION SYSTEM - 175 MODELS
E150ELEDB 1996	IGNITION SYSTEM
E150ELEIS 1991	IGNITION SYSTEM
E150ELENC 1992	IGNITION SYSTEM
E150ELEUC 1997	IGNITION SYSTEM
E150ELEUE 1997	IGNITION SYSTEM
E150EXEDB 1996	IGNITION SYSTEM
E150XEIS 1991	IGNITION SYSTEM
E150XENC 1992	IGNITION SYSTEM
E150XEUC 1997	IGNITION SYSTEM
E150XEUE 1997	IGNITION SYSTEM
E150GLEDB 1996	IGNITION SYSTEM
E150GLEIS 1991	IGNITION SYSTEM
E150GLENC 1992	IGNITION SYSTEM
E150GLEUC 1997	IGNITION SYSTEM
E150GLEUE 1997	IGNITION SYSTEM
E150JLEDB 1996	IGNITION SYSTEM
E150JLEIE 1991	IGNITION SYSTEM - 150 MODELS
E150JLEIE 1991	IGNITION SYSTEM - 175 MODELS
E150JLENC 1992	IGNITION SYSTEM
E150JLEUC 1997	IGNITION SYSTEM
E150JLEUE 1997	IGNITION SYSTEM
E150NXEDB 1996	IGNITION SYSTEM
E150NXEIS 1991	IGNITION SYSTEM
E150NXENC 1992	IGNITION SYSTEM
E150NXEUC 1997	IGNITION SYSTEM
E150NXEUE 1997	IGNITION SYSTEM
E150SLEDB 1996	IGNITION SYSTEM
E150SLEUC 1997	IGNITION SYSTEM
E150SLEUE 1997	IGNITION SYSTEM
E150STLCCA 1988	IGNITION SYSTEM
E150STLCDC 1986	IGNITION SYSTEM
E150STLCEM 1989	IGNITION SYSTEM

E150STLCOH 1985	IGNITION SYSTEM
E150STLCOS 1985	IGNITION SYSTEM
E150STLCRD 1984	IGNITION SYSTEM
E150STLCTE 1983	IGNITION SYSTEM
E150STLCUR 1987	IGNITION SYSTEM
E150STLEIE 1991	IGNITION SYSTEM
E150STLESB 1990	IGNITION SYSTEM
E150TLCCA 1988	IGNITION SYSTEM
E150TLCDC 1986	IGNITION SYSTEM
E150TLCEM 1989	IGNITION SYSTEM - 150 MODELS
E150TLCEM 1989	IGNITION SYSTEM - 175 MODELS
E150TLCOS 1985	IGNITION SYSTEM
E150TLCRD 1984	IGNITION SYSTEM
E150TLCUR 1987	IGNITION SYSTEM
E150TLEIE 1991	IGNITION SYSTEM - 150 MODELS
E150TLEIE 1991	IGNITION SYSTEM - 175 MODELS
E150TLESB 1990	IGNITION SYSTEM - 150 MODELS
E150TLESB 1990	IGNITION SYSTEM - 175 MODELS
E150TRLCIA 1981	IGNITION SYSTEM
E150TRLCIH 1981	IGNITION SYSTEM
E150TRLCNM 1982	IGNITION SYSTEM
E150TRLCSF 1980	IGNITION SYSTEM
E150TRLC SR 1980	IGNITION SYSTEM
E150TRLCTB 1983	IGNITION SYSTEM
E150TRLCTE 1983	IGNITION SYSTEM
E150TRXCIA 1981	IGNITION SYSTEM
E150TRXCIH 1981	IGNITION SYSTEM
E150TRXCNM 1982	IGNITION SYSTEM
E150TRXCSF 1980	IGNITION SYSTEM
E150TRXCSR 1980	IGNITION SYSTEM
E150TRXCTB 1983	IGNITION SYSTEM
E150TRXCTE 1983	IGNITION SYSTEM
E150TXCCA 1988	IGNITION SYSTEM
E150TXCDC 1986	IGNITION SYSTEM
E150TXCEM 1989	IGNITION SYSTEM - 150 MODELS

E150TXCEM 1989	IGNITION SYSTEM - 175 MODELS
E150TXCOS 1985	IGNITION SYSTEM
E150TXCRD 1984	IGNITION SYSTEM
E150TXCUR 1987	IGNITION SYSTEM
E150TXEIE 1991	IGNITION SYSTEM - 150 MODELS
E150TXEIE 1991	IGNITION SYSTEM - 175 MODELS
E150TXESB 1990	IGNITION SYSTEM - 150 MODELS
E150TXESB 1990	IGNITION SYSTEM - 175 MODELS
E150WTLEOR 1995	IGNITION SYSTEM
E150WTLERC 1994	IGNITION SYSTEM
E150WTLERV 1994	IGNITION SYSTEM
E150WTLETG 1993	IGNITION SYSTEM
E150WTLETS 1993	IGNITION SYSTEM
E150WTXEOR 1995	IGNITION SYSTEM
E150WTXERC 1994	IGNITION SYSTEM
E150WTXERV 1994	IGNITION SYSTEM
E150WTXETG 1993	IGNITION SYSTEM
E150WTXETS 1993	IGNITION SYSTEM
E155WTLCDR 1986	IGNITION SYSTEM - 35 AMP
E155WTLCOG 1985	IGNITION SYSTEM - 35 AMP
E155WTLCRS 1984	IGNITION SYSTEM - 35 AMP
E155WTLCUA 1987	IGNITION SYSTEM - 35 AMP
E155WTLEIB 1991	IGNITION SYSTEM - 35 AMP
E155WTLENE 1992	IGNITION SYSTEM - 35 AMP
E155WTLESM 1990	IGNITION SYSTEM - 35 AMP
E155WTLZ 1989	IGNITION SYSTEM - 35 AMP
E155WTXCDR 1986	IGNITION SYSTEM - 35 AMP
E155WTXCOC 1985	IGNITION SYSTEM - 35 AMP
E155WTXCRS 1984	IGNITION SYSTEM - 35 AMP
E155WTXCUA 1987	IGNITION SYSTEM - 35 AMP
E155WTXEIB 1991	IGNITION SYSTEM - 35 AMP
E155WTXENE 1992	IGNITION SYSTEM - 35 AMP
E155WTXESM 1990	IGNITION SYSTEM - 35 AMP
E155WTXZ 1989	IGNITION SYSTEM - 35 AMP
E15ECCS 1988	IGNITION

E15ECDE 1986	IGNITION
E15ECEC 1989	IGNITION
E15ECIS 1981	MAGNETO
E15ECNC 1982	MAGNETO
E15ECOB 1985	IGNITION
E15ECRM 1984	MAGNETO
E15ECSD 1980	MAGNETO
E15ECTR 1983	MAGNETO
E15ECUD 1987	IGNITION
E15EECR 1998	IGNITION -- ELECTRIC
E15EECR 1998	IGNITION -- ROPE
E15EEDS 1996	IGNITION - ELECTRIC
E15EEDS 1996	IGNITION - ROPE
E15EEIA 1991	IGNITION
E15EENM 1992	IGNITION
E15EEOD 1995	IGNITION - ELECTRIC
E15EEOD 1995	IGNITION - ROPE
E15EERE 1994	IGNITION - ELECTRIC
E15EERE 1994	IGNITION - ROPE
E15EESR 1990	IGNITION
E15EETB 1993	IGNITION - ELECTRIC
E15EETB 1993	IGNITION - ROPE
E15EEUC 1997	IGNITION - ELECTRIC
E15EEUC 1997	IGNITION - ROPE
E15ELCCS 1988	IGNITION
E15ELCDE 1986	IGNITION
E15ELCEC 1989	IGNITION
E15ELCOB 1985	IGNITION
E15ELCRM 1984	MAGNETO
E15ELCSD 1980	MAGNETO
E15ELCTR 1983	MAGNETO
E15ELCUD 1987	IGNITION
E15ELECR 1998	IGNITION -- ELECTRIC
E15ELECR 1998	IGNITION -- ROPE
E15ELEDS 1996	IGNITION - ELECTRIC

E15ELED5 1996	IGNITION - ROPE
E15ELEIA 1991	IGNITION
E15ELENM 1992	IGNITION
E15ELEOD 1995	IGNITION - ELECTRIC
E15ELEOD 1995	IGNITION - ROPE
E15ELERE 1994	IGNITION - ELECTRIC
E15ELERE 1994	IGNITION - ROPE
E15ELESR 1990	IGNITION
E15ELETB 1993	IGNITION - ELECTRIC
E15ELETB 1993	IGNITION - ROPE
E15ELEUC 1997	IGNITION - ELECTRIC
E15ELEUC 1997	IGNITION - ROPE
E15RCCS 1988	IGNITION
E15RCDE 1986	IGNITION
E15RCEC 1989	IGNITION
E15RCIS 1981	MAGNETO
E15RCNC 1982	MAGNETO
E15RCOB 1985	IGNITION
E15RCRM 1984	MAGNETO
E15RCSD 1980	MAGNETO
E15RCTA 1983	MAGNETO
E15RCTR 1983	MAGNETO
E15RCUD 1987	IGNITION
E15RECR 1998	IGNITION -- ELECTRIC
E15RECR 1998	IGNITION -- ROPE
E15REDS 1996	IGNITION - ELECTRIC
E15REDS 1996	IGNITION - ROPE
E15REIA 1991	IGNITION
E15RELECR 1998	IGNITION -- ELECTRIC
E15RELECR 1998	IGNITION -- ROPE
E15RELED5 1996	IGNITION - ELECTRIC
E15RELED5 1996	IGNITION - ROPE
E15RELEIA 1991	IGNITION
E15RELENM 1992	IGNITION
E15RELEOD 1995	IGNITION - ELECTRIC

E15RELEOD 1995	IGNITION - ROPE
E15RELERE 1994	IGNITION - ELECTRIC
E15RELERE 1994	IGNITION - ROPE
E15RELESR 1990	IGNITION
E15RELETB 1993	IGNITION - ELECTRIC
E15RELETB 1993	IGNITION - ROPE
E15RELEUC 1997	IGNITION - ELECTRIC
E15RELEUC 1997	IGNITION - ROPE
E15RENM 1992	IGNITION
E15REOD 1995	IGNITION - ELECTRIC
E15REOD 1995	IGNITION - ROPE
E15RERE 1994	IGNITION - ELECTRIC
E15RERE 1994	IGNITION - ROPE
E15RESR 1990	IGNITION
E15RETB 1993	IGNITION - ELECTRIC
E15RETB 1993	IGNITION - ROPE
E15REUC 1997	IGNITION - ELECTRIC
E15REUC 1997	IGNITION - ROPE
E15RLCCS 1988	IGNITION
E15RLCDE 1986	IGNITION
E15RLCEC 1989	IGNITION
E15RLCIS 1981	MAGNETO
E15RLCNC 1982	MAGNETO
E15RLCOB 1985	IGNITION
E15RLCRM 1984	MAGNETO
E15RLCSD 1980	MAGNETO
E15RLCTA 1983	MAGNETO
E15RLCTR 1983	MAGNETO
E15RLCUD 1987	IGNITION
E15RLECR 1998	IGNITION -- ELECTRIC
E15RLECR 1998	IGNITION -- ROPE
E15RLEDS 1996	IGNITION - ELECTRIC
E15RLEDS 1996	IGNITION - ROPE
E15RLEIA 1991	IGNITION
E15RLENM 1992	IGNITION

E15RLEOD 1995	IGNITION - ELECTRIC
E15RLEOD 1995	IGNITION - ROPE
E15RLERE 1994	IGNITION - ELECTRIC
E15RLERE 1994	IGNITION - ROPE
E15RLESR 1990	IGNITION
E15RLETB 1993	IGNITION - ELECTRIC
E15RLETB 1993	IGNITION - ROPE
E15RLEUC 1997	IGNITION - ELECTRIC
E15RLEUC 1997	IGNITION - ROPE
E15WREES 1999	IGNITION
E15WRLEES 1999	IGNITION
E15WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
E15WRLSSC Commercial, Rope Start, Tiller, 20 IN shaft 2000	IGNITION
E15WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
E15WRSSC Commercial, Rope Start, Tiller, 15 IN shaft 2000	IGNITION
E175EXEDB 1996	IGNITION SYSTEM
E175EXEIS 1991	IGNITION SYSTEM
E175EXENC 1992	IGNITION SYSTEM
E175XEUC 1997	IGNITION SYSTEM
E175XEUE 1997	IGNITION SYSTEM
E175GLEDB 1996	IGNITION SYSTEM
E175GLEIS 1991	IGNITION SYSTEM
E175GLENC 1992	IGNITION SYSTEM
E175GLEUC 1997	IGNITION SYSTEM
E175GLEUE 1997	IGNITION SYSTEM
E175NXEDB 1996	IGNITION SYSTEM
E175NXENC 1992	IGNITION SYSTEM
E175NXEUC 1997	IGNITION SYSTEM
E175NXEUE 1997	IGNITION SYSTEM
E175SLEDB 1996	IGNITION SYSTEM
E175SLEUC 1997	IGNITION SYSTEM
E175SLEUE 1997	IGNITION SYSTEM
E175STLCCM 1988	IGNITION SYSTEM
E175STLCEB 1989	IGNITION SYSTEM - 150 MODELS
E175STLCEB 1989	IGNITION SYSTEM - 175 MODELS

E175STLEID 1991	IGNITION SYSTEM - 150 MODELS
E175STLEID 1991	IGNITION SYSTEM - 175 MODELS
E175STLESE 1990	IGNITION SYSTEM - 150 MODELS
E175STLESE 1990	IGNITION SYSTEM - 175 MODELS
E175TLCCM 1988	IGNITION SYSTEM
E175TLCDR 1986	IGNITION SYSTEM
E175TLCOC 1985	IGNITION SYSTEM
E175TLCUA 1987	IGNITION SYSTEM
E175TRLCIM 1981	IGNITION SYSTEM
E175TRLCNB 1982	IGNITION SYSTEM
E175TRLCSA 1980	IGNITION SYSTEM
E175TRLCSF 1980	IGNITION SYSTEM
E175TRLCTD 1983	IGNITION SYSTEM
E175TRLCTE 1983	IGNITION SYSTEM
E175TRXCIH 1981	IGNITION SYSTEM
E175TRXCIM 1981	IGNITION SYSTEM
E175TRXCNB 1982	IGNITION SYSTEM
E175TRXCSA 1980	IGNITION SYSTEM
E175TRXCSF 1980	IGNITION SYSTEM
E175TRXCTD 1983	IGNITION SYSTEM
E175TRXCTE 1983	IGNITION SYSTEM
E175TXCCM 1988	IGNITION SYSTEM
E175TXCDR 1986	IGNITION SYSTEM
E175TXCEB 1989	IGNITION SYSTEM - 150 MODELS
E175TXCEB 1989	IGNITION SYSTEM - 175 MODELS
E175TXCOC 1985	IGNITION SYSTEM
E175TXCUA 1987	IGNITION SYSTEM
E175TXEID 1991	IGNITION SYSTEM - 150 MODELS
E175TXEID 1991	IGNITION SYSTEM - 175 MODELS
E175TXESE 1990	IGNITION SYSTEM - 150 MODELS
E175TXESE 1990	IGNITION SYSTEM - 175 MODELS
E185ESERK 1994	IGNITION SYSTEM & STARTER MOTOR
E185ESXENR 1992	IGNITION SYSTEM & STARTER MOTOR
E185ESXESS 1990	IGNITION SYSTEM & STARTER MOTOR
E185ESXETA 1993	IGNITION SYSTEM & STARTER MOTOR

E185ESXETF 1993	IGNITION SYSTEM & STARTER MOTOR
E185ESXW 1989	IGNITION SYSTEM & STARTER MOTOR
E185TLCOC 1985	IGNITION SYSTEM
E185TLCRS 1984	IGNITION SYSTEM
E185TXCOC 1985	IGNITION SYSTEM
E185TXCRS 1984	IGNITION SYSTEM
E200CXARC 1994	IGNITION SYSTEM & STARTER MOTOR
E200CXARK 1994	IGNITION SYSTEM & STARTER MOTOR
E200CXATF 1993	IGNITION SYSTEM & STARTER MOTOR
E200CXATS 1993	IGNITION SYSTEM & STARTER MOTOR
E200CXCCR 1988	IGNITION SYSTEM & STARTER MOTOR
E200CXCEA 1989	IGNITION SYSTEM & STARTER MOTOR
E200CXECM 1998	IGNITION SYSTEM
E200CXEDR 1996	IGNITION SYSTEM
E200CXEIB 1991	IGNITION SYSTEM & STARTER MOTOR
E200CXENE 1992	IGNITION SYSTEM & STARTER MOTOR
E200CXEOC 1995	IGNITION SYSTEM & STARTER MOTOR
E200CXERK 1994	IGNITION SYSTEM & STARTER MOTOR
E200CXERS 1994	IGNITION SYSTEM & STARTER MOTOR
E200CXESM 1990	IGNITION SYSTEM & STARTER MOTOR
E200CXETD 1993	IGNITION SYSTEM & STARTER MOTOR
E200CXETF 1993	IGNITION SYSTEM & STARTER MOTOR
E200CXEUA 1997	IGNITION SYSTEM
E200CZARK 1994	IGNITION SYSTEM & STARTER MOTOR
E200CZATF 1993	IGNITION SYSTEM & STARTER MOTOR
E200CZATS 1993	IGNITION SYSTEM & STARTER MOTOR
E200CZEOC 1995	IGNITION SYSTEM & STARTER MOTOR
E200CZERK 1994	IGNITION SYSTEM & STARTER MOTOR
E200CZERS 1994	IGNITION SYSTEM & STARTER MOTOR
E200CZETD 1993	IGNITION SYSTEM & STARTER MOTOR
E200CZETF 1993	IGNITION SYSTEM & STARTER MOTOR
E200STLCCM 1988	IGNITION SYSTEM & STARTER MOTOR
E200STLCDR 1986	IGNITION SYSTEM
E200STLCEB 1989	IGNITION SYSTEM & STARTER MOTOR
E200STLCUA 1987	IGNITION SYSTEM

E200TXEDR 1996	IGNITION SYSTEM
E200TXEIB 1991	IGNITION SYSTEM & STARTER MOTOR
E200TXENE 1992	IGNITION SYSTEM & STARTER MOTOR
E200TXEOC 1995	IGNITION SYSTEM & STARTER MOTOR
E200TXERK 1994	IGNITION SYSTEM & STARTER MOTOR
E200TXERS 1994	IGNITION SYSTEM & STARTER MOTOR
E200TXESM 1990	IGNITION SYSTEM & STARTER MOTOR
E200TXETD 1993	IGNITION SYSTEM & STARTER MOTOR
E200TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
E200TXEUA 1997	IGNITION SYSTEM
E200TZARK 1994	IGNITION SYSTEM & STARTER MOTOR
E200TZATF 1993	IGNITION SYSTEM & STARTER MOTOR
E200TZATS 1993	IGNITION SYSTEM & STARTER MOTOR
E200TZEOC 1995	IGNITION SYSTEM & STARTER MOTOR
E200TZERK 1994	IGNITION SYSTEM & STARTER MOTOR
E200TZERS 1994	IGNITION SYSTEM & STARTER MOTOR
E200TZETD 1993	IGNITION SYSTEM & STARTER MOTOR
E200TZETF 1993	IGNITION SYSTEM & STARTER MOTOR
E200WPXEEN 1999	IGNITION SYSTEM
E200WPXEES 1999	IGNITION SYSTEM
E200WPXSIF commercial, elec start, TNT, 25 in shaft 2001	IGNITION SYSTEM
E200WPXSSC Commercial, Elec Start, TNT, 25 IN shaft 2000	IGNITION SYSTEM
E20CRCCA 1988	IGNITION
E20CRCDC 1986	IGNITION
E20CRCEM 1989	IGNITION
E20CRCOS 1985	IGNITION
E20CRCUR 1987	IGNITION
E20CREDA 1996	IGNITION
E20CREIE 1991	IGNITION
E20CREND 1992	IGNITION
E20CREOR 1995	IGNITION
E20CRERC 1994	IGNITION
E20CRESB 1990	IGNITION
E20CRETS 1993	IGNITION
E20CREUM 1997	IGNITION

E20CRLCCA 1988	IGNITION
E20CRLCDC 1986	IGNITION
E20CRLCEM 1989	IGNITION
E20CRLCOS 1985	IGNITION
E20CRLCUR 1987	IGNITION
E20CRLEDA 1996	IGNITION
E20CRLEIE 1991	IGNITION
E20CRLEND 1992	IGNITION
E20CRLEOR 1995	IGNITION
E20CRLERC 1994	IGNITION
E20CRLESB 1990	IGNITION
E20CRLETS 1993	IGNITION
E20CRLEUM 1997	IGNITION
E20ECCA 1988	IGNITION
E20ECDC 1986	IGNITION
E20ECEM 1989	IGNITION
E20ECOS 1985	IGNITION
E20ECUR 1987	IGNITION
E20EEIE 1991	IGNITION
E20EEND 1992	IGNITION
E20EEOR 1995	IGNITION
E20EERC 1994	IGNITION
E20EESB 1990	IGNITION
E20EETS 1993	IGNITION
E20ELCCA 1988	IGNITION
E20ELCDC 1986	IGNITION
E20ELCEM 1989	IGNITION
E20ELCOS 1985	IGNITION
E20ELCUR 1987	IGNITION
E20ELEIE 1991	IGNITION
E20ELEND 1992	IGNITION
E20ELEOR 1995	IGNITION
E20ELERC 1994	IGNITION
E20ELESB 1990	IGNITION
E20ELETS 1993	IGNITION

E20TECDC 1986	IGNITION
E225CLCUB 1987	IGNITION SYSTEM
E225CXARC 1994	IGNITION SYSTEM & STARTER MOTOR
E225CXARK 1994	IGNITION SYSTEM & STARTER MOTOR
E225CXATF 1993	IGNITION SYSTEM & STARTER MOTOR
E225CXATS 1993	IGNITION SYSTEM & STARTER MOTOR
E225CXCCE 1988	IGNITION SYSTEM & STARTER MOTOR
E225CXCED 1989	IGNITION SYSTEM & STARTER MOTOR
E225CXCUB 1987	IGNITION SYSTEM
E225CXECS 1998	IGNITION SYSTEM
E225CXEDE 1996	IGNITION SYSTEM
E225CXEIC 1991	IGNITION SYSTEM & STARTER MOTOR
E225CXENR 1992	IGNITION SYSTEM & STARTER MOTOR
E225CXEOB 1995	IGNITION SYSTEM & STARTER MOTOR
E225CXERK 1994	IGNITION SYSTEM & STARTER MOTOR
E225CXERM 1994	IGNITION SYSTEM & STARTER MOTOR
E225CXESS 1990	IGNITION SYSTEM & STARTER MOTOR
E225CXETA 1993	IGNITION SYSTEM & STARTER MOTOR
E225CXETF 1993	IGNITION SYSTEM & STARTER MOTOR
E225CXEUD 1997	IGNITION SYSTEM
E225CZARK 1994	IGNITION SYSTEM & STARTER MOTOR
E225CZATF 1993	IGNITION SYSTEM & STARTER MOTOR
E225CZATS 1993	IGNITION SYSTEM & STARTER MOTOR
E225CZECS 1998	IGNITION SYSTEM
E225CZEDE 1996	IGNITION SYSTEM
E225CZEOb 1995	IGNITION SYSTEM & STARTER MOTOR
E225CZERK 1994	IGNITION SYSTEM & STARTER MOTOR
E225CZERM 1994	IGNITION SYSTEM & STARTER MOTOR
E225CZETA 1993	IGNITION SYSTEM & STARTER MOTOR
E225CZETF 1993	IGNITION SYSTEM & STARTER MOTOR
E225CZEUD 1997	IGNITION SYSTEM
E225PLCCE 1988	IGNITION SYSTEM & STARTER MOTOR
E225PLCED 1989	IGNITION SYSTEM & STARTER MOTOR
E225PLCUB 1987	IGNITION SYSTEM
E225PLEIC 1991	IGNITION SYSTEM & STARTER MOTOR

E225PLENR 1992	IGNITION SYSTEM & STARTER MOTOR
E225PLERK 1994	IGNITION SYSTEM & STARTER MOTOR
E225PLERM 1994	IGNITION SYSTEM & STARTER MOTOR
E225PLESS 1990	IGNITION SYSTEM & STARTER MOTOR
E225PLETA 1993	IGNITION SYSTEM & STARTER MOTOR
E225PLETF 1993	IGNITION SYSTEM & STARTER MOTOR
E225PTLCDA 1986	IGNITION SYSTEM
E225PTXCDA 1986	IGNITION SYSTEM
E225PXARC 1994	IGNITION SYSTEM & STARTER MOTOR
E225PXARK 1994	IGNITION SYSTEM & STARTER MOTOR
E225PXATF 1993	IGNITION SYSTEM & STARTER MOTOR
E225PXATS 1993	IGNITION SYSTEM & STARTER MOTOR
E225PXCCE 1988	IGNITION SYSTEM & STARTER MOTOR
E225PXCED 1989	IGNITION SYSTEM & STARTER MOTOR
E225PXCUB 1987	IGNITION SYSTEM
E225PXEDE 1996	IGNITION SYSTEM
E225PXEIC 1991	IGNITION SYSTEM & STARTER MOTOR
E225PXENR 1992	IGNITION SYSTEM & STARTER MOTOR
E225PXEOB 1995	IGNITION SYSTEM & STARTER MOTOR
E225PXERK 1994	IGNITION SYSTEM & STARTER MOTOR
E225PXERM 1994	IGNITION SYSTEM & STARTER MOTOR
E225PXESS 1990	IGNITION SYSTEM & STARTER MOTOR
E225PXETA 1993	IGNITION SYSTEM & STARTER MOTOR
E225PXETF 1993	IGNITION SYSTEM & STARTER MOTOR
E225PZARK 1994	IGNITION SYSTEM & STARTER MOTOR
E225PZATF 1993	IGNITION SYSTEM & STARTER MOTOR
E225PZATS 1993	IGNITION SYSTEM & STARTER MOTOR
E225PZEOB 1995	IGNITION SYSTEM & STARTER MOTOR
E225PZERK 1994	IGNITION SYSTEM & STARTER MOTOR
E225PZERM 1994	IGNITION SYSTEM & STARTER MOTOR
E225PZETA 1993	IGNITION SYSTEM & STARTER MOTOR
E225PZETF 1993	IGNITION SYSTEM & STARTER MOTOR
E225STLECS 1998	IGNITION SYSTEM
E225STLEDE 1996	IGNITION SYSTEM
E225STLEOB 1995	IGNITION SYSTEM & STARTER MOTOR

E225STLERC 1994	IGNITION SYSTEM & STARTER MOTOR
E225STLERK 1994	IGNITION SYSTEM & STARTER MOTOR
E225STLETF 1993	IGNITION SYSTEM & STARTER MOTOR
E225STLEUD 1997	IGNITION SYSTEM
E225TLCCE 1988	IGNITION SYSTEM & STARTER MOTOR
E225TLCDA 1986	IGNITION SYSTEM
E225TLCED 1989	IGNITION SYSTEM & STARTER MOTOR
E225TLCUB 1987	IGNITION SYSTEM
E225TLEIC 1991	IGNITION SYSTEM & STARTER MOTOR
E225TLENR 1992	IGNITION SYSTEM & STARTER MOTOR
E225TLERK 1994	IGNITION SYSTEM & STARTER MOTOR
E225TLERM 1994	IGNITION SYSTEM & STARTER MOTOR
E225TLESS 1990	IGNITION SYSTEM & STARTER MOTOR
E225TLETA 1993	IGNITION SYSTEM & STARTER MOTOR
E225TLETF 1993	IGNITION SYSTEM & STARTER MOTOR
E225TXARC 1994	IGNITION SYSTEM & STARTER MOTOR
E225TXARK 1994	IGNITION SYSTEM & STARTER MOTOR
E225TXATF 1993	IGNITION SYSTEM & STARTER MOTOR
E225TXATS 1993	IGNITION SYSTEM & STARTER MOTOR
E225TXCCE 1988	IGNITION SYSTEM & STARTER MOTOR
E225TXCDA 1986	IGNITION SYSTEM
E225TXCED 1989	IGNITION SYSTEM & STARTER MOTOR
E225TXCUB 1987	IGNITION SYSTEM
E225TXECS 1998	IGNITION SYSTEM
E225TXEDE 1996	IGNITION SYSTEM
E225TXEIC 1991	IGNITION SYSTEM & STARTER MOTOR
E225TXENR 1992	IGNITION SYSTEM & STARTER MOTOR
E225TXEOB 1995	IGNITION SYSTEM & STARTER MOTOR
E225TXERK 1994	IGNITION SYSTEM & STARTER MOTOR
E225TXERM 1994	IGNITION SYSTEM & STARTER MOTOR
E225TXESS 1990	IGNITION SYSTEM & STARTER MOTOR
E225TXETA 1993	IGNITION SYSTEM & STARTER MOTOR
E225TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
E225TXEUD 1997	IGNITION SYSTEM
E225TZARK 1994	IGNITION SYSTEM & STARTER MOTOR

E225TZATF 1993	IGNITION SYSTEM & STARTER MOTOR
E225TZATS 1993	IGNITION SYSTEM & STARTER MOTOR
E225TZECS 1998	IGNITION SYSTEM
E225TZEDE 1996	IGNITION SYSTEM
E225TZEOb 1995	IGNITION SYSTEM & STARTER MOTOR
E225TZERK 1994	IGNITION SYSTEM & STARTER MOTOR
E225TZERM 1994	IGNITION SYSTEM & STARTER MOTOR
E225TZETA 1993	IGNITION SYSTEM & STARTER MOTOR
E225TZETF 1993	IGNITION SYSTEM & STARTER MOTOR
E225TZEUD 1997	IGNITION SYSTEM
E235STLCOR 1985	IGNITION SYSTEM
E235STLCRC 1984	IGNITION SYSTEM
E235STLCTS 1983	IGNITION SYSTEM
E235STLCOR 1985	IGNITION SYSTEM
E235STLCRC 1984	IGNITION SYSTEM
E235STRLCIB 1981	IGNITION SYSTEM
E235STRLCIH 1981	IGNITION SYSTEM
E235STRLCNE 1982	IGNITION SYSTEM
E235STRLCSM 1980	IGNITION SYSTEM
E235STRLCTD 1983	IGNITION SYSTEM
E235STRLCTS 1983	IGNITION SYSTEM
E235STRXCIB 1981	IGNITION SYSTEM
E235STRXCIH 1981	IGNITION SYSTEM
E235STRXCNE 1982	IGNITION SYSTEM
E235STRXCSCM 1980	IGNITION SYSTEM
E235STRXCTD 1983	IGNITION SYSTEM
E235STRXCTS 1983	IGNITION SYSTEM
E235TXCOR 1985	IGNITION SYSTEM
E235TXCRC 1984	IGNITION SYSTEM
E250CXARC 1994	IGNITION SYSTEM & STARTER MOTOR
E250CXATF 1993	IGNITION SYSTEM & STARTER MOTOR
E250CXATS 1993	IGNITION SYSTEM & STARTER MOTOR
E250CXECD 1998	IGNITION SYSTEM
E250CXEIE 1991	IGNITION SYSTEM & STARTER MOTOR
E250CXEND 1992	IGNITION SYSTEM & STARTER MOTOR

E250CXEOR 1995	IGNITION SYSTEM & STARTER MOTOR
E250CXERC 1994	IGNITION SYSTEM & STARTER MOTOR
E250CXETF 1993	IGNITION SYSTEM & STARTER MOTOR
E250CXETS 1993	IGNITION SYSTEM & STARTER MOTOR
E250CZATF 1993	IGNITION SYSTEM & STARTER MOTOR
E250CZATS 1993	IGNITION SYSTEM & STARTER MOTOR
E250CZECD 1998	IGNITION SYSTEM
E250CZEND 1992	IGNITION SYSTEM & STARTER MOTOR
E250CZEOR 1995	IGNITION SYSTEM & STARTER MOTOR
E250CZERC 1994	IGNITION SYSTEM & STARTER MOTOR
E250CZETF 1993	IGNITION SYSTEM & STARTER MOTOR
E250CZETS 1993	IGNITION SYSTEM & STARTER MOTOR
E250PXECD 1998	IGNITION SYSTEM
E250PZECD 1998	IGNITION SYSTEM
E250TXARC 1994	IGNITION SYSTEM & STARTER MOTOR
E250TXATF 1993	IGNITION SYSTEM & STARTER MOTOR
E250TXATS 1993	IGNITION SYSTEM & STARTER MOTOR
E250TXEIE 1991	IGNITION SYSTEM & STARTER MOTOR
E250TXEND 1992	IGNITION SYSTEM & STARTER MOTOR
E250TXEOR 1995	IGNITION SYSTEM & STARTER MOTOR
E250TXERC 1994	IGNITION SYSTEM & STARTER MOTOR
E250TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
E250TXETS 1993	IGNITION SYSTEM & STARTER MOTOR
E250TZATF 1993	IGNITION SYSTEM & STARTER MOTOR
E250TZATS 1993	IGNITION SYSTEM & STARTER MOTOR
E250TZEND 1992	IGNITION SYSTEM & STARTER MOTOR
E250TZEOR 1995	IGNITION SYSTEM & STARTER MOTOR
E250TZERC 1994	IGNITION SYSTEM & STARTER MOTOR
E250TZETF 1993	IGNITION SYSTEM & STARTER MOTOR
E250TZETS 1993	IGNITION SYSTEM & STARTER MOTOR
E25CNE 1982	MAGNETO
E25ECCM 1988	IGNITION
E25ECDR 1986	IGNITION
E25ECEB 1989	IGNITION
E25ECIB 1981	MAGNETO

E25ECIM 1981	MAGNETO
E25ECOC 1985	IGNITION
E25ECRS 1984	IGNITION
E25ECTD 1983	MAGNETO
E25ECUA 1987	IGNITION
E25EECE 1998	IGNITION
E25EEDM 1996	IGNITION
E25EEID 1991	IGNITION
E25EENS 1992	IGNITION
E25EEOA 1995	IGNITION
E25EERR 1994	IGNITION
E25EESE 1990	IGNITION
E25EETC 1993	IGNITION
E25EEUB 1997	IGNITION
E25ELCCM 1988	IGNITION
E25ELCDR 1986	IGNITION
E25ELCEB 1989	IGNITION
E25ELCIB 1981	MAGNETO
E25ELCIM 1981	MAGNETO
E25ELCNE 1982	MAGNETO
E25ELCOC 1985	IGNITION
E25ELCRS 1984	IGNITION
E25ELCTD 1983	MAGNETO
E25ELCUA 1987	IGNITION
E25ELECE 1998	IGNITION
E25ELEDM 1996	IGNITION
E25ELEID 1991	IGNITION
E25ELENS 1992	IGNITION
E25ELEOA 1995	IGNITION
E25ELERR 1994	IGNITION
E25ELESE 1990	IGNITION
E25ELETG 1993	IGNITION
E25ELEUB 1997	IGNITION
E25JRECA 1998	IGNITION
E25JREDC 1996	IGNITION

E25JREOS 1995	IGNITION
E25RCCA 1988	IGNITION
E25RCDC 1986	IGNITION
E25RCCEM 1989	IGNITION
E25RCIM 1981	MAGNETO
E25RCNB 1982	MAGNETO
E25RCOS 1985	IGNITION
E25RCRD 1984	IGNITION
E25RCSA 1980	MAGNETO
E25RCTE 1983	MAGNETO
E25RCUR 1987	IGNITION
E25RECB 1998	IGNITION
E25REDA 1996	IGNITION
E25REIE 1991	IGNITION
E25REND 1992	IGNITION
E25REOR 1995	IGNITION
E25RERC 1994	IGNITION
E25RESB 1990	IGNITION
E25RETS 1993	IGNITION
E25REUM 1997	IGNITION
E25RLCCA 1988	IGNITION
E25RLCDC 1986	IGNITION
E25RLCEM 1989	IGNITION
E25RLCIM 1981	MAGNETO
E25RLCNB 1982	MAGNETO
E25RLCOS 1985	IGNITION
E25RLCRD 1984	IGNITION
E25RLCSA 1980	MAGNETO
E25RLCTE 1983	MAGNETO
E25RLCUR 1987	IGNITION
E25RLECB 1998	IGNITION
E25RLEDA 1996	IGNITION
E25RLEIE 1991	IGNITION
E25RLEND 1992	IGNITION
E25RLEOR 1995	IGNITION

E25RLERC 1994	IGNITION
E25RLESB 1990	IGNITION
E25RLETS 1993	IGNITION
E25RLEUM 1997	IGNITION
E25RSA 1981	MAGNETO
E25RSLA 1981	MAGNETO
E25RSLS 1983	MAGNETO
E25RSS 1983	MAGNETO
E25RWCDC 1986	MAGNETO
E25RWCIM 1981	MAGNETO
E25RWCOS 1985	MAGNETO
E25RWCRD 1984	MAGNETO
E25RWCTE 1983	MAGNETO
E25RWCUR 1987	MAGNETO
E25RWEDC 1996	IGNITION - H25FP
E25RWEDC 1996	IGNITION - 25RS - 25RW - S25RP
E25RWEIM 1991	IGNITION
E25RWENB 1992	IGNITION
E25RWEOS 1995	IGNITION - H25FP
E25RWEOS 1995	IGNITION - 25RS - 25RW - S25RP
E25RWERD 1994	IGNITION - 25RW
E25RWESA 1990	IGNITION
E25RWETE 1993	IGNITION - 25RW
E25RWEUR 1997	IGNITION - H25FP
E25RWEUR 1997	IGNITION - 25RS, 25RW, S25RP
E25RWK 1989	IGNITION
E25RWLCDC 1986	MAGNETO
E25RWLCIM 1981	MAGNETO
E25RWLCOS 1985	MAGNETO
E25RWLCRD 1984	MAGNETO
E25RWLCTE 1983	MAGNETO
E25RWLCUR 1987	MAGNETO
E25RWLEDC 1996	IGNITION - H25FP
E25RWLEDC 1996	IGNITION - 25RS - 25RW - S25RP
E25RWLEIM 1991	IGNITION

E25RWLENB 1992	IGNITION
E25RWLEOS 1995	IGNITION - H25FP
E25RWLEOS 1995	IGNITION - 25RS - 25RW - S25RP
E25RWLERD 1994	IGNITION - 25RW
E25RWLESA 1990	IGNITION
E25RWLETE 1993	IGNITION - 25RW
E25RWLEUR 1997	IGNITION - H25FP
E25RWLEUR 1997	IGNITION - 25RS, 25RW, S25RP
E25RWLK 1989	IGNITION
E25TECCA 1988	IGNITION
E25TECDC 1986	IGNITION
E25TECEM 1989	IGNITION
E25TECIM 1981	MAGNETO
E25TECNB 1982	MAGNETO
E25TECOS 1985	IGNITION
E25TECRD 1984	IGNITION
E25TECSA 1980	MAGNETO
E25TECTE 1983	MAGNETO
E25TECUR 1987	IGNITION
E25TEECB 1998	IGNITION
E25TEEDA 1996	IGNITION
E25TEEIE 1991	IGNITION
E25TEEND 1992	IGNITION
E25TEEOR 1995	IGNITION
E25TEERC 1994	IGNITION
E25TEESB 1990	IGNITION
E25TEETS 1993	IGNITION
E25TEEUM 1997	IGNITION
E25TELCCA 1988	IGNITION
E25TELCDC 1986	IGNITION
E25TELCCEM 1989	IGNITION
E25TELCIM 1981	MAGNETO
E25TELCNB 1982	MAGNETO
E25TELCOS 1985	IGNITION
E25TELCRD 1984	IGNITION

E25TELCSA 1980	MAGNETO
E25TELCCTE 1983	MAGNETO
E25TELCUR 1987	IGNITION
E25TELECB 1998	IGNITION
E25TELEDA 1996	IGNITION
E25TELEIE 1991	IGNITION
E25TELEND 1992	IGNITION
E25TELEOR 1995	IGNITION
E25TELESB 1990	IGNITION
E25TELETS 1993	IGNITION
E25TELEUM 1997	IGNITION
E25WREEN 1999	IGNITION
E25WREES 1999	IGNITION
E25WRLEEN 1999	IGNITION
E25WRLEES 1999	IGNITION
E25WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
E25WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	IGNITION
E25WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
E25WRSSC Commercial, Rope Start, 15 IN. shaft 2000	IGNITION
E275CLCUR 1987	IGNITION SYSTEM - 35 AMP
E275CXCCA 1988	IGNITION SYSTEM & STARTER MOTOR
E275CXCUR 1987	IGNITION SYSTEM - 35 AMP
E275PLCCA 1988	IGNITION SYSTEM & STARTER MOTOR
E275PLCUR 1987	IGNITION SYSTEM - 35 AMP
E275PTLCDC 1986	IGNITION SYSTEM - 35 AMP
E275PTXCDC 1986	IGNITION SYSTEM - 35 AMP
E275PXCCA 1988	IGNITION SYSTEM & STARTER MOTOR
E275PXCUR 1987	IGNITION SYSTEM - 35 AMP
E275TLCOS 1985	IGNITION SYSTEM - 35 AMP
E275TXCOS 1985	IGNITION SYSTEM - 35 AMP
E28ELCDS 1986	MAGNETO
E28ESLCCR 1988	IGNITION
E28ESLCEA 1989	IGNITION
E28ESLCUC 1987	MAGNETO
E28ESLEDR 1996	IGNITION

E28ESLEIB 1991	IGNITION
E28ESLENE 1992	IGNITION
E28ESLEOC 1995	IGNITION
E28ESLERS 1994	IGNITION
E28ESLESM 1990	IGNITION
E28ESLETD 1993	IGNITION
E2RCIB 1981	MAGNETO
E2RCNE 1982	MAGNETO
E2RCOC 1985	MAGNETO
E2RCRS 1984	MAGNETO
E2RCSM 1980	MAGNETO
E2RCTD 1983	MAGNETO
E300CLCUR 1987	IGNITION SYSTEM - 35 AMP
E300CXCCA 1988	IGNITION SYSTEM & STARTER MOTOR
E300CXCEM 1989	IGNITION SYSTEM & STARTER MOTOR
E300XCXUR 1987	IGNITION SYSTEM - 35 AMP
E300CXEIE 1991	IGNITION SYSTEM & STARTER MOTOR
E300CXEND 1992	IGNITION SYSTEM & STARTER MOTOR
E300CXEOR 1995	IGNITION SYSTEM & STARTER MOTOR
E300CXERC 1994	IGNITION SYSTEM & STARTER MOTOR
E300CXESB 1990	IGNITION SYSTEM & STARTER MOTOR
E300CXETF 1993	IGNITION SYSTEM & STARTER MOTOR
E300CXETS 1993	IGNITION SYSTEM & STARTER MOTOR
E300PLCCA 1988	IGNITION SYSTEM & STARTER MOTOR
E300PLCEM 1989	IGNITION SYSTEM & STARTER MOTOR
E300PLCUR 1987	IGNITION SYSTEM - 35 AMP
E300PLEIE 1991	IGNITION SYSTEM & STARTER MOTOR
E300PLEND 1992	IGNITION SYSTEM & STARTER MOTOR
E300PLEOR 1995	IGNITION SYSTEM & STARTER MOTOR
E300PLERC 1994	IGNITION SYSTEM & STARTER MOTOR
E300PLESB 1990	IGNITION SYSTEM & STARTER MOTOR
E300PLETF 1993	IGNITION SYSTEM & STARTER MOTOR
E300PLETS 1993	IGNITION SYSTEM & STARTER MOTOR
E300PXCCA 1988	IGNITION SYSTEM & STARTER MOTOR
E300PXCEM 1989	IGNITION SYSTEM & STARTER MOTOR

E300PXCUR 1987	IGNITION SYSTEM - 35 AMP
E300PXEIE 1991	IGNITION SYSTEM & STARTER MOTOR
E300PXEND 1992	IGNITION SYSTEM & STARTER MOTOR
E300PXEOR 1995	IGNITION SYSTEM & STARTER MOTOR
E300PXERC 1994	IGNITION SYSTEM & STARTER MOTOR
E300PXESB 1990	IGNITION SYSTEM & STARTER MOTOR
E300PXETF 1993	IGNITION SYSTEM & STARTER MOTOR
E300PXETS 1993	IGNITION SYSTEM & STARTER MOTOR
E300TLCDC 1986	IGNITION SYSTEM - 35 AMP
E300TLCOS 1985	IGNITION SYSTEM - 35 AMP
E300TXCDC 1986	IGNITION SYSTEM - 35 AMP
E300TXCOS 1985	IGNITION SYSTEM - 35 AMP
E30ECCE 1988	IGNITION
E30ECDM 1986	IGNITION
E30ECED 1989	IGNITION
E30EOCA 1985	IGNITION
E30ECRR 1984	IGNITION
E30ECUB 1987	IGNITION
E30EECS 1998	IGNITION
E30EEDE 1996	IGNITION
E30EEIC 1991	IGNITION
E30EENR 1992	IGNITION
E30EEOB 1995	IGNITION
E30EERM 1994	IGNITION
E30EESS 1990	IGNITION
E30EETA 1993	IGNITION
E30EEUD 1997	IGNITION
E30ELCCE 1988	IGNITION
E30ELCDM 1986	IGNITION
E30ELCED 1989	IGNITION
E30ELCOA 1985	IGNITION
E30ELCRR 1984	IGNITION
E30ELCUB 1987	IGNITION
E30ELECS 1998	IGNITION
E30ELEDE 1996	IGNITION

E30ELEIC 1991	IGNITION
E30ELENR 1992	IGNITION
E30ELEOB 1995	IGNITION
E30ELERM 1994	IGNITION
E30ELESS 1990	IGNITION
E30ELETA 1993	IGNITION
E30ELEUD 1997	IGNITION
E30RCCE 1988	IGNITION
E30RCDM 1986	IGNITION
E30RCED 1989	IGNITION
E30RCOA 1985	IGNITION
E30RCUB 1987	IGNITION
E30REDE 1996	IGNITION
E30REIC 1991	IGNITION
E30RENr 1992	IGNITION
E30REOB 1995	IGNITION
E30RERM 1994	IGNITION
E30RESS 1990	IGNITION
E30RETA 1993	IGNITION
E30REUD 1997	IGNITION
E30RLCCE 1988	IGNITION
E30RLCDM 1986	IGNITION
E30RLCED 1989	IGNITION
E30RLCOA 1985	IGNITION
E30RLCUB 1987	IGNITION
E30RLEDE 1996	IGNITION
E30RLEIC 1991	IGNITION
E30RLENr 1992	IGNITION
E30RLEOB 1995	IGNITION
E30RLERM 1994	IGNITION
E30RLESS 1990	IGNITION
E30RLETA 1993	IGNITION
E30RLEUD 1997	IGNITION
E30TECCE 1988	IGNITION
E30TECDM 1986	IGNITION

E30TECED 1989	IGNITION
E30TECOA 1985	IGNITION
E30TECUB 1987	IGNITION
E30TEECS 1998	IGNITION
E30TEEDE 1996	IGNITION
E30TEEIC 1991	IGNITION
E30TEENR 1992	IGNITION
E30TEEOB 1995	IGNITION
E30TEERM 1994	IGNITION
E30TEESS 1990	IGNITION
E30TEETA 1993	IGNITION
E30TEEUD 1997	IGNITION
E30TELCCE 1988	IGNITION
E30TELCDM 1986	IGNITION
E30TELCED 1989	IGNITION
E30TELCOA 1985	IGNITION
E30TELCUB 1987	IGNITION
E30TELECB 1998	IGNITION
E30TELEDE 1996	IGNITION
E30TELEIC 1991	IGNITION
E30TELENR 1992	IGNITION
E30TELEOB 1995	IGNITION
E30TELERM 1994	IGNITION
E30TELESS 1990	IGNITION
E30TELETA 1993	IGNITION
E30TELEUD 1997	IGNITION
E35AELCDE 1986	IGNITION SYSTEM
E35AELCUD 1987	IGNITION SYSTEM
E35ARLCDE 1986	IGNITION SYSTEM
E35ARLCUD 1987	IGNITION SYSTEM
E35ECIG 1981	MAGNETO
E35ECND 1982	MAGNETO
E35ECRR 1984	IGNITION
E35ECSM 1980	MAGNETO
E35ECTS 1983	MAGNETO

E35ELCIG 1981	MAGNETO
E35ELCND 1982	MAGNETO
E35ELCRR 1984	IGNITION
E35ELCSM 1980	MAGNETO
E35ELCTS 1983	MAGNETO
E35RCCE 1988	IGNITION
E35RCDM 1986	IGNITION
E35RCED 1989	IGNITION
E35RCIG 1981	MAGNETO
E35RCND 1982	MAGNETO
E35RCRR 1984	IGNITION
E35RCTS 1983	MAGNETO
E35RCUB 1987	IGNITION
E35REIC 1991	IGNITION
E35RENr 1992	IGNITION
E35RERM 1994	IGNITION
E35RESS 1990	IGNITION
E35RETA 1993	IGNITION
E35RLCCE 1988	IGNITION
E35RLCDM 1986	IGNITION
E35RLCED 1989	IGNITION
E35RLCIG 1981	MAGNETO
E35RLCND 1982	MAGNETO
E35RLCRR 1984	IGNITION
E35RLCTS 1983	MAGNETO
E35RLCUB 1987	IGNITION
E35RLEIC 1991	IGNITION
E35RLENr 1992	IGNITION
E35RLERM 1994	IGNITION
E35RLESS 1990	IGNITION
E35RLETA 1993	IGNITION
E35TCSM 1980	MAGNETO
E35TELCNB 1982	MAGNETO
E35TELCRR 1984	IGNITION
E35TELCTS 1983	MAGNETO

E35TLESM 1980	MAGNETO
E3BRCEC 1989	IGNITION
E3BRESR 1990	IGNITION
E3RCCM 1988	IGNITION
E3RCUA 1987	IGNITION
E3REIA 1991	IGNITION
E3RENM 1992	IGNITION
E3REOD 1995	IGNITION
E3RERE 1994	IGNITION
E3RETB 1993	IGNITION
E3REUC 1997	IGNITION
E40AELCCS 1988	IGNITION SYSTEM
E40ARLCCS 1988	IGNITION SYSTEM
E40ATLCCS 1988	IGNITION SYSTEM
E40ECCS 1988	IGNITION SYSTEM
E40ECDE 1986	IGNITION SYSTEM
E40ECEC 1989	IGNITION SYSTEM - ROPE START
E40ECEC 1989	IGNITION SYSTEM - ELECTRIC START
E40ECOB 1985	IGNITION SYSTEM
E40ECRM 1984	IGNITION SYSTEM
E40ECUD 1987	IGNITION SYSTEM
E40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40EEIA 1991	IGNITION SYSTEM - ROPE START
E40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40EENJ 1992	IGNITION SYSTEM - ROPE START
E40EENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)

E40EENM 1992	IGNITION SYSTEM - ROPE START
E40EENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E40EEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40EEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40EEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40EEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
E40EERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40EERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40EERE 1994	IGNITION SYSTEM - 40 ROPE START
E40EERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40EESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40EESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40EESR 1990	IGNITION SYSTEM - ROPE START
E40EETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40EETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40EETB 1993	IGNITION SYSTEM - 40 ROPE START
E40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40ELCCS 1988	IGNITION SYSTEM
E40ELCDE 1986	IGNITION SYSTEM
E40ELCEC 1989	IGNITION SYSTEM - ROPE START
E40ELCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40ELCOB 1985	IGNITION SYSTEM
E40ELCRM 1984	IGNITION SYSTEM
E40ELCUD 1987	IGNITION SYSTEM
E40ELECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
E40ELECR 1998	IGNITION SYSTEM -- ROPE START
E40ELEDs 1996	IGNITION SYSTEM - 40 ROPE START
E40ELEDs 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
E40ELEDs 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
E40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS

E40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40ELEIA 1991	IGNITION SYSTEM - ROPE START
E40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40ELENJ 1992	IGNITION SYSTEM - ROPE START
E40ELENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40ELENM 1992	IGNITION SYSTEM - ROPE START
E40ELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E40ELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40ELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40ELEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40ELEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
E40ELERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40ELERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40ELERE 1994	IGNITION SYSTEM - 40 ROPE START
E40ELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40ELESR 1990	IGNITION SYSTEM - ROPE START
E40ELETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40ELETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
E40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

E40ELEUC 1997	IGNITION SYSTEM - ROPE START
E40ELEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
E40JRECA 1998	IGNITION SYSTEM
E40JREDC 1996	IGNITION SYSTEM
E40JREOS 1995	IGNITION SYSTEM
E40JREUR 1997	IGNITION SYSTEM
E40RCCS 1988	IGNITION SYSTEM
E40RCDE 1986	IGNITION SYSTEM
E40RCEC 1989	IGNITION SYSTEM - ROPE START
E40RCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40RCOB 1985	IGNITION SYSTEM
E40RCRM 1984	IGNITION SYSTEM
E40RCUD 1987	IGNITION SYSTEM
E40RECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
E40RECR 1998	IGNITION SYSTEM -- ROPE START
E40REDS 1996	IGNITION SYSTEM - 40 ROPE START
E40REDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
E40REDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
E40REIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40REIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40REIA 1991	IGNITION SYSTEM - ROPE START
E40RENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40RENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E40RENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40RENM 1992	IGNITION SYSTEM - ROPE START
E40RENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E40REOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40REOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40REOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40REOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
E40RERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS

E40RERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40RERE 1994	IGNITION SYSTEM - 40 ROPE START
E40RERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40RESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40RESR 1990	IGNITION SYSTEM - ROPE START
E40RETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40RETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40RETB 1993	IGNITION SYSTEM - 40 ROPE START
E40RETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40REUC 1997	IGNITION SYSTEM - ROPE START
E40REUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
E40RLCCS 1988	IGNITION SYSTEM
E40RLCDE 1986	IGNITION SYSTEM
E40RLCEC 1989	IGNITION SYSTEM - ROPE START
E40RLCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40RLCOB 1985	IGNITION SYSTEM
E40RLCRM 1984	IGNITION SYSTEM
E40RLCUD 1987	IGNITION SYSTEM
E40RLECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
E40RLECR 1998	IGNITION SYSTEM -- ROPE START
E40RLEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40RLEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
E40RLEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
E40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40RLEIA 1991	IGNITION SYSTEM - ROPE START
E40RLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40RLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E40RLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)

E40RLENM 1992	IGNITION SYSTEM - ROPE START
E40RLENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E40RLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40RLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40RLEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40RLEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
E40RLERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40RLERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40RLERE 1994	IGNITION SYSTEM - 40 ROPE START
E40RLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40RLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40RLESR 1990	IGNITION SYSTEM - ROPE START
E40RLETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40RLETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40RLETB 1993	IGNITION SYSTEM - 40 ROPE START
E40RLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RLEUC 1997	IGNITION SYSTEM - ROPE START
E40RLEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
E40RSLR 1983	MAGNETO-RS AND RW MODELS ONLY
E40RSR 1983	MAGNETO-RS AND RW MODELS ONLY
E40RWADB 1986	IGNITION
E40RWCOM 1985	IGNITION
E40RWCRA 1984	IGNITION
E40RWLCDB 1986	IGNITION
E40RWLCOM 1985	IGNITION
E40RWLCRA 1984	IGNITION
E40RWLCTR 1983	MAGNETO-RS AND RW MODELS ONLY
E40RWLTR 1983	MAGNETO-RS AND RW MODELS ONLY
E40TECCS 1988	IGNITION SYSTEM

E40TECDE 1986	IGNITION SYSTEM
E40TECEC 1989	IGNITION SYSTEM - ROPE START
E40TECEC 1989	IGNITION SYSTEM - ELECTRIC START
E40TECOB 1985	IGNITION SYSTEM
E40TECRM 1984	IGNITION SYSTEM
E40TECUD 1987	IGNITION SYSTEM
E40TEECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
E40TEECR 1998	IGNITION SYSTEM -- ROPE START
E40TEEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40TEEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
E40TEEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
E40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TEEIA 1991	IGNITION SYSTEM - ROPE START
E40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TEENJ 1992	IGNITION SYSTEM - ROPE START
E40TEENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E40TEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E40TEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TEENM 1992	IGNITION SYSTEM - ROPE START
E40TEENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E40TEEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40TEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TEEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40TEEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
E40TEERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS

E40TEERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40TEERE 1994	IGNITION SYSTEM - 40 ROPE START
E40TEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TEESR 1990	IGNITION SYSTEM - ROPE START
E40TEETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40TEETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40TEETB 1993	IGNITION SYSTEM - 40 ROPE START
E40TEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TEEUC 1997	IGNITION SYSTEM - ROPE START
E40TEEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
E40TELCCS 1988	IGNITION SYSTEM
E40TELCDE 1986	IGNITION SYSTEM
E40TELCEC 1989	IGNITION SYSTEM - ROPE START
E40TELCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40TELCOB 1985	IGNITION SYSTEM
E40TELCRM 1984	IGNITION SYSTEM
E40TELECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
E40TELECR 1998	IGNITION SYSTEM -- ROPE START
E40TELEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40TELEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
E40TELEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
E40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TELEIA 1991	IGNITION SYSTEM - ROPE START
E40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TELENJ 1992	IGNITION SYSTEM - ROPE START
E40TELENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)

E40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TELENM 1992	IGNITION SYSTEM - ROPE START
E40TELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E40TELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TELEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40TELEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
E40TELERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40TELERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40TELERE 1994	IGNITION SYSTEM - 40 ROPE START
E40TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TELESR 1990	IGNITION SYSTEM - ROPE START
E40TELETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40TELETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40TELETB 1993	IGNITION SYSTEM - 40 ROPE START
E40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TELEUC 1997	IGNITION SYSTEM - ROPE START
E40TELEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
E40TLCCS 1988	IGNITION SYSTEM
E40TLCDE 1986	IGNITION SYSTEM
E40TLCEC 1989	IGNITION SYSTEM - ROPE START
E40TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40TLCUD 1987	IGNITION SYSTEM
E40TLECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
E40TLECR 1998	IGNITION SYSTEM -- ROPE START

E40TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40TLEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
E40TLEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
E40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TLEIA 1991	IGNITION SYSTEM - ROPE START
E40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TLENJ 1992	IGNITION SYSTEM - ROPE START
E40TLENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TLENM 1992	IGNITION SYSTEM - ROPE START
E40TLENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E40TLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TLEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40TLEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
E40TLERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40TLERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40TLERE 1994	IGNITION SYSTEM - 40 ROPE START
E40TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TLESR 1990	IGNITION SYSTEM - ROPE START
E40TLETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS

E40TLETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40TLETB 1993	IGNITION SYSTEM - 40 ROPE START
E40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TLETF 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40TLETF 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40TLETF 1993	IGNITION SYSTEM - 40 ROPE START
E40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TLEUC 1997	IGNITION SYSTEM - ROPE START
E40TLEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
E40TTLCCS 1988	IGNITION SYSTEM
E40TTLCEC 1989	IGNITION SYSTEM - ROPE START
E40TTLCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40TTLECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
E40TTLECR 1998	IGNITION SYSTEM -- ROPE START
E40TTLEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40TTLEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
E40TTLEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
E40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TTLEIA 1991	IGNITION SYSTEM - ROPE START
E40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TTLENM 1992	IGNITION SYSTEM - ROPE START
E40TTLENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E40TTLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40TTLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TTLEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40TTLEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS

E40TTLERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40TTLERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40TTLERE 1994	IGNITION SYSTEM - 40 ROPE START
E40TTLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TTLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TTLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TTLESR 1990	IGNITION SYSTEM - ROPE START
E40TTLETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40TTLETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40TTLETB 1993	IGNITION SYSTEM - 40 ROPE START
E40TTLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TTLETF 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E40TTLETF 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E40TTLETF 1993	IGNITION SYSTEM - 40 ROPE START
E40TTLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TTLEUC 1997	IGNITION SYSTEM - ROPE START
E40TTLEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
E40WREES 1999	IGNITION SYSTEM
E40WRLEES 1999	IGNITION SYSTEM
E40WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
E40WRLSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
E40WRSIR commercial, rope start, 15 in shaft 2001	IGNITION SYSTEM
E40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
E40WRYEES 1999	IGNITION SYSTEM
E40WRYSIR commercial, rope start, 25 in shaft 2001	IGNITION SYSTEM
E40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	IGNITION SYSTEM
E45RCCDS 1986	IGNITION SYSTEM
E45RCCUC 1987	IGNITION SYSTEM
E45RCE 1989	IGNITION
E45RCEIA 1991	IGNITION SYSTEM
E45RCENM 1992	IGNITION SYSTEM - ELECTRIC

E45RCENM 1992	IGNITION SYSTEM - ROPE START
E45RCEOD 1995	IGNITION SYSTEM
E45RCERE 1994	IGNITION SYSTEM
E45RCESR 1990	IGNITION
E45RCETB 1993	IGNITION SYSTEM
E45RCLCDS 1986	IGNITION SYSTEM
E45RCLCUC 1987	IGNITION SYSTEM
E45RCLE 1989	IGNITION
E45RCLEDS 1996	IGNITION SYSTEM
E45RCLEIA 1991	IGNITION SYSTEM
E45RCLENM 1992	IGNITION SYSTEM - ELECTRIC
E45RCLENM 1992	IGNITION SYSTEM - ROPE START
E45RCLEOD 1995	IGNITION SYSTEM
E45RCLERE 1994	IGNITION SYSTEM
E45RCLESR 1990	IGNITION
E45RCLETB 1993	IGNITION SYSTEM
E45RCLEUC 1997	IGNITION SYSTEM
E45WMLE 1989	IGNITION
E45WMLEIA 1991	IGNITION SYSTEM
E45WMLENM 1992	IGNITION SYSTEM - ELECTRIC
E45WMLENM 1992	IGNITION SYSTEM - ROPE START
E45WMLESR 1990	IGNITION
E48ESLCCC 1988	IGNITION SYSTEM
E48ESLCER 1989	IGNITION SYSTEM
E48ESLCUS 1987	IGNITION SYSTEM
E48ESLEDC 1996	IGNITION SYSTEM
E48ESLEIM 1991	IGNITION SYSTEM
E48ESLENB 1992	IGNITION SYSTEM
E48ESLEOS 1995	IGNITION SYSTEM
E48ESLERD 1994	IGNITION SYSTEM
E48ESLESA 1990	IGNITION SYSTEM
E48ESLETE 1993	IGNITION SYSTEM
E4BRCICI 1981	MAGNETO
E4BRECRJ 1998	IGNITION
E4BRHCCS 1988	IGNITION

E4BRHCDE 1986	IGNITION
E4BRHCNR 1982	MAGNETO
E4BRHCOB 1985	IGNITION
E4BRHCRM 1984	IGNITION
E4BRHCTA 1983	MAGNETO
E4BRHCUD 1987	IGNITION
E4BRHLCCS 1988	IGNITION
E4BRHLCDE 1986	IGNITION
E4BRHLCNR 1982	MAGNETO
E4BRHLCOB 1985	IGNITION
E4BRHLCRM 1984	IGNITION
E4BRHLCCTA 1983	MAGNETO
E4BRHLCUD 1987	IGNITION
E4BRLCIC 1981	MAGNETO
E4BRLECRJ 1998	IGNITION
E4RCCS 1988	IGNITION
E4RCEC 1989	IGNITION
E4RCUD 1987	IGNITION
E4RDHCCS 1988	MAGNETO
E4RDHCDE 1986	MAGNETO
E4RDHCEC 1989	IGNITION
E4RDHCUD 1987	MAGNETO
E4RDHEIA 1991	IGNITION
E4RDHENM 1992	IGNITION
E4RDHEOD 1995	MAGNETO
E4RDHERE 1994	MAGNETO
E4RDHESR 1990	IGNITION
E4RDHETB 1993	IGNITION
E4RDHLCCS 1988	MAGNETO
E4RDHLCEC 1989	IGNITION
E4RDHLCUD 1987	MAGNETO
E4RDHLEIA 1991	IGNITION
E4RDHLENM 1992	IGNITION
E4RDHLEOD 1995	MAGNETO
E4RDHLERE 1994	MAGNETO

E4RDHLESR 1990	IGNITION
E4RDHLETB 1993	IGNITION
E4REDS 1996	IGNITION
E4REIA 1991	IGNITION
E4RENM 1992	IGNITION
E4REOD 1995	IGNITION
E4RERE 1994	IGNITION
E4RESR 1990	IGNITION
E4RETB 1993	IGNITION
E4REUC 1997	IGNITION
E4RLCCS 1988	IGNITION
E4RLCEC 1989	IGNITION
E4RLCSS 1980	MAGNETO
E4RLCUD 1987	IGNITION
E4RLEDs 1996	IGNITION
E4RLEIA 1991	IGNITION
E4RLENM 1992	IGNITION
E4RLEOD 1995	IGNITION
E4RLERE 1994	IGNITION
E4RLESR 1990	IGNITION
E4RLETB 1993	IGNITION
E4RLEUC 1997	IGNITION
E4WCIC 1981	MAGNETO
E4WCNR 1982	MAGNETO
E4WCSS 1980	MAGNETO
E50BECCS 1988	IGNITION SYSTEM
E50BECDE 1986	IGNITION SYSTEM
E50BECEC 1989	IGNITION SYSTEM - ROPE START
E50BECEC 1989	IGNITION SYSTEM - ELECTRIC START
E50BECIC 1981	IGNITION SYSTEM
E50BECNR 1982	IGNITION SYSTEM
E50BECOB 1985	IGNITION SYSTEM
E50BECRM 1984	IGNITION SYSTEM
E50BECTA 1983	IGNITION SYSTEM
E50BECUD 1987	IGNITION SYSTEM

E50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50BEEIA 1991	IGNITION SYSTEM - ROPE START
E50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BEENJ 1992	IGNITION SYSTEM - ROPE START
E50BEENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BEENM 1992	IGNITION SYSTEM - ROPE START
E50BEENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E50BEEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50BEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50BEEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E50BEEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
E50BEERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E50BEERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E50BEERE 1994	IGNITION SYSTEM - 40 ROPE START
E50BEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50BEESR 1990	IGNITION SYSTEM - ROPE START
E50BEETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E50BEETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E50BEETB 1993	IGNITION SYSTEM - 40 ROPE START

E50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50BELCCS 1988	IGNITION SYSTEM
E50BELCDE 1986	IGNITION SYSTEM
E50BELCEC 1989	IGNITION SYSTEM - ROPE START
E50BELCEC 1989	IGNITION SYSTEM - ELECTRIC START
E50BELCIC 1981	IGNITION SYSTEM
E50BELCNR 1982	IGNITION SYSTEM
E50BELCOB 1985	IGNITION SYSTEM
E50BELCRM 1984	IGNITION SYSTEM
E50BELCTA 1983	IGNITION SYSTEM
E50BELCUD 1987	IGNITION SYSTEM
E50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50BELEIA 1991	IGNITION SYSTEM - ROPE START
E50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BELENJ 1992	IGNITION SYSTEM - ROPE START
E50BELENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BELENM 1992	IGNITION SYSTEM - ROPE START
E50BELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E50BELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50BELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50BELEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E50BELEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
E50BELERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS

E50BELERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E50BELERE 1994	IGNITION SYSTEM - 40 ROPE START
E50BELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50BELESR 1990	IGNITION SYSTEM - ROPE START
E50BELETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E50BELETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E50BELETB 1993	IGNITION SYSTEM - 40 ROPE START
E50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50DTLECA 1998	IGNITION SYSTEM
E50DTLEDC 1996	IGNITION SYSTEM
E50DTLEDC 1996	IGNITION SYSTEM - E70RNLIB ONLY
E50DTLEOS 1995	IGNITION SYSTEM
E50DTLEUR 1997	IGNITION SYSTEM
E50ECSR 1980	IGNITION SYSTEM
E50ELCSR 1980	IGNITION SYSTEM
E50ELED 1996	IGNITION SYSTEM
E50ELED 1996	IGNITION SYSTEM - E70RNLIB ONLY
E50ELEOS 1995	IGNITION SYSTEM
E50ELEUR 1997	IGNITION SYSTEM
E50ESLECC 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
E50ESLECC 1998	IGNITION SYSTEM -- ROPE START
E50ESLEUR 1997	IGNITION SYSTEM - ROPE START
E50ESLEUR 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
E50JEDS 1996	IGNITION SYSTEM - 40 ROPE START
E50JEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
E50JEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
E50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50JEIA 1991	IGNITION SYSTEM - ROPE START
E50JENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)

E50JENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E50JENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50JENJ 1992	IGNITION SYSTEM - ROPE START
E50JENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E50JENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50JENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E50JENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50JENM 1992	IGNITION SYSTEM - ROPE START
E50JENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E50JEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50JEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50JEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E50JEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
E50JERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E50JERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E50JERE 1994	IGNITION SYSTEM - 40 ROPE START
E50JERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50JETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E50JETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E50JETB 1993	IGNITION SYSTEM - 40 ROPE START
E50JETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50JEUC 1997	IGNITION SYSTEM - ROPE START
E50JEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
E50RNLIA 1990	IGNITION SYSTEM
E50RNLIB 1992	IGNITION SYSTEM
E50TELCCS 1988	IGNITION SYSTEM
E50TELCDE 1986	IGNITION SYSTEM

E50TELCEC 1989	IGNITION SYSTEM - ROPE START
E50TELCEC 1989	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TELCOB 1985	IGNITION SYSTEM
E50TELCRM 1984	IGNITION SYSTEM
E50TELECTA 1983	IGNITION SYSTEM
E50TELCUD 1987	IGNITION SYSTEM
E50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TELEIA 1991	IGNITION SYSTEM - ROPE START
E50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50TELENM 1992	IGNITION SYSTEM - ROPE START
E50TELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E50TELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50TELEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E50TELEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
E50TELERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E50TELERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E50TELERE 1994	IGNITION SYSTEM - 40 ROPE START
E50TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TELESR 1990	IGNITION SYSTEM - ROPE START
E50TELETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E50TELETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E50TELETB 1993	IGNITION SYSTEM - 40 ROPE START
E50TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

E50TLCCS 1988	IGNITION SYSTEM
E50TLCDE 1986	IGNITION SYSTEM
E50TLCEC 1989	IGNITION SYSTEM - ROPE START
E50TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
E50TLCOB 1985	IGNITION SYSTEM
E50TLCRM 1984	IGNITION SYSTEM
E50TLCUD 1987	IGNITION SYSTEM
E50TLECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
E50TLECR 1998	IGNITION SYSTEM -- ROPE START
E50TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
E50TLEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
E50TLEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
E50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TLEIA 1991	IGNITION SYSTEM - ROPE START
E50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50TLENJ 1992	IGNITION SYSTEM - ROPE START
E50TLENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
E50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50TLENM 1992	IGNITION SYSTEM - ROPE START
E50TLENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
E50TLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50TLEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E50TLEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS

E50TLERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E50TLERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E50TLERE 1994	IGNITION SYSTEM - 40 ROPE START
E50TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TLESR 1990	IGNITION SYSTEM - ROPE START
E50TLETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E50TLETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E50TLETB 1993	IGNITION SYSTEM - 40 ROPE START
E50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLETF 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
E50TLETF 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
E50TLETF 1993	IGNITION SYSTEM - 40 ROPE START
E50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLEUC 1997	IGNITION SYSTEM - ROPE START
E50TLEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
E50TSLECC 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
E50TSLECC 1998	IGNITION SYSTEM -- ROPE START
E50TSLEUS 1997	IGNITION SYSTEM - ROPE START
E50TSLEUS 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
E50TTLECA 1998	IGNITION SYSTEM
E50TTLEDC 1996	IGNITION SYSTEM
E50TTLEOS 1995	IGNITION SYSTEM
E50TTLEUR 1997	IGNITION SYSTEM
E55RCIM 1981	IGNITION SYSTEM
E55RLCSA 1980	IGNITION SYSTEM
E55RSLC 1997	IGNITION SYSTEM
E55RSLG 1995	IGNITION SYSTEM
E55RSLN 1983	IGNITION SYSTEM
E55RSLN-2 1983	IGNITION SYSTEM

E55RSLW 1996	IGNITION SYSTEM
E55RSN 1983	IGNITION SYSTEM
E55RSN-2 1983	IGNITION SYSTEM
E55RSYN 1983	IGNITION SYSTEM
E55RSYN-2 1983	IGNITION SYSTEM
E55RWLCDC 1986	IGNITION SYSTEM
E55RWLCOS 1985	IGNITION SYSTEM
E55RWLCRD 1984	IGNITION SYSTEM
E55RWLCUC 1987	IGNITION SYSTEM
E55RWLE 1989	IGNITION
E55RWLEIA 1991	IGNITION SYSTEM
E55RWLENM 1992	IGNITION SYSTEM - ELECTRIC
E55RWLENM 1992	IGNITION SYSTEM - ROPE START
E55RWLERE 1994	IGNITION SYSTEM
E55RWLESR 1990	IGNITION
E55RWLETB 1993	IGNITION SYSTEM
E55TLCIM 1981	IGNITION SYSTEM
E55WREES 1999	IGNITION SYSTEM
E55WRLEES 1999	IGNITION SYSTEM
E55WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
E55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM
E55WRSIR commercial, rope start, 15 in shaft 2001	IGNITION SYSTEM
E55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
E55WRYEES 1999	IGNITION SYSTEM
E55WRYSIR commercial, rope start, 25 in shaft 2001	IGNITION SYSTEM
E55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	IGNITION SYSTEM
E5DRECR 1998	IGNITION
E5DRLECR 1998	IGNITION
E5R4EEM 1999	IGNITION
E5R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	IGNITION
E5R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. Shaft 2000	IGNITION
E5RB4EER 1999	IGNITION
E5RBL4EER 1999	IGNITION
E5RCIC 1981	MAGNETO - 7.5
E5RCIC 1981	MAGNETO-4.5

E5RCSS 1980	MAGNETO - 7.5
E5RCSS 1980	MAGNETO-4.5
E5RHCIC 1981	MAGNETO - 7.5
E5RHCIC 1981	MAGNETO-4.5
E5RHCNR 1982	MAGNETO - 4.5
E5RHCNR 1982	MAGNETO - 7.5
E5RHCSS 1980	MAGNETO - 7.5
E5RHCSS 1980	MAGNETO-4.5
E5RHCTA 1983	MAGNETO-4.5
E5RHCTA 1983	MAGNETO-7.5
E5RHLCIC 1981	MAGNETO - 7.5
E5RHLCIC 1981	MAGNETO-4.5
E5RHLCNR 1982	MAGNETO - 4.5
E5RHLCNR 1982	MAGNETO - 7.5
E5RHLCSS 1980	MAGNETO - 7.5
E5RHLCSS 1980	MAGNETO-4.5
E5RHLCTA 1983	MAGNETO-4.5
E5RHLCTA 1983	MAGNETO-7.5
E5RL4EEM 1999	IGNITION
E5RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	IGNITION
E5RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. Shaft 2000	IGNITION
E5RLCIC 1981	MAGNETO - 7.5
E5RLCIC 1981	MAGNETO-4.5
E5RLCSS 1980	MAGNETO - 7.5
E5RLCSS 1980	MAGNETO-4.5
E60ECIA 1981	IGNITION SYSTEM
E60ECIH 1981	IGNITION SYSTEM
E60ECNM 1982	IGNITION SYSTEM
E60ECSR 1980	IGNITION SYSTEM
E60ECTB 1983	IGNITION SYSTEM
E60ELCCR 1988	IGNITION SYSTEM
E60ELCDS 1986	IGNITION SYSTEM
E60ELCEA 1989	IGNITION SYSTEM 60EL - 60TL
E60ELCEA 1989	IGNITION SYSTEM 60TTL
E60ELCIA 1981	IGNITION SYSTEM

E60ELCIH 1981	IGNITION SYSTEM
E60ELCNM 1982	IGNITION SYSTEM
E60ELCOD 1985	IGNITION SYSTEM
E60ELCRE 1984	IGNITION SYSTEM
E60ELCSR 1980	IGNITION SYSTEM
E60ELCTB 1983	IGNITION SYSTEM
E60ELCUC 1987	IGNITION SYSTEM
E60ELED R 1996	IGNITION SYSTEM
E60ELED R 1996	IGNITION SYSTEM - E70RNLIB ONLY
E60ELEIB 1991	IGNITION SYSTEM
E60ELENE 1992	IGNITION SYSTEM
E60ELEOC 1995	IGNITION SYSTEM
E60ELERS 1994	IGNITION SYSTEM
E60ELERV 1994	IGNITION SYSTEM
E60ELES M 1990	IGNITION SYSTEM 60EL - 60TL
E60ELES M 1990	IGNITION SYSTEM 60TTL
E60ELET D 1993	IGNITION SYSTEM
E60ELEUA 1997	IGNITION SYSTEM
E60TLCCR 1988	IGNITION SYSTEM
E60TLCDS 1986	IGNITION SYSTEM
E60TLCEA 1989	IGNITION SYSTEM 60EL - 60TL
E60TLCEA 1989	IGNITION SYSTEM 60TTL
E60TLCIA 1981	IGNITION SYSTEM
E60TLCIH 1981	IGNITION SYSTEM
E60TLCNM 1982	IGNITION SYSTEM
E60TLCOD 1985	IGNITION SYSTEM
E60TLCRE 1984	IGNITION SYSTEM
E60TLCTB 1983	IGNITION SYSTEM
E60TLCUC 1987	IGNITION SYSTEM
E60TLECM 1998	IGNITION SYSTEM
E60TLED R 1996	IGNITION SYSTEM
E60TLED R 1996	IGNITION SYSTEM - E70RNLIB ONLY
E60TLEIB 1991	IGNITION SYSTEM
E60TLENE 1992	IGNITION SYSTEM
E60TLEOC 1995	IGNITION SYSTEM

E60TLERS 1994	IGNITION SYSTEM
E60TLERV 1994	IGNITION SYSTEM
E60TLESM 1990	IGNITION SYSTEM 60EL - 60TL
E60TLESM 1990	IGNITION SYSTEM 60TTL
E60TLETD 1993	IGNITION SYSTEM
E60TLEUA 1997	IGNITION SYSTEM
E60TTLCCR 1988	IGNITION SYSTEM
E60TTLCEA 1989	IGNITION SYSTEM 60EL - 60TL
E60TTLCEA 1989	IGNITION SYSTEM 60TTL
E60TTLECM 1998	IGNITION SYSTEM
E60TTLEDR 1996	IGNITION SYSTEM
E60TTLEIB 1991	IGNITION SYSTEM
E60TTLENE 1992	IGNITION SYSTEM
E60TTLEOC 1995	IGNITION SYSTEM
E60TTLERS 1994	IGNITION SYSTEM
E60TTLERV 1994	IGNITION SYSTEM
E60TTLESM 1990	IGNITION SYSTEM 60EL - 60TL
E60TTLESM 1990	IGNITION SYSTEM 60TTL
E60TTLETD 1993	IGNITION SYSTEM
E60TTLEUA 1997	IGNITION SYSTEM
E65RSLC 1995	IGNITION SYSTEM
E65RSLM 1996	IGNITION SYSTEM
E65RSLZ2 1997	IGNITION SYSTEM
E65RWLCDR 1986	IGNITION SYSTEM
E65RWLCOC 1985	IGNITION SYSTEM
E65RWLCRS 1984	IGNITION SYSTEM
E65TELCDR 1986	IGNITION SYSTEM
E65TELCOC 1985	IGNITION SYSTEM
E65TELCRS 1984	IGNITION SYSTEM
E65WELEES 1999	IGNITION SYSTEM
E65WELSIR Commercial, elec start, 20 in shaft 2001	IGNITION SYSTEM
E65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	IGNITION SYSTEM
E65WMLCDR 1986	IGNITION SYSTEM
E65WMLCOC 1985	IGNITION SYSTEM
E65WMLCUA 1987	IGNITION SYSTEM

E65WMLEIB 1991	IGNITION SYSTEM
E65WMLENE 1992	IGNITION SYSTEM - VRO MODELS
E65WMLEOC 1995	IGNITION SYSTEM - VRO MODELS
E65WMLEOC 1995	IGNITION SYSTEM - NON-VRO MODELS
E65WMLERS 1994	IGNITION SYSTEM - VRO MODELS
E65WMLESM 1990	IGNITION SYSTEM
E65WMLETD 1993	IGNITION SYSTEM - VRO MODELS
E65WMLZ 1989	IGNITION SYSTEM
E65WRLEEO 1999	IGNITION SYSTEM
E65WRLEES 1999	IGNITION SYSTEM
E65WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
E65WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	IGNITION SYSTEM
E65WRYEEO 1999	IGNITION SYSTEM
E65WRYEES 1999	IGNITION SYSTEM
E65WRYSIR commercial, rope start, 22.5 in shaft 2001	IGNITION SYSTEM
E65WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	IGNITION SYSTEM
E65WTLCOB 1985	IGNITION SYSTEM
E65WTLCRS 1984	IGNITION SYSTEM
E6R4EEM 1999	IGNITION
E6R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	IGNITION
E6R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. Shaft 2000	IGNITION
E6RCCS 1988	IGNITION
E6RCDE 1986	MAGNETO
E6RCEC 1989	IGNITION
E6RCOB 1985	MAGNETO
E6RCRM 1984	MAGNETO - 6/8
E6RCUD 1987	IGNITION
E6RECR 1998	IGNITION
E6REDS 1996	IGNITION
E6REIA 1991	IGNITION
E6RENM 1992	IGNITION
E6REOD 1995	IGNITION
E6RERE 1994	IGNITION
E6RESR 1990	IGNITION
E6RETB 1993	IGNITION

E6REUC 1997	IGNITION
E6RL4EEM 1999	IGNITION
E6RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	IGNITION
E6RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. Shaft 2000	IGNITION
E6RLCCS 1988	IGNITION
E6RLCDE 1986	MAGNETO
E6RLCEC 1989	IGNITION
E6RLCOB 1985	MAGNETO
E6RLCRM 1984	MAGNETO - 6/8
E6RLCUD 1987	IGNITION
E6RLECR 1998	IGNITION
E6RLEDS 1996	IGNITION
E6RLEIA 1991	IGNITION
E6RLENM 1992	IGNITION
E6RLEOD 1995	IGNITION
E6RLERE 1994	IGNITION
E6RLESR 1990	IGNITION
E6RLETB 1993	IGNITION
E6RLEUC 1997	IGNITION
E6SLCCS 1988	IGNITION
E6SLCDE 1986	MAGNETO
E6SLCEC 1989	IGNITION
E6SLCOB 1985	MAGNETO
E6SLCRM 1984	MAGNETO - 6/8
E6SLCUD 1987	IGNITION
E6SLEDS 1996	IGNITION
E6SLEIA 1991	IGNITION
E6SLENM 1992	IGNITION
E6SLEOD 1995	IGNITION
E6SLERE 1994	IGNITION
E6SLESR 1990	IGNITION
E6SLETB 1993	IGNITION
E70ELCCA 1988	IGNITION SYSTEM
E70ELCDC 1986	IGNITION SYSTEM
E70ELCEM 1989	IGNITION SYSTEM

E70ELCIH 1981	IGNITION SYSTEM
E70ELCIM 1981	IGNITION SYSTEM
E70ELCNB 1982	IGNITION SYSTEM
E70ELCOS 1985	IGNITION SYSTEM
E70ELCRD 1984	IGNITION SYSTEM
E70ELCSA 1980	IGNITION SYSTEM
E70ELCTE 1983	IGNITION SYSTEM
E70ELCUR 1987	IGNITION SYSTEM
E70ELEIE 1991	IGNITION SYSTEM
E70ELEND 1992	IGNITION SYSTEM
E70ELEOR 1995	IGNITION SYSTEM
E70ELERC 1994	IGNITION SYSTEM
E70ELERV 1994	IGNITION SYSTEM
E70ELESB 1990	IGNITION SYSTEM
E70ELETs 1993	IGNITION SYSTEM
E70TLCCA 1988	IGNITION SYSTEM
E70TLCDC 1986	IGNITION SYSTEM
E70TLCEM 1989	IGNITION SYSTEM
E70TLCIM 1981	IGNITION SYSTEM
E70TLCNB 1982	IGNITION SYSTEM
E70TLCOS 1985	IGNITION SYSTEM
E70TLCRD 1984	IGNITION SYSTEM
E70TLCTE 1983	IGNITION SYSTEM
E70TLCUR 1987	IGNITION SYSTEM
E70TLECB 1998	IGNITION SYSTEM
E70TLEDA 1996	IGNITION SYSTEM
E70TLEDA 1996	IGNITION SYSTEM - E70RNLIB ONLY
E70TLEIE 1991	IGNITION SYSTEM
E70TLEND 1992	IGNITION SYSTEM
E70TLEOR 1995	IGNITION SYSTEM
E70TLERC 1994	IGNITION SYSTEM
E70TLERV 1994	IGNITION SYSTEM
E70TLESB 1990	IGNITION SYSTEM
E70TLETs 1993	IGNITION SYSTEM
E70TLEUM 1997	IGNITION SYSTEM

E70TTLEIE 1991	IGNITION SYSTEM
E70TTLEND 1992	IGNITION SYSTEM
E70TTLEOR 1995	IGNITION SYSTEM
E70TTLERC 1994	IGNITION SYSTEM
E70TTLERV 1994	IGNITION SYSTEM
E70TTLETS 1993	IGNITION SYSTEM
E75ECCA 1988	IGNITION SYSTEM
E75ECDC 1986	IGNITION SYSTEM
E75ECOS 1985	IGNITION SYSTEM
E75ECD 1984	IGNITION SYSTEM
E75ECUR 1987	IGNITION SYSTEM
E75ELCRD 1984	IGNITION SYSTEM
E75ERCIH 1981	IGNITION SYSTEM
E75ERCIM 1981	IGNITION SYSTEM
E75ERCNB 1982	IGNITION SYSTEM
E75ERCSA 1980	IGNITION SYSTEM
E75ERCTE 1983	IGNITION SYSTEM
E75ERLCIH 1981	IGNITION SYSTEM
E75ERLCIM 1981	IGNITION SYSTEM
E75ERLCNB 1982	IGNITION SYSTEM
E75ERLCSA 1980	IGNITION SYSTEM
E75ERLCTE 1983	IGNITION SYSTEM
E75TLCRD 1984	IGNITION SYSTEM
E75TRLCIH 1981	IGNITION SYSTEM
E75TRLCIM 1981	IGNITION SYSTEM
E75TRLCNB 1982	IGNITION SYSTEM
E75TRLCSA 1980	IGNITION SYSTEM
E75TRLCTE 1983	IGNITION SYSTEM
E85MLCSA 1980	IGNITION SYSTEM
E85STLCSA 1980	IGNITION SYSTEM
E85STXCSA 1980	IGNITION SYSTEM
E85TTLEIE 1991	IGNITION SYSTEM
E85TTLEND 1992	IGNITION SYSTEM
E85TTLEOR 1995	IGNITION SYSTEM
E85TTLERC 1994	IGNITION SYSTEM

E85TTLETS 1993	IGNITION SYSTEM
E88MSLCCC 1988	IGNITION SYSTEM
E88MSLCER 1989	IGNITION SYSTEM
E88MSLCUS 1987	IGNITION SYSTEM
E88MSLEDC 1996	IGNITION SYSTEM
E88MSLEIM 1991	IGNITION SYSTEM
E88MSLENB 1992	IGNITION SYSTEM
E88MSLEOS 1995	IGNITION SYSTEM
E88MSLERD 1994	IGNITION SYSTEM
E88MSLESA 1990	IGNITION SYSTEM
E88MSLETE 1993	IGNITION SYSTEM
E88TSLEDR 1996	IGNITION SYSTEM
E88TSLEOC 1995	IGNITION SYSTEM
E88TSLERS 1994	IGNITION SYSTEM
E8DREEA 1999	IGNITION
E8DRSSM Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
E8FRECA 1998	IGNITION -- ELECTRIC
E8FRECA 1998	IGNITION -- ROPE
E8FREDC 1996	IGNITION - ELECTRIC
E8FREDC 1996	IGNITION - ROPE
E8FREUR 1997	IGNITION - ELECTRIC
E8FREUR 1997	IGNITION - ROPE
E8FRLECA 1998	IGNITION -- ELECTRIC
E8FRLECA 1998	IGNITION -- ROPE
E8FRXECA 1998	IGNITION -- ELECTRIC
E8FRXECA 1998	IGNITION -- ROPE
E8FRXEDC 1996	IGNITION - ELECTRIC
E8FRXEDC 1996	IGNITION - ROPE
E8FRXEUR 1997	IGNITION - ELECTRIC
E8FRXEUR 1997	IGNITION - ROPE
E8R4EEM 1999	IGNITION
E8R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	IGNITION
E8R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
E8RB4EEM 1999	IGNITION
E8RBL4EEM 1999	IGNITION

E8RCCS 1988	IGNITION
E8RCDE 1986	MAGNETO
E8RCEC 1989	IGNITION
E8RCIC 1981	MAGNETO - 7.5
E8RCIC 1981	MAGNETO-4.5
E8RCNR 1982	MAGNETO - 4.5
E8RCNR 1982	MAGNETO - 7.5
E8RCOB 1985	MAGNETO
E8RCRM 1984	MAGNETO - 6/8
E8RCSS 1980	MAGNETO - 7.5
E8RCSS 1980	MAGNETO-4.5
E8RCTA 1983	MAGNETO-4.5
E8RCTA 1983	MAGNETO-7.5
E8RCUD 1987	IGNITION
E8RECR 1998	IGNITION
E8REDS 1996	IGNITION
E8REIA 1991	IGNITION
E8RENM 1992	IGNITION
E8REOD 1995	IGNITION
E8RERE 1994	IGNITION
E8RESR 1990	IGNITION
E8RETB 1993	IGNITION
E8REUC 1997	IGNITION
E8RL4EEM 1999	IGNITION
E8RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	IGNITION
E8RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
E8RLCCS 1988	IGNITION
E8RLCDE 1986	MAGNETO
E8RLCEC 1989	IGNITION
E8RLCIC 1981	MAGNETO - 7.5
E8RLCIC 1981	MAGNETO-4.5
E8RLCNR 1982	MAGNETO - 4.5
E8RLCNR 1982	MAGNETO - 7.5
E8RLCOB 1985	MAGNETO
E8RLCRM 1984	MAGNETO - 6/8

E8RLCSS 1980	MAGNETO - 7.5
E8RLCSS 1980	MAGNETO-4.5
E8RLCTA 1983	MAGNETO-4.5
E8RLCTA 1983	MAGNETO-7.5
E8RLCUD 1987	IGNITION
E8RLECR 1998	IGNITION
E8RLEDS 1996	IGNITION
E8RLEIA 1991	IGNITION
E8RLENM 1992	IGNITION
E8RLEOD 1995	IGNITION
E8RLERE 1994	IGNITION
E8RLESR 1990	IGNITION
E8RLETB 1993	IGNITION
E8RLEUC 1997	IGNITION
E8RVL4SIC 4-stroke, rope start, tiller, 20 in shaft, wht 2001	IGNITION
E8RVL4SSB 4-Stroke, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
E8SRLCCS 1988	IGNITION
E8SRLCDE 1986	MAGNETO
E8SRLCEC 1989	IGNITION
E8SRLCNR 1982	MAGNETO - 4.5
E8SRLCNR 1982	MAGNETO - 7.5
E8SRLCOB 1985	MAGNETO
E8SRLCRM 1984	MAGNETO - 6/8
E8SRLCTA 1983	MAGNETO-4.5
E8SRLCTA 1983	MAGNETO-7.5
E8SRLCUD 1987	IGNITION
E8SRLECA 1998	IGNITION
E8SRLEDS 1996	IGNITION
E8SRLEIA 1991	IGNITION
E8SRLENM 1992	IGNITION
E8SRLEOD 1995	IGNITION
E8SRLERE 1994	IGNITION
E8SRLESR 1990	IGNITION
E8SRLETB 1993	IGNITION

E8SRLEUC 1997	IGNITION
E8WREES 1999	IGNITION
E8WRLEES 1999	IGNITION
E8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	IGNITION
E8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
E8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	IGNITION
E8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
E90JLEIE 1991	IGNITION SYSTEM
E90JLEND 1992	IGNITION SYSTEM
E90JLEOR 1995	IGNITION SYSTEM
E90JLERC 1994	IGNITION SYSTEM
E90JLETS 1993	IGNITION SYSTEM
E90MLCDC 1986	IGNITION SYSTEM
E90MLCIH 1981	IGNITION SYSTEM
E90MLCIM 1981	IGNITION SYSTEM
E90MLCNB 1982	IGNITION SYSTEM
E90MLCOS 1985	IGNITION SYSTEM
E90MLCRD 1984	IGNITION SYSTEM
E90MLCTE 1983	IGNITION SYSTEM
E90MLCUR 1987	IGNITION SYSTEM
E90MLEOR 1995	IGNITION SYSTEM
E90MLERC 1994	IGNITION SYSTEM
E90TLCCA 1988	IGNITION SYSTEM
E90TLCDC 1986	IGNITION SYSTEM
E90TLCEM 1989	IGNITION SYSTEM
E90TLCIH 1981	IGNITION SYSTEM
E90TLCIM 1981	IGNITION SYSTEM
E90TLCNB 1982	IGNITION SYSTEM
E90TLCOS 1985	IGNITION SYSTEM
E90TLCRD 1984	IGNITION SYSTEM
E90TLCTE 1983	IGNITION SYSTEM
E90TLCUR 1987	IGNITION SYSTEM
E90TLEDA 1996	IGNITION SYSTEM
E90TLEIE 1991	IGNITION SYSTEM
E90TLEND 1992	IGNITION SYSTEM

E90TLEOR 1995	IGNITION SYSTEM
E90TLERC 1994	IGNITION SYSTEM
E90TLESB 1990	IGNITION SYSTEM
E90TLETS 1993	IGNITION SYSTEM
E90TSLECM 1998	IGNITION SYSTEM
E90TSLEUA 1997	IGNITION SYSTEM
E90TXARC 1994	IGNITION SYSTEM
E90TXATS 1993	IGNITION SYSTEM
E90TXCDC 1986	IGNITION SYSTEM
E90TXCIH 1981	IGNITION SYSTEM
E90TXCIM 1981	IGNITION SYSTEM
E90TXCNB 1982	IGNITION SYSTEM
E90TXCOS 1985	IGNITION SYSTEM
E90TXCRD 1984	IGNITION SYSTEM
E90TXCTE 1983	IGNITION SYSTEM
EJR-CCM 1988	MAGNETO
EJR-CDR 1986	MAGNETO
EJR-CEB 1989	MAGNETO
EJR-CUA 1987	MAGNETO
EJR-ESE 1990	MAGNETO
HE10FDEDC 1996	IGNITION - ELECTRIC
HE10FDEDC 1996	IGNITION - ROPE
HE10FDLEDC 1996	IGNITION - ELECTRIC
HE10FDLEDC 1996	IGNITION - ROPE
HE10FELECA 1998	IGNITION -- ELECTRIC
HE10FELECA 1998	IGNITION -- ROPE
HE10FELEDC 1996	IGNITION - ELECTRIC
HE10FELEDC 1996	IGNITION - ROPE
HE10FELEUR 1997	IGNITION - ELECTRIC
HE10FELEUR 1997	IGNITION - ROPE
HE10FOEUR 1997	IGNITION - ELECTRIC
HE10FOEUR 1997	IGNITION - ROPE
HE10FOLEUR 1997	IGNITION - ELECTRIC
HE10FOLEUR 1997	IGNITION - ROPE
HE10FTEDC 1996	IGNITION - ELECTRIC

HE10FTEDC 1996	IGNITION - ROPE
HE10FTEUR 1997	IGNITION - ELECTRIC
HE10FTEUR 1997	IGNITION - ROPE
HE10FTLEDC 1996	IGNITION - ELECTRIC
HE10FTLEDC 1996	IGNITION - ROPE
HE10FTLEUR 1997	IGNITION - ELECTRIC
HE10FTLEUR 1997	IGNITION - ROPE
HE115TXADA 1996	IGNITION SYSTEM
HE130CXADA 1996	IGNITION SYSTEM
HE130CXAUM 1997	IGNITION SYSTEM
HE130TXACB 1998	IGNITION SYSTEM
HE130TXADA 1996	IGNITION SYSTEM
HE130TXAUM 1997	IGNITION SYSTEM
HE15KCF 1997	IGNITION
HE15KCLF 1997	IGNITION
HE15KCLN 1996	IGNITION
HE15KCLO 1998	IGNITION
HE15KCN 1996	IGNITION
HE15KCO 1998	IGNITION
HE15RPLW 1997	IGNITION
HE15RPW 1997	IGNITION
HE20CREDA 1996	IGNITION
HE20CRLEDA 1996	IGNITION
HE25FPO 1996	IGNITION - H25FP
HE25FPO 1996	IGNITION - 25RS - 25RW - S25RP
HE25FPV 1997	IGNITION - H25FP
HE25FPV 1997	IGNITION - 25RS, 25RW, S25RP
HE25RAEDA 1996	IGNITION
HE25RAEUM 1997	IGNITION
HE25REDA 1996	IGNITION
HE25RLEDA 1996	IGNITION
HE25RSLO 1996	IGNITION - H25FP
HE25RSLO 1996	IGNITION - 25RS - 25RW - S25RP
HE25RSLV 1997	IGNITION - H25FP
HE25RSLV 1997	IGNITION - 25RS, 25RW, S25RP

HE25TELEDA 1996	IGNITION
HE30REDE 1996	IGNITION
HE30RLEDE 1996	IGNITION
HE40REDS 1996	IGNITION SYSTEM - 40 ROPE START
HE40REDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
HE40REDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
HE40REUC 1997	IGNITION SYSTEM - ROPE START
HE40REUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
HE40RLEDS 1996	IGNITION SYSTEM - 40 ROPE START
HE40RLEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
HE40RLEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
HE40RLEUC 1997	IGNITION SYSTEM - ROPE START
HE40RLEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
HE45RCLEDS 1996	IGNITION SYSTEM
HE45RCLEUC 1997	IGNITION SYSTEM
HE55RSLC 1997	IGNITION SYSTEM
HE55RSLW 1996	IGNITION SYSTEM
HE55WMLM 1996	IGNITION SYSTEM
HE55WMLZ 1997	IGNITION SYSTEM
HE5FRECA 1998	IGNITION
HE5FREUR 1997	IGNITION
HE5FRLECA 1998	IGNITION
HE5FRLEUR 1997	IGNITION
HE6FRECA 1998	IGNITION
HE6FREUR 1997	IGNITION
HE6FRLECA 1998	IGNITION
HE6FRLEUR 1997	IGNITION
HE70TXEDA 1996	IGNITION SYSTEM
HE70TXEDA 1996	IGNITION SYSTEM - E70RNLIB ONLY
HE70TXEUM 1997	IGNITION SYSTEM
HE88MSLEDC 1996	IGNITION SYSTEM
HE8FREDC 1996	IGNITION - ELECTRIC
HE8FREDC 1996	IGNITION - ROPE
HE8FREUR 1997	IGNITION - ELECTRIC

HE8FREUR 1997	IGNITION - ROPE
HE8FRLEDC 1996	IGNITION - ELECTRIC
HE8FRLEDC 1996	IGNITION - ROPE
HE8FRLEUR 1997	IGNITION - ELECTRIC
HE8FRLEUR 1997	IGNITION - ROPE
HE90MLEDA 1996	IGNITION SYSTEM
HE90TXADA 1996	IGNITION SYSTEM
HJ10FDEDC 1996	IGNITION - ELECTRIC
HJ10FDEDC 1996	IGNITION - ROPE
HJ10FDLEDC 1996	IGNITION - ELECTRIC
HJ10FDLEDC 1996	IGNITION - ROPE
HJ10FELECA 1998	IGNITION -- ELECTRIC
HJ10FELECA 1998	IGNITION -- ROPE
HJ10FELEDC 1996	IGNITION - ELECTRIC
HJ10FELEDC 1996	IGNITION - ROPE
HJ10FELEUR 1997	IGNITION - ELECTRIC
HJ10FELEUR 1997	IGNITION - ROPE
HJ10FOEUR 1997	IGNITION - ELECTRIC
HJ10FOEUR 1997	IGNITION - ROPE
HJ10FOLEUR 1997	IGNITION - ELECTRIC
HJ10FOLEUR 1997	IGNITION - ROPE
HJ10FTEDC 1996	IGNITION - ELECTRIC
HJ10FTEDC 1996	IGNITION - ROPE
HJ10FTEUR 1997	IGNITION - ELECTRIC
HJ10FTEUR 1997	IGNITION - ROPE
HJ10FTLEDC 1996	IGNITION - ELECTRIC
HJ10FTLEDC 1996	IGNITION - ROPE
HJ10FTLEUR 1997	IGNITION - ELECTRIC
HJ10FTLEUR 1997	IGNITION - ROPE
HJ115TXADA 1996	IGNITION SYSTEM
HJ130CXADA 1996	IGNITION SYSTEM
HJ130CXAUM 1997	IGNITION SYSTEM
HJ130TXACB 1998	IGNITION SYSTEM
HJ130TXADA 1996	IGNITION SYSTEM
HJ130TXAUM 1997	IGNITION SYSTEM

HJ15KCF 1997	IGNITION
HJ15KCLF 1997	IGNITION
HJ15KCLN 1996	IGNITION
HJ15KCLO 1998	IGNITION
HJ15KCN 1996	IGNITION
HJ15KCO 1998	IGNITION
HJ15RPLW 1997	IGNITION
HJ15RPW 1997	IGNITION
HJ20CREDA 1996	IGNITION
HJ20CRLEDA 1996	IGNITION
HJ25FPO 1996	IGNITION - H25FP
HJ25FPO 1996	IGNITION - 25RS - 25RW - S25RP
HJ25FPV 1997	IGNITION - H25FP
HJ25FPV 1997	IGNITION - 25RS, 25RW, S25RP
HJ25RAEDA 1996	IGNITION
HJ25RAEUM 1997	IGNITION
HJ25RLEDA 1996	IGNITION
HJ25RLSV 1997	IGNITION - H25FP
HJ25RLSV 1997	IGNITION - 25RS, 25RW, S25RP
HJ25RSLO 1996	IGNITION - H25FP
HJ25RSLO 1996	IGNITION - 25RS - 25RW - S25RP
HJ25TELEDA 1996	IGNITION
HJ30REDE 1996	IGNITION
HJ30RLEDE 1996	IGNITION
HJ40REDS 1996	IGNITION SYSTEM - 40 ROPE START
HJ40REDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
HJ40REDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
HJ40REUC 1997	IGNITION SYSTEM - ROPE START
HJ40REUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
HJ40RLEDS 1996	IGNITION SYSTEM - 40 ROPE START
HJ40RLEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
HJ40RLEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
HJ40RLEUC 1997	IGNITION SYSTEM - ROPE START
HJ40RLEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START

HJ45RCLEDS 1996	IGNITION SYSTEM
HJ45RCLEUC 1997	IGNITION SYSTEM
HJ55RSLC 1997	IGNITION SYSTEM
HJ55RSLW 1996	IGNITION SYSTEM
HJ55WMLM 1996	IGNITION SYSTEM
HJ55WMLZ 1997	IGNITION SYSTEM
HJ5FRECA 1998	IGNITION
HJ5FREUR 1997	IGNITION
HJ5FRLECA 1998	IGNITION
HJ5FRLEUR 1997	IGNITION
HJ6FRECA 1998	IGNITION
HJ6FREUR 1997	IGNITION
HJ6FRLECA 1998	IGNITION
HJ6FRLEUR 1997	IGNITION
HJ70TXEDA 1996	IGNITION SYSTEM
HJ70TXEDA 1996	IGNITION SYSTEM - E70RNLIB ONLY
HJ70TXEUM 1997	IGNITION SYSTEM
HJ88MSLEDC 1996	IGNITION SYSTEM
HJ8FREDC 1996	IGNITION - ELECTRIC
HJ8FREDC 1996	IGNITION - ROPE
HJ8FREUR 1997	IGNITION - ELECTRIC
HJ8FREUR 1997	IGNITION - ROPE
HJ8FRLEDC 1996	IGNITION - ELECTRIC
HJ8FRLEDC 1996	IGNITION - ROPE
HJ8FRLEUR 1997	IGNITION - ELECTRIC
HJ8FRLEUR 1997	IGNITION - ROPE
HJ90MLEDA 1996	IGNITION SYSTEM
HJ90TXADA 1996	IGNITION SYSTEM
J100MLCSC 1980	IGNITION SYSTEM
J100STLCCA 1988	IGNITION SYSTEM
J100STLCEM 1989	IGNITION SYSTEM
J100STLEIE 1991	IGNITION SYSTEM
J100STLEND 1992	IGNITION SYSTEM
J100STLERC 1994	IGNITION SYSTEM
J100STLESB 1990	IGNITION SYSTEM

J100STLETS 1993	IGNITION SYSTEM
J100TRLCSC 1980	IGNITION SYSTEM
J100TRXCSC 1980	IGNITION SYSTEM
J100WMLCDR 1986	IGNITION SYSTEM
J100WMLCOC 1985	IGNITION SYSTEM
J100WMLCRS 1984	IGNITION SYSTEM
J100WTLCDR 1986	IGNITION SYSTEM
J100WTLCOG 1985	IGNITION SYSTEM
J100WTLCRS 1984	IGNITION SYSTEM
J100WTLGUA 1987	IGNITION SYSTEM
J100WTLEDR 1996	IGNITION SYSTEM
J100WTLEIB 1991	IGNITION SYSTEM
J100WTLENE 1992	IGNITION SYSTEM
J100WTLEOC 1995	IGNITION SYSTEM
J100WTLERS 1994	IGNITION SYSTEM
J100WTLESM 1990	IGNITION SYSTEM
J100WTLETD 1993	IGNITION SYSTEM
J100WTLEUA 1997	IGNITION SYSTEM
J100WTLZ 1989	IGNITION SYSTEM
J100WTXCDR 1986	IGNITION SYSTEM
J100WTXCUA 1987	IGNITION SYSTEM
J100WTXEDR 1996	IGNITION SYSTEM
J100WTXEIB 1991	IGNITION SYSTEM
J100WTXENE 1992	IGNITION SYSTEM
J100WTXEOG 1995	IGNITION SYSTEM
J100WTXERS 1994	IGNITION SYSTEM
J100WTXESM 1990	IGNITION SYSTEM
J100WTXETD 1993	IGNITION SYSTEM
J100WTXEUA 1997	IGNITION SYSTEM
J100WTXZ 1989	IGNITION SYSTEM
J10ECCD 1988	IGNITION
J10ECDB 1986	IGNITION
J10ECES 1989	IGNITION
J10ECOM 1985	IGNITION
J10ECSE 1980	MAGNETO

J10ECUE 1987	IGNITION
J10EECC 1998	IGNITION -- ELECTRIC
J10EECC 1998	IGNITION -- ROPE
J10EEDD 1996	IGNITION - ELECTRIC
J10EEDD 1996	IGNITION - ROPE
J10EEIR 1991	IGNITION
J10EENA 1992	IGNITION
J10EEOE 1995	IGNITION - ELECTRIC
J10EEOE 1995	IGNITION - ROPE
J10EERB 1994	IGNITION - ELECTRIC
J10EERB 1994	IGNITION - ROPE
J10EESC 1990	IGNITION
J10EETM 1993	IGNITION - ELECTRIC
J10EETM 1993	IGNITION - ROPE
J10EEUS 1997	IGNITION - ELECTRIC
J10EEUS 1997	IGNITION - ROPE
J10ELCCD 1988	IGNITION
J10ELCDB 1986	IGNITION
J10ELCES 1989	IGNITION
J10ELCID 1981	MAGNETO
J10ELCNS 1982	MAGNETO
J10ELCOM 1985	IGNITION
J10ELCRA 1984	MAGNETO
J10ELCSE 1980	MAGNETO
J10ELCTC 1983	MAGNETO
J10ELCUE 1987	IGNITION
J10ELECC 1998	IGNITION -- ELECTRIC
J10ELECC 1998	IGNITION -- ROPE
J10ELEDD 1996	IGNITION - ELECTRIC
J10ELEDD 1996	IGNITION - ROPE
J10ELEER 1999	IGNITION -- ROPE
J10ELEER 1999	IGNITION -- ELECTRIC
J10ELEIR 1991	IGNITION
J10ELENA 1992	IGNITION
J10ELEOE 1995	IGNITION - ELECTRIC

J10ELEOE 1995	IGNITION - ROPE
J10ELERB 1994	IGNITION - ELECTRIC
J10ELERB 1994	IGNITION - ROPE
J10ELESC 1990	IGNITION
J10ELETM 1993	IGNITION - ELECTRIC
J10ELETM 1993	IGNITION - ROPE
J10ELEUS 1997	IGNITION - ELECTRIC
J10ELEUS 1997	IGNITION - ROPE
J10ELSIM elec start, remote, 20 in shaft 2001	IGNITION - ROPE
J10ELSIM elec start, remote, 20 in shaft 2001	IGNITION - ELECTRIC
J10ELSSA Electric Start, 15 IN. shaft 2000	IGNITION - ROPE
J10ELSSA Electric Start, 15 IN. shaft 2000	IGNITION-ELECTRIC
J10EVLISIC elec start, 20 in shaft, wht 2001	IGNITION - ROPE
J10EVLISIC elec start, 20 in shaft, wht 2001	IGNITION - ELECTRIC
J10EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION - ROPE
J10EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION-ELECTRIC
J10FOECA 1998	IGNITION -- ELECTRIC
J10FOECA 1998	IGNITION -- ROPE
J10FOLECA 1998	IGNITION -- ELECTRIC
J10FOLECA 1998	IGNITION -- ROPE
J10RCCD 1988	IGNITION
J10RCDB 1986	IGNITION
J10RCES 1989	IGNITION
J10RCID 1981	MAGNETO
J10RCNS 1982	MAGNETO
J10RCOM 1985	IGNITION
J10RCRA 1984	MAGNETO
J10RCSE 1980	MAGNETO
J10RCTC 1983	MAGNETO
J10RCTR 1983	MAGNETO
J10RCUE 1987	IGNITION
J10RECC 1998	IGNITION -- ELECTRIC
J10RECC 1998	IGNITION -- ROPE
J10REDD 1996	IGNITION - ELECTRIC
J10REDD 1996	IGNITION - ROPE

J10REER 1999	IGNITION -- ROPE
J10REER 1999	IGNITION -- ELECTRIC
J10REIR 1991	IGNITION
J10RELECC 1998	IGNITION -- ELECTRIC
J10RELECC 1998	IGNITION -- ROPE
J10RELEDD 1996	IGNITION - ELECTRIC
J10RELEDD 1996	IGNITION - ROPE
J10RELEIR 1991	IGNITION
J10RELENA 1992	IGNITION
J10RELEOE 1995	IGNITION - ELECTRIC
J10RELEOE 1995	IGNITION - ROPE
J10RELERB 1994	IGNITION - ELECTRIC
J10RELERB 1994	IGNITION - ROPE
J10RELESC 1990	IGNITION
J10RELETM 1993	IGNITION - ELECTRIC
J10RELETM 1993	IGNITION - ROPE
J10RELEUS 1997	IGNITION - ELECTRIC
J10RELEUS 1997	IGNITION - ROPE
J10RENA 1992	IGNITION
J10REOE 1995	IGNITION - ELECTRIC
J10REOE 1995	IGNITION - ROPE
J10RERB 1994	IGNITION - ELECTRIC
J10RERB 1994	IGNITION - ROPE
J10RESC 1990	IGNITION
J10RETM 1993	IGNITION - ELECTRIC
J10RETM 1993	IGNITION - ROPE
J10REUS 1997	IGNITION - ELECTRIC
J10REUS 1997	IGNITION - ROPE
J10RGTSIC elec start,15 in shaft, wht 2001	IGNITION - ROPE
J10RGTSIC elec start,15 in shaft, wht 2001	IGNITION - ELECTRIC
J10RGTSSS Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
J10RGTSSS Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC
J10RLCCD 1988	IGNITION
J10RLCDB 1986	IGNITION
J10RLCES 1989	IGNITION

J10RLCID 1981	MAGNETO
J10RLCNS 1982	MAGNETO
J10RLCOM 1985	IGNITION
J10RLCRA 1984	MAGNETO
J10RLCSE 1980	MAGNETO
J10RLCTC 1983	MAGNETO
J10RLCTR 1983	MAGNETO
J10RLCUE 1987	IGNITION
J10RLECC 1998	IGNITION -- ELECTRIC
J10RLECC 1998	IGNITION -- ROPE
J10RLEDD 1996	IGNITION - ELECTRIC
J10RLEDD 1996	IGNITION - ROPE
J10RLEER 1999	IGNITION -- ROPE
J10RLEER 1999	IGNITION -- ELECTRIC
J10RLEIR 1991	IGNITION
J10RLENA 1992	IGNITION
J10RLEOE 1995	IGNITION - ELECTRIC
J10RLEOE 1995	IGNITION - ROPE
J10RLERB 1994	IGNITION - ELECTRIC
J10RLERB 1994	IGNITION - ROPE
J10RLESC 1990	IGNITION
J10RLETM 1993	IGNITION - ELECTRIC
J10RLETM 1993	IGNITION - ROPE
J10RLEUS 1997	IGNITION - ELECTRIC
J10RLEUS 1997	IGNITION - ROPE
J10RLGTSIC elec start,20 in shaft, wht 2001	IGNITION - ROPE
J10RLGTSIC elec start,20 in shaft, wht 2001	IGNITION - ELECTRIC
J10RLGTSSS Rope Start, Tiller, 20 IN. shaft, N/A USA 2000	IGNITION - ROPE
J10RLGTSSS Rope Start, Tiller, 20 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC
J10RLSDC	IGNITION
J10RLSDC - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSIM rope start, tiller, 20 in shaft 2001	IGNITION - ROPE
J10RLSIM rope start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
J10RLSOS	IGNITION
J10RLSOS - FR	22-5_SYSTÈME D'ALLUMAGE

J10RLSRD	IGNITION
J10RLSRD - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSSA Rope Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J10RLSSA Rope Start, Tiller, 20 IN. shaft 2000	IGNITION-ELECTRIC
J10RLSTE	IGNITION
J10RLSTE - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSUR	IGNITION
J10RLSUR - FR	02-5_SYSTÈME D'ALLUMAGE
J10RSDC	IGNITION
J10RSDC - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSIM rope start, tiller, 15 in shaft 2001	IGNITION - ROPE
J10RSIM rope start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
J10RSOS	IGNITION
J10RSOS - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSRD	IGNITION
J10RSRD - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSSA Rope Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J10RSSA Rope Start, Tiller, 15 IN. shaft 2000	IGNITION-ELECTRIC
J10RSTE	IGNITION
J10RSTE - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSUR	IGNITION
J10RSUR - FR	02-5_SYSTÈME D'ALLUMAGE
J10RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ROPE
J10RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ELECTRIC
J10RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION - ROPE
J10RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION-ELECTRIC
J10RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J10RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J10RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION - ROPE
J10RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION-ELECTRIC
J10SELCCD 1988	IGNITION
J10SELCDB 1986	IGNITION
J10SELCES 1989	IGNITION
J10SELCID 1981	MAGNETO
J10SELCNS 1982	MAGNETO

J10SELCOM 1985	IGNITION
J10SELCRA 1984	MAGNETO
J10SELCSE 1980	MAGNETO
J10SELCTC 1983	MAGNETO
J10SELCUE 1987	IGNITION
J10SELECC 1998	IGNITION -- ELECTRIC
J10SELECC 1998	IGNITION -- ROPE
J10SELEDD 1996	IGNITION - ELECTRIC
J10SELEDD 1996	IGNITION - ROPE
J10SELEIR 1991	IGNITION
J10SELENA 1992	IGNITION
J10SELEOE 1995	IGNITION - ELECTRIC
J10SELEOE 1995	IGNITION - ROPE
J10SELERB 1994	IGNITION - ELECTRIC
J10SELERB 1994	IGNITION - ROPE
J10SELESC 1990	IGNITION
J10SELETM 1993	IGNITION - ELECTRIC
J10SELETM 1993	IGNITION - ROPE
J10SELEUS 1997	IGNITION - ELECTRIC
J10SELEUS 1997	IGNITION - ROPE
J10TEEER 1999	IGNITION -- ROPE
J10TEEER 1999	IGNITION -- ELECTRIC
J10TEGSSS Electric Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
J10TEGSSS Electric Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC
J10TEGTSIC elec start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J10TEGTSIC elec start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J10TELEER 1999	IGNITION -- ROPE
J10TELEER 1999	IGNITION -- ELECTRIC
J10TELSIM elec start, tiller, 20 in shaft 2001	IGNITION - ROPE
J10TELSIM elec start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
J10TELSSA Electric Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J10TELSSA Electric Start, Tiller, 20 IN. shaft 2000	IGNITION-ELECTRIC
J10TESIM elec start, tiller, 15 in shaft 2001	IGNITION - ROPE
J10TESIM elec start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
J10TESSA Electric Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE

J10TESSA Electric Start, Tiller, 15 IN. shaft 2000	IGNITION-ELECTRIC
J10TVESIM elec start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J10TVESIM elec start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J110MLCCA 1988	IGNITION SYSTEM
J110MLCDC 1986	IGNITION SYSTEM
J110MLCEM 1989	IGNITION SYSTEM
J110MLCUR 1987	IGNITION SYSTEM
J110TLAEM 1989	IGNITION SYSTEM
J110TLCCA 1988	IGNITION SYSTEM
J110TLCDC 1986	IGNITION SYSTEM
J110TLCDF 1986	IGNITION SYSTEM
J110TLCEM 1989	IGNITION SYSTEM
J110TLCUR 1987	IGNITION SYSTEM
J110TXCCA 1988	IGNITION SYSTEM
J110TXCEM 1989	IGNITION SYSTEM
J110TXCUR 1987	IGNITION SYSTEM
J112TSLEDR 1996	IGNITION SYSTEM
J112TSLEOC 1995	IGNITION SYSTEM
J112TSLERS 1994	IGNITION SYSTEM
J112TSXEDR 1996	IGNITION SYSTEM
J112TSXEOC 1995	IGNITION SYSTEM
J112TSXERS 1994	IGNITION SYSTEM
J115JKLEOC 1995	IGNITION SYSTEM
J115JKLERS 1994	IGNITION SYSTEM
J115JLEDA 1996	IGNITION SYSTEM
J115JLEIE 1991	IGNITION SYSTEM
J115JLEND 1992	IGNITION SYSTEM
J115JLEOR 1995	IGNITION SYSTEM
J115JLERC 1994	IGNITION SYSTEM
J115JLETS 1993	IGNITION SYSTEM
J115JLEUM 1997	IGNITION SYSTEM
J115MLCIH 1981	IGNITION SYSTEM
J115MLCIM 1981	IGNITION SYSTEM
J115MLCNB 1982	IGNITION SYSTEM
J115MLCOS 1985	IGNITION SYSTEM

J115MLCRD 1984	IGNITION SYSTEM
J115MLCSA 1980	IGNITION SYSTEM
J115MLCTE 1983	IGNITION SYSTEM
J115MLEIE 1991	IGNITION SYSTEM
J115MLEND 1992	IGNITION SYSTEM
J115MLEOR 1995	IGNITION SYSTEM
J115MLERS 1994	IGNITION SYSTEM
J115MLESB 1990	IGNITION SYSTEM
J115MLETS 1993	IGNITION SYSTEM
J115TLAIE 1991	IGNITION SYSTEM
J115TLAND 1992	IGNITION SYSTEM
J115TLARC 1994	IGNITION SYSTEM
J115TLASB 1990	IGNITION SYSTEM
J115TLATS 1993	IGNITION SYSTEM
J115TLCIH 1981	IGNITION SYSTEM
J115TLCIM 1981	IGNITION SYSTEM
J115TLCNB 1982	IGNITION SYSTEM
J115TLCOS 1985	IGNITION SYSTEM
J115TLCRD 1984	IGNITION SYSTEM
J115TLCSA 1980	IGNITION SYSTEM
J115TLCTE 1983	IGNITION SYSTEM
J115TLEDA 1996	IGNITION SYSTEM
J115TLEIE 1991	IGNITION SYSTEM
J115TLEND 1992	IGNITION SYSTEM
J115TLEOR 1995	IGNITION SYSTEM
J115TLERC 1994	IGNITION SYSTEM
J115TLESB 1990	IGNITION SYSTEM
J115TLETS 1993	IGNITION SYSTEM
J115TSLECM 1998	IGNITION SYSTEM
J115TSLEUA 1997	IGNITION SYSTEM
J115TSXECM 1998	IGNITION SYSTEM
J115TSXEUA 1997	IGNITION SYSTEM
J115TXADA 1996	IGNITION SYSTEM
J115TXAOR 1995	IGNITION SYSTEM
J115TXARS 1994	IGNITION SYSTEM

J115TXATS 1993	IGNITION SYSTEM
J115TXCIH 1981	IGNITION SYSTEM
J115TXCIM 1981	IGNITION SYSTEM
J115TXCNCB 1982	IGNITION SYSTEM
J115TXCRD 1984	IGNITION SYSTEM
J115TXCSA 1980	IGNITION SYSTEM
J115TXCTE 1983	IGNITION SYSTEM
J115TXEIE 1991	IGNITION SYSTEM
J115TXEND 1992	IGNITION SYSTEM
J115TXESB 1990	IGNITION SYSTEM
J120TLAEM 1989	IGNITION SYSTEM & STARTER MOTOR
J120TLAIE 1991	IGNITION SYSTEM & STARTER MOTOR
J120TLAND 1992	IGNITION SYSTEM & STARTER MOTOR
J120TLARC 1994	IGNITION SYSTEM
J120TLARK 1994	IGNITION SYSTEM
J120TLASB 1990	IGNITION SYSTEM & STARTER MOTOR
J120TLATF 1993	IGNITION SYSTEM & STARTER MOTOR
J120TLATS 1993	IGNITION SYSTEM & STARTER MOTOR
J120TLCCA 1988	IGNITION SYSTEM & STARTER MOTOR
J120TLCDC 1986	IGNITION SYSTEM
J120TLCEM 1989	IGNITION SYSTEM & STARTER MOTOR
J120TLCOS 1985	IGNITION SYSTEM
J120TLCUR 1987	IGNITION SYSTEM
J120TLEIE 1991	IGNITION SYSTEM & STARTER MOTOR
J120TLEND 1992	IGNITION SYSTEM & STARTER MOTOR
J120TLERC 1994	IGNITION SYSTEM
J120TLERK 1994	IGNITION SYSTEM
J120TLESB 1990	IGNITION SYSTEM & STARTER MOTOR
J120TLETF 1993	IGNITION SYSTEM & STARTER MOTOR
J120TLETS 1993	IGNITION SYSTEM & STARTER MOTOR
J120TXARC 1994	IGNITION SYSTEM
J120TXARK 1994	IGNITION SYSTEM
J120TXATF 1993	IGNITION SYSTEM & STARTER MOTOR
J120TXATS 1993	IGNITION SYSTEM & STARTER MOTOR
J120TXCCA 1988	IGNITION SYSTEM & STARTER MOTOR

J120TXCDC 1986	IGNITION SYSTEM
J120TXCEM 1989	IGNITION SYSTEM & STARTER MOTOR
J120TXCOS 1985	IGNITION SYSTEM
J120TXCUR 1987	IGNITION SYSTEM
J120TXEIE 1991	IGNITION SYSTEM & STARTER MOTOR
J120TXEND 1992	IGNITION SYSTEM & STARTER MOTOR
J120TXERC 1994	IGNITION SYSTEM
J120TXERK 1994	IGNITION SYSTEM
J120TXESB 1990	IGNITION SYSTEM & STARTER MOTOR
J120TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
J120TXETS 1993	IGNITION SYSTEM & STARTER MOTOR
J125ESXENR 1992	IGNITION SYSTEM & STARTER MOTOR
J125ESXERK 1994	IGNITION SYSTEM
J125ESXESS 1990	IGNITION SYSTEM & STARTER MOTOR
J125ESXETA 1993	IGNITION SYSTEM & STARTER MOTOR
J125ESXETF 1993	IGNITION SYSTEM & STARTER MOTOR
J125ESXW 1989	IGNITION SYSTEM & STARTER MOTOR
J125WTPLE 1995	IGNITION SYSTEM
J130CXAOR 1995	IGNITION SYSTEM
J130PLEED 1999	IGNITION SYSTEM
J130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM
J130PXEEED 1999	IGNITION SYSTEM
J130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	IGNITION SYSTEM
J130TLECE 1998	IGNITION SYSTEM
J130TLEDM 1996	IGNITION SYSTEM
J130TLEOA 1995	IGNITION SYSTEM
J130TLEUB 1997	IGNITION SYSTEM
J130TXACB 1998	IGNITION SYSTEM
J130TXADA 1996	IGNITION SYSTEM
J130TXAOR 1995	IGNITION SYSTEM
J130TXAUM 1997	IGNITION SYSTEM
J130VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	IGNITION SYSTEM
J135PLSIF elec start, TNT, 20 in shaft 2001	IGNITION
J135VLSIF elec start, TNT, 20 in shaft, wht 2001	IGNITION
J135VXSIF elec start, TNT, 25 in shaft, wht 2001	IGNITION

J140CXARC 1994	IGNITION SYSTEM
J140CXARK 1994	IGNITION SYSTEM
J140CXATF 1993	IGNITION SYSTEM & STARTER MOTOR
J140CXATS 1993	IGNITION SYSTEM & STARTER MOTOR
J140CXCCS 1988	IGNITION SYSTEM & STARTER MOTOR
J140CXCEC 1989	IGNITION SYSTEM & STARTER MOTOR
J140CXEIA 1991	IGNITION SYSTEM & STARTER MOTOR
J140CXENM 1992	IGNITION SYSTEM & STARTER MOTOR
J140CXERE 1994	IGNITION SYSTEM
J140CXERK 1994	IGNITION SYSTEM
J140CXESR 1990	IGNITION SYSTEM & STARTER MOTOR
J140CXETB 1993	IGNITION SYSTEM & STARTER MOTOR
J140CXETF 1993	IGNITION SYSTEM & STARTER MOTOR
J140MLCIH 1981	IGNITION SYSTEM
J140MLCIM 1981	IGNITION SYSTEM
J140MLCNB 1982	IGNITION SYSTEM
J140MLCSA 1980	IGNITION SYSTEM
J140MLCTE 1983	IGNITION SYSTEM
J140TLAEB 1989	IGNITION SYSTEM & STARTER MOTOR
J140TLANS 1992	IGNITION SYSTEM & STARTER MOTOR
J140TLARK 1994	IGNITION SYSTEM
J140TLARR 1994	IGNITION SYSTEM
J140TLASE 1990	IGNITION SYSTEM & STARTER MOTOR
J140TLATC 1993	IGNITION SYSTEM & STARTER MOTOR
J140TLATF 1993	IGNITION SYSTEM & STARTER MOTOR
J140TLCCM 1988	IGNITION SYSTEM & STARTER MOTOR
J140TLCDC 1986	IGNITION SYSTEM
J140TLCEB 1989	IGNITION SYSTEM & STARTER MOTOR
J140TLCIH 1981	IGNITION SYSTEM
J140TLCIM 1981	IGNITION SYSTEM
J140TLCNB 1982	IGNITION SYSTEM
J140TLCOS 1985	IGNITION SYSTEM
J140TLCRD 1984	IGNITION SYSTEM
J140TLCSA 1980	IGNITION SYSTEM
J140TLCTE 1983	IGNITION SYSTEM

J140TLCUA 1987	IGNITION SYSTEM
J140TLEID 1991	IGNITION SYSTEM & STARTER MOTOR
J140TLENS 1992	IGNITION SYSTEM & STARTER MOTOR
J140TLERK 1994	IGNITION SYSTEM
J140TLERR 1994	IGNITION SYSTEM
J140TLESE 1990	IGNITION SYSTEM & STARTER MOTOR
J140TLETC 1993	IGNITION SYSTEM & STARTER MOTOR
J140TLETF 1993	IGNITION SYSTEM & STARTER MOTOR
J140TXARC 1994	IGNITION SYSTEM
J140TXARK 1994	IGNITION SYSTEM
J140TXATF 1993	IGNITION SYSTEM & STARTER MOTOR
J140TXATS 1993	IGNITION SYSTEM & STARTER MOTOR
J140TXCCM 1988	IGNITION SYSTEM & STARTER MOTOR
J140TXCDC 1986	IGNITION SYSTEM
J140TXCEB 1989	IGNITION SYSTEM & STARTER MOTOR
J140TXCIH 1981	IGNITION SYSTEM
J140TXCIM 1981	IGNITION SYSTEM
J140TXCNB 1982	IGNITION SYSTEM
J140TXCOS 1985	IGNITION SYSTEM
J140TXCRD 1984	IGNITION SYSTEM
J140TXCSA 1980	IGNITION SYSTEM
J140TXCTE 1983	IGNITION SYSTEM
J140TXCUA 1987	IGNITION SYSTEM
J140TXEID 1991	IGNITION SYSTEM & STARTER MOTOR
J140TXENS 1992	IGNITION SYSTEM & STARTER MOTOR
J140TXERK 1994	IGNITION SYSTEM
J140TXERR 1994	IGNITION SYSTEM
J140TXESE 1990	IGNITION SYSTEM & STARTER MOTOR
J140TXETC 1993	IGNITION SYSTEM & STARTER MOTOR
J140TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
J150CXCCA 1988	IGNITION SYSTEM
J150CXCEM 1989	IGNITION SYSTEM - 150 MODELS
J150CXCEM 1989	IGNITION SYSTEM - 175 MODELS
J150CXEIE 1991	IGNITION SYSTEM - 150 MODELS
J150CXEIE 1991	IGNITION SYSTEM - 175 MODELS

J150CXESB 1990	IGNITION SYSTEM - 150 MODELS
J150CXESB 1990	IGNITION SYSTEM - 175 MODELS
J150ELAIS 1991	IGNITION SYSTEM
J150ELANC 1992	IGNITION SYSTEM
J150ELEDB 1996	IGNITION SYSTEM
J150ELEIS 1991	IGNITION SYSTEM
J150ELENC 1992	IGNITION SYSTEM
J150ELEUC 1997	IGNITION SYSTEM
J150ELEUE 1997	IGNITION SYSTEM
J150EXEDB 1996	IGNITION SYSTEM
J150EXEIS 1991	IGNITION SYSTEM
J150EXENC 1992	IGNITION SYSTEM
J150XEUC 1997	IGNITION SYSTEM
J150XEUE 1997	IGNITION SYSTEM
J150GLEDB 1996	IGNITION SYSTEM
J150GLEIS 1991	IGNITION SYSTEM
J150GLENC 1992	IGNITION SYSTEM
J150GLEUC 1997	IGNITION SYSTEM
J150GLEUE 1997	IGNITION SYSTEM
J150GTLCUR 1987	IGNITION SYSTEM
J150JLEDB 1996	IGNITION SYSTEM
J150JLEIE 1991	IGNITION SYSTEM - 150 MODELS
J150JLEIE 1991	IGNITION SYSTEM - 175 MODELS
J150JLENC 1992	IGNITION SYSTEM
J150JLEUC 1997	IGNITION SYSTEM
J150JLEUE 1997	IGNITION SYSTEM
J150NXEDB 1996	IGNITION SYSTEM
J150NXEIS 1991	IGNITION SYSTEM
J150NXENC 1992	IGNITION SYSTEM
J150NXEUC 1997	IGNITION SYSTEM
J150NXEUE 1997	IGNITION SYSTEM
J150SLEDB 1996	IGNITION SYSTEM
J150SLEUC 1997	IGNITION SYSTEM
J150SLEUE 1997	IGNITION SYSTEM
J150STLACA 1988	IGNITION SYSTEM

J150STLCCA 1988	IGNITION SYSTEM
J150STLCDC 1986	IGNITION SYSTEM
J150STLCEM 1989	IGNITION SYSTEM
J150STLCOH 1985	IGNITION SYSTEM
J150STLCOS 1985	IGNITION SYSTEM
J150STLCRD 1984	IGNITION SYSTEM
J150STLCTE 1983	IGNITION SYSTEM
J150STLCUR 1987	IGNITION SYSTEM
J150STLEIE 1991	IGNITION SYSTEM
J150STLESB 1990	IGNITION SYSTEM
J150TLAEM 1989	IGNITION SYSTEM - 150 MODELS
J150TLAEM 1989	IGNITION SYSTEM - 175 MODELS
J150TLAIE 1991	IGNITION SYSTEM - 150 MODELS
J150TLAIE 1991	IGNITION SYSTEM - 175 MODELS
J150TLASB 1990	IGNITION SYSTEM - 150 MODELS
J150TLASB 1990	IGNITION SYSTEM - 175 MODELS
J150TLCCA 1988	IGNITION SYSTEM
J150TLCDC 1986	IGNITION SYSTEM
J150TLCCEM 1989	IGNITION SYSTEM - 150 MODELS
J150TLCCEM 1989	IGNITION SYSTEM - 175 MODELS
J150TLCIA 1981	IGNITION SYSTEM
J150TLCIH 1981	IGNITION SYSTEM
J150TLCNM 1982	IGNITION SYSTEM
J150TLCOS 1985	IGNITION SYSTEM
J150TLCRD 1984	IGNITION SYSTEM
J150TLCSF 1980	IGNITION SYSTEM
J150TLCSR 1980	IGNITION SYSTEM
J150TLCTB 1983	IGNITION SYSTEM
J150TLCTE 1983	IGNITION SYSTEM
J150TLCUR 1987	IGNITION SYSTEM
J150TLEIE 1991	IGNITION SYSTEM - 150 MODELS
J150TLEIE 1991	IGNITION SYSTEM - 175 MODELS
J150TLESB 1990	IGNITION SYSTEM - 150 MODELS
J150TLESB 1990	IGNITION SYSTEM - 175 MODELS
J150TXCCA 1988	IGNITION SYSTEM

J150TXCDC 1986	IGNITION SYSTEM
J150TXCEM 1989	IGNITION SYSTEM - 150 MODELS
J150TXCEM 1989	IGNITION SYSTEM - 175 MODELS
J150TXCIA 1981	IGNITION SYSTEM
J150TXCIH 1981	IGNITION SYSTEM
J150TXCNM 1982	IGNITION SYSTEM
J150TXCOS 1985	IGNITION SYSTEM
J150TXCRD 1984	IGNITION SYSTEM
J150TXCSF 1980	IGNITION SYSTEM
J150TXCSR 1980	IGNITION SYSTEM
J150TXCTB 1983	IGNITION SYSTEM
J150TXCTE 1983	IGNITION SYSTEM
J150TXCUR 1987	IGNITION SYSTEM
J150TXEIE 1991	IGNITION SYSTEM - 150 MODELS
J150TXEIE 1991	IGNITION SYSTEM - 175 MODELS
J150TXESB 1990	IGNITION SYSTEM - 150 MODELS
J150TXESB 1990	IGNITION SYSTEM - 175 MODELS
J150WTLEOR 1995	IGNITION SYSTEM
J150WTLERC 1994	IGNITION SYSTEM
J150WTLERV 1994	IGNITION SYSTEM
J150WTLETG 1993	IGNITION SYSTEM
J150WTLETS 1993	IGNITION SYSTEM
J150WTXEOR 1995	IGNITION SYSTEM
J150WTXERC 1994	IGNITION SYSTEM
J150WTXERV 1994	IGNITION SYSTEM
J150WTXETG 1993	IGNITION SYSTEM
J150WTXETS 1993	IGNITION SYSTEM
J155WTLCDR 1986	IGNITION SYSTEM - 35 AMP
J155WTLCOG 1985	IGNITION SYSTEM - 35 AMP
J155WTLCRS 1984	IGNITION SYSTEM - 35 AMP
J155WTLCUA 1987	IGNITION SYSTEM - 35 AMP
J155WTLEIB 1991	IGNITION SYSTEM - 35 AMP
J155WTLENE 1992	IGNITION SYSTEM - 35 AMP
J155WTLISM 1990	IGNITION SYSTEM - 35 AMP
J155WTLZ 1989	IGNITION SYSTEM - 35 AMP

J155WTXCDR 1986	IGNITION SYSTEM - 35 AMP
J155WTXCOC 1985	IGNITION SYSTEM - 35 AMP
J155WTXCRS 1984	IGNITION SYSTEM - 35 AMP
J155WTXCUA 1987	IGNITION SYSTEM - 35 AMP
J155WTXEIB 1991	IGNITION SYSTEM - 35 AMP
J155WTXENE 1992	IGNITION SYSTEM - 35 AMP
J155WTXESM 1990	IGNITION SYSTEM - 35 AMP
J155WTXZ 1989	IGNITION SYSTEM - 35 AMP
J15ECCS 1988	IGNITION
J15ECDE 1986	IGNITION
J15EDEC 1989	IGNITION
J15ECIS 1981	MAGNETO
J15ECNC 1982	MAGNETO
J15ECOB 1985	IGNITION
J15ECRM 1984	MAGNETO
J15ECSD 1980	MAGNETO
J15ECTR 1983	MAGNETO
J15ECUD 1987	IGNITION
J15EECR 1998	IGNITION -- ELECTRIC
J15EECR 1998	IGNITION -- ROPE
J15EEDS 1996	IGNITION - ELECTRIC
J15EEDS 1996	IGNITION - ROPE
J15EEIA 1991	IGNITION
J15EENM 1992	IGNITION
J15EEOD 1995	IGNITION - ELECTRIC
J15EEOD 1995	IGNITION - ROPE
J15EERE 1994	IGNITION - ELECTRIC
J15EERE 1994	IGNITION - ROPE
J15EESR 1990	IGNITION
J15EETB 1993	IGNITION - ELECTRIC
J15EETB 1993	IGNITION - ROPE
J15EEUC 1997	IGNITION - ELECTRIC
J15EEUC 1997	IGNITION - ROPE
J15ELCCS 1988	IGNITION
J15ELCDE 1986	IGNITION

J15ELCEC 1989	IGNITION
J15ELCOB 1985	IGNITION
J15ELCRM 1984	MAGNETO
J15ELCSD 1980	MAGNETO
J15ELCTR 1983	MAGNETO
J15ELCUD 1987	IGNITION
J15ELECR 1998	IGNITION -- ELECTRIC
J15ELECR 1998	IGNITION -- ROPE
J15ELEDS 1996	IGNITION - ELECTRIC
J15ELEDS 1996	IGNITION - ROPE
J15ELEEA 1999	IGNITION -- ROPE
J15ELEEA 1999	IGNITION -- ELECTRIC
J15ELEIA 1991	IGNITION
J15ELENM 1992	IGNITION
J15ELEOD 1995	IGNITION - ELECTRIC
J15ELEOD 1995	IGNITION - ROPE
J15ELERE 1994	IGNITION - ELECTRIC
J15ELERE 1994	IGNITION - ROPE
J15ELSR 1990	IGNITION
J15LETB 1993	IGNITION - ELECTRIC
J15LETB 1993	IGNITION - ROPE
J15LEUC 1997	IGNITION - ELECTRIC
J15LEUC 1997	IGNITION - ROPE
J15ELSIB elec start, remote, 20 in shaft 2001	IGNITION - ROPE
J15ELSIB elec start, remote, 20 in shaft 2001	IGNITION - ELECTRIC
J15ELSSM Electric Start, 20 IN. shaft 2000	IGNITION - ROPE
J15ELSSM Electric Start, 20 IN. shaft 2000	IGNITION-ELECTRIC
J15EVLISIC elec start, remote, 20 in shaft, wht 2001	IGNITION - ROPE
J15EVLISIC elec start, remote, 20 in shaft, wht 2001	IGNITION - ELECTRIC
J15EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION - ROPE
J15EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION-ELECTRIC
J15RCCS 1988	IGNITION
J15RCDE 1986	IGNITION
J15RCEC 1989	IGNITION
J15RCIS 1981	MAGNETO

J15RCNC 1982	MAGNETO
J15RCOB 1985	IGNITION
J15RCRM 1984	MAGNETO
J15RCSD 1980	MAGNETO
J15RCTA 1983	MAGNETO
J15RCTR 1983	MAGNETO
J15RCUD 1987	IGNITION
J15RECR 1998	IGNITION -- ELECTRIC
J15RECR 1998	IGNITION -- ROPE
J15REDS 1996	IGNITION - ELECTRIC
J15REDS 1996	IGNITION - ROPE
J15REEA 1999	IGNITION -- ROPE
J15REEA 1999	IGNITION -- ELECTRIC
J15REIA 1991	IGNITION
J15RELECR 1998	IGNITION -- ELECTRIC
J15RELECR 1998	IGNITION -- ROPE
J15RELEDS 1996	IGNITION - ELECTRIC
J15RELEDS 1996	IGNITION - ROPE
J15RELEIA 1991	IGNITION
J15RELENM 1992	IGNITION
J15RELEOD 1995	IGNITION - ELECTRIC
J15RELEOD 1995	IGNITION - ROPE
J15RELERE 1994	IGNITION - ELECTRIC
J15RELERE 1994	IGNITION - ROPE
J15RELESR 1990	IGNITION
J15RELETB 1993	IGNITION - ELECTRIC
J15RELETB 1993	IGNITION - ROPE
J15RELEUC 1997	IGNITION - ELECTRIC
J15RELEUC 1997	IGNITION - ROPE
J15RENM 1992	IGNITION
J15REOD 1995	IGNITION - ELECTRIC
J15REOD 1995	IGNITION - ROPE
J15RERE 1994	IGNITION - ELECTRIC
J15RERE 1994	IGNITION - ROPE
J15RESR 1990	IGNITION

J15RETB 1993	IGNITION - ELECTRIC
J15RETB 1993	IGNITION - ROPE
J15REUC 1997	IGNITION - ELECTRIC
J15REUC 1997	IGNITION - ROPE
J15RLCCS 1988	IGNITION
J15RLCDE 1986	IGNITION
J15RLCEC 1989	IGNITION
J15RLCIS 1981	MAGNETO
J15RLCNC 1982	MAGNETO
J15RLCOB 1985	IGNITION
J15RLCRM 1984	MAGNETO
J15RLCSD 1980	MAGNETO
J15RLCTA 1983	MAGNETO
J15RLCTR 1983	MAGNETO
J15RLCUD 1987	IGNITION
J15RLECR 1998	IGNITION -- ELECTRIC
J15RLECR 1998	IGNITION -- ROPE
J15RLEDS 1996	IGNITION - ELECTRIC
J15RLEDS 1996	IGNITION - ROPE
J15RLEEA 1999	IGNITION -- ROPE
J15RLEEA 1999	IGNITION -- ELECTRIC
J15RLEIA 1991	IGNITION
J15RLENM 1992	IGNITION
J15RLEOD 1995	IGNITION - ELECTRIC
J15RLEOD 1995	IGNITION - ROPE
J15RLERE 1994	IGNITION - ELECTRIC
J15RLERE 1994	IGNITION - ROPE
J15RLESR 1990	IGNITION
J15RLETB 1993	IGNITION - ELECTRIC
J15RLETB 1993	IGNITION - ROPE
J15RLEUC 1997	IGNITION - ELECTRIC
J15RLEUC 1997	IGNITION - ROPE
J15RLSDR	IGNITION
J15RLSDR - FR	22-5_SYSTÈME D'ALLUMAGE
J15RLSIB rope start, tiller, 20 in shaft 2001	IGNITION - ROPE

J15RLSIB rope start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
J15RLSOC	IGNITION
J15RLSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J15RLSRS	IGNITION
J15RLSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J15RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J15RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION-ELECTRIC
J15RLSTD	IGNITION
J15RLSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J15RLSUA	IGNITION
J15RLSUA - FR	02-5_SYSTÈME D'ALLUMAGE
J15RSDR	IGNITION
J15RSDR - FR	22-5_SYSTÈME D'ALLUMAGE
J15RSIB rope start, tiller, 15 in shaft 2001	IGNITION - ROPE
J15RSIB rope start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
J15RSOC	IGNITION
J15RSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J15RSRS	IGNITION
J15RSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J15RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J15RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION-ELECTRIC
J15RSTD	IGNITION
J15RSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J15RSUA	IGNITION
J15RSUA - FR	02-5_SYSTÈME D'ALLUMAGE
J15RTSDC	IGNITION
J15RTSDC - FR	22-5_SYSTÈME D'ALLUMAGE
J15RTSOS	IGNITION
J15RTSOS - FR	22-5_SYSTÈME D'ALLUMAGE
J15RTSUR	IGNITION
J15RTSUR - FR	02-5_SYSTÈME D'ALLUMAGE
J15RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ROPE
J15RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ELECTRIC
J15RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION - ROPE
J15RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION-ELECTRIC

J15RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J15RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J15RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION - ROPE
J15RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION-ELECTRIC
J15TEEEA 1999	IGNITION -- ROPE
J15TEEEA 1999	IGNITION -- ELECTRIC
J15TELEEA 1999	IGNITION -- ROPE
J15TELEEA 1999	IGNITION -- ELECTRIC
J15TELSIB elec start, tiller, 20 in shaft 2001	IGNITION - ROPE
J15TELSIB elec start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
J15TELSSM Electric Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J15TELSSM Electric Start, Tiller, 20 IN. shaft 2000	IGNITION-ELECTRIC
J15TESIB elec start, tiller, 15 in shaft 2001	IGNITION - ROPE
J15TESIB elec start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
J15TESSM Electric Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J15TESSM Electric Start, Tiller, 15 IN. shaft 2000	IGNITION-ELECTRIC
J15TVESIB elec start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J15TVESIB elec start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J15WREES 1999	IGNITION
J15WRLEES 1999	IGNITION
J15WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
J15WRLSOB	IGNITION
J15WRLSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRLSRM	IGNITION
J15WRLSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRLSSC Commercial, Rope Start, Tiller, 20 IN shaft 2000	IGNITION
J15WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
J15WRSOB	IGNITION
J15WRSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRSRM	IGNITION
J15WRSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRSSC Commercial, Rope Start, Tiller, 15 IN shaft 2000	IGNITION
J175EXEDB 1996	IGNITION SYSTEM
J175EXEIS 1991	IGNITION SYSTEM
J175EXENC 1992	IGNITION SYSTEM

J175EXEUC 1997	IGNITION SYSTEM
J175EXEUE 1997	IGNITION SYSTEM
J175GLEDB 1996	IGNITION SYSTEM
J175GLEIS 1991	IGNITION SYSTEM
J175GLENC 1992	IGNITION SYSTEM
J175GLEUC 1997	IGNITION SYSTEM
J175GLEUE 1997	IGNITION SYSTEM
J175NXEDB 1996	IGNITION SYSTEM
J175NXENC 1992	IGNITION SYSTEM
J175NXEUC 1997	IGNITION SYSTEM
J175NXEUE 1997	IGNITION SYSTEM
J175SLEDB 1996	IGNITION SYSTEM
J175SLEUC 1997	IGNITION SYSTEM
J175SLEUE 1997	IGNITION SYSTEM
J175STLACM 1988	IGNITION SYSTEM
J175STLCCM 1988	IGNITION SYSTEM
J175STLCEB 1989	IGNITION SYSTEM - 150 MODELS
J175STLCEB 1989	IGNITION SYSTEM - 175 MODELS
J175STLEID 1991	IGNITION SYSTEM - 150 MODELS
J175STLEID 1991	IGNITION SYSTEM - 175 MODELS
J175STLESE 1990	IGNITION SYSTEM - 150 MODELS
J175STLESE 1990	IGNITION SYSTEM - 175 MODELS
J175TLCCM 1988	IGNITION SYSTEM
J175TLCDR 1986	IGNITION SYSTEM
J175TLCIH 1981	IGNITION SYSTEM
J175TLCIM 1981	IGNITION SYSTEM
J175TLCNB 1982	IGNITION SYSTEM
J175TLCOC 1985	IGNITION SYSTEM
J175TLCSA 1980	IGNITION SYSTEM
J175TLCSE 1980	IGNITION SYSTEM
J175TLCTD 1983	IGNITION SYSTEM
J175TLCTE 1983	IGNITION SYSTEM
J175TLCUA 1987	IGNITION SYSTEM
J175TXCCM 1988	IGNITION SYSTEM
J175TXCDR 1986	IGNITION SYSTEM

J175TXCEB 1989	IGNITION SYSTEM - 150 MODELS
J175TXCEB 1989	IGNITION SYSTEM - 175 MODELS
J175TXCIH 1981	IGNITION SYSTEM
J175TXCIM 1981	IGNITION SYSTEM
J175TXCNCB 1982	IGNITION SYSTEM
J175TXCOC 1985	IGNITION SYSTEM
J175TXCSA 1980	IGNITION SYSTEM
J175TXCSF 1980	IGNITION SYSTEM
J175TXCTD 1983	IGNITION SYSTEM
J175TXCTE 1983	IGNITION SYSTEM
J175TXCUA 1987	IGNITION SYSTEM
J175TXEID 1991	IGNITION SYSTEM - 150 MODELS
J175TXEID 1991	IGNITION SYSTEM - 175 MODELS
J175TXESE 1990	IGNITION SYSTEM - 150 MODELS
J175TXESE 1990	IGNITION SYSTEM - 175 MODELS
J185ESERK 1994	IGNITION SYSTEM & STARTER MOTOR
J185ESXENR 1992	IGNITION SYSTEM & STARTER MOTOR
J185ESXESS 1990	IGNITION SYSTEM & STARTER MOTOR
J185ESXETA 1993	IGNITION SYSTEM & STARTER MOTOR
J185ESXETF 1993	IGNITION SYSTEM & STARTER MOTOR
J185ESXW 1989	IGNITION SYSTEM & STARTER MOTOR
J185TLCOC 1985	IGNITION SYSTEM
J185TLCRS 1984	IGNITION SYSTEM
J185TXCOC 1985	IGNITION SYSTEM
J185TXCR 1984	IGNITION SYSTEM
J200CXARC 1994	IGNITION SYSTEM & STARTER MOTOR
J200CXARK 1994	IGNITION SYSTEM & STARTER MOTOR
J200CXATF 1993	IGNITION SYSTEM & STARTER MOTOR
J200CXATS 1993	IGNITION SYSTEM & STARTER MOTOR
J200CXCCR 1988	IGNITION SYSTEM & STARTER MOTOR
J200CXCEA 1989	IGNITION SYSTEM & STARTER MOTOR
J200CXECM 1998	IGNITION SYSTEM
J200CXEDR 1996	IGNITION SYSTEM
J200CXEEB 1999	IGNITION SYSTEM
J200CXEEN 1999	IGNITION SYSTEM

J200CXEIB 1991	IGNITION SYSTEM & STARTER MOTOR
J200CXENE 1992	IGNITION SYSTEM & STARTER MOTOR
J200CXEOC 1995	IGNITION SYSTEM & STARTER MOTOR
J200CXERK 1994	IGNITION SYSTEM & STARTER MOTOR
J200CXERS 1994	IGNITION SYSTEM & STARTER MOTOR
J200CXESM 1990	IGNITION SYSTEM & STARTER MOTOR
J200CXETD 1993	IGNITION SYSTEM & STARTER MOTOR
J200CXETF 1993	IGNITION SYSTEM & STARTER MOTOR
J200CXEUA 1997	IGNITION SYSTEM
J200CXSE Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000	IGNITION SYSTEM
J200CZARK 1994	IGNITION SYSTEM & STARTER MOTOR
J200CZATF 1993	IGNITION SYSTEM & STARTER MOTOR
J200CZATS 1993	IGNITION SYSTEM & STARTER MOTOR
J200CZEOC 1995	IGNITION SYSTEM & STARTER MOTOR
J200CZERK 1994	IGNITION SYSTEM & STARTER MOTOR
J200CZERS 1994	IGNITION SYSTEM & STARTER MOTOR
J200CZETD 1993	IGNITION SYSTEM & STARTER MOTOR
J200CZETF 1993	IGNITION SYSTEM & STARTER MOTOR
J200PLEEB 1999	IGNITION SYSTEM
J200PLEEN 1999	IGNITION SYSTEM
J200PLSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM
J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM
J200PXEEB 1999	IGNITION SYSTEM
J200PXEEB 1999	IGNITION SYSTEM
J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	IGNITION SYSTEM
J200STLACM 1988	IGNITION SYSTEM & STARTER MOTOR
J200STLCCM 1988	IGNITION SYSTEM & STARTER MOTOR
J200STLCDR 1986	IGNITION SYSTEM
J200STLCEB 1989	IGNITION SYSTEM & STARTER MOTOR
J200STLCUA 1987	IGNITION SYSTEM
J200STLECE 1998	IGNITION SYSTEM
J200STLEDM 1996	IGNITION SYSTEM
J200STLEID 1991	IGNITION SYSTEM & STARTER MOTOR
J200STLENS 1992	IGNITION SYSTEM & STARTER MOTOR
J200STLEOA 1995	IGNITION SYSTEM & STARTER MOTOR

J200TXESM 1990	IGNITION SYSTEM & STARTER MOTOR
J200TXETD 1993	IGNITION SYSTEM & STARTER MOTOR
J200TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
J200TXEUA 1997	IGNITION SYSTEM
J200TZARK 1994	IGNITION SYSTEM & STARTER MOTOR
J200TZATF 1993	IGNITION SYSTEM & STARTER MOTOR
J200TZATS 1993	IGNITION SYSTEM & STARTER MOTOR
J200TZE0C 1995	IGNITION SYSTEM & STARTER MOTOR
J200TZERK 1994	IGNITION SYSTEM & STARTER MOTOR
J200TZERS 1994	IGNITION SYSTEM & STARTER MOTOR
J200TZETD 1993	IGNITION SYSTEM & STARTER MOTOR
J200TZETF 1993	IGNITION SYSTEM & STARTER MOTOR
J200VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	IGNITION SYSTEM
J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	IGNITION SYSTEM
J200VLSIF elec start, TNT, 20 in shaft, wht 2001	IGNITION SYSTEM
J200VXSIF elec start, TNT, 25 in shaft, wht 2001	IGNITION SYSTEM
J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	IGNITION SYSTEM
J200WPXEEN 1999	IGNITION SYSTEM
J200WPXEES 1999	IGNITION SYSTEM
J200WPXSIF commercial, elec start, TNT, 25 in shaft 2001	IGNITION SYSTEM
J200WPXSSC Commercial, Elec Start, TNT, 25 IN shaft 2000	IGNITION SYSTEM
J20CRCCA 1988	IGNITION
J20CRCDC 1986	IGNITION
J20CRCEM 1989	IGNITION
J20CRCOS 1985	IGNITION
J20CRCUR 1987	IGNITION
J20CREDA 1996	IGNITION
J20CREIE 1991	IGNITION
J20CREND 1992	IGNITION
J20CREOR 1995	IGNITION
J20CRERC 1994	IGNITION
J20CRESB 1990	IGNITION
J20CRETS 1993	IGNITION
J20CREUM 1997	IGNITION

J20CRLCCA 1988	IGNITION
J20CRLCDC 1986	IGNITION
J20CRLCEM 1989	IGNITION
J20CRLCOS 1985	IGNITION
J20CRLCUR 1987	IGNITION
J20CRLEDA 1996	IGNITION
J20CRLEIE 1991	IGNITION
J20CRLEND 1992	IGNITION
J20CRLEOR 1995	IGNITION
J20CRLERC 1994	IGNITION
J20CRLESB 1990	IGNITION
J20CRLETS 1993	IGNITION
J20CRLEUM 1997	IGNITION
J20ECCA 1988	IGNITION
J20ECDC 1986	IGNITION
J20ECEM 1989	IGNITION
J20ECOS 1985	IGNITION
J20ECUR 1987	IGNITION
J20EEIE 1991	IGNITION
J20EEND 1992	IGNITION
J20EEOR 1995	IGNITION
J20EERC 1994	IGNITION
J20EESB 1990	IGNITION
J20EETS 1993	IGNITION
J20ELCCA 1988	IGNITION
J20ELCDC 1986	IGNITION
J20ELCEM 1989	IGNITION
J20ELCOS 1985	IGNITION
J20ELCUR 1987	IGNITION
J20ELEIE 1991	IGNITION
J20ELEND 1992	IGNITION
J20ELEOR 1995	IGNITION
J20ELERC 1994	IGNITION
J20ELESB 1990	IGNITION
J20ELETS 1993	IGNITION

J20TECDC 1986	IGNITION
J225CLCUB 1987	IGNITION SYSTEM
J225CXARC 1994	IGNITION SYSTEM & STARTER MOTOR
J225CXARK 1994	IGNITION SYSTEM & STARTER MOTOR
J225CXATF 1993	IGNITION SYSTEM & STARTER MOTOR
J225CXATS 1993	IGNITION SYSTEM & STARTER MOTOR
J225XCCE 1988	IGNITION SYSTEM & STARTER MOTOR
J225XCED 1989	IGNITION SYSTEM & STARTER MOTOR
J225XCUB 1987	IGNITION SYSTEM
J225XECS 1998	IGNITION SYSTEM
J225XEDE 1996	IGNITION SYSTEM
J225XEEC 1999	IGNITION SYSTEM
J225XEEN 1999	IGNITION SYSTEM
J225XEIC 1991	IGNITION SYSTEM & STARTER MOTOR
J225XENR 1992	IGNITION SYSTEM & STARTER MOTOR
J225XEOB 1995	IGNITION SYSTEM & STARTER MOTOR
J225XERK 1994	IGNITION SYSTEM & STARTER MOTOR
J225XERM 1994	IGNITION SYSTEM & STARTER MOTOR
J225XESS 1990	IGNITION SYSTEM & STARTER MOTOR
J225XETA 1993	IGNITION SYSTEM & STARTER MOTOR
J225XETF 1993	IGNITION SYSTEM & STARTER MOTOR
J225XEUD 1997	IGNITION SYSTEM
J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	IGNITION SYSTEM
J225CZARK 1994	IGNITION SYSTEM & STARTER MOTOR
J225CZATF 1993	IGNITION SYSTEM & STARTER MOTOR
J225CZATS 1993	IGNITION SYSTEM & STARTER MOTOR
J225CZecs 1998	IGNITION SYSTEM
J225CZEDE 1996	IGNITION SYSTEM
J225CZEOB 1995	IGNITION SYSTEM & STARTER MOTOR
J225CZERK 1994	IGNITION SYSTEM & STARTER MOTOR
J225CZERM 1994	IGNITION SYSTEM & STARTER MOTOR
J225CZETA 1993	IGNITION SYSTEM & STARTER MOTOR
J225CZETF 1993	IGNITION SYSTEM & STARTER MOTOR
J225CZEUD 1997	IGNITION SYSTEM
J225HGLSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM

J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	IGNITION SYSTEM
J225HPLEEN 1999	IGNITION SYSTEM
J225HPLEES 1999	IGNITION SYSTEM
J225HPLSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM
J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	IGNITION SYSTEM
J225PLAED 1989	IGNITION SYSTEM & STARTER MOTOR
J225PLASS 1990	IGNITION SYSTEM & STARTER MOTOR
J225PLCCE 1988	IGNITION SYSTEM & STARTER MOTOR
J225PLCED 1989	IGNITION SYSTEM & STARTER MOTOR
J225PLCUB 1987	IGNITION SYSTEM
J225PLEEC 1999	IGNITION SYSTEM
J225PLEEN 1999	IGNITION SYSTEM
J225PLEIC 1991	IGNITION SYSTEM & STARTER MOTOR
J225PLENR 1992	IGNITION SYSTEM & STARTER MOTOR
J225PLERK 1994	IGNITION SYSTEM & STARTER MOTOR
J225PLERM 1994	IGNITION SYSTEM & STARTER MOTOR
J225PLESS 1990	IGNITION SYSTEM & STARTER MOTOR
J225PLETA 1993	IGNITION SYSTEM & STARTER MOTOR
J225PLETF 1993	IGNITION SYSTEM & STARTER MOTOR
J225PLSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM
J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM
J225PTLCDA 1986	IGNITION SYSTEM
J225PTXCDA 1986	IGNITION SYSTEM
J225PXARC 1994	IGNITION SYSTEM & STARTER MOTOR
J225PXARK 1994	IGNITION SYSTEM & STARTER MOTOR
J225PXATF 1993	IGNITION SYSTEM & STARTER MOTOR
J225PXATS 1993	IGNITION SYSTEM & STARTER MOTOR
J225PXCCE 1988	IGNITION SYSTEM & STARTER MOTOR
J225PXCED 1989	IGNITION SYSTEM & STARTER MOTOR
J225PXCUB 1987	IGNITION SYSTEM
J225PXEDE 1996	IGNITION SYSTEM
J225PXEEC 1999	IGNITION SYSTEM
J225PXEEEN 1999	IGNITION SYSTEM
J225PXEIC 1991	IGNITION SYSTEM & STARTER MOTOR
J225PXENR 1992	IGNITION SYSTEM & STARTER MOTOR

J225PXEOB 1995	IGNITION SYSTEM & STARTER MOTOR
J225PXERK 1994	IGNITION SYSTEM & STARTER MOTOR
J225PXERM 1994	IGNITION SYSTEM & STARTER MOTOR
J225PXESS 1990	IGNITION SYSTEM & STARTER MOTOR
J225PXETA 1993	IGNITION SYSTEM & STARTER MOTOR
J225PXETF 1993	IGNITION SYSTEM & STARTER MOTOR
J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	IGNITION SYSTEM
J225PZARK 1994	IGNITION SYSTEM & STARTER MOTOR
J225PZATF 1993	IGNITION SYSTEM & STARTER MOTOR
J225PZATS 1993	IGNITION SYSTEM & STARTER MOTOR
J225PZEOB 1995	IGNITION SYSTEM & STARTER MOTOR
J225PZERK 1994	IGNITION SYSTEM & STARTER MOTOR
J225PZERM 1994	IGNITION SYSTEM & STARTER MOTOR
J225PZETA 1993	IGNITION SYSTEM & STARTER MOTOR
J225PZETF 1993	IGNITION SYSTEM & STARTER MOTOR
J225STLECS 1998	IGNITION SYSTEM
J225STLEDE 1996	IGNITION SYSTEM
J225STLEOB 1995	IGNITION SYSTEM & STARTER MOTOR
J225STLERC 1994	IGNITION SYSTEM & STARTER MOTOR
J225STLERK 1994	IGNITION SYSTEM & STARTER MOTOR
J225STLETF 1993	IGNITION SYSTEM & STARTER MOTOR
J225STLEUD 1997	IGNITION SYSTEM
J225TLAED 1989	IGNITION SYSTEM & STARTER MOTOR
J225TLASS 1990	IGNITION SYSTEM & STARTER MOTOR
J225TLCCE 1988	IGNITION SYSTEM & STARTER MOTOR
J225TLCDA 1986	IGNITION SYSTEM
J225TLCED 1989	IGNITION SYSTEM & STARTER MOTOR
J225TLCUB 1987	IGNITION SYSTEM
J225TLEIC 1991	IGNITION SYSTEM & STARTER MOTOR
J225TLENR 1992	IGNITION SYSTEM & STARTER MOTOR
J225TLERK 1994	IGNITION SYSTEM & STARTER MOTOR
J225TLERM 1994	IGNITION SYSTEM & STARTER MOTOR
J225TLESS 1990	IGNITION SYSTEM & STARTER MOTOR
J225TLETA 1993	IGNITION SYSTEM & STARTER MOTOR
J225TLETF 1993	IGNITION SYSTEM & STARTER MOTOR

J225TXARC 1994	IGNITION SYSTEM & STARTER MOTOR
J225TXARK 1994	IGNITION SYSTEM & STARTER MOTOR
J225TXATF 1993	IGNITION SYSTEM & STARTER MOTOR
J225TXATS 1993	IGNITION SYSTEM & STARTER MOTOR
J225TXCCE 1988	IGNITION SYSTEM & STARTER MOTOR
J225TXCDA 1986	IGNITION SYSTEM
J225TXCED 1989	IGNITION SYSTEM & STARTER MOTOR
J225TXCUB 1987	IGNITION SYSTEM
J225TXECS 1998	IGNITION SYSTEM
J225TXEDE 1996	IGNITION SYSTEM
J225TXEIC 1991	IGNITION SYSTEM & STARTER MOTOR
J225TXENR 1992	IGNITION SYSTEM & STARTER MOTOR
J225TXEOB 1995	IGNITION SYSTEM & STARTER MOTOR
J225TXERK 1994	IGNITION SYSTEM & STARTER MOTOR
J225TXERM 1994	IGNITION SYSTEM & STARTER MOTOR
J225TXESS 1990	IGNITION SYSTEM & STARTER MOTOR
J225TXETA 1993	IGNITION SYSTEM & STARTER MOTOR
J225TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
J225TXEUD 1997	IGNITION SYSTEM
J225TZARK 1994	IGNITION SYSTEM & STARTER MOTOR
J225TZATF 1993	IGNITION SYSTEM & STARTER MOTOR
J225TZATS 1993	IGNITION SYSTEM & STARTER MOTOR
J225TZECS 1998	IGNITION SYSTEM
J225TZEDE 1996	IGNITION SYSTEM
J225TZEOb 1995	IGNITION SYSTEM & STARTER MOTOR
J225TZERK 1994	IGNITION SYSTEM & STARTER MOTOR
J225TZERM 1994	IGNITION SYSTEM & STARTER MOTOR
J225TZETA 1993	IGNITION SYSTEM & STARTER MOTOR
J225TZETF 1993	IGNITION SYSTEM & STARTER MOTOR
J225TZEUD 1997	IGNITION SYSTEM
J225VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	IGNITION SYSTEM
J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	IGNITION SYSTEM
J225VLSIF elec start, TNT, 20 in shaft, wht 2001	IGNITION SYSTEM
J225VXSIF elec start, TNT, 25 in shaft, wht 2001	IGNITION SYSTEM

J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	IGNITION SYSTEM
J235STLCOR 1985	IGNITION SYSTEM
J235STLCRC 1984	IGNITION SYSTEM
J235STLCTS 1983	IGNITION SYSTEM
J235TLCIB 1981	IGNITION SYSTEM
J235TLCIH 1981	IGNITION SYSTEM
J235TLCNE 1982	IGNITION SYSTEM
J235TLCOR 1985	IGNITION SYSTEM
J235TLCRC 1984	IGNITION SYSTEM
J235TLCSM 1980	IGNITION SYSTEM
J235TLCTD 1983	IGNITION SYSTEM
J235TLCTS 1983	IGNITION SYSTEM
J235TXCIB 1981	IGNITION SYSTEM
J235TXCIH 1981	IGNITION SYSTEM
J235TXCNE 1982	IGNITION SYSTEM
J235TXCOR 1985	IGNITION SYSTEM
J235TXCRC 1984	IGNITION SYSTEM
J235TXCSM 1980	IGNITION SYSTEM
J235TXCTD 1983	IGNITION SYSTEM
J235TXCTS 1983	IGNITION SYSTEM
J250CXARC 1994	IGNITION SYSTEM & STARTER MOTOR
J250CXATF 1993	IGNITION SYSTEM & STARTER MOTOR
J250CXATS 1993	IGNITION SYSTEM & STARTER MOTOR
J250CXECD 1998	IGNITION SYSTEM
J250CXEEN 1999	IGNITION SYSTEM
J250CXEES 1999	IGNITION SYSTEM
J250CXEIE 1991	IGNITION SYSTEM & STARTER MOTOR
J250CXEND 1992	IGNITION SYSTEM & STARTER MOTOR
J250CXEOR 1995	IGNITION SYSTEM & STARTER MOTOR
J250CXERC 1994	IGNITION SYSTEM & STARTER MOTOR
J250CXETF 1993	IGNITION SYSTEM & STARTER MOTOR
J250CXETS 1993	IGNITION SYSTEM & STARTER MOTOR
J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	IGNITION SYSTEM
J250CZATF 1993	IGNITION SYSTEM & STARTER MOTOR
J250CZATS 1993	IGNITION SYSTEM & STARTER MOTOR

J250CZECD 1998	IGNITION SYSTEM
J250CZEEN 1999	IGNITION SYSTEM
J250CZEES 1999	IGNITION SYSTEM
J250CZEND 1992	IGNITION SYSTEM & STARTER MOTOR
J250CZEOR 1995	IGNITION SYSTEM & STARTER MOTOR
J250CZERC 1994	IGNITION SYSTEM & STARTER MOTOR
J250CZETF 1993	IGNITION SYSTEM & STARTER MOTOR
J250CZETS 1993	IGNITION SYSTEM & STARTER MOTOR
J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	IGNITION SYSTEM
J250PXECD 1998	IGNITION SYSTEM
J250PXEEEN 1999	IGNITION SYSTEM
J250PXEEES 1999	IGNITION SYSTEM
J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000	IGNITION SYSTEM
J250PZECD 1998	IGNITION SYSTEM
J250PZEEN 1999	IGNITION SYSTEM
J250PZEES 1999	IGNITION SYSTEM
J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000	IGNITION SYSTEM
J250TXARC 1994	IGNITION SYSTEM & STARTER MOTOR
J250TXATF 1993	IGNITION SYSTEM & STARTER MOTOR
J250TXATS 1993	IGNITION SYSTEM & STARTER MOTOR
J250TXEIE 1991	IGNITION SYSTEM & STARTER MOTOR
J250TXEND 1992	IGNITION SYSTEM & STARTER MOTOR
J250TXEOR 1995	IGNITION SYSTEM & STARTER MOTOR
J250TXERC 1994	IGNITION SYSTEM & STARTER MOTOR
J250TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
J250TXETS 1993	IGNITION SYSTEM & STARTER MOTOR
J250TZATF 1993	IGNITION SYSTEM & STARTER MOTOR
J250TZATS 1993	IGNITION SYSTEM & STARTER MOTOR
J250TZEND 1992	IGNITION SYSTEM & STARTER MOTOR
J250TZEOR 1995	IGNITION SYSTEM & STARTER MOTOR
J250TZERC 1994	IGNITION SYSTEM & STARTER MOTOR
J250TZETF 1993	IGNITION SYSTEM & STARTER MOTOR
J250TZETS 1993	IGNITION SYSTEM & STARTER MOTOR
J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	IGNITION SYSTEM

J250VCZSIF elec start, TNT, 30 in shaft, wht, cntr rotate 2001	IGNITION SYSTEM
J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	IGNITION SYSTEM
J250VXSIF elec start, TNT, 25 in shaft, wht 2001	IGNITION SYSTEM
J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	IGNITION SYSTEM
J250VZSSIF elec start, TNT, 30 in shaft, wht 2001	IGNITION SYSTEM
J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	IGNITION SYSTEM
J25ECCM 1988	IGNITION
J25ECDR 1986	IGNITION
J25ECEB 1989	IGNITION
J25ECIB 1981	MAGNETO
J25ECIM 1981	MAGNETO
J25ECNE 1982	MAGNETO
J25ECOC 1985	IGNITION
J25ECRS 1984	IGNITION
J25ECTD 1983	MAGNETO
J25ECUA 1987	IGNITION
J25EECE 1998	IGNITION
J25EEDM 1996	IGNITION
J25EEED 1999	IGNITION
J25EEEN 1999	IGNITION
J25EEID 1991	IGNITION
J25EENS 1992	IGNITION
J25EEOA 1995	IGNITION
J25EERR 1994	IGNITION
J25EESE 1990	IGNITION
J25EETC 1993	IGNITION
J25EEUB 1997	IGNITION
J25ELCCM 1988	IGNITION
J25ELCDR 1986	IGNITION
J25ELCEB 1989	IGNITION
J25ELCIB 1981	MAGNETO
J25ELCIM 1981	MAGNETO
J25ELCNE 1982	MAGNETO
J25ELCOC 1985	IGNITION

J25ELCRS 1984	IGNITION
J25ELCTD 1983	MAGNETO
J25ELCUA 1987	IGNITION
J25ELECE 1998	IGNITION
J25ELEDM 1996	IGNITION
J25ELEED 1999	IGNITION
J25ELEEN 1999	IGNITION
J25ELEID 1991	IGNITION
J25ELENS 1992	IGNITION
J25ELEOA 1995	IGNITION
J25ELERR 1994	IGNITION
J25ELESE 1990	IGNITION
J25ELETC 1993	IGNITION
J25ELEUB 1997	IGNITION
J25ELSIC elec start, remote, 20 in shaft 2001	IGNITION
J25ELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSNF Electric start, Carb, White, Remote, 20 in., 4 Amp Alt 2002	IGNITION
J25ELSOB	IGNITION
J25ELSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSRM	IGNITION
J25ELSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSSS Elec. Start, 20 IN. shaft 2000	IGNITION
J25ELSTA	IGNITION
J25ELSTA - FR	22-5_SYSTÈME D'ALLUMAGE
J25ESIC elec start, remote, 15 in shaft 2001	IGNITION
J25ESSS Elec. Start, 15 IN. shaft 2000	IGNITION
J25EVLSIC elec start, remote, 120 in shaft, wht 2001	IGNITION
J25EVSIC elec start, remote, 15 in shaft, wht 2001	IGNITION
J25GTESOC	IGNITION
J25GTESOC - FR	22-5_SYSTÈME D'ALLUMAGE
J25GTESRS	IGNITION
J25GTESRS - FR	22-5_SYSTÈME D'ALLUMAGE
J25JRECA 1998	IGNITION
J25JREDC 1996	IGNITION

J25JREEM 1999	IGNITION
J25JREEN 1999	IGNITION
J25JREOS 1995	IGNITION
J25JREUR 1997	IGNITION
J25JRSIE jet drive, rope start, tiller, 15 in shaft 2001	IGNITION
J25JRSSB Jet Drive,Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J25JRTSSS Jet Drive, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
J25RCCA 1988	IGNITION
J25RCDC 1986	IGNITION
J25RCEM 1989	IGNITION
J25RCIM 1981	MAGNETO
J25RCNB 1982	MAGNETO
J25RCOS 1985	IGNITION
J25RCRD 1984	IGNITION
J25RCSA 1980	MAGNETO
J25RCTE 1983	MAGNETO
J25RCUR 1987	IGNITION
J25RECB 1998	IGNITION
J25REDA 1996	IGNITION
J25REEB 1999	IGNITION
J25REEN 1999	IGNITION
J25REIE 1991	IGNITION
J25RELCNB 1982	MAGNETO
J25REND 1992	IGNITION
J25REOR 1995	IGNITION
J25RERC 1994	IGNITION
J25RESB 1990	IGNITION
J25RETS 1993	IGNITION
J25REUM 1997	IGNITION
J25RLCCA 1988	IGNITION
J25RLCDC 1986	IGNITION
J25RLCEM 1989	IGNITION
J25RLCIM 1981	MAGNETO
J25RLCNB 1982	MAGNETO
J25RLCOS 1985	IGNITION

J25RLCRD 1984	IGNITION
J25RLCSA 1980	MAGNETO
J25RLCTE 1983	MAGNETO
J25RLCUR 1987	IGNITION
J25RLECB 1998	IGNITION
J25RLEDA 1996	IGNITION
J25RLEEB 1999	IGNITION
J25RLEEN 1999	IGNITION
J25RLEIE 1991	IGNITION
J25RLEND 1992	IGNITION
J25RLEOR 1995	IGNITION
J25RLERC 1994	IGNITION
J25RLESB 1990	IGNITION
J25RLETS 1993	IGNITION
J25RLEUM 1997	IGNITION
J25RLSID rope start, tiller, 20 in shaft 2001	IGNITION
J25RLSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25RLSNF Rope start, White, Tiller, 20 in. shaft, A/C Light 2002	IGNITION
J25RLSOA	IGNITION
J25RLSOA - FR	22-5_SYSTÈME D'ALLUMAGE
J25RLSRR	IGNITION
J25RLSRR - FR	22-5_SYSTÈME D'ALLUMAGE
J25RLSSE Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J25RLSTC	IGNITION
J25RLSTC - FR	22-5_SYSTÈME D'ALLUMAGE
J25RSA 1981	MAGNETO
J25RSID rope start, tiller, 15 in shaft 2001	IGNITION
J25RSLA 1981	MAGNETO
J25RSLS 1983	MAGNETO
J25RSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25RSNF Rope start, White, Tiller, 15 in. shaft, A/C Light 2002	IGNITION
J25RSOA	IGNITION
J25RSOA - FR	22-5_SYSTÈME D'ALLUMAGE
J25RSRR	IGNITION
J25RSRR - FR	22-5_SYSTÈME D'ALLUMAGE

J25RSS 1983	MAGNETO
J25RSSE Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J25RSTC	IGNITION
J25RSTC - FR	22-5_SYSTÈME D'ALLUMAGE
J25RTSOS	IGNITION
J25RTSOS - FR	22-5_SYSTÈME D'ALLUMAGE
J25RVLSID rope start, tiller, 20 in shaft, wht 2001	IGNITION
J25RVSID rope start, tiller, 15 in shaft, wht 2001	IGNITION
J25RWCDC 1986	MAGNETO
J25RWCIM 1981	MAGNETO
J25RWCOS 1985	MAGNETO
J25RWCRD 1984	MAGNETO
J25RWCTE 1983	MAGNETO
J25RWCUR 1987	MAGNETO
J25RWEDC 1996	IGNITION - H25FP
J25RWEDC 1996	IGNITION - 25RS - 25RW - S25RP
J25RWEIM 1991	IGNITION
J25RWENB 1992	IGNITION
J25RWEOS 1995	IGNITION - H25FP
J25RWEOS 1995	IGNITION - 25RS - 25RW - S25RP
J25RWERD 1994	IGNITION - 25RW
J25RWESA 1990	IGNITION
J25RWETE 1993	IGNITION - 25RW
J25RWEUR 1997	IGNITION - H25FP
J25RWEUR 1997	IGNITION - 25RS, 25RW, S25RP
J25RWK 1989	IGNITION
J25RWLCDC 1986	MAGNETO
J25RWLCIM 1981	MAGNETO
J25RWLCOS 1985	MAGNETO
J25RWLCRD 1984	MAGNETO
J25RWLCTE 1983	MAGNETO
J25RWLCUR 1987	MAGNETO
J25RWLEDC 1996	IGNITION - H25FP
J25RWLEDC 1996	IGNITION - 25RS - 25RW - S25RP
J25RWLEIM 1991	IGNITION

J25RWLENB 1992	IGNITION
J25RWLEOS 1995	IGNITION - H25FP
J25RWLEOS 1995	IGNITION - 25RS - 25RW - S25RP
J25RWLERD 1994	IGNITION - 25RW
J25RWLESA 1990	IGNITION
J25RWLETE 1993	IGNITION - 25RW
J25RWLEUR 1997	IGNITION - H25FP
J25RWLEUR 1997	IGNITION - 25RS, 25RW, S25RP
J25RWLK 1989	IGNITION
J25TECCA 1988	IGNITION
J25TECDC 1986	IGNITION
J25TECEM 1989	IGNITION
J25TECIM 1981	MAGNETO
J25TECNB 1982	MAGNETO
J25TECOS 1985	IGNITION
J25TECRD 1984	IGNITION
J25TECSA 1980	MAGNETO
J25TECTE 1983	MAGNETO
J25TECUR 1987	IGNITION
J25TEECB 1998	IGNITION
J25TEEDA 1996	IGNITION
J25TEEEE 1999	IGNITION
J25TEEEN 1999	IGNITION
J25TEEIE 1991	IGNITION
J25TEEND 1992	IGNITION
J25TEEOR 1995	IGNITION
J25TEERC 1994	IGNITION
J25TEESB 1990	IGNITION
J25TEETS 1993	IGNITION
J25TEEUM 1997	IGNITION
J25TELCCA 1988	IGNITION
J25TELCDC 1986	IGNITION
J25TELCCEM 1989	IGNITION
J25TELCIM 1981	MAGNETO
J25TELCOS 1985	IGNITION

J25TELCRD 1984	IGNITION
J25TELCSA 1980	MAGNETO
J25TELCCTE 1983	MAGNETO
J25TELCUR 1987	IGNITION
J25TELECB 1998	IGNITION
J25TELEDA 1996	IGNITION
J25TELEEE 1999	IGNITION
J25TELEEN 1999	IGNITION
J25TELEIE 1991	IGNITION
J25TELEND 1992	IGNITION
J25TELEOR 1995	IGNITION
J25TELERC	IGNITION
J25TELESB 1990	IGNITION
J25TELETS 1993	IGNITION
J25TELEUM 1997	IGNITION
J25TELSIS elec start, tiller, 20 in shaft 2001	IGNITION
J25TELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSNF Electric start, White, Tiller, 20 in., 4 Amp Alt 2002	IGNITION
J25TELSOM	IGNITION
J25TELSOM - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSRA	IGNITION
J25TELSRA - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSSD Elec. Start, Tiller, 20 IN. shaft 2000	IGNITION
J25TELSTR	IGNITION
J25TELSTR - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESIS elec start, tiller, 15 in shaft 2001	IGNITION
J25TESNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESNF Electric start, White, Tiller, 15 in. shaft, 4 Amp Alt 2002	IGNITION
J25TESOM	IGNITION
J25TESOM - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESRA	IGNITION
J25TESRA - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESSD Elec. Start, Tiller, 15 IN. shaft 2000	IGNITION
J25TESTR	IGNITION

J25TESTR - FR	22-5_SYSTÈME D'ALLUMAGE
J25TVLSIS elec start, tiller, 20 in shaft 2001	IGNITION
J25TVSIS elec start, tiller, 15 in shaft 2001	IGNITION
J25WREEN 1999	IGNITION
J25WREES 1999	IGNITION
J25WRLEEN 1999	IGNITION
J25WRLEES 1999	IGNITION
J25WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
J25WRLSOB	IGNITION
J25WRLSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J25WRLSRM	IGNITION
J25WRLSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J25WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	IGNITION
J25WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
J25WRSOB	IGNITION
J25WRSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J25WRSRM	IGNITION
J25WRSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J25WRSSC Commercial, Rope Start, 15 IN. shaft 2000	IGNITION
J275CLCUR 1987	IGNITION SYSTEM - 35 AMP
J275CXCCA 1988	IGNITION SYSTEM & STARTER MOTOR
J275CXCUR 1987	IGNITION SYSTEM - 35 AMP
J275PLCCA 1988	IGNITION SYSTEM & STARTER MOTOR
J275PLCUR 1987	IGNITION SYSTEM - 35 AMP
J275PTLCDC 1986	IGNITION SYSTEM - 35 AMP
J275PTXCDC 1986	IGNITION SYSTEM - 35 AMP
J275PXCCA 1988	IGNITION SYSTEM & STARTER MOTOR
J275PXCUR 1987	IGNITION SYSTEM - 35 AMP
J275TLCOS 1985	IGNITION SYSTEM - 35 AMP
J275TXCOS 1985	IGNITION SYSTEM - 35 AMP
J28ELCDS 1986	MAGNETO
J28ESLCCR 1988	IGNITION
J28ESLCEA 1989	IGNITION
J28ESLCUC 1987	MAGNETO
J28ESLEDR 1996	IGNITION

J28ESLEIB 1991	IGNITION
J28ESLENE 1992	IGNITION
J28ESLEOC 1995	IGNITION
J28ESLERS 1994	IGNITION
J28ESLESM 1990	IGNITION
J28ESLETD 1993	IGNITION
J2RCIB 1981	MAGNETO
J2RCNE 1982	MAGNETO
J2RCOC 1985	MAGNETO
J2RCRS 1984	MAGNETO
J2RCSM 1980	MAGNETO
J2RCTD 1983	MAGNETO
J300CLCUR 1987	IGNITION SYSTEM - 35 AMP
J300CXCCA 1988	IGNITION SYSTEM & STARTER MOTOR
J300CXCEM 1989	IGNITION SYSTEM & STARTER MOTOR
J300CXCUR 1987	IGNITION SYSTEM - 35 AMP
J300CXEIE 1991	IGNITION SYSTEM & STARTER MOTOR
J300CXEND 1992	IGNITION SYSTEM & STARTER MOTOR
J300CXEOR 1995	IGNITION SYSTEM & STARTER MOTOR
J300CXERC 1994	IGNITION SYSTEM & STARTER MOTOR
J300CXESB 1990	IGNITION SYSTEM & STARTER MOTOR
J300CXETF 1993	IGNITION SYSTEM & STARTER MOTOR
J300CXETS 1993	IGNITION SYSTEM & STARTER MOTOR
J300PLCCA 1988	IGNITION SYSTEM & STARTER MOTOR
J300PLCEM 1989	IGNITION SYSTEM & STARTER MOTOR
J300PLCUR 1987	IGNITION SYSTEM - 35 AMP
J300PLEIE 1991	IGNITION SYSTEM & STARTER MOTOR
J300PLEND 1992	IGNITION SYSTEM & STARTER MOTOR
J300PLEOR 1995	IGNITION SYSTEM & STARTER MOTOR
J300PLERC 1994	IGNITION SYSTEM & STARTER MOTOR
J300PLESB 1990	IGNITION SYSTEM & STARTER MOTOR
J300PLETF 1993	IGNITION SYSTEM & STARTER MOTOR
J300PLETS 1993	IGNITION SYSTEM & STARTER MOTOR
J300PXCCA 1988	IGNITION SYSTEM & STARTER MOTOR
J300PXCEM 1989	IGNITION SYSTEM & STARTER MOTOR

J300PXCUR 1987	IGNITION SYSTEM - 35 AMP
J300PXEIE 1991	IGNITION SYSTEM & STARTER MOTOR
J300PXEND 1992	IGNITION SYSTEM & STARTER MOTOR
J300PXEOR 1995	IGNITION SYSTEM & STARTER MOTOR
J300PXERC 1994	IGNITION SYSTEM & STARTER MOTOR
J300PXESB 1990	IGNITION SYSTEM & STARTER MOTOR
J300PXETF 1993	IGNITION SYSTEM & STARTER MOTOR
J300PXETS 1993	IGNITION SYSTEM & STARTER MOTOR
J300TLCDC 1986	IGNITION SYSTEM - 35 AMP
J300TLCOS 1985	IGNITION SYSTEM - 35 AMP
J300TXCDC 1986	IGNITION SYSTEM - 35 AMP
J300TXCOS 1985	IGNITION SYSTEM - 35 AMP
J30ECCE 1988	IGNITION
J30ECDM 1986	IGNITION
J30ECED 1989	IGNITION
J30EOCA 1985	IGNITION
J30ECRR 1984	IGNITION
J30ECUB 1987	IGNITION
J30EECS 1998	IGNITION
J30EEDE 1996	IGNITION
J30EEEC 1999	IGNITION
J30EEEN 1999	IGNITION
J30EEIC 1991	IGNITION
J30EENR 1992	IGNITION
J30EEOB 1995	IGNITION
J30EERM 1994	IGNITION
J30EESS 1990	IGNITION
J30EETA 1993	IGNITION
J30EEUD 1997	IGNITION
J30ELCCE 1988	IGNITION
J30ELCDM 1986	IGNITION
J30ELCED 1989	IGNITION
J30ELCOA 1985	IGNITION
J30ELCRR 1984	IGNITION
J30ELCUB 1987	IGNITION

J30ELECS 1998	IGNITION
J30ELEDE 1996	IGNITION
J30ELEEC 1999	IGNITION
J30ELEEN 1999	IGNITION
J30ELEIC 1991	IGNITION
J30ELENR 1992	IGNITION
J30ELEOB 1995	IGNITION
J30ELERM 1994	IGNITION
J30ELESS 1990	IGNITION
J30ELETA 1993	IGNITION
J30ELEUD 1997	IGNITION
J30ELSIA elec start, remote, 20 in shaft 2001	IGNITION
J30ELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSNF Electric start, Carb, White, Remote, 20 in., 4 Amp Alt, 2002	IGNITION
J30ELSOD	IGNITION
J30ELSOD - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSRE	IGNITION
J30ELSRE - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSSR Elec. Start, 20 IN. shaft 2000	IGNITION
J30ELSTB	IGNITION
J30ELSTB - FR	22-5_SYSTÈME D'ALLUMAGE
J30ESIA elec start, remote, 15 in shaft 2001	IGNITION
J30ESSR Elec. Start, 15 IN. shaft 2000	IGNITION
J30EVLSIA elec start, remote, 20 in shaft, wht 2001	IGNITION
J30JREEM 1999	IGNITION SYSTEM
J30JRSIE jet drive, rope start, 15 in shaft 2001	IGNITION SYSTEM
J30JRSSB Jet Drive, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
J30MLSRC	IGNITION
J30MLSRC - FR	22-5_SYSTÈME D'ALLUMAGE
J30MLSTS	IGNITION
J30MLSTS - FR	22-5_SYSTÈME D'ALLUMAGE
J30RCCE 1988	IGNITION
J30RCDM 1986	IGNITION
J30RCED 1989	IGNITION

J30RCOA 1985	IGNITION
J30RCUB 1987	IGNITION
J30REDE 1996	IGNITION
J30REEC 1999	IGNITION
J30REEN 1999	IGNITION
J30REIC 1991	IGNITION
J30RENR 1992	IGNITION
J30REOB 1995	IGNITION
J30RERM 1994	IGNITION
J30RESS 1990	IGNITION
J30RETA 1993	IGNITION
J30REUD 1997	IGNITION
J30RLCCE 1988	IGNITION
J30RLCDM 1986	IGNITION
J30RLCED 1989	IGNITION
J30RLCOA 1985	IGNITION
J30RLCUB 1987	IGNITION
J30RLEDE 1996	IGNITION
J30RLEEC 1999	IGNITION
J30RLEEN 1999	IGNITION
J30RLEIC 1991	IGNITION
J30RLENR 1992	IGNITION
J30RLEOB 1995	IGNITION
J30RLERM 1994	IGNITION
J30RLESS 1990	IGNITION
J30RLETA 1993	IGNITION
J30RLEUD 1997	IGNITION
J30RLSIA rope start, tiller, 20 in shaft 2001	IGNITION
J30RLSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J30RLSNF Rope start, White, Tiller, 20 in. shaft, A/C Light 2002	IGNITION
J30RLSOD	IGNITION
J30RLSOD - FR	22-5_SYSTÈME D'ALLUMAGE
J30RLSRE	IGNITION
J30RLSRE - FR	22-5_SYSTÈME D'ALLUMAGE
J30RLSSR Rope Start, Tiller, 20 IN. shaft 2000	IGNITION

J30RLSTB	IGNITION
J30RLSTB - FR	22-5_SYSTÈME D'ALLUMAGE
J30RSIA rope start, tiller, 15 in shaft 2001	IGNITION
J30RSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J30RSNF Rope start, White, Tiller,15 in. shaft, A/C Light 2002	IGNITION
J30RSOD	IGNITION
J30RSOD - FR	22-5_SYSTÈME D'ALLUMAGE
J30RSRE	IGNITION
J30RSRE - FR	22-5_SYSTÈME D'ALLUMAGE
J30RSSR Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J30RSTB	IGNITION
J30RSTB - FR	22-5_SYSTÈME D'ALLUMAGE
J30RVLSIA rope start, tiller, 20 in shaft, wht 2001	IGNITION
J30RVSIA rope start, tiller, 15 in shaft, wht 2001	IGNITION
J30TECCE 1988	IGNITION
J30TECDM 1986	IGNITION
J30TECED 1989	IGNITION
J30TECOA 1985	IGNITION
J30TECUB 1987	IGNITION
J30TEECS 1998	IGNITION
J30TEEDE 1996	IGNITION
J30TEEIC 1991	IGNITION
J30TEENR 1992	IGNITION
J30TEEOB 1995	IGNITION
J30TEERM 1994	IGNITION
J30TEESS 1990	IGNITION
J30TEETA 1993	IGNITION
J30TEEUD 1997	IGNITION
J30TELCCE 1988	IGNITION
J30TELCDM 1986	IGNITION
J30TELCED 1989	IGNITION
J30TELCOA 1985	IGNITION
J30TELCUB 1987	IGNITION
J30TELECS 1998	IGNITION
J30TELEDE 1996	IGNITION

J30TELEIC 1991	IGNITION
J30TELENR 1992	IGNITION
J30TELEOB 1995	IGNITION
J30TELERM 1994	IGNITION
J30TELESS 1990	IGNITION
J30TELETA 1993	IGNITION
J30TELEUD 1997	IGNITION
J35AELCDE 1986	IGNITION SYSTEM
J35AELCUD 1987	IGNITION SYSTEM
J35ARLCDE 1986	IGNITION SYSTEM
J35ARLCUD 1987	IGNITION SYSTEM
J35ECIG 1981	MAGNETO
J35ECND 1982	MAGNETO
J35ECRR 1984	IGNITION
J35ECSM 1980	MAGNETO
J35ECTS 1983	MAGNETO
J35ELCIG 1981	MAGNETO
J35ELCND 1982	MAGNETO
J35ELCRR 1984	IGNITION
J35ELCSM 1980	MAGNETO
J35ELCTS 1983	MAGNETO
J35RCCE 1988	IGNITION
J35RCDM 1986	IGNITION
J35RCED 1989	IGNITION
J35RCIG 1981	MAGNETO
J35RCND 1982	MAGNETO
J35RCRR 1984	IGNITION
J35RCSM 1980	MAGNETO
J35RCTS 1983	MAGNETO
J35RCUB 1987	IGNITION
J35REIC 1991	IGNITION
J35RENr 1992	IGNITION
J35RERM 1994	IGNITION
J35RESS 1990	IGNITION
J35RETA 1993	IGNITION

J35RLCCE 1988	IGNITION
J35RLCDM 1986	IGNITION
J35RLCED 1989	IGNITION
J35RLCIG 1981	MAGNETO
J35RLCND 1982	MAGNETO
J35RLCRR 1984	IGNITION
J35RLCSM 1980	MAGNETO
J35RLCTS 1983	MAGNETO
J35RLCUB 1987	IGNITION
J35RLEIC 1991	IGNITION
J35RLENR 1992	IGNITION
J35RLERM 1994	IGNITION
J35RLESS 1990	IGNITION
J35RLETA 1993	IGNITION
J35TELCNB 1982	MAGNETO
J35TELCRR 1984	IGNITION
J35TELCTS 1983	MAGNETO
J3BRCEC 1989	IGNITION
J3BRESR 1990	IGNITION
J3RCCM 1988	IGNITION
J3RCUA 1987	IGNITION
J3REIA 1991	IGNITION
J3RENM 1992	IGNITION
J3REOD 1995	IGNITION
J3RERE 1994	IGNITION
J3RETB 1993	IGNITION
J3REUC 1997	IGNITION
J40AELCCS 1988	IGNITION SYSTEM
J40ARLCCS 1988	IGNITION SYSTEM
J40ATLCCS 1988	IGNITION SYSTEM
J40ECCS 1988	IGNITION SYSTEM
J40ECDE 1986	IGNITION SYSTEM
J40ECEC 1989	IGNITION SYSTEM - ROPE START
J40ECEC 1989	IGNITION SYSTEM - ELECTRIC START
J40ECOB 1985	IGNITION SYSTEM

J40ECRM 1984	IGNITION SYSTEM
J40ECUD 1987	IGNITION SYSTEM
J40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40EEIA 1991	IGNITION SYSTEM - ROPE START
J40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40EENJ 1992	IGNITION SYSTEM - ROPE START
J40EENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40EENM 1992	IGNITION SYSTEM - ROPE START
J40EENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J40EEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40EEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40EEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40EEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
J40EERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40EERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40EERE 1994	IGNITION SYSTEM - 40 ROPE START
J40EERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40EESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40EESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40EESR 1990	IGNITION SYSTEM - ROPE START
J40EETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS

J40EETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40EETB 1993	IGNITION SYSTEM - 40 ROPE START
J40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40ELCCS 1988	IGNITION SYSTEM
J40ELCDE 1986	IGNITION SYSTEM
J40ELCEC 1989	IGNITION SYSTEM - ROPE START
J40ELCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40ELCOB 1985	IGNITION SYSTEM
J40ELCRM 1984	IGNITION SYSTEM
J40ELCUD 1987	IGNITION SYSTEM
J40ELECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
J40ELECR 1998	IGNITION SYSTEM -- ROPE START
J40ELEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40ELEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
J40ELEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
J40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40ELEIA 1991	IGNITION SYSTEM - ROPE START
J40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40ELENJ 1992	IGNITION SYSTEM - ROPE START
J40ELENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40ELENM 1992	IGNITION SYSTEM - ROPE START
J40ELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J40ELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40ELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY

J40ELEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40ELEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
J40ELERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40ELERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40ELERE 1994	IGNITION SYSTEM - 40 ROPE START
J40ELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40ELESR 1990	IGNITION SYSTEM - ROPE START
J40ELETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40ELETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
J40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40ELEUC 1997	IGNITION SYSTEM - ROPE START
J40ELEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
J40JPLEEC 1999	IGNITION SYSTEM
J40JPLSIA jet drive,elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM
J40JPLSSR Jet Drive, Elec Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM
J40JRECA 1998	IGNITION SYSTEM
J40JREDC 1996	IGNITION SYSTEM
J40JREOS 1995	IGNITION SYSTEM
J40JREUR 1997	IGNITION SYSTEM
J40JVLSIA jet drive,elec start, TNT, 20 in shaft, wht 2001	IGNITION SYSTEM
J40PLEEA 1999	IGNITION SYSTEM -- ELECTRIC START
J40PLEEA 1999	IGNITION SYSTEM -- ROPE START
J40PLSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - ELECTRIC START
J40PLSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J40PLSNF - FR	22-4_ÉLÉMENTS ÉLECTRIQUES
J40PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	ELECTRICAL / IGNITION SYSTEM
J40PLSOC	ELECTRICAL / IGNITION SYSTEM
J40PLSOC - FR	22-5_SYSTÈME D'ALLUMAGE

J40PLSRS	ELECTRICAL / IGNITION SYSTEM
J40PLSRS - FR	22-4_ÉLÉMENTS ÉLECTRIQUES
J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM - ELECTRIC START
J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J40PLSTD	ELECTRICAL / IGNITION SYSTEM
J40PLSTD - FR	22-4_ÉLÉMENTS ÉLECTRIQUES
J40RCCS 1988	IGNITION SYSTEM
J40RCDE 1986	IGNITION SYSTEM
J40RCEC 1989	IGNITION SYSTEM - ROPE START
J40RCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40RCOB 1985	IGNITION SYSTEM
J40RCRM 1984	IGNITION SYSTEM
J40RCUD 1987	IGNITION SYSTEM
J40RECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
J40RECR 1998	IGNITION SYSTEM -- ROPE START
J40REDS 1996	IGNITION SYSTEM - 40 ROPE START
J40REDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
J40REDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
J40REEA 1999	IGNITION SYSTEM -- ELECTRIC START
J40REEA 1999	IGNITION SYSTEM -- ROPE START
J40REIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40REIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40REIA 1991	IGNITION SYSTEM - ROPE START
J40RENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40RENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J40RENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40RENM 1992	IGNITION SYSTEM - ROPE START
J40RENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J40REOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40REOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40REOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS

J40REOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
J40RERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40RERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40RERE 1994	IGNITION SYSTEM - 40 ROPE START
J40RERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40RESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40RESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40RESR 1990	IGNITION SYSTEM - ROPE START
J40RETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40RETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40RETB 1993	IGNITION SYSTEM - 40 ROPE START
J40RETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40REUC 1997	IGNITION SYSTEM - ROPE START
J40REUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
J40RLCCS 1988	IGNITION SYSTEM
J40RLCDE 1986	IGNITION SYSTEM
J40RLCEC 1989	IGNITION SYSTEM - ROPE START
J40RLCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40RLCOB 1985	IGNITION SYSTEM
J40RLCRM 1984	IGNITION SYSTEM
J40RLCUD 1987	IGNITION SYSTEM
J40RLECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
J40RLECR 1998	IGNITION SYSTEM -- ROPE START
J40RLEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40RLEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
J40RLEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
J40RLEEA 1999	IGNITION SYSTEM -- ELECTRIC START
J40RLEEA 1999	IGNITION SYSTEM -- ROPE START
J40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40RLEIA 1991	IGNITION SYSTEM - ROPE START

J40RLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40RLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J40RLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40RLENM 1992	IGNITION SYSTEM - ROPE START
J40RLENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J40RLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40RLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40RLEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40RLEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
J40RLERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40RLERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40RLERE 1994	IGNITION SYSTEM - 40 ROPE START
J40RLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40RLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40RLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40RLESR 1990	IGNITION SYSTEM - ROPE START
J40RLETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40RLETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40RLETB 1993	IGNITION SYSTEM - 40 ROPE START
J40RLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40RLEUC 1997	IGNITION SYSTEM - ROPE START
J40RLEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
J40RLSIF rope start, 20 in shaft 2001	IGNITION SYSTEM - ELECTRIC START
J40RLSIF rope start, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J40RLSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J40RLSNF 20 in. shaft, White, Tiller, Rope, Touch Trim 2002	IGNITION SYSTEM
J40RLSOC	IGNITION SYSTEM
J40RLSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J40RLSRS	IGNITION SYSTEM

J40RLSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - ELECTRIC START
J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J40RLSTD	IGNITION SYSTEM
J40RLSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J40RSIF rope start, 15 in shaft 2001	IGNITION SYSTEM - ELECTRIC START
J40RSIF rope start, 15 in shaft 2001	IGNITION SYSTEM - ROPE START
J40RSLR 1983	MAGNETO-RS AND RW MODELS ONLY
J40RSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J40RSNF 15 in. shaft, White, Tiller, Rope, Touch Trim 2002	IGNITION SYSTEM
J40RSOC	IGNITION SYSTEM
J40RSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J40RSR 1983	MAGNETO-RS AND RW MODELS ONLY
J40RSRS	IGNITION SYSTEM
J40RSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J40RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM - ELECTRIC START
J40RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J40RSTD	IGNITION SYSTEM
J40RSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J40RWADB 1986	IGNITION
J40RWCOM 1985	IGNITION
J40RWCR 1984	IGNITION
J40RWCTR 1983	MAGNETO-RS AND RW MODELS ONLY
J40RWLCDB 1986	IGNITION
J40RWLCOM 1985	IGNITION
J40RWLCRA 1984	IGNITION
J40RWLCTR 1983	MAGNETO-RS AND RW MODELS ONLY
J40TECCS 1988	IGNITION SYSTEM
J40TECDE 1986	IGNITION SYSTEM
J40TECEC 1989	IGNITION SYSTEM - ROPE START
J40TECEC 1989	IGNITION SYSTEM - ELECTRIC START
J40TECOB 1985	IGNITION SYSTEM
J40TECRM 1984	IGNITION SYSTEM
J40TECUD 1987	IGNITION SYSTEM
J40TEECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START

J40TEECR 1998	IGNITION SYSTEM -- ROPE START
J40TEEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40TEEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
J40TEEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
J40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TEEIA 1991	IGNITION SYSTEM - ROPE START
J40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TEENJ 1992	IGNITION SYSTEM - ROPE START
J40TEENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J40TEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J40TEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TEENM 1992	IGNITION SYSTEM - ROPE START
J40TEENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J40TEEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40TEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TEEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40TEEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
J40TEERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40TEERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40TEERE 1994	IGNITION SYSTEM - 40 ROPE START
J40TEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TEESR 1990	IGNITION SYSTEM - ROPE START

J40TEETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40TEETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40TEETB 1993	IGNITION SYSTEM - 40 ROPE START
J40TEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TEEUC 1997	IGNITION SYSTEM - ROPE START
J40TEEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
J40TELCCS 1988	IGNITION SYSTEM
J40TELCDE 1986	IGNITION SYSTEM
J40TELCEC 1989	IGNITION SYSTEM - ROPE START
J40TELCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40TELCOB 1985	IGNITION SYSTEM
J40TELCRM 1984	IGNITION SYSTEM
J40TELECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
J40TELECR 1998	IGNITION SYSTEM -- ROPE START
J40TELEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40TELEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
J40TELEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
J40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TELEIA 1991	IGNITION SYSTEM - ROPE START
J40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TELENJ 1992	IGNITION SYSTEM - ROPE START
J40TELENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TELENM 1992	IGNITION SYSTEM - ROPE START
J40TELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)

J40TELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TELEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40TELEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
J40TELERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40TELERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40TELERE 1994	IGNITION SYSTEM - 40 ROPE START
J40TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TELESR 1990	IGNITION SYSTEM - ROPE START
J40TELETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40TELETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40TELETB 1993	IGNITION SYSTEM - 40 ROPE START
J40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TELEUC 1997	IGNITION SYSTEM - ROPE START
J40TELEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
J40TLCCS 1988	IGNITION SYSTEM
J40TLCDE 1986	IGNITION SYSTEM
J40TLCEC 1989	IGNITION SYSTEM - ROPE START
J40TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40TLCUD 1987	IGNITION SYSTEM
J40TLECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
J40TLECR 1998	IGNITION SYSTEM -- ROPE START
J40TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40TLEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
J40TLEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
J40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TLEIA 1991	IGNITION SYSTEM - ROPE START

J40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TLENJ 1992	IGNITION SYSTEM - ROPE START
J40TLENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TLENM 1992	IGNITION SYSTEM - ROPE START
J40TLENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J40TLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TLEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40TLEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
J40TLERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40TLERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40TLERE 1994	IGNITION SYSTEM - 40 ROPE START
J40TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TLESR 1990	IGNITION SYSTEM - ROPE START
J40TLETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40TLETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40TLETB 1993	IGNITION SYSTEM - 40 ROPE START
J40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TLETF 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS

J40TLETF 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40TLETF 1993	IGNITION SYSTEM - 40 ROPE START
J40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TLEUC 1997	IGNITION SYSTEM - ROPE START
J40TLEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
J40TPLEEA 1999	IGNITION SYSTEM -- ELECTRIC START
J40TPLEEA 1999	IGNITION SYSTEM -- ROPE START
J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001	IGNITION SYSTEM - ELECTRIC START
J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - ELECTRIC START
J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J40TTLCCS 1988	IGNITION SYSTEM
J40TTLCEC 1989	IGNITION SYSTEM - ROPE START
J40TTLCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40TTLECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
J40TTLECR 1998	IGNITION SYSTEM -- ROPE START
J40TTLEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40TTLEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
J40TTLEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
J40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TTLEIA 1991	IGNITION SYSTEM - ROPE START
J40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TTLENM 1992	IGNITION SYSTEM - ROPE START
J40TTLENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J40TTLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40TTLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TTLEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS

J40TTLEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
J40TTLERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40TTLERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40TTLERE 1994	IGNITION SYSTEM - 40 ROPE START
J40TTLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TTLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TTLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TTLESR 1990	IGNITION SYSTEM - ROPE START
J40TTLETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40TTLETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40TTLETB 1993	IGNITION SYSTEM - 40 ROPE START
J40TTLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TTLETF 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J40TTLETF 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J40TTLETF 1993	IGNITION SYSTEM - 40 ROPE START
J40TTLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TTLEUC 1997	IGNITION SYSTEM - ROPE START
J40TTLEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
J40WREES 1999	IGNITION SYSTEM
J40WRLEES 1999	IGNITION SYSTEM
J40WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
J40WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM
J40WRSIR commercial, rope start, 15 in shaft 2001	IGNITION SYSTEM
J40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
J40WRYEES 1999	IGNITION SYSTEM
J40WRYSIR commercial, rope start, 25 in shaft 2001	IGNITION SYSTEM
J40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	IGNITION SYSTEM
J45RCCDS 1986	IGNITION SYSTEM
J45RCCUC 1987	IGNITION SYSTEM
J45RCE 1989	IGNITION

J45RCEIA 1991	IGNITION SYSTEM
J45RCENM 1992	IGNITION SYSTEM - ELECTRIC
J45RCENM 1992	IGNITION SYSTEM - ROPE START
J45RCEOD 1995	IGNITION SYSTEM
J45RCERE 1994	IGNITION SYSTEM
J45RCESR 1990	IGNITION
J45RCETB 1993	IGNITION SYSTEM
J45RCLCDS 1986	IGNITION SYSTEM
J45RCLCUC 1987	IGNITION SYSTEM
J45RCLE 1989	IGNITION
J45RCLEDS 1996	IGNITION SYSTEM
J45RCLEIA 1991	IGNITION SYSTEM
J45RCLENM 1992	IGNITION SYSTEM - ELECTRIC
J45RCLENM 1992	IGNITION SYSTEM - ROPE START
J45RCLEOD 1995	IGNITION SYSTEM
J45RCLERE 1994	IGNITION SYSTEM
J45RCLESR 1990	IGNITION
J45RCLETB 1993	IGNITION SYSTEM
J45RCLEUC 1997	IGNITION SYSTEM
J45WMLE 1989	IGNITION
J45WMLEIA 1991	IGNITION SYSTEM
J45WMLNEM 1992	IGNITION SYSTEM - ELECTRIC
J45WMLNEM 1992	IGNITION SYSTEM - ROPE START
J45WMLESR 1990	IGNITION
J48ESLCCC 1988	IGNITION SYSTEM
J48ESLCER 1989	IGNITION SYSTEM
J48ESLCUS 1987	IGNITION SYSTEM
J48ESLEDC 1996	IGNITION SYSTEM
J48ESLEIM 1991	IGNITION SYSTEM
J48ESLENB 1992	IGNITION SYSTEM
J48ESLEOS 1995	IGNITION SYSTEM
J48ESLERD 1994	IGNITION SYSTEM
J48ESLESA 1990	IGNITION SYSTEM
J48ESLETE 1993	IGNITION SYSTEM
J4BRCIC 1981	MAGNETO

J4BRECRJ 1998	IGNITION
J4BRHCCS 1988	IGNITION
J4BRHCDE 1986	IGNITION
J4BRHCNR 1982	MAGNETO
J4BRHCOB 1985	IGNITION
J4BRHCRM 1984	IGNITION
J4BRHCTA 1983	MAGNETO
J4BRHCUD 1987	IGNITION
J4BRHLCCS 1988	IGNITION
J4BRHLCDE 1986	IGNITION
J4BRHLCNR 1982	MAGNETO
J4BRHLCOB 1985	IGNITION
J4BRHLCRM 1984	IGNITION
J4BRHLCTA 1983	MAGNETO
J4BRHLCUD 1987	IGNITION
J4BRLCIC 1981	MAGNETO
J4BRLECRJ 1998	IGNITION
J4RCCS 1988	IGNITION
J4RCEC 1989	IGNITION
J4RCUD 1987	IGNITION
J4RDHCCS 1988	MAGNETO
J4RDHCDE 1986	MAGNETO
J4RDHCEC 1989	IGNITION
J4RDHCUD 1987	MAGNETO
J4RDHEIA 1991	IGNITION
J4RDHENM 1992	IGNITION
J4RDHEOD 1995	MAGNETO
J4RDHERE 1994	MAGNETO
J4RDHESR 1990	IGNITION
J4RDHETB 1993	IGNITION
J4RDHLCCS 1988	MAGNETO
J4RDHLCEC 1989	IGNITION
J4RDHLCUD 1987	MAGNETO
J4RDHLEIA 1991	IGNITION
J4RDHLENM 1992	IGNITION

J4RDHLEOD 1995	MAGNETO
J4RDHLERE 1994	MAGNETO
J4RDHLESR 1990	IGNITION
J4RDHLETB 1993	IGNITION
J4REDS 1996	IGNITION
J4REEA 1999	IGNITION
J4REIA 1991	IGNITION
J4RENM 1992	IGNITION
J4REOD 1995	IGNITION
J4RERE 1994	IGNITION
J4RESR 1990	IGNITION
J4RETB 1993	IGNITION
J4REUC 1997	IGNITION
J4RLCCS 1988	IGNITION
J4RLCEC 1989	IGNITION
J4RLCSS 1980	MAGNETO
J4RLCUD 1987	IGNITION
J4RLEDs 1996	IGNITION
J4RLEEA 1999	IGNITION
J4RLEIA 1991	IGNITION
J4RLENM 1992	IGNITION
J4RLEOD 1995	IGNITION
J4RLERE 1994	IGNITION
J4RLESr 1990	IGNITION
J4RLETB 1993	IGNITION
J4RLEUC 1997	IGNITION
J4RLSIB Rope Start, Tiller, 20 IN. shaft 2001	IGNITION
J4RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J4RSIB Rope Start, Tiller, 15 IN. shaft 2001	IGNITION
J4RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J4WCIC 1981	MAGNETO
J4WCNR 1982	MAGNETO
J4WCSS 1980	MAGNETO
J50BECCS 1988	IGNITION SYSTEM
J50BECDE 1986	IGNITION SYSTEM

J50BECEC 1989	IGNITION SYSTEM - ROPE START
J50BECEC 1989	IGNITION SYSTEM - ELECTRIC START
J50BECIC 1981	IGNITION SYSTEM
J50BECNR 1982	IGNITION SYSTEM
J50BECOB 1985	IGNITION SYSTEM
J50BECRM 1984	IGNITION SYSTEM
J50BECTA 1983	IGNITION SYSTEM
J50BECUD 1987	IGNITION SYSTEM
J50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50BEEIA 1991	IGNITION SYSTEM - ROPE START
J50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BEENJ 1992	IGNITION SYSTEM - ROPE START
J50BEENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BEENM 1992	IGNITION SYSTEM - ROPE START
J50BEENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J50BEEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50BEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50BEEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J50BEEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
J50BEERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J50BEERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J50BEERE 1994	IGNITION SYSTEM - 40 ROPE START
J50BEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

J50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50BEESR 1990	IGNITION SYSTEM - ROPE START
J50BEETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J50BEETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J50BEETB 1993	IGNITION SYSTEM - 40 ROPE START
J50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50BELCCS 1988	IGNITION SYSTEM
J50BELCDE 1986	IGNITION SYSTEM
J50BELCEC 1989	IGNITION SYSTEM - ROPE START
J50BELCEC 1989	IGNITION SYSTEM - ELECTRIC START
J50BELCIC 1981	IGNITION SYSTEM
J50BELCNR 1982	IGNITION SYSTEM
J50BELCOB 1985	IGNITION SYSTEM
J50BELCRM 1984	IGNITION SYSTEM
J50BELCTA 1983	IGNITION SYSTEM
J50BELCUD 1987	IGNITION SYSTEM
J50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50BELEIA 1991	IGNITION SYSTEM - ROPE START
J50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BELENJ 1992	IGNITION SYSTEM - ROPE START
J50BELENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BELENM 1992	IGNITION SYSTEM - ROPE START
J50BELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)

J50BELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50BELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50BELEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J50BELEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
J50BELERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J50BELERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J50BELERE 1994	IGNITION SYSTEM - 40 ROPE START
J50BELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50BELESR 1990	IGNITION SYSTEM - ROPE START
J50BELETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J50BELETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J50BELETB 1993	IGNITION SYSTEM - 40 ROPE START
J50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50DTLECA 1998	IGNITION SYSTEM
J50DTLEDC 1996	IGNITION SYSTEM
J50DTLEDC 1996	IGNITION SYSTEM - E70RNLIB ONLY
J50DTLEOS 1995	IGNITION SYSTEM
J50DTLEUR 1997	IGNITION SYSTEM
J50ECSR 1980	IGNITION SYSTEM
J50ELCSR 1980	IGNITION SYSTEM
J50ELED 1996	IGNITION SYSTEM
J50ELED 1996	IGNITION SYSTEM - E70RNLIB ONLY
J50ELEER 1999	IGNITION SYSTEM -- ELECTRIC START
J50ELEER 1999	IGNITION SYSTEM -- ROPE START
J50ELEOS 1995	IGNITION SYSTEM
J50ELEUR 1997	IGNITION SYSTEM
J50ELSIF elec start, 20 in shaft 2001	IGNITION SYSTEM - ELECTRIC START
J50ELSIF elec start, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM - ELECTRIC START

J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J50ESLECC 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
J50ESLECC 1998	IGNITION SYSTEM -- ROPE START
J50ESLEUR 1997	IGNITION SYSTEM - ROPE START
J50ESLEUR 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
J50JEDS 1996	IGNITION SYSTEM - 40 ROPE START
J50JEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
J50JEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
J50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50JEIA 1991	IGNITION SYSTEM - ROPE START
J50JENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50JENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J50JENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50JENJ 1992	IGNITION SYSTEM - ROPE START
J50JENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J50JENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50JENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J50JENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50JENM 1992	IGNITION SYSTEM - ROPE START
J50JENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J50JEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50JEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50JEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J50JEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
J50JERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J50JERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J50JERE 1994	IGNITION SYSTEM - 40 ROPE START

J50JERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50JETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J50JETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J50JETB 1993	IGNITION SYSTEM - 40 ROPE START
J50JETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50JEUC 1997	IGNITION SYSTEM - ROPE START
J50JEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
J50PLEEA 1999	IGNITION SYSTEM -- ELECTRIC START
J50PLEEA 1999	IGNITION SYSTEM -- ROPE START
J50PLSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - ELECTRIC START
J50PLSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J50PLSNF - FR	22-4_ÉLÉMENTS ÉLECTRIQUES
J50PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	ELECTRICAL / IGNITION SYSTEM
J50PLSOC	ELECTRICAL / IGNITION SYSTEM
J50PLSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J50PLSRS	ELECTRICAL / IGNITION SYSTEM
J50PLSRS - FR	22-4_ÉLÉMENTS ÉLECTRIQUES
J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - ELECTRIC START
J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J50PLSTD	ELECTRICAL / IGNITION SYSTEM
J50PLSTD - FR	22-4_ÉLÉMENTS ÉLECTRIQUES
J50TELCCS 1988	IGNITION SYSTEM
J50TELCDE 1986	IGNITION SYSTEM
J50TELCEC 1989	IGNITION SYSTEM - ROPE START
J50TELCEC 1989	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TELCOB 1985	IGNITION SYSTEM
J50TELCRM 1984	IGNITION SYSTEM
J50TELCCTA 1983	IGNITION SYSTEM
J50TELCUD 1987	IGNITION SYSTEM
J50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TELEIA 1991	IGNITION SYSTEM - ROPE START
J50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)

J50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50TELENM 1992	IGNITION SYSTEM - ROPE START
J50TELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J50TELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50TELEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J50TELEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
J50TELERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J50TELERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J50TELERE 1994	IGNITION SYSTEM - 40 ROPE START
J50TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TELESR 1990	IGNITION SYSTEM - ROPE START
J50TELETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J50TELETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J50TELETB 1993	IGNITION SYSTEM - 40 ROPE START
J50TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLCCS 1988	IGNITION SYSTEM
J50TLCDE 1986	IGNITION SYSTEM
J50TLCEC 1989	IGNITION SYSTEM - ROPE START
J50TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
J50TLCOB 1985	IGNITION SYSTEM
J50TLCRM 1984	IGNITION SYSTEM
J50TLCUD 1987	IGNITION SYSTEM
J50TLECR 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
J50TLECR 1998	IGNITION SYSTEM -- ROPE START
J50TLEDS 1996	IGNITION SYSTEM - 40 ROPE START

J50TLEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
J50TLEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
J50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TLEIA 1991	IGNITION SYSTEM - ROPE START
J50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50TLENJ 1992	IGNITION SYSTEM - ROPE START
J50TLENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
J50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50TLENM 1992	IGNITION SYSTEM - ROPE START
J50TLENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
J50TLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50TLEOD 1995	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J50TLEOD 1995	IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS
J50TLERE 1994	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J50TLERE 1994	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J50TLERE 1994	IGNITION SYSTEM - 40 ROPE START
J50TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TLESR 1990	IGNITION SYSTEM - ROPE START
J50TLETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS

J50TLETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J50TLETB 1993	IGNITION SYSTEM - 40 ROPE START
J50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLETF 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
J50TLETF 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
J50TLETF 1993	IGNITION SYSTEM - 40 ROPE START
J50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLEUC 1997	IGNITION SYSTEM - ROPE START
J50TLEUC 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
J50TSLECC 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
J50TSLECC 1998	IGNITION SYSTEM -- ROPE START
J50TSLEUS 1997	IGNITION SYSTEM - ROPE START
J50TSLEUS 1997	IGNITION SYSTEM - 40-50 ELECTRIC START
J50TTLECA 1998	IGNITION SYSTEM
J50TTLEDC 1996	IGNITION SYSTEM
J50TTLEOS 1995	IGNITION SYSTEM
J50TTLEUR 1997	IGNITION SYSTEM
J55APRL	IGNITION & ELECTRICAL
J55APRL - FR	22-5_SYSTÈME D'ALLUMAGE
J55APRLSOM	IGNITION & ELECTRICAL
J55APRLSOM - FR	22-5_SYSTÈME D'ALLUMAGE
J55APRLSRA	IGNITION & ELECTRICAL
J55APRLSRA - FR	22-5_SYSTÈME D'ALLUMAGE
J55APRLSRG	IGNITION & ELECTRICAL
J55APRLSRG - FR	22-5_SYSTÈME D'ALLUMAGE
J55MLSOR	IGNITION & ELECTRICAL
J55MLSOR - FR	22-5_SYSTÈME D'ALLUMAGE
J55MLSRC	IGNITION & ELECTRICAL
J55MLSRC - FR	22-5_SYSTÈME D'ALLUMAGE
J55MLSRG	IGNITION & ELECTRICAL
J55MLSRG - FR	22-5_SYSTÈME D'ALLUMAGE
J55MRL	IGNITION & ELECTRICAL
J55MRL - FR	22-5_SYSTÈME D'ALLUMAGE

J55RCIM 1981	IGNITION SYSTEM
J55RLCIM 1981	IGNITION SYSTEM
J55RLCSA 1980	IGNITION SYSTEM
J55RSLC 1997	IGNITION SYSTEM
J55RSLG 1995	IGNITION SYSTEM
J55RSLN 1983	IGNITION SYSTEM
J55RSLN-2 1983	IGNITION SYSTEM
J55RSLW 1996	IGNITION SYSTEM
J55RSN 1983	IGNITION SYSTEM
J55RSN-2 1983	IGNITION SYSTEM
J55RSYN 1983	IGNITION SYSTEM
J55RSYN-2 1983	IGNITION SYSTEM
J55RWLCDC 1986	IGNITION SYSTEM
J55RWLCOS 1985	IGNITION SYSTEM
J55RWLCRD 1984	IGNITION SYSTEM
J55RWLCUC 1987	IGNITION SYSTEM
J55RWLE 1989	IGNITION
J55RWLEIA 1991	IGNITION SYSTEM
J55RWLENM 1992	IGNITION SYSTEM - ELECTRIC
J55RWLENM 1992	IGNITION SYSTEM - ROPE START
J55RWLERE 1994	IGNITION SYSTEM
J55RWLESR 1990	IGNITION
J55RWLETB 1993	IGNITION SYSTEM
J55WREES 1999	IGNITION SYSTEM
J55WRLEES 1999	IGNITION SYSTEM
J55WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
J55WRLSOE	IGNITION SYSTEM
J55WRLSOE - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRLSRB	IGNITION SYSTEM
J55WRLSRB - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRLSRG	IGNITION SYSTEM
J55WRLSRG - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM
J55WRLSTM	IGNITION SYSTEM
J55WRLSTM - FR	22-5_SYSTÈME D'ALLUMAGE

J55WRSIR commercial, rope start, 15 in shaft 2001	IGNITION SYSTEM
J55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
J55WRYEES 1999	IGNITION SYSTEM
J55WRY SIR commercial, rope start, 25 in shaft 2001	IGNITION SYSTEM
J55WRYSOB	IGNITION SYSTEM
J55WRYSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRYSRM	IGNITION SYSTEM
J55WRYSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	IGNITION SYSTEM
J5DRECR 1998	IGNITION
J5DRLECR 1998	IGNITION
J5RCIC 1981	MAGNETO - 7.5
J5RCIC 1981	MAGNETO-4.5
J5RCSS 1980	MAGNETO - 7.5
J5RCSS 1980	MAGNETO-4.5
J5RHCIC 1981	MAGNETO - 7.5
J5RHCIC 1981	MAGNETO-4.5
J5RHCNR 1982	MAGNETO - 4.5
J5RHCNR 1982	MAGNETO - 7.5
J5RHCSS 1980	MAGNETO - 7.5
J5RHCSS 1980	MAGNETO-4.5
J5RHCTA 1983	MAGNETO-4.5
J5RHCTA 1983	MAGNETO-7.5
J5RHLCIC 1981	MAGNETO - 7.5
J5RHLCIC 1981	MAGNETO-4.5
J5RHLCNR 1982	MAGNETO - 4.5
J5RHLCNR 1982	MAGNETO - 7.5
J5RHLCSS 1980	MAGNETO - 7.5
J5RHLCSS 1980	MAGNETO-4.5
J5RHLCTA 1983	MAGNETO-4.5
J5RHLCTA 1983	MAGNETO-7.5
J5RLCIC 1981	MAGNETO - 7.5
J5RLCIC 1981	MAGNETO-4.5
J5RLCSS 1980	MAGNETO - 7.5
J5RLCSS 1980	MAGNETO-4.5

J60ECIA 1981	IGNITION SYSTEM
J60ECIH 1981	IGNITION SYSTEM
J60ECNM 1982	IGNITION SYSTEM
J60ECSR 1980	IGNITION SYSTEM
J60ECTB 1983	IGNITION SYSTEM
J60ELCCR 1988	IGNITION SYSTEM
J60ELCDS 1986	IGNITION SYSTEM
J60ELCEA 1989	IGNITION SYSTEM 60EL - 60TL
J60ELCEA 1989	IGNITION SYSTEM 60TTL
J60ELCIA 1981	IGNITION SYSTEM
J60ELCIH 1981	IGNITION SYSTEM
J60ELCNM 1982	IGNITION SYSTEM
J60ELCOD 1985	IGNITION SYSTEM
J60ELCRE 1984	IGNITION SYSTEM
J60ELCSR 1980	IGNITION SYSTEM
J60ELCTB 1983	IGNITION SYSTEM
J60ELCUC 1987	IGNITION SYSTEM
J60ELEDR 1996	IGNITION SYSTEM
J60ELEDR 1996	IGNITION SYSTEM - E70RNLIB ONLY
J60ELEIB 1991	IGNITION SYSTEM
J60ELENE 1992	IGNITION SYSTEM
J60ELEOC 1995	IGNITION SYSTEM
J60ELERS 1994	IGNITION SYSTEM
J60ELERV 1994	IGNITION SYSTEM
J60ELES 1990	IGNITION SYSTEM 60EL - 60TL
J60ELES 1990	IGNITION SYSTEM 60TTL
J60ELETD 1993	IGNITION SYSTEM
J60ELEUA 1997	IGNITION SYSTEM
J60PLEEB 1999	IGNITION SYSTEM
J60PLSID elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM
J60PLSSE Elec Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM
J60TLCCR 1988	IGNITION SYSTEM
J60TLCDS 1986	IGNITION SYSTEM
J60TLCEA 1989	IGNITION SYSTEM 60EL - 60TL
J60TLCEA 1989	IGNITION SYSTEM 60TTL

J60TLCIA 1981	IGNITION SYSTEM
J60TLCIH 1981	IGNITION SYSTEM
J60TLCNM 1982	IGNITION SYSTEM
J60TLCOD 1985	IGNITION SYSTEM
J60TLCRE 1984	IGNITION SYSTEM
J60TLCTB 1983	IGNITION SYSTEM
J60TLCUC 1987	IGNITION SYSTEM
J60TLECM 1998	IGNITION SYSTEM
J60TLEDR 1996	IGNITION SYSTEM
J60TLEDR 1996	IGNITION SYSTEM - E70RNLIB ONLY
J60TLEIB 1991	IGNITION SYSTEM
J60TLENE 1992	IGNITION SYSTEM
J60TLEOC 1995	IGNITION SYSTEM
J60TLERS 1994	IGNITION SYSTEM
J60TLERV 1994	IGNITION SYSTEM
J60TLESM 1990	IGNITION SYSTEM 60EL - 60TL
J60TLESM 1990	IGNITION SYSTEM 60TTL
J60TLETD 1993	IGNITION SYSTEM
J60TLEUA 1997	IGNITION SYSTEM
J60TTLCCR 1988	IGNITION SYSTEM
J60TTLCEA 1989	IGNITION SYSTEM 60EL - 60TL
J60TTLCEA 1989	IGNITION SYSTEM 60TTL
J60TTLECM 1998	IGNITION SYSTEM
J60TTLEDR 1996	IGNITION SYSTEM
J60TTLEIB 1991	IGNITION SYSTEM
J60TTLENE 1992	IGNITION SYSTEM
J60TTLEOC 1995	IGNITION SYSTEM
J60TTLERS 1994	IGNITION SYSTEM
J60TTLERV 1994	IGNITION SYSTEM
J60TTLESM 1990	IGNITION SYSTEM 60EL - 60TL
J60TTLESM 1990	IGNITION SYSTEM 60TTL
J60TTLETD 1993	IGNITION SYSTEM
J60TTLEUA 1997	IGNITION SYSTEM
J60VLSID elec start, TNT, 20 in shaft, wht 2001	IGNITION SYSTEM
J65RSLC 1995	IGNITION SYSTEM

J65RSLM 1996	IGNITION SYSTEM
J65RSLZ2 1997	IGNITION SYSTEM
J65RWLCDR 1986	IGNITION SYSTEM
J65RWLCOC 1985	IGNITION SYSTEM
J65RWLCRS 1984	IGNITION SYSTEM
J65TELCDR 1986	IGNITION SYSTEM
J65TELCOC 1985	IGNITION SYSTEM
J65TELCRS 1984	IGNITION SYSTEM
J65WELEES 1999	IGNITION SYSTEM
J65WELSIR Commercial, elec start, 20 in shaft 2001	IGNITION SYSTEM
J65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	IGNITION SYSTEM
J65WMLCDR 1986	IGNITION SYSTEM
J65WMLCOC 1985	IGNITION SYSTEM
J65WMLCUA 1987	IGNITION SYSTEM
J65WMLEIB 1991	IGNITION SYSTEM
J65WMLENE 1992	IGNITION SYSTEM - VRO MODELS
J65WMLEOC 1995	IGNITION SYSTEM - VRO MODELS
J65WMLEOC 1995	IGNITION SYSTEM - NON-VRO MODELS
J65WMLERS 1994	IGNITION SYSTEM - VRO MODELS
J65WMLESM 1990	IGNITION SYSTEM
J65WMLETD 1993	IGNITION SYSTEM - VRO MODELS
J65WMLZ 1989	IGNITION SYSTEM
J65WRLEEO 1999	IGNITION SYSTEM
J65WRLEES 1999	IGNITION SYSTEM
J65WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
J65WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	IGNITION SYSTEM
J65WRYEEO 1999	IGNITION SYSTEM
J65WRYEES 1999	IGNITION SYSTEM
J65WRYSIR commercial, rope start, 22.5 in shaft 2001	IGNITION SYSTEM
J65WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	IGNITION SYSTEM
J65WTLCOE 1985	IGNITION SYSTEM
J65WTLCRS 1984	IGNITION SYSTEM
J6R4SRC	IGNITION
J6R4SRC - FR	12-5_SYSTÈME D'ALLUMAGE
J6R4STS	IGNITION

J6R4STS - FR	12-5_SYSTÈME D'ALLUMAGE
J6RCCS 1988	IGNITION
J6RCDE 1986	MAGNETO
J6RCEC 1989	IGNITION
J6RCOB 1985	MAGNETO
J6RCRM 1984	MAGNETO - 6/8
J6RCUD 1987	IGNITION
J6RECR 1998	IGNITION
J6REDS 1996	IGNITION
J6REEA 1999	IGNITION
J6REIA 1991	IGNITION
J6RENM 1992	IGNITION
J6REOD 1995	IGNITION
J6RERE 1994	IGNITION
J6RESR 1990	IGNITION
J6RETB 1993	IGNITION
J6REUC 1997	IGNITION
J6RL4SRC	IGNITION
J6RL4SRC - FR	12-5_SYSTÈME D'ALLUMAGE
J6RL4STS	IGNITION
J6RL4STS - FR	12-5_SYSTÈME D'ALLUMAGE
J6RLCCS 1988	IGNITION
J6RLCDE 1986	MAGNETO
J6RLCEC 1989	IGNITION
J6RLCOB 1985	MAGNETO
J6RLCRM 1984	MAGNETO - 6/8
J6RLCUD 1987	IGNITION
J6RLECR 1998	IGNITION
J6RLEDS 1996	IGNITION
J6RLEEA 1999	IGNITION
J6RLEIA 1991	IGNITION
J6RLENM 1992	IGNITION
J6RLEOD 1995	IGNITION
J6RLERE 1994	IGNITION
J6RLESR 1990	IGNITION

J6RLETB 1993	IGNITION
J6RLEUC 1997	IGNITION
J6RLSIB rope start, tiller, 20 in shaft 2001	IGNITION
J6RLSOC	IGNITION
J6RLSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J6RLSRS	IGNITION
J6RLSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J6RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J6RLSTD	IGNITION
J6RLSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J6RLVSIB rope start, tiller, 20 in shaft, wht 2001	IGNITION
J6RSIB rope start, tiller, 15 in shaft 2001	IGNITION
J6RSOC	IGNITION
J6RSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J6RSRS	IGNITION
J6RSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J6RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J6RSTD	IGNITION
J6RSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J6RVSIB rope start, tiller, 15 in shaft, wht 2001	IGNITION
J6SLCCS 1988	IGNITION
J6SLCDE 1986	MAGNETO
J6SLCEC 1989	IGNITION
J6SLCOB 1985	MAGNETO
J6SLCRM 1984	MAGNETO - 6/8
J6SLCUD 1987	IGNITION
J6SLEDS 1996	IGNITION
J6SLEIA 1991	IGNITION
J6SLENM 1992	IGNITION
J6SLEOD 1995	IGNITION
J6SLERE 1994	IGNITION
J6SLESR 1990	IGNITION
J6SLETB 1993	IGNITION
J70ELCCA 1988	IGNITION SYSTEM
J70ELCDC 1986	IGNITION SYSTEM

J70ELCEM 1989	IGNITION SYSTEM
J70ELCIH 1981	IGNITION SYSTEM
J70ELCIM 1981	IGNITION SYSTEM
J70ELCNB 1982	IGNITION SYSTEM
J70ELCOS 1985	IGNITION SYSTEM
J70ELCRD 1984	IGNITION SYSTEM
J70ELCSA 1980	IGNITION SYSTEM
J70ELCTE 1983	IGNITION SYSTEM
J70ELCUR 1987	IGNITION SYSTEM
J70ELEIE 1991	IGNITION SYSTEM
J70ELEND 1992	IGNITION SYSTEM
J70ELEOR 1995	IGNITION SYSTEM
J70ELERC 1994	IGNITION SYSTEM
J70ELERV 1994	IGNITION SYSTEM
J70ELESB 1990	IGNITION SYSTEM
J70ELETs 1993	IGNITION SYSTEM
J70JLEOS 1995	IGNITION SYSTEM
J70PLEEE 1999	IGNITION SYSTEM
J70PLSIS elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM
J70PLSSD Elec Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM
J70TLCCA 1988	IGNITION SYSTEM
J70TLCDC 1986	IGNITION SYSTEM
J70TLCEM 1989	IGNITION SYSTEM
J70TLCIM 1981	IGNITION SYSTEM
J70TLCNB 1982	IGNITION SYSTEM
J70TLCOS 1985	IGNITION SYSTEM
J70TLCRD 1984	IGNITION SYSTEM
J70TLCTE 1983	IGNITION SYSTEM
J70TLCUR 1987	IGNITION SYSTEM
J70TLECB 1998	IGNITION SYSTEM
J70TLEDA 1996	IGNITION SYSTEM
J70TLEDA 1996	IGNITION SYSTEM - E70RNLIB ONLY
J70TLEIE 1991	IGNITION SYSTEM
J70TLEND 1992	IGNITION SYSTEM
J70TLEOR 1995	IGNITION SYSTEM

J70TLERC 1994	IGNITION SYSTEM
J70TLERV 1994	IGNITION SYSTEM
J70TLESB 1990	IGNITION SYSTEM
J70TLETS 1993	IGNITION SYSTEM
J70TLEUM 1997	IGNITION SYSTEM
J70TTLEIE 1991	IGNITION SYSTEM
J70TTLEND 1992	IGNITION SYSTEM
J70TTLEOR 1995	IGNITION SYSTEM
J70TTLERC 1994	IGNITION SYSTEM
J70TTLERV 1994	IGNITION SYSTEM
J70TTLETS 1993	IGNITION SYSTEM
J70VLSIS elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM
J75ECCA 1988	IGNITION SYSTEM
J75ECDC 1986	IGNITION SYSTEM
J75ECNB 1982	IGNITION SYSTEM
J75ECOS 1985	IGNITION SYSTEM
J75ECD 1984	IGNITION SYSTEM
J75ECTE 1983	IGNITION SYSTEM
J75ECUR 1987	IGNITION SYSTEM
J75ELCNB 1982	IGNITION SYSTEM
J75ELCRD 1984	IGNITION SYSTEM
J75ELCTE 1983	IGNITION SYSTEM
J75ERCIH 1981	IGNITION SYSTEM
J75ERCIM 1981	IGNITION SYSTEM
J75ERCSA 1980	IGNITION SYSTEM
J75ERLCIH 1981	IGNITION SYSTEM
J75ERLCIM 1981	IGNITION SYSTEM
J75ERLCSA 1980	IGNITION SYSTEM
J75TELCIM 1981	IGNITION SYSTEM
J75TLCNB 1982	IGNITION SYSTEM
J75TLCRD 1984	IGNITION SYSTEM
J75TLCTE 1983	IGNITION SYSTEM
J75TRLCIH 1981	IGNITION SYSTEM
J75TRLCSA 1980	IGNITION SYSTEM
J85MLCSA 1980	IGNITION SYSTEM

J85TLCSA 1980	IGNITION SYSTEM
J85TTLEIE 1991	IGNITION SYSTEM
J85TTLEND 1992	IGNITION SYSTEM
J85TTLEOR 1995	IGNITION SYSTEM
J85TTLERC 1994	IGNITION SYSTEM
J85TTLETS 1993	IGNITION SYSTEM
J85TXCSA 1980	IGNITION SYSTEM
J88MSLCCC 1988	IGNITION SYSTEM
J88MSLCER 1989	IGNITION SYSTEM
J88MSLCUS 1987	IGNITION SYSTEM
J88MSLEDC 1996	IGNITION SYSTEM
J88MSLEIM 1991	IGNITION SYSTEM
J88MSLENB 1992	IGNITION SYSTEM
J88MSLEOS 1995	IGNITION SYSTEM
J88MSLERD 1994	IGNITION SYSTEM
J88MSLESA 1990	IGNITION SYSTEM
J88MSLETE 1993	IGNITION SYSTEM
J88TSLEDR 1996	IGNITION SYSTEM
J88TSLEOC 1995	IGNITION SYSTEM
J88TSLERS 1994	IGNITION SYSTEM
J8DREEA 1999	IGNITION
J8FRECA 1998	IGNITION -- ELECTRIC
J8FRECA 1998	IGNITION -- ROPE
J8FREDC 1996	IGNITION - ELECTRIC
J8FREDC 1996	IGNITION - ROPE
J8FREUR 1997	IGNITION - ELECTRIC
J8FREUR 1997	IGNITION - ROPE
J8FRLECA 1998	IGNITION -- ELECTRIC
J8FRLECA 1998	IGNITION -- ROPE
J8FRXECA 1998	IGNITION -- ELECTRIC
J8FRXECA 1998	IGNITION -- ROPE
J8FRXEDC 1996	IGNITION - ELECTRIC
J8FRXEDC 1996	IGNITION - ROPE
J8FRXEUR 1997	IGNITION - ELECTRIC
J8FRXEUR 1997	IGNITION - ROPE

J8R4SRC	IGNITION
J8R4SRC - FR	12-5_SYSTÈME D'ALLUMAGE
J8R4STS	IGNITION
J8R4STS - FR	12-5_SYSTÈME D'ALLUMAGE
J8RCCS 1988	IGNITION
J8RCDE 1986	MAGNETO
J8RCEC 1989	IGNITION
J8RCIC 1981	MAGNETO - 7.5
J8RCIC 1981	MAGNETO-4.5
J8RCNR 1982	MAGNETO - 4.5
J8RCNR 1982	MAGNETO - 7.5
J8RCOB 1985	MAGNETO
J8RCRM 1984	MAGNETO - 6/8
J8RCSS 1980	MAGNETO - 7.5
J8RCSS 1980	MAGNETO-4.5
J8RCTA 1983	MAGNETO-4.5
J8RCTA 1983	MAGNETO-7.5
J8RCUD 1987	IGNITION
J8RECR 1998	IGNITION
J8REDS 1996	IGNITION
J8REEM 1999	IGNITION
J8REIA 1991	IGNITION
J8RENM 1992	IGNITION
J8REOD 1995	IGNITION
J8RERE 1994	IGNITION
J8RESR 1990	IGNITION
J8RETB 1993	IGNITION
J8REUC 1997	IGNITION
J8RL4SRC	IGNITION
J8RL4SRC - FR	12-5_SYSTÈME D'ALLUMAGE
J8RL4STS	IGNITION
J8RL4STS - FR	12-5_SYSTÈME D'ALLUMAGE
J8RLCCS 1988	IGNITION
J8RLCDE 1986	MAGNETO
J8RLCEC 1989	IGNITION

J8RLCIC 1981	MAGNETO - 7.5
J8RLCIC 1981	MAGNETO-4.5
J8RLCNR 1982	MAGNETO - 4.5
J8RLCNR 1982	MAGNETO - 7.5
J8RLCOB 1985	MAGNETO
J8RLCRM 1984	MAGNETO - 6/8
J8RLCSS 1980	MAGNETO - 7.5
J8RLCSS 1980	MAGNETO-4.5
J8RLCTA 1983	MAGNETO-4.5
J8RLCTA 1983	MAGNETO-7.5
J8RLCUD 1987	IGNITION
J8RLECR 1998	IGNITION
J8RLEDS 1996	IGNITION
J8RLEEM 1999	IGNITION
J8RLEIA 1991	IGNITION
J8RLENM 1992	IGNITION
J8RLEOD 1995	IGNITION
J8RLERE 1994	IGNITION
J8RLESR 1990	IGNITION
J8RLETB 1993	IGNITION
J8RLEUC 1997	IGNITION
J8RLSIE rope start, tiller, 20 in shaft 2001	IGNITION
J8RLSOR	IGNITION
J8RLSOR - FR	22-5_SYSTÈME D'ALLUMAGE
J8RLSRC	IGNITION
J8RLSRC - FR	22-5_SYSTÈME D'ALLUMAGE
J8RLSSB Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J8RLSTS	IGNITION
J8RLSTS - FR	22-5_SYSTÈME D'ALLUMAGE
J8RLVSIE rope start, tiller, 20 in shaft, wht 2001	IGNITION
J8RLXSIE rope start, tiller, 25 in shaft, wht 2001	IGNITION
J8RSIE rope start, tiller, 15 in shaft 2001	IGNITION
J8RSOR	IGNITION
J8RSOR - FR	22-5_SYSTÈME D'ALLUMAGE
J8RSRC	IGNITION

J8RSRC - FR	22-5_SYSTÈME D'ALLUMAGE
J8RSSB Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J8RSTD	IGNITION
J8RSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J8RVSIE rope start, tiller, 15 in shaft, wht 2001	IGNITION
J8RXEEM 1999	IGNITION
J8RXSIE rope start, tiller, 25 in shaft 2001	IGNITION
J8RXSSB Rope Start, Tiller, 25 IN. shaft 2000	IGNITION
J8SRLCCS 1988	IGNITION
J8SRLCDE 1986	MAGNETO
J8SRLCEC 1989	IGNITION
J8SRLCNR 1982	MAGNETO - 4.5
J8SRLCNR 1982	MAGNETO - 7.5
J8SRLCOB 1985	MAGNETO
J8SRLCRM 1984	MAGNETO - 6/8
J8SRLCTA 1983	MAGNETO-4.5
J8SRLCTA 1983	MAGNETO-7.5
J8SRLCUD 1987	IGNITION
J8SRLECA 1998	IGNITION
J8SRLEDS 1996	IGNITION
J8SRLEIA 1991	IGNITION
J8SRLENM 1992	IGNITION
J8SRLEOD 1995	IGNITION
J8SRLERE 1994	IGNITION
J8SRLESR 1990	IGNITION
J8SRLETB 1993	IGNITION
J8SRLEUC 1997	IGNITION
J8WREES 1999	IGNITION
J8WRLEES 1999	IGNITION
J8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	IGNITION
J8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	IGNITION
J8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J90JLEIE 1991	IGNITION SYSTEM
J90JLEND 1992	IGNITION SYSTEM

J90JLEOR 1995	IGNITION SYSTEM
J90JLERC 1994	IGNITION SYSTEM
J90JLETS 1993	IGNITION SYSTEM
J90MLCDC 1986	IGNITION SYSTEM
J90MLCIH 1981	IGNITION SYSTEM
J90MLCIM 1981	IGNITION SYSTEM
J90MLCNB 1982	IGNITION SYSTEM
J90MLCOS 1985	IGNITION SYSTEM
J90MLCRD 1984	IGNITION SYSTEM
J90MLCTE 1983	IGNITION SYSTEM
J90MLCUR 1987	IGNITION SYSTEM
J90MLEOR 1995	IGNITION SYSTEM
J90MLERC 1994	IGNITION SYSTEM
J90TLAEM 1989	IGNITION SYSTEM
J90TLAIE 1991	IGNITION SYSTEM
J90TLAND 1992	IGNITION SYSTEM
J90TLARC 1994	IGNITION SYSTEM
J90TLASB 1990	IGNITION SYSTEM
J90TLATS 1993	IGNITION SYSTEM
J90TLCCA 1988	IGNITION SYSTEM
J90TLCDC 1986	IGNITION SYSTEM
J90TLCEM 1989	IGNITION SYSTEM
J90TLCIH 1981	IGNITION SYSTEM
J90TLCIM 1981	IGNITION SYSTEM
J90TLCNB 1982	IGNITION SYSTEM
J90TLCOS 1985	IGNITION SYSTEM
J90TLCRD 1984	IGNITION SYSTEM
J90TLCTE 1983	IGNITION SYSTEM
J90TLCUR 1987	IGNITION SYSTEM
J90TLEDA 1996	IGNITION SYSTEM
J90TLEIE 1991	IGNITION SYSTEM
J90TLEND 1992	IGNITION SYSTEM
J90TLEOR 1995	IGNITION SYSTEM
J90TLERC 1994	IGNITION SYSTEM
J90TLESB 1990	IGNITION SYSTEM

J90TLETS 1993	IGNITION SYSTEM
J90TSLECM 1998	IGNITION SYSTEM
J90TSLEUA 1997	IGNITION SYSTEM
J90TXARC 1994	IGNITION SYSTEM
J90TXATS 1993	IGNITION SYSTEM
J90TXCDC 1986	IGNITION SYSTEM
J90TXCIH 1981	IGNITION SYSTEM
J90TXCIM 1981	IGNITION SYSTEM
J90TXCNB 1982	IGNITION SYSTEM
J90TXCOS 1985	IGNITION SYSTEM
J90TXCRD 1984	IGNITION SYSTEM
J90TXCTE 1983	IGNITION SYSTEM
JCO-CCM 1988	MAGNETO
JCO-CDR 1986	MAGNETO
JCO-CEB 1989	MAGNETO
JCO-CUA 1987	MAGNETO
JCO-ESE 1990	MAGNETO
L150GLEDC 1996	IGNITION SYSTEM
L150GLEUC 1997	IGNITION SYSTEM
L150GLEUR 1997	IGNITION SYSTEM
LE200SLEDR 1996	IGNITION SYSTEM
LE200SLEOC 1995	IGNITION SYSTEM & STARTER MOTOR
LJ200SLEDR 1996	IGNITION SYSTEM
LJ200SLEOC 1995	IGNITION SYSTEM & STARTER MOTOR
M55RWLR 1988	IGNITION SYSTEM
N65WMLM 1988	IGNITION SYSTEM
R45RCLR 1988	IGNITION SYSTEM
R45RCR 1988	IGNITION SYSTEM
R55RWLR 1988	IGNITION SYSTEM
RJ130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM
RJ130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	IGNITION SYSTEM
RJ130VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	IGNITION SYSTEM
RJ135PLSIF elec start, TNT, 20 in shaft 2001	IGNITION
RJ135VXSIF elec start, TNT, 20 in shaft, wht 2001	IGNITION
RJ200PLSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM

RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM
RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	IGNITION SYSTEM
RJ200VXSIF elec start, TNT, 25 in shaft, wht 2001	IGNITION SYSTEM
RJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	IGNITION SYSTEM
RJ225CXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	IGNITION SYSTEM
RJ225CXSSS Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	IGNITION SYSTEM
RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	IGNITION SYSTEM
RJ225HLSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM
RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	IGNITION SYSTEM
RJ225PLSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM
RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM
RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	IGNITION SYSTEM
RJ225VXSIF elec start, TNT, 25 in shaft, wht 2001	IGNITION SYSTEM
RJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	IGNITION SYSTEM
RJ250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	IGNITION SYSTEM
RJ250VXSIF elec start, TNT, 25 in shaft, wht 2001	IGNITION SYSTEM
RJ250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	IGNITION SYSTEM
RJ250VZSSIF elec start, TNT, 30 in shaft, wht 2001	IGNITION SYSTEM
RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	IGNITION SYSTEM
RJ50ELSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - ELECTRIC START
RJ50ELSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
RJ70PLSIS elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM
RJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM
S45RCLR 1988	IGNITION SYSTEM
S45RCR 1988	IGNITION SYSTEM
SE100WMPLM 1996	IGNITION SYSTEM
SE100WMPLZ 1997	IGNITION SYSTEM
SE100WTPLM 1996	IGNITION SYSTEM
SE100WTPLZ 1997	IGNITION SYSTEM
SE10RPB 1996	IGNITION
SE10RPLB 1996	IGNITION
SE10RPLT 1997	IGNITION
SE10RPLY 1998	IGNITION
SE10RPT 1997	IGNITION

SE10RPY 1998	IGNITION
SE125RWYJ 1997	IGNITION SYSTEM
SE125RWYN 1998	IGNITION SYSTEM
SE125RWYV 1996	IGNITION SYSTEM
SE125WTPLJ 1997	IGNITION SYSTEM
SE125WTPLN 1998	IGNITION SYSTEM
SE125WTPLV 1996	IGNITION SYSTEM
SE125WTPXJ 1997	IGNITION SYSTEM
SE125WTPXN 1998	IGNITION SYSTEM
SE125WTPXV 1996	IGNITION SYSTEM
SE150WTPLB 1996	IGNITION SYSTEM
SE150WTPLT 1997	IGNITION SYSTEM
SE150WTPLT4 1997	IGNITION SYSTEM
SE150WTPXB 1996	IGNITION SYSTEM
SE150WTPXT 1997	IGNITION SYSTEM
SE150WTPXT4 1997	IGNITION SYSTEM
SE15BAECA 1998	IGNITION -- ELECTRIC
SE15BAECA 1998	IGNITION -- ROPE
SE15BAEDC 1996	IGNITION - ELECTRIC
SE15BAEDC 1996	IGNITION - ROPE
SE15BAEEM 1999	IGNITION -- ROPE
SE15BAEEM 1999	IGNITION -- ELECTRIC
SE15BAEUR 1997	IGNITION - ELECTRIC
SE15BAEUR 1997	IGNITION - ROPE
SE15BASIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ROPE
SE15BASIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ELECTRIC
SE15BASSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
SE15BASSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC
SE15RPC 1998	IGNITION
SE15RPG 1996	IGNITION
SE15RPLC 1998	IGNITION
SE15RPLG 1996	IGNITION
SE15RPLW 1997	IGNITION
SE15RPW 1997	IGNITION
SE200WTPLA 1996	IGNITION SYSTEM

SE200WTPLG 1998	IGNITION SYSTEM
SE200WTPLS 1997	IGNITION SYSTEM
SE200WTPXA 1996	IGNITION SYSTEM
SE200WTPXG 1998	IGNITION SYSTEM
SE200WTPXS 1997	IGNITION SYSTEM
SE225GLECC 1998	IGNITION SYSTEM
SE225NXECC 1998	IGNITION SYSTEM
SE225NZECC 1998	IGNITION SYSTEM
SE225QXECC 1998	IGNITION SYSTEM
SE225QZECC 1998	IGNITION SYSTEM
SE25RDECA 1998	IGNITION
SE25RDEDC 1996	IGNITION
SE25RDEEM 1999	IGNITION
SE25RDEEN 1999	IGNITION
SE25RDEUR 1997	IGNITION
SE25RDSIE rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION
SE25RDSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
SE25RPLP 1998	IGNITION
SE25RPLV 1997	IGNITION - H25FP
SE25RPLV 1997	IGNITION - 25RS, 25RW, S25RP
SE25RPP 1998	IGNITION
SE25RPV 1997	IGNITION - H25FP
SE25RPV 1997	IGNITION - 25RS, 25RW, S25RP
SE35REDE 1996	IGNITION
SE35RLEDE 1996	IGNITION
SE40RPB 1997	IGNITION SYSTEM
SE40RPH 1996	IGNITION SYSTEM
SE40RPLB 1997	IGNITION SYSTEM
SE40RPLH 1996	IGNITION SYSTEM
SE40RPLT2 1998	IGNITION SYSTEM
SE40RPT2 1998	IGNITION SYSTEM
SE40RPYB 1997	IGNITION SYSTEM
SE40RPYH 1996	IGNITION SYSTEM
SE40RPYT2 1998	IGNITION SYSTEM
SE40RSLD 1997	IGNITION SYSTEM

SE40RSLR 1998	IGNITION SYSTEM
SE40RSLZ 1996	IGNITION SYSTEM
SE45RSLB 1997	IGNITION SYSTEM
SE45RSLH 1996	IGNITION SYSTEM
SE50TLED5 1996	IGNITION SYSTEM - 40 ROPE START
SE50TLED5 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
SE50TLED5 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
SE55RSC 1997	IGNITION SYSTEM
SE55RSLC 1997	IGNITION SYSTEM
SE55RSLM2 1998	IGNITION SYSTEM
SE55RSLW 1996	IGNITION SYSTEM
SE55RSM2 1998	IGNITION SYSTEM
SE55RSW 1996	IGNITION SYSTEM
SE55RSYC 1997	IGNITION SYSTEM
SE55RSYM2 1998	IGNITION SYSTEM
SE55RSYW 1996	IGNITION SYSTEM
SE65RSLD 1998	IGNITION SYSTEM
SE65RSLM 1996	IGNITION SYSTEM
SE65RSLZ2 1997	IGNITION SYSTEM
SE65RSYD 1998	IGNITION SYSTEM
SE65RSYM 1996	IGNITION SYSTEM
SE65RSYZ2 1997	IGNITION SYSTEM
SE65WMLD 1998	IGNITION SYSTEM
SE65WMLM 1996	IGNITION SYSTEM
SE65WMLZ2 1997	IGNITION SYSTEM
SE65WMYD 1998	IGNITION SYSTEM
SE65WMYM 1996	IGNITION SYSTEM
SE65WMYZ2 1997	IGNITION SYSTEM
SJ100WMPLM 1996	IGNITION SYSTEM
SJ100WMPLZ 1997	IGNITION SYSTEM
SJ100WTPLM 1996	IGNITION SYSTEM
SJ100WTPLZ 1997	IGNITION SYSTEM
SJ10REDD 1996	IGNITION - ELECTRIC
SJ10REDD 1996	IGNITION - ROPE

SJ10RLEDD 1996	IGNITION - ELECTRIC
SJ10RLEDD 1996	IGNITION - ROPE
SJ10RPB 1996	IGNITION
SJ10RPLB 1996	IGNITION
SJ10RPLT 1997	IGNITION
SJ10RPLY 1998	IGNITION
SJ10RPT 1997	IGNITION
SJ10RPY 1998	IGNITION
SJ10SELEDD 1996	IGNITION - ELECTRIC
SJ10SELEDD 1996	IGNITION - ROPE
SJ125RWYJ 1997	IGNITION SYSTEM
SJ125RWYN 1998	IGNITION SYSTEM
SJ125RWYV 1996	IGNITION SYSTEM
SJ125WTPLJ 1997	IGNITION SYSTEM
SJ125WTPLN 1998	IGNITION SYSTEM
SJ125WTPLV 1996	IGNITION SYSTEM
SJ125WTPXJ 1997	IGNITION SYSTEM
SJ125WTPXN 1998	IGNITION SYSTEM
SJ125WTPXV 1996	IGNITION SYSTEM
SJ130CXADA 1996	IGNITION SYSTEM
SJ130TLEDM 1996	IGNITION SYSTEM
SJ130TXADA 1996	IGNITION SYSTEM
SJ150ELEDDB 1996	IGNITION SYSTEM
SJ150WTPLB 1996	IGNITION SYSTEM
SJ150WTPLT 1997	IGNITION SYSTEM
SJ150WTPLT4 1997	IGNITION SYSTEM
SJ150WTPXB 1996	IGNITION SYSTEM
SJ150WTPXT 1997	IGNITION SYSTEM
SJ150WTPXT4 1997	IGNITION SYSTEM
SJ15BAECA 1998	IGNITION -- ELECTRIC
SJ15BAECA 1998	IGNITION -- ROPE
SJ15BAEDC 1996	IGNITION - ELECTRIC
SJ15BAEDC 1996	IGNITION - ROPE
SJ15BAEEM 1999	IGNITION -- ROPE
SJ15BAEEM 1999	IGNITION -- ELECTRIC

SJ15BAEUR 1997	IGNITION - ELECTRIC
SJ15BAEUR 1997	IGNITION - ROPE
SJ15REDS 1996	IGNITION - ELECTRIC
SJ15REDS 1996	IGNITION - ROPE
SJ15RLEDS 1996	IGNITION - ELECTRIC
SJ15RLEDS 1996	IGNITION - ROPE
SJ15RPC 1998	IGNITION
SJ15RPG 1996	IGNITION
SJ15RPLC 1998	IGNITION
SJ15RPLG 1996	IGNITION
SJ15RPLW 1997	IGNITION
SJ15RPW 1997	IGNITION
SJ15RTEEM 1999	IGNITION -- ROPE
SJ15RTEEM 1999	IGNITION -- ELECTRIC
SJ15RTSIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ROPE
SJ15RTSIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ELECTRIC
SJ15RTSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
SJ15RTSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC
SJ200CXECM 1998	IGNITION SYSTEM
SJ200CXEUA 1997	IGNITION SYSTEM
SJ200SLECE 1998	IGNITION SYSTEM
SJ200SLEDM 1996	IGNITION SYSTEM
SJ200SLEUB 1997	IGNITION SYSTEM
SJ200TXECM 1998	IGNITION SYSTEM
SJ200TXEUA 1997	IGNITION SYSTEM
SJ200WTPLA 1996	IGNITION SYSTEM
SJ200WTPLG 1998	IGNITION SYSTEM
SJ200WTPLS 1997	IGNITION SYSTEM
SJ200WTPXA 1996	IGNITION SYSTEM
SJ200WTPXG 1998	IGNITION SYSTEM
SJ200WTPXS 1997	IGNITION SYSTEM
SJ225CXECS 1998	IGNITION SYSTEM
SJ225CXEDE 1996	IGNITION SYSTEM
SJ225CXEUD 1997	IGNITION SYSTEM
SJ225GLECC 1998	IGNITION SYSTEM

SJ225NxECC 1998	IGNITION SYSTEM
SJ225NZECC 1998	IGNITION SYSTEM
SJ225PXED 1996	IGNITION SYSTEM
SJ225QxECC 1998	IGNITION SYSTEM
SJ225QZECC 1998	IGNITION SYSTEM
SJ225SLECS 1998	IGNITION SYSTEM
SJ225SLEDE 1996	IGNITION SYSTEM
SJ225SLEUD 1997	IGNITION SYSTEM
SJ225TXECS 1998	IGNITION SYSTEM
SJ225TXED 1996	IGNITION SYSTEM
SJ225TXEUD 1997	IGNITION SYSTEM
SJ25RDECA 1998	IGNITION
SJ25RDEDC 1996	IGNITION
SJ25RDEEM 1999	IGNITION
SJ25RDEEMN 1999	IGNITION
SJ25RDEUR 1997	IGNITION
SJ25REDA 1996	IGNITION
SJ25RLEDA 1996	IGNITION
SJ25RPLP 1998	IGNITION
SJ25RPLV 1997	IGNITION - H25FP
SJ25RPLV 1997	IGNITION - 25RS, 25RW, S25RP
SJ25RPP 1998	IGNITION
SJ25RPV 1997	IGNITION - H25FP
SJ25RPV 1997	IGNITION - 25RS, 25RW, S25RP
SJ25RTEEM 1999	IGNITION
SJ25RTSIE rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION
SJ25RTSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
SJ25TEEDA 1996	IGNITION
SJ25TEEUM 1997	IGNITION
SJ30EEDE 1996	IGNITION
SJ30REDE 1996	IGNITION
SJ30RLEDE 1996	IGNITION
SJ30TEEUD 1997	IGNITION
SJ35REDE 1996	IGNITION
SJ35RLEDE 1996	IGNITION

SJ3REDS 1996	IGNITION
SJ40EEDS 1996	IGNITION SYSTEM - 40 ROPE START
SJ40EEDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
SJ40EEDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
SJ40REDS 1996	IGNITION SYSTEM - 40 ROPE START
SJ40REDS 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
SJ40REDS 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
SJ40RLEDs 1996	IGNITION SYSTEM - 40 ROPE START
SJ40RLEDs 1996	IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS
SJ40RLEDs 1996	IGNITION SYSTEM - ELECTRIC START 40TE MODELS
SJ40RPB 1997	IGNITION SYSTEM
SJ40RPH 1996	IGNITION SYSTEM
SJ40RPLB 1997	IGNITION SYSTEM
SJ40RPLH 1996	IGNITION SYSTEM
SJ40RPLT2 1998	IGNITION SYSTEM
SJ40RPT2 1998	IGNITION SYSTEM
SJ40RPYB 1997	IGNITION SYSTEM
SJ40RPYH 1996	IGNITION SYSTEM
SJ40RPYT2 1998	IGNITION SYSTEM
SJ40RSLD 1997	IGNITION SYSTEM
SJ40RSLR 1998	IGNITION SYSTEM
SJ40RSLZ 1996	IGNITION SYSTEM
SJ45RSLB 1997	IGNITION SYSTEM
SJ45RSLH 1996	IGNITION SYSTEM
SJ4REDS 1996	IGNITION
SJ4RLEDs 1996	IGNITION
SJ55RSC 1997	IGNITION SYSTEM
SJ55RSLC 1997	IGNITION SYSTEM
SJ55RSLM2 1998	IGNITION SYSTEM
SJ55RSLW 1996	IGNITION SYSTEM
SJ55RSM2 1998	IGNITION SYSTEM
SJ55RSW 1996	IGNITION SYSTEM
SJ55RSYC 1997	IGNITION SYSTEM
SJ55RSYM2 1998	IGNITION SYSTEM

SJ55RSYW 1996	IGNITION SYSTEM
SJ60TLEDR 1996	IGNITION SYSTEM
SJ60TLEDR 1996	IGNITION SYSTEM - E70RNLIB ONLY
SJ65RSLD 1998	IGNITION SYSTEM
SJ65RSLM 1996	IGNITION SYSTEM
SJ65RSLZ2 1997	IGNITION SYSTEM
SJ65RSYD 1998	IGNITION SYSTEM
SJ65RSYM 1996	IGNITION SYSTEM
SJ65RSYZ2 1997	IGNITION SYSTEM
SJ65WMLD 1998	IGNITION SYSTEM
SJ65WMLM 1996	IGNITION SYSTEM
SJ65WMLZ2 1997	IGNITION SYSTEM
SJ65WMYD 1998	IGNITION SYSTEM
SJ65WMYM 1996	IGNITION SYSTEM
SJ65WMYZ2 1997	IGNITION SYSTEM
SJ6REDS 1996	IGNITION
SJ6RLEDS 1996	IGNITION
SJ70TLEDA 1996	IGNITION SYSTEM
SJ70TLEDA 1996	IGNITION SYSTEM - E70RNLIB ONLY
SJ8REDS 1996	IGNITION
SJ8RLEDS 1996	IGNITION
T65WMLM 1988	IGNITION SYSTEM
TE10ELCES 1989	IGNITION
TE10ELESC 1990	IGNITION
TE10RELEIR 1991	IGNITION
TE10RELENA 1992	IGNITION
TE10RELESC 1990	IGNITION
TE10RELETM 1993	IGNITION - ELECTRIC
TE10RELETM 1993	IGNITION - ROPE
TE10RLCES 1989	IGNITION
TE10RLESC 1990	IGNITION
TE110TLCEM 1989	IGNITION SYSTEM
TE110TLESF 1989	IGNITION SYSTEM
TE110TXCEM 1989	IGNITION SYSTEM
TE115TLEIE 1991	IGNITION SYSTEM

TE115TLEND 1992	IGNITION SYSTEM
TE115TLESB 1990	IGNITION SYSTEM
TE115TLETS 1993	IGNITION SYSTEM
TE120TXCEM 1989	IGNITION SYSTEM & STARTER MOTOR
TE150GLEIS 1991	IGNITION SYSTEM
TE150GLENC 1992	IGNITION SYSTEM
TE150SLCEM 1989	IGNITION SYSTEM
TE150SLEIE 1991	IGNITION SYSTEM
TE150SLESB 1990	IGNITION SYSTEM
TE150TXCEM 1989	IGNITION SYSTEM - 150 MODELS
TE150TXCEM 1989	IGNITION SYSTEM - 175 MODELS
TE15RLCEC 1989	IGNITION
TE200TXCEA 1989	IGNITION SYSTEM & STARTER MOTOR
TE20CRCEM 1989	IGNITION
TE20CREND 1992	IGNITION
TE20CRESB 1990	IGNITION
TE20CRETS 1993	IGNITION
TE20CRLCEM 1989	IGNITION
TE20CRLEIE 1991	IGNITION
TE20CRLEND 1992	IGNITION
TE20CRLESB 1990	IGNITION
TE20CRLESF 1989	IGNITION
TE20CRLETS 1993	IGNITION
TE25ELCEB 1989	IGNITION
TE25ELEID 1991	IGNITION
TE25ELENS 1992	IGNITION
TE25ELESE 1990	IGNITION
TE25ELESF 1989	IGNITION
TE25ELETC 1993	IGNITION
TE30ELCED 1989	IGNITION
TE30ELESF 1989	IGNITION
TE30ELESS 1990	IGNITION
TE40ELCEC 1989	IGNITION SYSTEM - ROPE START
TE40ELCEC 1989	IGNITION SYSTEM - ELECTRIC START
TE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS

TE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE40ELEIA 1991	IGNITION SYSTEM - ROPE START
TE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
TE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
TE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TE40ELENJ 1992	IGNITION SYSTEM - ROPE START
TE40ELENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
TE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
TE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
TE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TE40ELENM 1992	IGNITION SYSTEM - ROPE START
TE40ELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
TE40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE40ELESR 1990	IGNITION SYSTEM - ROPE START
TE40ELETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
TE40ELETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
TE40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
TE40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
TE40TELESF 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE40TELESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE40TELESF 1990	IGNITION SYSTEM - ROPE START
TE40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE40TELESR 1990	IGNITION SYSTEM - ROPE START
TE48ESLETE 1993	IGNITION SYSTEM
TE50TLCEC 1989	IGNITION SYSTEM - ROPE START
TE50TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
TE50TLESF 1989	IGNITION SYSTEM - ROPE START
TE50TLESF 1989	IGNITION SYSTEM - ELECTRIC START

TE50TLESF 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE50TLESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE50TLESF 1990	IGNITION SYSTEM - ROPE START
TE50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE50TLESR 1990	IGNITION SYSTEM - ROPE START
TE60TLCEA 1989	IGNITION SYSTEM 60EL - 60TL
TE60TLCEA 1989	IGNITION SYSTEM 60TTL
TE60TLEIB 1991	IGNITION SYSTEM
TE60TLENE 1992	IGNITION SYSTEM
TE60TLESF 1989	IGNITION SYSTEM 60EL - 60TL
TE60TLESF 1989	IGNITION SYSTEM 60TTL
TE60TLESF 1990	IGNITION SYSTEM 60EL - 60TL
TE60TLESF 1990	IGNITION SYSTEM 60TTL
TE60TLESM 1990	IGNITION SYSTEM 60EL - 60TL
TE60TLESM 1990	IGNITION SYSTEM 60TTL
TE60TLETD 1993	IGNITION SYSTEM
TE70TLCEM 1989	IGNITION SYSTEM
TE70TLESB 1990	IGNITION SYSTEM
TE70TLESF 1989	IGNITION SYSTEM
TE70TLESF 1990	IGNITION SYSTEM
TE8RCEC 1989	IGNITION
TE8RLCEC 1989	IGNITION
TE8RLESCF 1990	IGNITION
TE90TLCEM 1989	IGNITION SYSTEM
TE90TLEIE 1991	IGNITION SYSTEM
TE90TLEND 1992	IGNITION SYSTEM
TE90TLESB 1990	IGNITION SYSTEM
TE90TLESF 1989	IGNITION SYSTEM
TE90TLESF 1990	IGNITION SYSTEM
TE90TLETS 1993	IGNITION SYSTEM
TJ10ELCES 1989	IGNITION
TJ10ELESC 1990	IGNITION
TJ10RELEIR 1991	IGNITION
TJ10RELENA 1992	IGNITION

TJ10RELESC 1990	IGNITION
TJ10RELETM 1993	IGNITION - ELECTRIC
TJ10RELETM 1993	IGNITION - ROPE
TJ10RLCES 1989	IGNITION
TJ10RLESC 1990	IGNITION
TJ110TLCEM 1989	IGNITION SYSTEM
TJ110TXCEM 1989	IGNITION SYSTEM
TJ115TLEIE 1991	IGNITION SYSTEM
TJ115TLEND 1992	IGNITION SYSTEM
TJ115TLESB 1990	IGNITION SYSTEM
TJ115TLETS 1993	IGNITION SYSTEM
TJ120TXCEM 1989	IGNITION SYSTEM & STARTER MOTOR
TJ150GLEIS 1991	IGNITION SYSTEM
TJ150GLENC 1992	IGNITION SYSTEM
TJ150SLCEM 1989	IGNITION SYSTEM
TJ150SLEIE 1991	IGNITION SYSTEM
TJ150SLESB 1990	IGNITION SYSTEM
TJ150TXCEM 1989	IGNITION SYSTEM - 150 MODELS
TJ150TXCEM 1989	IGNITION SYSTEM - 175 MODELS
TJ15RLCEC 1989	IGNITION
TJ200TXCEA 1989	IGNITION SYSTEM & STARTER MOTOR
TJ20CRCEM 1989	IGNITION
TJ20CREND 1992	IGNITION
TJ20CRESB 1990	IGNITION
TJ20CRETS 1993	IGNITION
TJ20CRLCEM 1989	IGNITION
TJ20CRLEIE 1991	IGNITION
TJ20CRLEND 1992	IGNITION
TJ20CRLESB 1990	IGNITION
TJ20CRLESF 1989	IGNITION
TJ20CRLETS 1993	IGNITION
TJ25ELCEB 1989	IGNITION
TJ25ELEID 1991	IGNITION
TJ25ELENS 1992	IGNITION
TJ25ELESE 1990	IGNITION

TJ25ELESF 1989	IGNITION
TJ25ELETB 1993	IGNITION
TJ30ELCED 1989	IGNITION
TJ30ELESF 1989	IGNITION
TJ30ELESS 1990	IGNITION
TJ40ELCEC 1989	IGNITION SYSTEM - ROPE START
TJ40ELCEC 1989	IGNITION SYSTEM - ELECTRIC START
TJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40ELEIA 1991	IGNITION SYSTEM - ROPE START
TJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
TJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
TJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TJ40ELENJ 1992	IGNITION SYSTEM - ROPE START
TJ40ELENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
TJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
TJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
TJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TJ40ELENM 1992	IGNITION SYSTEM - ROPE START
TJ40ELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
TJ40ELESF 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ40ELESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40ELESF 1990	IGNITION SYSTEM - ROPE START
TJ40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40ELESR 1990	IGNITION SYSTEM - ROPE START
TJ40ELETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
TJ40ELETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
TJ40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
TJ40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

TJ40TELESF 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ40TELESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40TELESF 1990	IGNITION SYSTEM - ROPE START
TJ40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40TELESR 1990	IGNITION SYSTEM - ROPE START
TJ48ESLETE 1993	IGNITION SYSTEM
TJ50TLCEC 1989	IGNITION SYSTEM - ROPE START
TJ50TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
TJ50TLESF 1989	IGNITION SYSTEM - ROPE START
TJ50TLESF 1989	IGNITION SYSTEM - ELECTRIC START
TJ50TLESF 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ50TLESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ50TLESF 1990	IGNITION SYSTEM - ROPE START
TJ50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ50TLESR 1990	IGNITION SYSTEM - ROPE START
TJ60TLCEA 1989	IGNITION SYSTEM 60EL - 60TL
TJ60TLCEA 1989	IGNITION SYSTEM 60TTL
TJ60TLEIB 1991	IGNITION SYSTEM
TJ60TLENE 1992	IGNITION SYSTEM
TJ60TLESF 1989	IGNITION SYSTEM 60EL - 60TL
TJ60TLESF 1989	IGNITION SYSTEM 60TTL
TJ60TLESF 1990	IGNITION SYSTEM 60EL - 60TL
TJ60TLESF 1990	IGNITION SYSTEM 60TTL
TJ60TLESM 1990	IGNITION SYSTEM 60EL - 60TL
TJ60TLESM 1990	IGNITION SYSTEM 60TTL
TJ60TLETD 1993	IGNITION SYSTEM
TJ70TLCEM 1989	IGNITION SYSTEM
TJ70TLESB 1990	IGNITION SYSTEM
TJ70TLESF 1989	IGNITION SYSTEM
TJ70TLESF 1990	IGNITION SYSTEM
TJ8RCEC 1989	IGNITION
TJ8RLCEC 1989	IGNITION
TJ90TLCEM 1989	IGNITION SYSTEM

TJ90TLEIE 1991	IGNITION SYSTEM
TJ90TLEND 1992	IGNITION SYSTEM
TJ90TLESB 1990	IGNITION SYSTEM
TJ90TLETS 1993	IGNITION SYSTEM
U25RWA 1988	MAGNETO
U25RWLA 1988	MAGNETO
V115SHLETS 1993	IGNITION SYSTEM
V115SLEIE 1991	IGNITION SYSTEM
V115SLEND 1992	IGNITION SYSTEM
V115SLETS 1993	IGNITION SYSTEM
V90SLEIE 1991	IGNITION SYSTEM
V90SLEND 1992	IGNITION SYSTEM
V90SLETE 1993	IGNITION SYSTEM
VE100SLEIE 1991	IGNITION SYSTEM
VE100SLEND 1992	IGNITION SYSTEM
VE100SLESB 1990	IGNITION SYSTEM
VE100SLETS 1993	IGNITION SYSTEM
VE115TLEIE 1991	IGNITION SYSTEM
VE115TLESB 1990	IGNITION SYSTEM
VE115TLETS 1993	IGNITION SYSTEM
VE115TXEIE 1991	IGNITION SYSTEM
VE115TXESB 1990	IGNITION SYSTEM
VE120TLEIE 1991	IGNITION SYSTEM & STARTER MOTOR
VE120TLEND 1992	IGNITION SYSTEM & STARTER MOTOR
VE120TLESB 1990	IGNITION SYSTEM & STARTER MOTOR
VE120TLETF 1993	IGNITION SYSTEM & STARTER MOTOR
VE120TLETS 1993	IGNITION SYSTEM & STARTER MOTOR
VE120TXEIE 1991	IGNITION SYSTEM & STARTER MOTOR
VE120TXEND 1992	IGNITION SYSTEM & STARTER MOTOR
VE120TXESB 1990	IGNITION SYSTEM & STARTER MOTOR
VE120TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
VE120TXETS 1993	IGNITION SYSTEM & STARTER MOTOR
VE140TLEID 1991	IGNITION SYSTEM & STARTER MOTOR
VE140TLENS 1992	IGNITION SYSTEM & STARTER MOTOR
VE140TLESE 1990	IGNITION SYSTEM & STARTER MOTOR

VE140TLETC 1993	IGNITION SYSTEM & STARTER MOTOR
VE140TLETF 1993	IGNITION SYSTEM & STARTER MOTOR
VE140TXEID 1991	IGNITION SYSTEM & STARTER MOTOR
VE140TXENS 1992	IGNITION SYSTEM & STARTER MOTOR
VE140TXESE 1990	IGNITION SYSTEM & STARTER MOTOR
VE140TXETC 1993	IGNITION SYSTEM & STARTER MOTOR
VE140TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
VE14RCCS 1988	MAGNETO
VE14RCEC 1989	IGNITION
VE150ELEIS 1991	IGNITION SYSTEM
VE150ELENC 1992	IGNITION SYSTEM
VE150EXEIS 1991	IGNITION SYSTEM
VE150EXENC 1992	IGNITION SYSTEM
VE150GLEIS 1991	IGNITION SYSTEM
VE150SLEIE 1991	IGNITION SYSTEM
VE150SLESB 1990	IGNITION SYSTEM
VE150TLEIE 1991	IGNITION SYSTEM - 150 MODELS
VE150TLEIE 1991	IGNITION SYSTEM - 175 MODELS
VE150TLESB 1990	IGNITION SYSTEM - 150 MODELS
VE150TLESB 1990	IGNITION SYSTEM - 175 MODELS
VE150TXEIE 1991	IGNITION SYSTEM - 150 MODELS
VE150TXEIE 1991	IGNITION SYSTEM - 175 MODELS
VE150TXESB 1990	IGNITION SYSTEM - 150 MODELS
VE150TXESB 1990	IGNITION SYSTEM - 175 MODELS
VE175EXEIS 1991	IGNITION SYSTEM
VE175EXENC 1992	IGNITION SYSTEM
VE175GLEIS 1991	IGNITION SYSTEM
VE175GLENC 1992	IGNITION SYSTEM
VE175SLEID 1991	IGNITION SYSTEM - 150 MODELS
VE175SLEID 1991	IGNITION SYSTEM - 175 MODELS
VE175SLESE 1990	IGNITION SYSTEM - 150 MODELS
VE175SLESE 1990	IGNITION SYSTEM - 175 MODELS
VE175TXEID 1991	IGNITION SYSTEM - 150 MODELS
VE175TXEID 1991	IGNITION SYSTEM - 175 MODELS
VE175TXESE 1990	IGNITION SYSTEM - 150 MODELS

VE175TXESE 1990	IGNITION SYSTEM - 175 MODELS
VE200SLEID 1991	IGNITION SYSTEM & STARTER MOTOR
VE200SLENS 1992	IGNITION SYSTEM & STARTER MOTOR
VE200SLESE 1990	IGNITION SYSTEM & STARTER MOTOR
VE200SLETC 1993	IGNITION SYSTEM & STARTER MOTOR
VE200SLETF 1993	IGNITION SYSTEM & STARTER MOTOR
VE200TXEIB 1991	IGNITION SYSTEM & STARTER MOTOR
VE200TXENE 1992	IGNITION SYSTEM & STARTER MOTOR
VE200TXESM 1990	IGNITION SYSTEM & STARTER MOTOR
VE200TXETD 1993	IGNITION SYSTEM & STARTER MOTOR
VE200TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
VE200TZETD 1993	IGNITION SYSTEM & STARTER MOTOR
VE200TZETF 1993	IGNITION SYSTEM & STARTER MOTOR
VE225PLEIC 1991	IGNITION SYSTEM & STARTER MOTOR
VE225PLENR 1992	IGNITION SYSTEM & STARTER MOTOR
VE225PLESS 1990	IGNITION SYSTEM & STARTER MOTOR
VE225PLETA 1993	IGNITION SYSTEM & STARTER MOTOR
VE225PLETF 1993	IGNITION SYSTEM & STARTER MOTOR
VE225PXEIC 1991	IGNITION SYSTEM & STARTER MOTOR
VE225PXENR 1992	IGNITION SYSTEM & STARTER MOTOR
VE225PXESS 1990	IGNITION SYSTEM & STARTER MOTOR
VE225PXETA 1993	IGNITION SYSTEM & STARTER MOTOR
VE225PXETF 1993	IGNITION SYSTEM & STARTER MOTOR
VE225PZETA 1993	IGNITION SYSTEM & STARTER MOTOR
VE225PZETF 1993	IGNITION SYSTEM & STARTER MOTOR
VE225STLETF 1993	IGNITION SYSTEM & STARTER MOTOR
VE225TLEIC 1991	IGNITION SYSTEM & STARTER MOTOR
VE225TLENR 1992	IGNITION SYSTEM & STARTER MOTOR
VE225TLESS 1990	IGNITION SYSTEM & STARTER MOTOR
VE225TLETA 1993	IGNITION SYSTEM & STARTER MOTOR
VE225TLETF 1993	IGNITION SYSTEM & STARTER MOTOR
VE225TXEIC 1991	IGNITION SYSTEM & STARTER MOTOR
VE225TXENR 1992	IGNITION SYSTEM & STARTER MOTOR
VE225TXESS 1990	IGNITION SYSTEM & STARTER MOTOR
VE225TXETA 1993	IGNITION SYSTEM & STARTER MOTOR

VE225TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
VE225TZETA 1993	IGNITION SYSTEM & STARTER MOTOR
VE225TZETF 1993	IGNITION SYSTEM & STARTER MOTOR
VE25ELEID 1991	IGNITION
VE25ELENS 1992	IGNITION
VE25ELESE 1990	IGNITION
VE25ELETG 1993	IGNITION
VE25REIE 1991	IGNITION
VE25RESB 1990	IGNITION
VE28ESLCCR 1988	IGNITION
VE28ESLCEA 1989	IGNITION
VE28ESLESM 1990	IGNITION
VE30EEIC 1991	IGNITION
VE30EENR 1992	IGNITION
VE30EESS 1990	IGNITION
VE30EETA 1993	IGNITION
VE30ELEIC 1991	IGNITION
VE30ELENR 1992	IGNITION
VE30ELESS 1990	IGNITION
VE30ELETA 1993	IGNITION
VE40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40EEIA 1991	IGNITION SYSTEM - ROPE START
VE40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VE40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40EENJ 1992	IGNITION SYSTEM - ROPE START
VE40EENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VE40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VE40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)

VE40EENM 1992	IGNITION SYSTEM - ROPE START
VE40EENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VE40EESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40EESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40EESR 1990	IGNITION SYSTEM - ROPE START
VE40EETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VE40EETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VE40EETB 1993	IGNITION SYSTEM - 40 ROPE START
VE40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40ELEIA 1991	IGNITION SYSTEM - ROPE START
VE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40ELENJ 1992	IGNITION SYSTEM - ROPE START
VE40ELENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40ELENM 1992	IGNITION SYSTEM - ROPE START
VE40ELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VE40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40ELESR 1990	IGNITION SYSTEM - ROPE START
VE40ELETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VE40ELETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VE40ELETB 1993	IGNITION SYSTEM - 40 ROPE START

VE40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40TELEIA 1991	IGNITION SYSTEM - ROPE START
VE40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VE40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TELENJ 1992	IGNITION SYSTEM - ROPE START
VE40TELENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VE40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VE40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TELENM 1992	IGNITION SYSTEM - ROPE START
VE40TELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VE40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40TELESR 1990	IGNITION SYSTEM - ROPE START
VE40ELETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VE40ELETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VE40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
VE40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40TLEIA 1991	IGNITION SYSTEM - ROPE START
VE40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VE40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)

VE40TLENJ 1992	IGNITION SYSTEM - ROPE START
VE40TLENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VE40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VE40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TLENM 1992	IGNITION SYSTEM - ROPE START
VE40TLENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VE40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40TLESR 1990	IGNITION SYSTEM - ROPE START
VE40TLETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VE40TLETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VE40TLETB 1993	IGNITION SYSTEM - 40 ROPE START
VE40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40TLETF 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VE40TLETF 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VE40TLETF 1993	IGNITION SYSTEM - 40 ROPE START
VE40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE48ESLCCC 1988	IGNITION SYSTEM
VE48ESLCER 1989	IGNITION SYSTEM
VE48ESLENB 1992	IGNITION SYSTEM
VE48ESLESA 1990	IGNITION SYSTEM
VE48ESLETE 1993	IGNITION SYSTEM
VE50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50BEEIA 1991	IGNITION SYSTEM - ROPE START
VE50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)

VE50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BEENJ 1992	IGNITION SYSTEM - ROPE START
VE50BEENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VE50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VE50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BEENM 1992	IGNITION SYSTEM - ROPE START
VE50BEENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VE50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50BEESR 1990	IGNITION SYSTEM - ROPE START
VE50BEETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VE50BEETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VE50BEETB 1993	IGNITION SYSTEM - 40 ROPE START
VE50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50BELEIA 1991	IGNITION SYSTEM - ROPE START
VE50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VE50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BELENJ 1992	IGNITION SYSTEM - ROPE START
VE50BELENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VE50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VE50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BELENM 1992	IGNITION SYSTEM - ROPE START

VE50BELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VE50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50BELESR 1990	IGNITION SYSTEM - ROPE START
VE50BELETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VE50BELETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VE50BELETB 1993	IGNITION SYSTEM - 40 ROPE START
VE50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VE50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50TELENM 1992	IGNITION SYSTEM - ROPE START
VE50TELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VE50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50TLEIA 1991	IGNITION SYSTEM - ROPE START
VE50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VE50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50TLENJ 1992	IGNITION SYSTEM - ROPE START
VE50TLENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VE50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VE50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50TLENM 1992	IGNITION SYSTEM - ROPE START
VE50TLENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VE50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS

VE50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50TLESR 1990	IGNITION SYSTEM - ROPE START
VE50TLETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VE50TLETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VE50TLETB 1993	IGNITION SYSTEM - 40 ROPE START
VE50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE50TLETF 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VE50TLETF 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VE50TLETF 1993	IGNITION SYSTEM - 40 ROPE START
VE50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE60ELEIB 1991	IGNITION SYSTEM
VE60ELENE 1992	IGNITION SYSTEM
VE60ELESMB 1990	IGNITION SYSTEM 60EL - 60TL
VE60ELESMB 1990	IGNITION SYSTEM 60TTL
VE60ELETD 1993	IGNITION SYSTEM
VE60TLEIB 1991	IGNITION SYSTEM
VE60TLENE 1992	IGNITION SYSTEM
VE60TLESMB 1990	IGNITION SYSTEM 60EL - 60TL
VE60TLESMB 1990	IGNITION SYSTEM 60TTL
VE70ELEIE 1991	IGNITION SYSTEM
VE70ELEND 1992	IGNITION SYSTEM
VE70ELESB 1990	IGNITION SYSTEM
VE70ELETB 1993	IGNITION SYSTEM
VE70TLEIE 1991	IGNITION SYSTEM
VE70TLEND 1992	IGNITION SYSTEM
VE70TLESB 1990	IGNITION SYSTEM
VE70TLETB 1993	IGNITION SYSTEM
VE88MSLCCC 1988	IGNITION SYSTEM
VE88MSLCER 1989	IGNITION SYSTEM
VE88MSLESA 1990	IGNITION SYSTEM
VE90MLEIE 1991	IGNITION SYSTEM
VE90MLEND 1992	IGNITION SYSTEM

VE90MLESB 1990	IGNITION SYSTEM
VE90MLETS 1993	IGNITION SYSTEM
VE90TLEIE 1991	IGNITION SYSTEM
VE90TLEND 1992	IGNITION SYSTEM
VE90TLESB 1990	IGNITION SYSTEM
VE90TLETS 1993	IGNITION SYSTEM
VJ100SLEIE 1991	IGNITION SYSTEM
VJ100SLEND 1992	IGNITION SYSTEM
VJ100SLESB 1990	IGNITION SYSTEM
VJ100SLETS 1993	IGNITION SYSTEM
VJ115TLAIE 1991	IGNITION SYSTEM
VJ115TLAND 1992	IGNITION SYSTEM
VJ115TLASB 1990	IGNITION SYSTEM
VJ115TLATS 1993	IGNITION SYSTEM
VJ115TLEIE 1991	IGNITION SYSTEM
VJ115TLESB 1990	IGNITION SYSTEM
VJ115TLETS 1993	IGNITION SYSTEM
VJ115TXEIE 1991	IGNITION SYSTEM
VJ115TXESB 1990	IGNITION SYSTEM
VJ120TLAIE 1991	IGNITION SYSTEM & STARTER MOTOR
VJ120TLAND 1992	IGNITION SYSTEM & STARTER MOTOR
VJ120TLASB 1990	IGNITION SYSTEM & STARTER MOTOR
VJ120TLATF 1993	IGNITION SYSTEM & STARTER MOTOR
VJ120TLATS 1993	IGNITION SYSTEM & STARTER MOTOR
VJ120TLEIE 1991	IGNITION SYSTEM & STARTER MOTOR
VJ120TLEND 1992	IGNITION SYSTEM & STARTER MOTOR
VJ120TLESB 1990	IGNITION SYSTEM & STARTER MOTOR
VJ120TLETF 1993	IGNITION SYSTEM & STARTER MOTOR
VJ120TLETS 1993	IGNITION SYSTEM & STARTER MOTOR
VJ120TXEIE 1991	IGNITION SYSTEM & STARTER MOTOR
VJ120TXEND 1992	IGNITION SYSTEM & STARTER MOTOR
VJ120TXESB 1990	IGNITION SYSTEM & STARTER MOTOR
VJ120TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
VJ120TXETS 1993	IGNITION SYSTEM & STARTER MOTOR
VJ140TLAID 1991	IGNITION SYSTEM & STARTER MOTOR

VJ140TLANS 1992	IGNITION SYSTEM & STARTER MOTOR
VJ140TLASE 1990	IGNITION SYSTEM & STARTER MOTOR
VJ140TLEID 1991	IGNITION SYSTEM & STARTER MOTOR
VJ140TLENS 1992	IGNITION SYSTEM & STARTER MOTOR
VJ140TLESE 1990	IGNITION SYSTEM & STARTER MOTOR
VJ140TLETC 1993	IGNITION SYSTEM & STARTER MOTOR
VJ140TLETF 1993	IGNITION SYSTEM & STARTER MOTOR
VJ140TXEID 1991	IGNITION SYSTEM & STARTER MOTOR
VJ140TXENS 1992	IGNITION SYSTEM & STARTER MOTOR
VJ140TXESE 1990	IGNITION SYSTEM & STARTER MOTOR
VJ140TXETC 1993	IGNITION SYSTEM & STARTER MOTOR
VJ140TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
VJ14RCCS 1988	MAGNETO
VJ14RCEC 1989	IGNITION
VJ150ELANC 1992	IGNITION SYSTEM
VJ150ELEIS 1991	IGNITION SYSTEM
VJ150ELENC 1992	IGNITION SYSTEM
VJ150EXEIS 1991	IGNITION SYSTEM
VJ150EXENC 1992	IGNITION SYSTEM
VJ150GLEIS 1991	IGNITION SYSTEM
VJ150SLEIE 1991	IGNITION SYSTEM
VJ150SLESB 1990	IGNITION SYSTEM
VJ150TLEIE 1991	IGNITION SYSTEM - 150 MODELS
VJ150TLEIE 1991	IGNITION SYSTEM - 175 MODELS
VJ150TLESB 1990	IGNITION SYSTEM - 150 MODELS
VJ150TLESB 1990	IGNITION SYSTEM - 175 MODELS
VJ150TXEIE 1991	IGNITION SYSTEM - 150 MODELS
VJ150TXEIE 1991	IGNITION SYSTEM - 175 MODELS
VJ150TXESB 1990	IGNITION SYSTEM - 150 MODELS
VJ150TXESB 1990	IGNITION SYSTEM - 175 MODELS
VJ175EXEIS 1991	IGNITION SYSTEM
VJ175EXENC 1992	IGNITION SYSTEM
VJ175GLEIS 1991	IGNITION SYSTEM
VJ175GLENC 1992	IGNITION SYSTEM
VJ175SLEID 1991	IGNITION SYSTEM - 150 MODELS

VJ175SLEID 1991	IGNITION SYSTEM - 175 MODELS
VJ175SLESE 1990	IGNITION SYSTEM - 150 MODELS
VJ175SLESE 1990	IGNITION SYSTEM - 175 MODELS
VJ175TXEID 1991	IGNITION SYSTEM - 150 MODELS
VJ175TXEID 1991	IGNITION SYSTEM - 175 MODELS
VJ175TXESE 1990	IGNITION SYSTEM - 150 MODELS
VJ175TXESE 1990	IGNITION SYSTEM - 175 MODELS
VJ200SLEID 1991	IGNITION SYSTEM & STARTER MOTOR
VJ200SLENS 1992	IGNITION SYSTEM & STARTER MOTOR
VJ200SLESE 1990	IGNITION SYSTEM & STARTER MOTOR
VJ200SLETC 1993	IGNITION SYSTEM & STARTER MOTOR
VJ200SLETF 1993	IGNITION SYSTEM & STARTER MOTOR
VJ200TXEIB 1991	IGNITION SYSTEM & STARTER MOTOR
VJ200TXENE 1992	IGNITION SYSTEM & STARTER MOTOR
VJ200TXESM 1990	IGNITION SYSTEM & STARTER MOTOR
VJ200TXETD 1993	IGNITION SYSTEM & STARTER MOTOR
VJ200TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
VJ200TZETD 1993	IGNITION SYSTEM & STARTER MOTOR
VJ200TZETF 1993	IGNITION SYSTEM & STARTER MOTOR
VJ225PLEIC 1991	IGNITION SYSTEM & STARTER MOTOR
VJ225PLENR 1992	IGNITION SYSTEM & STARTER MOTOR
VJ225PLESS 1990	IGNITION SYSTEM & STARTER MOTOR
VJ225PLETA 1993	IGNITION SYSTEM & STARTER MOTOR
VJ225PLETF 1993	IGNITION SYSTEM & STARTER MOTOR
VJ225PXEIC 1991	IGNITION SYSTEM & STARTER MOTOR
VJ225PXENR 1992	IGNITION SYSTEM & STARTER MOTOR
VJ225PXESS 1990	IGNITION SYSTEM & STARTER MOTOR
VJ225PXETA 1993	IGNITION SYSTEM & STARTER MOTOR
VJ225PXETF 1993	IGNITION SYSTEM & STARTER MOTOR
VJ225PZETA 1993	IGNITION SYSTEM & STARTER MOTOR
VJ225PZETF 1993	IGNITION SYSTEM & STARTER MOTOR
VJ225STLETF 1993	IGNITION SYSTEM & STARTER MOTOR
VJ225TLASS 1990	IGNITION SYSTEM & STARTER MOTOR
VJ225TLEIC 1991	IGNITION SYSTEM & STARTER MOTOR
VJ225TLENR 1992	IGNITION SYSTEM & STARTER MOTOR

VJ225TLESS 1990	IGNITION SYSTEM & STARTER MOTOR
VJ225TLETA 1993	IGNITION SYSTEM & STARTER MOTOR
VJ225TLETF 1993	IGNITION SYSTEM & STARTER MOTOR
VJ225TXEIC 1991	IGNITION SYSTEM & STARTER MOTOR
VJ225TXENR 1992	IGNITION SYSTEM & STARTER MOTOR
VJ225TXESS 1990	IGNITION SYSTEM & STARTER MOTOR
VJ225TXETA 1993	IGNITION SYSTEM & STARTER MOTOR
VJ225TXETF 1993	IGNITION SYSTEM & STARTER MOTOR
VJ225TZETA 1993	IGNITION SYSTEM & STARTER MOTOR
VJ225TZETF 1993	IGNITION SYSTEM & STARTER MOTOR
VJ25ELEID 1991	IGNITION
VJ25ELENS 1992	IGNITION
VJ25ELESE 1990	IGNITION
VJ25ELETC 1993	IGNITION
VJ25REIE 1991	IGNITION
VJ25RESB 1990	IGNITION
VJ28ESLCCR 1988	IGNITION
VJ28ESLCEA 1989	IGNITION
VJ28ESLESM 1990	IGNITION
VJ30EEIC 1991	IGNITION
VJ30EENR 1992	IGNITION
VJ30EESS 1990	IGNITION
VJ30EETA 1993	IGNITION
VJ30ELEIC 1991	IGNITION
VJ30ELENR 1992	IGNITION
VJ30ELESS 1990	IGNITION
VJ30ELETA 1993	IGNITION
VJ40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40EEIA 1991	IGNITION SYSTEM - ROPE START
VJ40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VJ40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)

VJ40EENJ 1992	IGNITION SYSTEM - ROPE START
VJ40EENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VJ40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VJ40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40EENM 1992	IGNITION SYSTEM - ROPE START
VJ40EENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VJ40EESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40EESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40EESR 1990	IGNITION SYSTEM - ROPE START
VJ40EETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VJ40EETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VJ40EETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40ELEIA 1991	IGNITION SYSTEM - ROPE START
VJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40ELENJ 1992	IGNITION SYSTEM - ROPE START
VJ40ELENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40ELENM 1992	IGNITION SYSTEM - ROPE START
VJ40ELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)

VJ40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40ELESR 1990	IGNITION SYSTEM - ROPE START
VJ40ELETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VJ40ELETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VJ40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40TELEIA 1991	IGNITION SYSTEM - ROPE START
VJ40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VJ40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TELENJ 1992	IGNITION SYSTEM - ROPE START
VJ40TELENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VJ40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VJ40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TELENM 1992	IGNITION SYSTEM - ROPE START
VJ40TELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VJ40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40TELESR 1990	IGNITION SYSTEM - ROPE START
VJ40ELETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VJ40ELETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VJ40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS

VJ40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40TLEIA 1991	IGNITION SYSTEM - ROPE START
VJ40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VJ40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TLENJ 1992	IGNITION SYSTEM - ROPE START
VJ40TLENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VJ40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VJ40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TLENM 1992	IGNITION SYSTEM - ROPE START
VJ40TLENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VJ40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40TLESR 1990	IGNITION SYSTEM - ROPE START
VJ40TLETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VJ40TLETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VJ40TLETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40TLETF 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VJ40TLETF 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VJ40TLETF 1993	IGNITION SYSTEM - 40 ROPE START
VJ40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ48ESLCCC 1988	IGNITION SYSTEM
VJ48ESLCER 1989	IGNITION SYSTEM
VJ48ESLENB 1992	IGNITION SYSTEM
VJ48ESLESA 1990	IGNITION SYSTEM
VJ48ESLETE 1993	IGNITION SYSTEM

VJ50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BEEIA 1991	IGNITION SYSTEM - ROPE START
VJ50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VJ50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BEENJ 1992	IGNITION SYSTEM - ROPE START
VJ50BEENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VJ50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VJ50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BEENM 1992	IGNITION SYSTEM - ROPE START
VJ50BEENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VJ50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BEESR 1990	IGNITION SYSTEM - ROPE START
VJ50BEETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VJ50BEETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VJ50BEETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BELEIA 1991	IGNITION SYSTEM - ROPE START
VJ50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VJ50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BELENJ 1992	IGNITION SYSTEM - ROPE START
VJ50BELENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)

VJ50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VJ50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BELENM 1992	IGNITION SYSTEM - ROPE START
VJ50BELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VJ50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BELESR 1990	IGNITION SYSTEM - ROPE START
VJ50BELETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VJ50BELETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VJ50BELETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VJ50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50TELENM 1992	IGNITION SYSTEM - ROPE START
VJ50TELENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VJ50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50TLEIA 1991	IGNITION SYSTEM - ROPE START
VJ50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)
VJ50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50TLENJ 1992	IGNITION SYSTEM - ROPE START
VJ50TLENJ 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VJ50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)

VJ50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50TLENM 1992	IGNITION SYSTEM - ROPE START
VJ50TLENM 1992	IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)
VJ50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50TLESR 1990	IGNITION SYSTEM - ROPE START
VJ50TLETB 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VJ50TLETB 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VJ50TLETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ50TLETF 1993	IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS
VJ50TLETF 1993	IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS
VJ50TLETF 1993	IGNITION SYSTEM - 40 ROPE START
VJ50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ60ELEIB 1991	IGNITION SYSTEM
VJ60ELENE 1992	IGNITION SYSTEM
VJ60ELES M 1990	IGNITION SYSTEM 60EL - 60TL
VJ60ELES M 1990	IGNITION SYSTEM 60TTL
VJ60ELET D 1993	IGNITION SYSTEM
VJ60TLEIB 1991	IGNITION SYSTEM
VJ60TLENE 1992	IGNITION SYSTEM
VJ60TLES M 1990	IGNITION SYSTEM 60EL - 60TL
VJ60TLES M 1990	IGNITION SYSTEM 60TTL
VJ70ELEIE 1991	IGNITION SYSTEM
VJ70ELEND 1992	IGNITION SYSTEM
VJ70ELESB 1990	IGNITION SYSTEM
VJ70ELET S 1993	IGNITION SYSTEM
VJ70TLEIE 1991	IGNITION SYSTEM
VJ70TLEND 1992	IGNITION SYSTEM
VJ70TLESB 1990	IGNITION SYSTEM
VJ70TLET S 1993	IGNITION SYSTEM

VJ88MSLCCC 1988	IGNITION SYSTEM
VJ88MSLCER 1989	IGNITION SYSTEM
VJ88MSLESA 1990	IGNITION SYSTEM
VJ90MLEIE 1991	IGNITION SYSTEM
VJ90MLEND 1992	IGNITION SYSTEM
VJ90MLESB 1990	IGNITION SYSTEM
VJ90MLETS 1993	IGNITION SYSTEM
VJ90TLAIE 1991	IGNITION SYSTEM
VJ90TLAND 1992	IGNITION SYSTEM
VJ90TLASB 1990	IGNITION SYSTEM
VJ90TLATS 1993	IGNITION SYSTEM
VJ90TLEIE 1991	IGNITION SYSTEM
VJ90TLEND 1992	IGNITION SYSTEM
VJ90TLESB 1990	IGNITION SYSTEM
VJ90TLETS 1993	IGNITION SYSTEM
W100WTLM 1988	IGNITION SYSTEM
W100WTXM 1988	IGNITION SYSTEM
X155WTLM 1988	IGNITION SYSTEM - 35 AMP
X155WTXM 1988	IGNITION SYSTEM - 35 AMP
X50ESLECC 1998	IGNITION SYSTEM -- 40-50 ELECTRIC START
X50ESLECC 1998	IGNITION SYSTEM -- ROPE START
XE112TSLEDR 1996	IGNITION SYSTEM
XE112TSLEOC 1995	IGNITION SYSTEM
XE112TSLERS 1994	IGNITION SYSTEM
XE112TSXEDR 1996	IGNITION SYSTEM
XE112TSXEOC 1995	IGNITION SYSTEM
XE112TSXERS 1994	IGNITION SYSTEM
XE115HLECM 1998	IGNITION SYSTEM
XE115HLEUA 1997	IGNITION SYSTEM
XE115HXECM 1998	IGNITION SYSTEM
XE115HXEUA 1997	IGNITION SYSTEM
XE88TSLEDR 1996	IGNITION SYSTEM
XE88TSLEOC 1995	IGNITION SYSTEM
XE88TSLERS 1994	IGNITION SYSTEM
XE90TSLECM 1998	IGNITION SYSTEM

XE90TSLEUA 1997	IGNITION SYSTEM
XJ112TSLEDR 1996	IGNITION SYSTEM
XJ112TSLEOC 1995	IGNITION SYSTEM
XJ112TSLERS 1994	IGNITION SYSTEM
XJ112TSXEDR 1996	IGNITION SYSTEM
XJ112TSXEOC 1995	IGNITION SYSTEM
XJ112TSXERS 1994	IGNITION SYSTEM
XJ115HLECM 1998	IGNITION SYSTEM
XJ115HLEUA 1997	IGNITION SYSTEM
XJ115HXECM 1998	IGNITION SYSTEM
XJ115HXEUA 1997	IGNITION SYSTEM
XJ88TSLEDR 1996	IGNITION SYSTEM
XJ88TSLEOC 1995	IGNITION SYSTEM
XJ88TSLERS 1994	IGNITION SYSTEM
XJ90TSLECM 1998	IGNITION SYSTEM
XJ90TSLEUA 1997	IGNITION SYSTEM