

Where Used: Part Number 0581778

Model Name	Diagram
10724A 1977	CYLINDER & CRANKCASE
10725A 1977	CYLINDER & CRANKCASE
10754A 1977	CYLINDER & CRANKCASE
10755A 1977	CYLINDER & CRANKCASE
10824M 1978	CYLINDER & CRANKCASE
10825M 1978	CYLINDER & CRANKCASE
10835M 1978	CYLINDER & CRANKCASE
10854M 1978	CYLINDER & CRANKCASE
10855M 1978	CYLINDER & CRANKCASE
10924B 1979	CYLINDER AND CRANKCASE
10925B 1979	CYLINDER AND CRANKCASE
10935B 1979	CYLINDER AND CRANKCASE
10955B 1979	CYLINDER AND CRANKCASE
10E77A 1977	CYLINDER & CRANKCASE
10E78M 1978	CYLINDER AND CRANKCASE
10EL77A 1977	CYLINDER & CRANKCASE
10EL78M 1978	CYLINDER AND CRANKCASE
10EL79B 1979	CYLINDER AND CRANKCASE
10R77A 1977	CYLINDER & CRANKCASE
10R78M 1978	CYLINDER AND CRANKCASE
10R79B 1979	CYLINDER AND CRANKCASE
10RL77A 1977	CYLINDER & CRANKCASE
10RL78M 1978	CYLINDER AND CRANKCASE
10RL79B 1979	CYLINDER AND CRANKCASE
10SEL78M 1978	CYLINDER AND CRANKCASE
10SEL79B 1979	CYLINDER AND CRANKCASE
15704M 1977	CYLINDER & CRANKCASE
15705M 1977	CYLINDER & CRANKCASE
15754M 1977	CYLINDER & CRANKCASE
15804B 1978	CYLINDER & CRANKCASE
15805B 1978	CYLINDER & CRANKCASE
15854B 1978	CYLINDER & CRANKCASE
15855B 1978	CYLINDER & CRANKCASE

15904E 1979	CYLINDER AND CRANKCASE
15905E 1979	CYLINDER AND CRANKCASE
15954E 1979	CYLINDER AND CRANKCASE
15955E 1979	CYLINDER AND CRANKCASE
15E77M 1977	CYLINDER & CRANKCASE
15E78B 1978	CYLINDER AND CRANKCASE
15E79E 1979	CYLINDER AND CRANKCASE
15EL77M 1977	CYLINDER & CRANKCASE
15EL78B 1978	CYLINDER AND CRANKCASE
15EL79E 1979	CYLINDER AND CRANKCASE
15R77M 1977	CYLINDER & CRANKCASE
15R78B 1978	CYLINDER AND CRANKCASE
15R79E 1979	CYLINDER AND CRANKCASE
15RL77M 1977	CYLINDER & CRANKCASE
15RL78B 1978	CYLINDER AND CRANKCASE
15RL79E 1979	CYLINDER AND CRANKCASE
20/35HP	BATTERY CHARGING KIT
25702H 1977	MAGNETO
25702S 1977	MAGNETO
25703H 1977	MAGNETO
25703S 1977	MAGNETO
25752H 1977	MAGNETO
25752S 1977	MAGNETO
25753H 1977	MAGNETO
25753S 1977	MAGNETO
25802C 1978	MAGNETO
25803C 1978	MAGNETO
25852C 1978	MAGNETO
25853C 1978	MAGNETO
25904R 1979	MAGNETO
25905R 1979	MAGNETO
25952R 1979	MAGNETO
25953R 1979	MAGNETO
25E77S 1977	MAGNETO
25E78C 1978	MAGNETO

25E79R 1979	MAGNETO
25EL77H 1977	MAGNETO
25EL77S 1977	MAGNETO
25EL78C 1978	MAGNETO
25EL79R 1979	MAGNETO
25R77H 1977	MAGNETO
25R77S 1977	MAGNETO
25R78C 1978	MAGNETO
25R79R 1979	MAGNETO
25RL77H 1977	MAGNETO
25RL77S 1977	MAGNETO
25RL78C 1978	MAGNETO
25RL79R 1979	MAGNETO
35702C 1977	MAGNETO
35702H 1977	MAGNETO
35703C 1977	MAGNETO
35703H 1977	MAGNETO
35752C 1977	MAGNETO
35752H 1977	MAGNETO
35753C 1977	MAGNETO
35753H 1977	MAGNETO
35802R 1978	MAGNETO
35803R 1978	MAGNETO
35852R 1978	MAGNETO
35853R 1978	MAGNETO
35902A 1979	MAGNETO
35903A 1979	MAGNETO
35952A 1979	MAGNETO
35953A 1979	MAGNETO
35E77C 1977	MAGNETO
35E77H 1977	MAGNETO
35E78R 1978	MAGNETO
35E79A 1979	MAGNETO
35EL77C 1977	MAGNETO
35EL77H 1977	MAGNETO

35EL78R 1978	MAGNETO
35EL79A 1979	MAGNETO
35R77C 1977	MAGNETO
35R77H 1977	MAGNETO
35R78R 1978	MAGNETO
35R79A 1979	MAGNETO
35RL77C 1977	MAGNETO
35RL77H 1977	MAGNETO
35RL78R 1978	MAGNETO
35RL79A 1979	MAGNETO
40/50HP (2 Stroke)	ELECTRIC START KIT (1993-Current models w/CD II Ignition)
40HP Rope 45-55HP Comm (2 Stroke) 1992-2001	TILLER ELECTRIC START KIT - 40, 55
50902C 1979	IGNITION SYSTEM
50903C 1979	IGNITION SYSTEM
50R79C 1979	IGNITION SYSTEM
50RL79C 1979	IGNITION SYSTEM
55874S 1978	IGNITION SYSTEM
55875S 1978	IGNITION SYSTEM
55974C 1979	IGNITION SYSTEM
55975C 1979	IGNITION SYSTEM
55E78S 1978	IGNITION SYSTEM
55E79C 1979	IGNITION SYSTEM
55EL78S 1978	IGNITION SYSTEM
55EL79C 1979	IGNITION SYSTEM
BE20SEECB 1998	IGNITION
BE20SEEDA 1996	IGNITION
BE20SEEUM 1997	IGNITION
BE20SELECB 1998	IGNITION
BE20SELEDA 1996	IGNITION
BE20SELEUM 1997	IGNITION
BE25EECE 1998	IGNITION
BE25EEDM 1996	IGNITION
BE25EEUB 1997	IGNITION
BE25ELECE 1998	IGNITION

BE25ELEDM 1996	IGNITION
BE25ELEUB 1997	IGNITION
BE25EREDC 1996	IGNITION
BE25ERLEDC 1996	IGNITION
BE30EECS 1998	IGNITION
BE30EEDE 1996	IGNITION
BE30EEUD 1997	IGNITION
BE30ELECS 1998	IGNITION
BE30ELEDE 1996	IGNITION
BE30ELEUD 1997	IGNITION
BJ20SEECB 1998	IGNITION
BJ20SEEDA 1996	IGNITION
BJ20SEEUM 1997	IGNITION
BJ20SELECB 1998	IGNITION
BJ20SELEDA 1996	IGNITION
BJ20SELEUM 1997	IGNITION
BJ25EECE 1998	IGNITION
BJ25EEDM 1996	IGNITION
BJ25EEED 1999	IGNITION
BJ25EEEN 1999	IGNITION
BJ25EEUB 1997	IGNITION
BJ25ELECE 1998	IGNITION
BJ25ELEDM 1996	IGNITION
BJ25ELEED 1999	IGNITION
BJ25ELEEN 1999	IGNITION
BJ25ELEUB 1997	IGNITION
BJ25ELSIC elec start, remote, 20 in shaft, n/a usa 2001	IGNITION
BJ25ELSSS Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION
BJ25EREDC 1996	IGNITION
BJ25ERLEDC 1996	IGNITION
BJ25ESIC elec start, remote, 15 in shaft, n/a usa 2001	IGNITION
BJ25ESSS Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION
BJ25EVSIC elec start, remote, 20 in shaft, wht, n/a usa 2001	IGNITION
BJ25EVSIC elec start, remote, 15 in shaft, wht, n/a usa 2001	IGNITION
BJ30EECS 1998	IGNITION

BJ30EEDE 1996	IGNITION
BJ30EEEC 1999	IGNITION
BJ30EEEN 1999	IGNITION
BJ30EEUD 1997	IGNITION
BJ30ELECS 1998	IGNITION
BJ30ELEDE 1996	IGNITION
BJ30ELEEC 1999	IGNITION
BJ30ELEEN 1999	IGNITION
BJ30ELEUD 1997	IGNITION
BJ30ELSIA elec start, remote, 20 in shaft, n/a usa 2001	IGNITION
BJ30ELSSR Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION
BJ30ESIA elec start, remote, 15 in shaft, n/a usa 2001	IGNITION
BJ30ESSR Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION
BJ30EVLZIA elec start, remote, 20 in shaft, wht, n/a usa 2001	IGNITION
BJ30EVSIA elec start, remote, 15 in shaft, wht, n/a usa 2001	IGNITION
E10ECCD 1988	IGNITION
E10ECDB 1986	IGNITION
E10ECES 1989	IGNITION
E10ECOM 1985	IGNITION
E10ECSE 1980	CYLINDER & CRANKCASE
E10ECUE 1987	IGNITION
E10EEIR 1991	IGNITION
E10EENA 1992	IGNITION
E10EESC 1990	IGNITION
E10ELCCD 1988	IGNITION
E10ELCDB 1986	IGNITION
E10ELCES 1989	IGNITION
E10ELCID 1981	CYLINDER & CRANKCASE
E10ELCNS 1982	CYLINDER & CRANKCASE
E10ELCOM 1985	IGNITION
E10ELCRA 1984	CYLINDER & CRANKCASE
E10ELCSE 1980	CYLINDER & CRANKCASE
E10ELCTC 1983	CYLINDER & CRANKCASE
E10ELCUE 1987	IGNITION
E10ELEIR 1991	IGNITION

E10ELENA 1992	IGNITION
E10ELESC 1990	IGNITION
E10RCCD 1988	IGNITION
E10RCDB 1986	IGNITION
E10RCES 1989	IGNITION
E10RCID 1981	CYLINDER & CRANKCASE
E10RCNS 1982	CYLINDER & CRANKCASE
E10RCOM 1985	IGNITION
E10RCRA 1984	CYLINDER & CRANKCASE
E10RCSE 1980	CYLINDER & CRANKCASE
E10RCTC 1983	CYLINDER & CRANKCASE
E10RCTR 1983	CYLINDER & CRANKCASE
E10RCUE 1987	IGNITION
E10REIR 1991	IGNITION
E10RELEIR 1991	IGNITION
E10RELENA 1992	IGNITION
E10RELESC 1990	IGNITION
E10RENA 1992	IGNITION
E10RESC 1990	IGNITION
E10RLCCD 1988	IGNITION
E10RLCDB 1986	IGNITION
E10RLCES 1989	IGNITION
E10RLCID 1981	CYLINDER & CRANKCASE
E10RLCNS 1982	CYLINDER & CRANKCASE
E10RLCOM 1985	IGNITION
E10RLCRA 1984	CYLINDER & CRANKCASE
E10RLCSE 1980	CYLINDER & CRANKCASE
E10RLCTC 1983	CYLINDER & CRANKCASE
E10RLCUE 1987	IGNITION
E10RLEIR 1991	IGNITION
E10RLENA 1992	IGNITION
E10RLESC 1990	IGNITION
E10SELCCD 1988	IGNITION
E10SELCDB 1986	IGNITION
E10SELCES 1989	IGNITION

E10SELCID 1981	CYLINDER & CRANKCASE
E10SELCNS 1982	CYLINDER & CRANKCASE
E10SELCOM 1985	IGNITION
E10SELCRA 1984	CYLINDER & CRANKCASE
E10SELCSE 1980	CYLINDER & CRANKCASE
E10SELCTC 1983	CYLINDER & CRANKCASE
E10SELCUE 1987	IGNITION
E10SELEIR 1991	IGNITION
E10SELENA 1992	IGNITION
E10SELESC 1990	IGNITION
E15ECCS 1988	IGNITION
E15ECDE 1986	IGNITION
E15ECEC 1989	IGNITION
E15ECIS 1981	CYLINDER & CRANKCASE
E15ECNC 1982	CYLINDER & CRANKCASE
E15ECOB 1985	IGNITION
E15ECRM 1984	CYLINDER & CRANKCASE
E15ECSD 1980	CYLINDER & CRANKCASE
E15ECTR 1983	CYLINDER & CRANKCASE
E15ECUD 1987	IGNITION
E15EEIA 1991	IGNITION
E15EENM 1992	IGNITION
E15EESR 1990	IGNITION
E15ELCCS 1988	IGNITION
E15ELCDE 1986	IGNITION
E15ELCEC 1989	IGNITION
E15ELCOB 1985	IGNITION
E15ELCRM 1984	CYLINDER & CRANKCASE
E15ELCSD 1980	CYLINDER & CRANKCASE
E15ELCTR 1983	CYLINDER & CRANKCASE
E15ELCUD 1987	IGNITION
E15ELEIA 1991	IGNITION
E15ELENM 1992	IGNITION
E15ELESR 1990	IGNITION
E15RCCS 1988	IGNITION



E15RCDE 1986	IGNITION
E15RCEC 1989	IGNITION
E15RCIS 1981	CYLINDER & CRANKCASE
E15RCNC 1982	CYLINDER & CRANKCASE
E15RCOB 1985	IGNITION
E15RCRM 1984	CYLINDER & CRANKCASE
E15RCSD 1980	CYLINDER & CRANKCASE
E15RCTA 1983	CYLINDER & CRANKCASE
E15RCTR 1983	CYLINDER & CRANKCASE
E15RCUD 1987	IGNITION
E15REIA 1991	IGNITION
E15RELEIA 1991	IGNITION
E15RELENM 1992	IGNITION
E15RELESR 1990	IGNITION
E15RENM 1992	IGNITION
E15RESR 1990	IGNITION
E15RLCCS 1988	IGNITION
E15RLCDE 1986	IGNITION
E15RLCEC 1989	IGNITION
E15RLCIS 1981	CYLINDER & CRANKCASE
E15RLCNC 1982	CYLINDER & CRANKCASE
E15RLCOB 1985	IGNITION
E15RLCRM 1984	CYLINDER & CRANKCASE
E15RLCSD 1980	CYLINDER & CRANKCASE
E15RLCTA 1983	CYLINDER & CRANKCASE
E15RLCTR 1983	CYLINDER & CRANKCASE
E15RLCUD 1987	IGNITION
E15RLEIA 1991	IGNITION
E15RLENM 1992	IGNITION
E15RLESR 1990	IGNITION
E20CRCCA 1988	IGNITION
E20CRCDC 1986	IGNITION
E20CRCOS 1985	IGNITION
E20CRCUR 1987	IGNITION
E20CRLCCA 1988	IGNITION

E20CRLCDC 1986	IGNITION
E20CRLCOS 1985	IGNITION
E20CRLCUR 1987	IGNITION
E20ECCA 1988	IGNITION
E20ECDC 1986	IGNITION
E20ECEM 1989	IGNITION
E20ECOS 1985	IGNITION
E20ECUR 1987	IGNITION
E20EEIE 1991	IGNITION
E20EEND 1992	IGNITION
E20EEOR 1995	IGNITION
E20EERC 1994	IGNITION
E20EESB 1990	IGNITION
E20EETS 1993	IGNITION
E20ELCCA 1988	IGNITION
E20ELCDC 1986	IGNITION
E20ELCEM 1989	IGNITION
E20ELCOS 1985	IGNITION
E20ELCUR 1987	IGNITION
E20ELEIE 1991	IGNITION
E20ELEND 1992	IGNITION
E20ELEOR 1995	IGNITION
E20ELERC 1994	IGNITION
E20ELESB 1990	IGNITION
E20ELETS 1993	IGNITION
E20TECDC 1986	IGNITION
E25CNE 1982	MAGNETO
E25ECCM 1988	IGNITION
E25ECDR 1986	IGNITION
E25ECEB 1989	IGNITION
E25ECIB 1981	MAGNETO
E25ECIM 1981	MAGNETO
E25ECOC 1985	IGNITION
E25ECRS 1984	IGNITION
E25ECTD 1983	MAGNETO

E25ECUA 1987	IGNITION
E25EECE 1998	IGNITION
E25EEDM 1996	IGNITION
E25EEID 1991	IGNITION
E25EENS 1992	IGNITION
E25EEOA 1995	IGNITION
E25EERR 1994	IGNITION
E25EESE 1990	IGNITION
E25EETC 1993	IGNITION
E25EEUB 1997	IGNITION
E25ELCCM 1988	IGNITION
E25ELCDR 1986	IGNITION
E25ELCEB 1989	IGNITION
E25ELCIB 1981	MAGNETO
E25ELCIM 1981	MAGNETO
E25ELCNE 1982	MAGNETO
E25ELCOC 1985	IGNITION
E25ELCRS 1984	IGNITION
E25ELCTD 1983	MAGNETO
E25ELCUA 1987	IGNITION
E25ELECE 1998	IGNITION
E25ELEDM 1996	IGNITION
E25ELEID 1991	IGNITION
E25ELENS 1992	IGNITION
E25ELEOA 1995	IGNITION
E25ELERR 1994	IGNITION
E25ELESE 1990	IGNITION
E25ELETG 1993	IGNITION
E25ELEUB 1997	IGNITION
E25RCCA 1988	IGNITION
E25RCDC 1986	IGNITION
E25RCIM 1981	MAGNETO
E25RCNB 1982	MAGNETO
E25RCOS 1985	IGNITION
E25RCRD 1984	IGNITION

E25RCSA 1980	MAGNETO
E25RCTE 1983	MAGNETO
E25RCUR 1987	IGNITION
E25RLCCA 1988	IGNITION
E25RLCDC 1986	IGNITION
E25RLCIM 1981	MAGNETO
E25RLCNB 1982	MAGNETO
E25RLCOS 1985	IGNITION
E25RLCRD 1984	IGNITION
E25RLCSA 1980	MAGNETO
E25RLCTE 1983	MAGNETO
E25RLCUR 1987	IGNITION
E25TECCA 1988	IGNITION
E25TECDC 1986	IGNITION
E25TECEM 1989	IGNITION
E25TECIM 1981	MAGNETO
E25TECNB 1982	MAGNETO
E25TECOS 1985	IGNITION
E25TECRD 1984	IGNITION
E25TECSA 1980	MAGNETO
E25TECTE 1983	MAGNETO
E25TECUR 1987	IGNITION
E25TEECB 1998	IGNITION
E25TEEDA 1996	IGNITION
E25TEEIE 1991	IGNITION
E25TEEND 1992	IGNITION
E25TEEOR 1995	IGNITION
E25TEERC 1994	IGNITION
E25TEESB 1990	IGNITION
E25TEETS 1993	IGNITION
E25TEEUM 1997	IGNITION
E25TELCCA 1988	IGNITION
E25TELCDC 1986	IGNITION
E25TELCEM 1989	IGNITION
E25TELCIM 1981	MAGNETO

E25TELCNB 1982	MAGNETO
E25TELCOS 1985	IGNITION
E25TELCRD 1984	IGNITION
E25TELCSA 1980	MAGNETO
E25TELCCTE 1983	MAGNETO
E25TELCUR 1987	IGNITION
E25TELECB 1998	IGNITION
E25TELEDA 1996	IGNITION
E25TELEIE 1991	IGNITION
E25TELEND 1992	IGNITION
E25TELEOR 1995	IGNITION
E25TELESB 1990	IGNITION
E25TELETS 1993	IGNITION
E25TELEUM 1997	IGNITION
E28ELCDS 1986	MAGNETO
E28ESLCCR 1988	IGNITION
E28ESLCEA 1989	IGNITION
E28ESLCUC 1987	MAGNETO
E28ESLEDR 1996	IGNITION
E28ESLEIB 1991	IGNITION
E28ESLENE 1992	IGNITION
E28ESLEOC 1995	IGNITION
E28ESLERS 1994	IGNITION
E28ESLESM 1990	IGNITION
E28ESLETD 1993	IGNITION
E30ECCE 1988	IGNITION
E30ECDM 1986	IGNITION
E30ECED 1989	IGNITION
E30EOA 1985	IGNITION
E30ECRR 1984	IGNITION
E30ECUB 1987	IGNITION
E30EECS 1998	IGNITION
E30EEDE 1996	IGNITION
E30EEIC 1991	IGNITION
E30EENR 1992	IGNITION

E30EEOB 1995	IGNITION
E30EERM 1994	IGNITION
E30EESS 1990	IGNITION
E30EETA 1993	IGNITION
E30EEUD 1997	IGNITION
E30ELCCE 1988	IGNITION
E30ELCDM 1986	IGNITION
E30ELCED 1989	IGNITION
E30ELCOA 1985	IGNITION
E30ELCRR 1984	IGNITION
E30ELCUB 1987	IGNITION
E30ELECS 1998	IGNITION
E30ELEDE 1996	IGNITION
E30ELEIC 1991	IGNITION
E30ELENR 1992	IGNITION
E30ELEOB 1995	IGNITION
E30ELERM 1994	IGNITION
E30ELESS 1990	IGNITION
E30ELETA 1993	IGNITION
E30ELEUD 1997	IGNITION
E30RCCE 1988	IGNITION
E30RCDM 1986	IGNITION
E30RCOA 1985	IGNITION
E30RCUB 1987	IGNITION
E30RLCCE 1988	IGNITION
E30RLCDM 1986	IGNITION
E30RLCOA 1985	IGNITION
E30RLCUB 1987	IGNITION
E30TECCE 1988	IGNITION
E30TECDM 1986	IGNITION
E30TECED 1989	IGNITION
E30TECOA 1985	IGNITION
E30TECUB 1987	IGNITION
E30TEECS 1998	IGNITION
E30TEEDE 1996	IGNITION

E30TEEIC 1991	IGNITION
E30TEENR 1992	IGNITION
E30TEEOB 1995	IGNITION
E30TEERM 1994	IGNITION
E30TEESS 1990	IGNITION
E30TEETA 1993	IGNITION
E30TEEUD 1997	IGNITION
E30TELCCE 1988	IGNITION
E30TELCDM 1986	IGNITION
E30TELCED 1989	IGNITION
E30TELCOA 1985	IGNITION
E30TELCUB 1987	IGNITION
E30TELECB 1998	IGNITION
E30TELEDE 1996	IGNITION
E30TELEIC 1991	IGNITION
E30TELENR 1992	IGNITION
E30TELEOB 1995	IGNITION
E30TELERM 1994	IGNITION
E30TELESS 1990	IGNITION
E30TELETA 1993	IGNITION
E30TELEUD 1997	IGNITION
E35AELCDE 1986	IGNITION SYSTEM
E35AELCUD 1987	IGNITION SYSTEM
E35ARLCDE 1986	IGNITION SYSTEM
E35ARLCUD 1987	IGNITION SYSTEM
E35ECIG 1981	MAGNETO
E35ECND 1982	MAGNETO
E35ECRR 1984	IGNITION
E35ECSM 1980	MAGNETO
E35ECTS 1983	MAGNETO
E35ELCIG 1981	MAGNETO
E35ELCND 1982	MAGNETO
E35ELCRR 1984	IGNITION
E35ELCSM 1980	MAGNETO
E35ELCTS 1983	MAGNETO

E35RCCE 1988	IGNITION
E35RCDM 1986	IGNITION
E35RCIG 1981	MAGNETO
E35RCND 1982	MAGNETO
E35RCRR 1984	IGNITION
E35RCTS 1983	MAGNETO
E35RCUB 1987	IGNITION
E35RLCCE 1988	IGNITION
E35RLCDM 1986	IGNITION
E35RLCIG 1981	MAGNETO
E35RLCND 1982	MAGNETO
E35RLCRR 1984	IGNITION
E35RLCTS 1983	MAGNETO
E35RLCUB 1987	IGNITION
E35TCSM 1980	MAGNETO
E35TELCNB 1982	MAGNETO
E35TELCRR 1984	IGNITION
E35TELCTS 1983	MAGNETO
E35TLESM 1980	MAGNETO
E40AELCCS 1988	IGNITION SYSTEM
E40ARLCCS 1988	IGNITION SYSTEM
E40ATLCCS 1988	IGNITION SYSTEM
E40ECCS 1988	IGNITION SYSTEM
E40ECDE 1986	IGNITION SYSTEM
E40ECEC 1989	IGNITION SYSTEM - ELECTRIC START
E40ECOB 1985	IGNITION SYSTEM
E40ECRM 1984	IGNITION SYSTEM
E40ECUD 1987	IGNITION SYSTEM
E40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)



E40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40EESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40EESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40ELCCS 1988	IGNITION SYSTEM
E40ELCDE 1986	IGNITION SYSTEM
E40ELCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40ELCOB 1985	IGNITION SYSTEM
E40ELCRM 1984	IGNITION SYSTEM
E40ELCUD 1987	IGNITION SYSTEM
E40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RCCS 1988	IGNITION SYSTEM
E40RCDE 1986	IGNITION SYSTEM
E40RCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40RCOB 1985	IGNITION SYSTEM
E40RCRM 1984	IGNITION SYSTEM
E40RCUD 1987	IGNITION SYSTEM
E40REIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40REIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40RENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40RENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40RESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40RESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS

E40RETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RLCCS 1988	IGNITION SYSTEM
E40RLCDE 1986	IGNITION SYSTEM
E40RLCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40RLCOB 1985	IGNITION SYSTEM
E40RLCRM 1984	IGNITION SYSTEM
E40RLCUD 1987	IGNITION SYSTEM
E40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40RLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40RLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40RLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40RLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40RLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TECCS 1988	IGNITION SYSTEM
E40TECDE 1986	IGNITION SYSTEM
E40TECEC 1989	IGNITION SYSTEM - ELECTRIC START
E40TECOB 1985	IGNITION SYSTEM
E40TECRM 1984	IGNITION SYSTEM
E40TECUD 1987	IGNITION SYSTEM
E40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TELCCS 1988	IGNITION SYSTEM
E40TELCDE 1986	IGNITION SYSTEM

E40TELCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40TELCOB 1985	IGNITION SYSTEM
E40TELCRM 1984	IGNITION SYSTEM
E40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TLCCS 1988	IGNITION SYSTEM
E40TLCDE 1986	IGNITION SYSTEM
E40TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40TLCUD 1987	IGNITION SYSTEM
E40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TTLCCS 1988	IGNITION SYSTEM
E40TTLCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS

E40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TTLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TTLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TTLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TTLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E45RCE 1989	IGNITION
E45RCEIA 1991	IGNITION SYSTEM
E45RCENM 1992	IGNITION SYSTEM - ELECTRIC
E45RCESR 1990	IGNITION
E45RCLE 1989	IGNITION
E45RCLEIA 1991	IGNITION SYSTEM
E45RCLENM 1992	IGNITION SYSTEM - ELECTRIC
E45RCLESR 1990	IGNITION
E45WMLE 1989	IGNITION
E45WMLEIA 1991	IGNITION SYSTEM
E45WMLLENM 1992	IGNITION SYSTEM - ELECTRIC
E45WMLLESR 1990	IGNITION
E48ESLCCC 1988	IGNITION SYSTEM
E48ESLCER 1989	IGNITION SYSTEM
E48ESLCUS 1987	IGNITION SYSTEM
E48ESLEIM 1991	IGNITION SYSTEM
E48ESLENB 1992	IGNITION SYSTEM
E48ESLESA 1990	IGNITION SYSTEM
E48ESLETE 1993	IGNITION SYSTEM
E50BECCS 1988	IGNITION SYSTEM
E50BECDE 1986	IGNITION SYSTEM
E50BECEC 1989	IGNITION SYSTEM - ELECTRIC START
E50BECIC 1981	IGNITION SYSTEM
E50BECNR 1982	IGNITION SYSTEM
E50BECOB 1985	IGNITION SYSTEM
E50BECRM 1984	IGNITION SYSTEM
E50BECTA 1983	IGNITION SYSTEM

E50BECUD 1987	IGNITION SYSTEM
E50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50BELCCS 1988	IGNITION SYSTEM
E50BELCDE 1986	IGNITION SYSTEM
E50BELCEC 1989	IGNITION SYSTEM - ELECTRIC START
E50BELCIC 1981	IGNITION SYSTEM
E50BELCNR 1982	IGNITION SYSTEM
E50BELCOB 1985	IGNITION SYSTEM
E50BELCRM 1984	IGNITION SYSTEM
E50BELCTA 1983	IGNITION SYSTEM
E50BELCUD 1987	IGNITION SYSTEM
E50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50ECSR 1980	IGNITION SYSTEM
E50ELCSR 1980	IGNITION SYSTEM

E50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50JENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50JENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50JENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50JENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50JETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50RNLIA 1990	IGNITION SYSTEM
E50RNLIB 1992	IGNITION SYSTEM
E50TELCCS 1988	IGNITION SYSTEM
E50TELCDE 1986	IGNITION SYSTEM
E50TELCEC 1989	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TELCOB 1985	IGNITION SYSTEM
E50TELCRM 1984	IGNITION SYSTEM
E50TELECTA 1983	IGNITION SYSTEM
E50TELCUD 1987	IGNITION SYSTEM
E50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLCCS 1988	IGNITION SYSTEM
E50TLCDE 1986	IGNITION SYSTEM
E50TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
E50TLCOB 1985	IGNITION SYSTEM
E50TLCRM 1984	IGNITION SYSTEM
E50TLCUD 1987	IGNITION SYSTEM
E50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS

E50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E55RCIM 1981	IGNITION SYSTEM
E55RLCSA 1980	IGNITION SYSTEM
E55RWLE 1989	IGNITION
E55RWLEIA 1991	IGNITION SYSTEM
E55RWLENM 1992	IGNITION SYSTEM - ELECTRIC
E55RWLESR 1990	IGNITION
E55TLCIM 1981	IGNITION SYSTEM
E60ECIA 1981	IGNITION SYSTEM
E60ECIH 1981	IGNITION SYSTEM
E60ECNM 1982	IGNITION SYSTEM
E60ECSR 1980	IGNITION SYSTEM
E60ECTB 1983	IGNITION SYSTEM
E60ELCIA 1981	IGNITION SYSTEM
E60ELCIH 1981	IGNITION SYSTEM
E60ELCNM 1982	IGNITION SYSTEM
E60ELCOD 1985	IGNITION SYSTEM
E60ELCRE 1984	IGNITION SYSTEM
E60ELCSR 1980	IGNITION SYSTEM
E60ELCTB 1983	IGNITION SYSTEM
E60TLCIA 1981	IGNITION SYSTEM
E60TLCIH 1981	IGNITION SYSTEM
E60TLCNM 1982	IGNITION SYSTEM
E60TLCOD 1985	IGNITION SYSTEM
E60TLCRE 1984	IGNITION SYSTEM

E60TLCTB 1983  
ELECTRICAL  
ELECTRICAL  
ELECTRICAL 1977  
ELECTRICAL 1978  
ELECTRICAL 1978  
ELECTRICAL 1979  
ELECTRICAL 1979  
ELECTRICAL 1980  
ELECTRICAL 1981  
ELECTRICAL 1982  
ELECTRICAL 1983  
ELECTRICAL 1983  
ELECTRICAL 1984  
ELECTRICAL 1984  
ELECTRICAL 1984  
ELECTRICAL 1985  
ELECTRICAL 1985  
ELECTRICAL 1986  
ELECTRICAL 1986  
ELECTRICAL 1987  
ELECTRICAL 1987  
ELECTRICAL 1988  
ELECTRICAL 1988  
ELECTRICAL 1989  
ELECTRICAL 1989  
ELECTRICAL 1989  
ELECTRICAL 1990  
ELECTRICAL 1990  
ELECTRICAL 1990  
ELECTRICAL 1991  
ELECTRICAL 1991  
ELECTRICAL 1991  
ELECTRICAL 1992  
ELECTRICAL 1992

IGNITION SYSTEM  
BATTERY CHARGING KIT - 25,30 HP (2-Stroke)  
ELECTRIC START KIT - 40,50 HP (Johnson 2-Stroke)  
BATTERY CHARGING KIT 9.9-15/25-35  
BATTERY CHARGING KIT 6 HP  
BATTERY CHARGING KIT 9.9-15/25-35  
BATTERY CHARGING KIT  
BATTERY CHARGING KIT 9.9 - 15/25 - 35  
BATTERY CHARGING KIT 9.9, 15, 25, 35  
BATTERY CHARGING KIT 9.9, 15, 25, 35  
ELECTRIC START KIT 55  
BATTERY CHARGING KIT 9.9,15,25,35  
ELECTRIC START KIT 55  
BATTERY CHARGING KIT 9.9, 15, 25, 30 & 35  
BATTERY CHARGING KIT 6 (COMMERCIAL ONLY)  
ELECTRIC STARTING KIT 40, 55  
BATTERY CHARGING KIT 9.9, 15, 20, 25, 30, 35  
ELECTRIC STARTING KIT 40,45,55  
BATTERY CHARGING KIT 9.9, 15, 20, 25, 30, 35  
ELECTRIC STARTING KIT 40,45,55  
BATTERY CHARGING KIT 9.9, 15, 20, 25, 30, 35  
ELECTRIC STARTING KIT 40,45,55  
BATTERY CHARGING KIT 9.9, 15, 20, 25, 30, 35  
ELECTRIC STARTING KIT 40,45,55  
BATTERY CHARGING KIT 9.9, 15, 20, 25, 30, 35  
ELECTRIC STARTING KIT 40  
ELECTRIC STARTING KIT 45, 55 COMMERCIALS  
BATTERY CHARGING KIT 9.9, 15, 20, 25, 30, 35  
ELECTRIC STARTING KIT 40  
ELECTRIC STARTING KIT 45, 55 COMMERCIALS  
BATTERY CHARGING KIT 9.9, 15, 20, 25, 30, 35  
ELECTRIC STARTING KIT 40  
ELECTRIC STARTING KIT 45, 55 COMMERCIALS  
BATTERY CHARGING KIT 9.9, 15, 20, 25, 30, 35  
BATTERY CHARGING KIT - 10 & 25 COMMERCIAL



ELECTRICAL 1992	ELECTRIC STARTING KIT 40,45,55
ELECTRICAL 1993	BATTERY CHARGING KIT - 20, 25, 30
ELECTRICAL 1993	ELECTRIC STARTING KIT - 45/55
ELECTRICAL 1994	BATTERY CHARGING KIT - 20, 25, 30
ELECTRICAL 1994	ELECTRIC STARTING KIT - 45/55
ELECTRICAL 1995	BATTERY CHARGING KIT - 20, 25, 30 (2-CYLINDER)
ELECTRICAL 1995	TILLER ELECTRIC STARTING KIT - 45/55
ELECTRICAL 1996	BATTERY CHARGING KIT - 20, 25, 30 (2-CYLINDER)
ELECTRICAL 1996	TILLER ELECTRIC STARTING KIT - 40, 50
ELECTRICAL 1996	TILLER ELECTRIC STARTING KIT - 45, 55
ELECTRICAL 1997	BATTERY CHARGING KIT - 20, 25, 30 (2-CYLINDER)
ELECTRICAL 1997	TILLER ELECTRIC STARTING KIT - 40, 50
ELECTRICAL 1997	TILLER ELECTRIC STARTING KIT - 45, 55
ELECTRICAL 1998	BATTERY CHARGING KIT -- 20, 25, 30 (2-CYLINDER)
ELECTRICAL 1998	TILLER ELECTRIC STARTING KIT -- 40, 50
ELECTRICAL 1998	TILLER ELECTRIC STARTING KIT -- 45, 55
ELECTRICAL 1999	BATTERY CHARGING KIT -- 20, 25, 30 (2-CYLINDER)
ELECTRICAL 1999	TILLER ELECTRIC STARTING KIT -- 40, 50
ELECTRICAL 1999	TILLER ELECTRIC STARTING KIT -- 40, 55
ELECTRICAL 2000	BATTERY CHARGING KIT - 20, 25, 30 (2-CYLINDER)
ELECTRICAL 2000	TILLER ELECTRIC STARTING KIT - 40, 50
ELECTRICAL 2000	TILLER ELECTRIC STARTING KIT - 40, 55
HE25TELEDA 1996	IGNITION
HE55WMLM 1996	IGNITION SYSTEM
HE55WMLZ 1997	IGNITION SYSTEM
HJ25TELEDA 1996	IGNITION
HJ55WMLM 1996	IGNITION SYSTEM
HJ55WMLZ 1997	IGNITION SYSTEM
J10ECCD 1988	IGNITION
J10ECDB 1986	IGNITION
J10ECES 1989	IGNITION
J10ECOM 1985	IGNITION
J10ECSE 1980	CYLINDER & CRANKCASE
J10ECUE 1987	IGNITION
J10EEIR 1991	IGNITION

J10EENA 1992	IGNITION
J10EESC 1990	IGNITION
J10ELCCD 1988	IGNITION
J10ELCDB 1986	IGNITION
J10ELCES 1989	IGNITION
J10ELCID 1981	CYLINDER & CRANKCASE
J10ELCNS 1982	CYLINDER & CRANKCASE
J10ELCOM 1985	IGNITION
J10ELCRA 1984	CYLINDER & CRANKCASE
J10ELCSE 1980	CYLINDER & CRANKCASE
J10ELCTC 1983	CYLINDER & CRANKCASE
J10ELCUE 1987	IGNITION
J10ELEIR 1991	IGNITION
J10ELENA 1992	IGNITION
J10ELESC 1990	IGNITION
J10RCCD 1988	IGNITION
J10RCDB 1986	IGNITION
J10RCES 1989	IGNITION
J10RCID 1981	CYLINDER & CRANKCASE
J10RCNS 1982	CYLINDER & CRANKCASE
J10RCOM 1985	IGNITION
J10RCRA 1984	CYLINDER & CRANKCASE
J10RCSE 1980	CYLINDER & CRANKCASE
J10RCTC 1983	CYLINDER & CRANKCASE
J10RCTR 1983	CYLINDER & CRANKCASE
J10RCUE 1987	IGNITION
J10REIR 1991	IGNITION
J10RELEIR 1991	IGNITION
J10RELENA 1992	IGNITION
J10RELESC 1990	IGNITION
J10RENA 1992	IGNITION
J10RESC 1990	IGNITION
J10RLCCD 1988	IGNITION
J10RLCDB 1986	IGNITION
J10RLCES 1989	IGNITION

J10RLCID 1981	CYLINDER & CRANKCASE
J10RLCNS 1982	CYLINDER & CRANKCASE
J10RLCOM 1985	IGNITION
J10RLCRA 1984	CYLINDER & CRANKCASE
J10RLCSE 1980	CYLINDER & CRANKCASE
J10RLCTC 1983	CYLINDER & CRANKCASE
J10RLCTR 1983	CYLINDER & CRANKCASE
J10RLCUE 1987	IGNITION
J10RLEIR 1991	IGNITION
J10RLENA 1992	IGNITION
J10RLESC 1990	IGNITION
J10SELCCD 1988	IGNITION
J10SELCDB 1986	IGNITION
J10SELCES 1989	IGNITION
J10SELCID 1981	CYLINDER & CRANKCASE
J10SELCNS 1982	CYLINDER & CRANKCASE
J10SELCOM 1985	IGNITION
J10SELCRA 1984	CYLINDER & CRANKCASE
J10SELCSE 1980	CYLINDER & CRANKCASE
J10SELCTC 1983	CYLINDER & CRANKCASE
J10SELCUE 1987	IGNITION
J10SELEIR 1991	IGNITION
J10SELENA 1992	IGNITION
J10SELESC 1990	IGNITION
J15ECCS 1988	IGNITION
J15ECDE 1986	IGNITION
J15ECEC 1989	IGNITION
J15ECIS 1981	CYLINDER & CRANKCASE
J15ECNC 1982	CYLINDER & CRANKCASE
J15ECOB 1985	IGNITION
J15ECRM 1984	CYLINDER & CRANKCASE
J15ECSO 1980	CYLINDER & CRANKCASE
J15ECTR 1983	CYLINDER & CRANKCASE
J15ECUD 1987	IGNITION
J15EEIA 1991	IGNITION

J15EENM 1992	IGNITION
J15EESR 1990	IGNITION
J15ELCCS 1988	IGNITION
J15ELCDE 1986	IGNITION
J15ELCEC 1989	IGNITION
J15ELCOB 1985	IGNITION
J15ELCRM 1984	CYLINDER & CRANKCASE
J15ELCSD 1980	CYLINDER & CRANKCASE
J15ELCTR 1983	CYLINDER & CRANKCASE
J15ELCUD 1987	IGNITION
J15ELEIA 1991	IGNITION
J15ELENM 1992	IGNITION
J15ELESR 1990	IGNITION
J15RCCS 1988	IGNITION
J15RCDE 1986	IGNITION
J15RCEC 1989	IGNITION
J15RCIS 1981	CYLINDER & CRANKCASE
J15RCNC 1982	CYLINDER & CRANKCASE
J15RCOB 1985	IGNITION
J15RCRM 1984	CYLINDER & CRANKCASE
J15RCSD 1980	CYLINDER & CRANKCASE
J15RCTA 1983	CYLINDER & CRANKCASE
J15RCTR 1983	CYLINDER & CRANKCASE
J15RCUD 1987	IGNITION
J15REIA 1991	IGNITION
J15RELEIA 1991	IGNITION
J15RELENM 1992	IGNITION
J15RELESR 1990	IGNITION
J15RENM 1992	IGNITION
J15RESR 1990	IGNITION
J15RLCCS 1988	IGNITION
J15RLCDE 1986	IGNITION
J15RLCEC 1989	IGNITION
J15RLCIS 1981	CYLINDER & CRANKCASE
J15RLCNC 1982	CYLINDER & CRANKCASE

J15RLCOB 1985	IGNITION
J15RLCRM 1984	CYLINDER & CRANKCASE
J15RLCSD 1980	CYLINDER & CRANKCASE
J15RLCTA 1983	CYLINDER & CRANKCASE
J15RLCTR 1983	CYLINDER & CRANKCASE
J15RLCUD 1987	IGNITION
J15RLEIA 1991	IGNITION
J15RLENM 1992	IGNITION
J15RLESR 1990	IGNITION
J20CRCCA 1988	IGNITION
J20CRCDC 1986	IGNITION
J20CRCOS 1985	IGNITION
J20CRCUR 1987	IGNITION
J20CRLCCA 1988	IGNITION
J20CRLCDC 1986	IGNITION
J20CRLCOS 1985	IGNITION
J20CRLCUR 1987	IGNITION
J20ECCA 1988	IGNITION
J20ECDC 1986	IGNITION
J20ECEM 1989	IGNITION
J20ECOS 1985	IGNITION
J20ECUR 1987	IGNITION
J20EEIE 1991	IGNITION
J20EEND 1992	IGNITION
J20EEOR 1995	IGNITION
J20EERC 1994	IGNITION
J20EESB 1990	IGNITION
J20EETS 1993	IGNITION
J20ELCCA 1988	IGNITION
J20ELCDC 1986	IGNITION
J20ELCEM 1989	IGNITION
J20ELCOS 1985	IGNITION
J20ELCUR 1987	IGNITION
J20ELEIE 1991	IGNITION
J20ELEND 1992	IGNITION

J20ELEOR 1995	IGNITION
J20ELERC 1994	IGNITION
J20ELESB 1990	IGNITION
J20ELETS 1993	IGNITION
J20TECDC 1986	IGNITION
J25ECCM 1988	IGNITION
J25ECDR 1986	IGNITION
J25ECEB 1989	IGNITION
J25ECIB 1981	MAGNETO
J25ECIM 1981	MAGNETO
J25ECNE 1982	MAGNETO
J25ECOC 1985	IGNITION
J25ECRS 1984	IGNITION
J25ECTD 1983	MAGNETO
J25ECUA 1987	IGNITION
J25EECE 1998	IGNITION
J25EEDM 1996	IGNITION
J25EEED 1999	IGNITION
J25EEEN 1999	IGNITION
J25EEID 1991	IGNITION
J25EENS 1992	IGNITION
J25EEOA 1995	IGNITION
J25EERR 1994	IGNITION
J25EESE 1990	IGNITION
J25EETC 1993	IGNITION
J25EEUB 1997	IGNITION
J25ELCCM 1988	IGNITION
J25ELCDR 1986	IGNITION
J25ELCEB 1989	IGNITION
J25ELCIB 1981	MAGNETO
J25ELCIM 1981	MAGNETO
J25ELCNE 1982	MAGNETO
J25ELCOC 1985	IGNITION
J25ELCRS 1984	IGNITION
J25ELCTD 1983	MAGNETO

J25ELCUA 1987	IGNITION
J25ELECE 1998	IGNITION
J25ELEDM 1996	IGNITION
J25ELEED 1999	IGNITION
J25ELEEN 1999	IGNITION
J25ELEID 1991	IGNITION
J25ELENS 1992	IGNITION
J25ELEOA 1995	IGNITION
J25ELERR 1994	IGNITION
J25ELESE 1990	IGNITION
J25ELETC 1993	IGNITION
J25ELEUB 1997	IGNITION
J25ELSIC elec start, remote, 20 in shaft 2001	IGNITION
J25ELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSNF Electric start, Carb, White, Remote, 20 in., 4 Amp Alt 2002	IGNITION
J25ELSOB	IGNITION
J25ELSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSRM	IGNITION
J25ELSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSSS Elec. Start, 20 IN. shaft 2000	IGNITION
J25ELSTA	IGNITION
J25ELSTA - FR	22-5_SYSTÈME D'ALLUMAGE
J25ESIC elec start, remote, 15 in shaft 2001	IGNITION
J25ESSS Elec. Start, 15 IN. shaft 2000	IGNITION
J25EVSIC elec start, remote, 120 in shaft, wht 2001	IGNITION
J25EVSIC elec start, remote, 15 in shaft, wht 2001	IGNITION
J25GTESOC	IGNITION
J25GTESOC - FR	22-5_SYSTÈME D'ALLUMAGE
J25GTESRS	IGNITION
J25GTESRS - FR	22-5_SYSTÈME D'ALLUMAGE
J25RCCA 1988	IGNITION
J25RCDC 1986	IGNITION
J25RCIM 1981	MAGNETO
J25RCNB 1982	MAGNETO

J25RCOS 1985	IGNITION
J25RCRD 1984	IGNITION
J25RCSA 1980	MAGNETO
J25RCTE 1983	MAGNETO
J25RCUR 1987	IGNITION
J25RELCNB 1982	MAGNETO
J25RLCCA 1988	IGNITION
J25RLCDC 1986	IGNITION
J25RLCIM 1981	MAGNETO
J25RLCNB 1982	MAGNETO
J25RLCOS 1985	IGNITION
J25RLCRD 1984	IGNITION
J25RLCSA 1980	MAGNETO
J25RLCTE 1983	MAGNETO
J25RLCUR 1987	IGNITION
J25TECCA 1988	IGNITION
J25TECDC 1986	IGNITION
J25TECEM 1989	IGNITION
J25TECIM 1981	MAGNETO
J25TECNB 1982	MAGNETO
J25TECOS 1985	IGNITION
J25TECRD 1984	IGNITION
J25TECSA 1980	MAGNETO
J25TECTE 1983	MAGNETO
J25TECUR 1987	IGNITION
J25TEECB 1998	IGNITION
J25TEEDA 1996	IGNITION
J25TEEEE 1999	IGNITION
J25TEEEN 1999	IGNITION
J25TEEIE 1991	IGNITION
J25TEEND 1992	IGNITION
J25TEEOR 1995	IGNITION
J25TEERC 1994	IGNITION
J25TEESB 1990	IGNITION
J25TEETS 1993	IGNITION



J25TEEUM 1997	IGNITION
J25TELCCA 1988	IGNITION
J25TELCDC 1986	IGNITION
J25TELCEM 1989	IGNITION
J25TELCIM 1981	MAGNETO
J25TELCOS 1985	IGNITION
J25TELCRD 1984	IGNITION
J25TELCSA 1980	MAGNETO
J25TELCCTE 1983	MAGNETO
J25TELCUR 1987	IGNITION
J25TELECB 1998	IGNITION
J25TELEDA 1996	IGNITION
J25TELEEE 1999	IGNITION
J25TELEEN 1999	IGNITION
J25TELEIE 1991	IGNITION
J25TELEND 1992	IGNITION
J25TELEOR 1995	IGNITION
J25TELERC	IGNITION
J25TELESB 1990	IGNITION
J25TELETS 1993	IGNITION
J25TELEUM 1997	IGNITION
J25TELSIS elec start, tiller, 20 in shaft 2001	IGNITION
J25TELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSNF Electric start, White, Tiller, 20 in., 4 Amp Alt 2002	IGNITION
J25TELSOM	IGNITION
J25TELSOM - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSRA	IGNITION
J25TELSRA - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSSD Elec. Start, Tiller, 20 IN. shaft 2000	IGNITION
J25TELSTR	IGNITION
J25TELSTR - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESIS elec start, tiller, 15 in shaft 2001	IGNITION
J25TESNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESNF Electric start, White, Tiller, 15 in. shaft, 4 Amp Alt 2002	IGNITION

J25TESOM	IGNITION
J25TESOM - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESRA	IGNITION
J25TESRA - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESSD Elec. Start, Tiller, 15 IN. shaft 2000	IGNITION
J25TESTR	IGNITION
J25TESTR - FR	22-5_SYSTÈME D'ALLUMAGE
J25TVLSIS elec start, tiller, 20 in shaft 2001	IGNITION
J25TVSIS elec start, tiller, 15 in shaft 2001	IGNITION
J28ELCDS 1986	MAGNETO
J28ESLCCR 1988	IGNITION
J28ESLCEA 1989	IGNITION
J28ESLCUC 1987	MAGNETO
J28ESLEDR 1996	IGNITION
J28ESLEIB 1991	IGNITION
J28ESLENE 1992	IGNITION
J28ESLEOC 1995	IGNITION
J28ESLERS 1994	IGNITION
J28ESLESM 1990	IGNITION
J28ESLETD 1993	IGNITION
J30ECCE 1988	IGNITION
J30ECDM 1986	IGNITION
J30ECED 1989	IGNITION
J30EOA 1985	IGNITION
J30ECRR 1984	IGNITION
J30ECUB 1987	IGNITION
J30EECS 1998	IGNITION
J30EEDE 1996	IGNITION
J30EEEC 1999	IGNITION
J30EEEN 1999	IGNITION
J30EEIC 1991	IGNITION
J30EENR 1992	IGNITION
J30EEOB 1995	IGNITION
J30EERM 1994	IGNITION
J30EESS 1990	IGNITION

J30EETA 1993	IGNITION
J30EEUD 1997	IGNITION
J30ELCCE 1988	IGNITION
J30ELCDM 1986	IGNITION
J30ELCED 1989	IGNITION
J30ELCOA 1985	IGNITION
J30ELCRR 1984	IGNITION
J30ELCUB 1987	IGNITION
J30ELECS 1998	IGNITION
J30ELEDE 1996	IGNITION
J30ELEEC 1999	IGNITION
J30ELEEN 1999	IGNITION
J30ELEIC 1991	IGNITION
J30ELENR 1992	IGNITION
J30ELEOB 1995	IGNITION
J30ELERM 1994	IGNITION
J30ELESS 1990	IGNITION
J30ELETA 1993	IGNITION
J30ELEUD 1997	IGNITION
J30ELSIA elec start, remote, 20 in shaft 2001	IGNITION
J30ELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSNF Electric start, Carb, White, Remote, 20 in., 4 Amp Alt, 2002	IGNITION
J30ELSOD	IGNITION
J30ELSOD - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSRE	IGNITION
J30ELSRE - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSSR Elec. Start, 20 IN. shaft 2000	IGNITION
J30ELSTB	IGNITION
J30ELSTB - FR	22-5_SYSTÈME D'ALLUMAGE
J30ESIA elec start, remote, 15 in shaft 2001	IGNITION
J30ESSR Elec. Start, 15 IN. shaft 2000	IGNITION
J30EVLSIA elec start, remote, 20 in shaft, wht 2001	IGNITION
J30RCCE 1988	IGNITION
J30RCDM 1986	IGNITION

J30RCOA 1985	IGNITION
J30RCUB 1987	IGNITION
J30RLCCE 1988	IGNITION
J30RLCDM 1986	IGNITION
J30RLCOA 1985	IGNITION
J30RLCUB 1987	IGNITION
J30TECCE 1988	IGNITION
J30TECDM 1986	IGNITION
J30TECED 1989	IGNITION
J30TECOA 1985	IGNITION
J30TECUB 1987	IGNITION
J30TEECS 1998	IGNITION
J30TEEDE 1996	IGNITION
J30TEEIC 1991	IGNITION
J30TEENR 1992	IGNITION
J30TEEOB 1995	IGNITION
J30TEERM 1994	IGNITION
J30TEESS 1990	IGNITION
J30TEETA 1993	IGNITION
J30TEEUD 1997	IGNITION
J30TELCCE 1988	IGNITION
J30TELCDM 1986	IGNITION
J30TELCED 1989	IGNITION
J30TELCOA 1985	IGNITION
J30TELCUB 1987	IGNITION
J30TELECS 1998	IGNITION
J30TELEDE 1996	IGNITION
J30TELEIC 1991	IGNITION
J30TELENR 1992	IGNITION
J30TELEOB 1995	IGNITION
J30TELERM 1994	IGNITION
J30TELESS 1990	IGNITION
J30TELETA 1993	IGNITION
J30TELEUD 1997	IGNITION
J35AELCDE 1986	IGNITION SYSTEM

J35AELCUD 1987	IGNITION SYSTEM
J35ARLCDE 1986	IGNITION SYSTEM
J35ARLCUD 1987	IGNITION SYSTEM
J35ECIG 1981	MAGNETO
J35ECND 1982	MAGNETO
J35ECRR 1984	IGNITION
J35ECSM 1980	MAGNETO
J35ECTS 1983	MAGNETO
J35ELCIG 1981	MAGNETO
J35ELCND 1982	MAGNETO
J35ELCRR 1984	IGNITION
J35ELCSM 1980	MAGNETO
J35ELCTS 1983	MAGNETO
J35RCCE 1988	IGNITION
J35RCDM 1986	IGNITION
J35RCIG 1981	MAGNETO
J35RCND 1982	MAGNETO
J35RCRR 1984	IGNITION
J35RCSM 1980	MAGNETO
J35RCTS 1983	MAGNETO
J35RCUB 1987	IGNITION
J35RLCCE 1988	IGNITION
J35RLCDM 1986	IGNITION
J35RLCIG 1981	MAGNETO
J35RLCND 1982	MAGNETO
J35RLCRR 1984	IGNITION
J35RLCSM 1980	MAGNETO
J35RLCTS 1983	MAGNETO
J35RLCUB 1987	IGNITION
J35TELCNB 1982	MAGNETO
J35TELCRR 1984	IGNITION
J35TELECTS 1983	MAGNETO
J40AELCCS 1988	IGNITION SYSTEM
J40ARLCCS 1988	IGNITION SYSTEM
J40ATLCCS 1988	IGNITION SYSTEM

J40ECCS 1988	IGNITION SYSTEM
J40ECDE 1986	IGNITION SYSTEM
J40ECEC 1989	IGNITION SYSTEM - ELECTRIC START
J40ECOB 1985	IGNITION SYSTEM
J40ECRM 1984	IGNITION SYSTEM
J40ECUD 1987	IGNITION SYSTEM
J40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40EESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40EESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40ELCCS 1988	IGNITION SYSTEM
J40ELCDE 1986	IGNITION SYSTEM
J40ELCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40ELCOB 1985	IGNITION SYSTEM
J40ELCRM 1984	IGNITION SYSTEM
J40ELCUD 1987	IGNITION SYSTEM
J40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

J40RCCS 1988	IGNITION SYSTEM
J40RCDE 1986	IGNITION SYSTEM
J40RCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40RCOB 1985	IGNITION SYSTEM
J40RCRM 1984	IGNITION SYSTEM
J40RCUD 1987	IGNITION SYSTEM
J40REIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40REIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40RENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40RENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40RESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40RESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40RETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40RLCCS 1988	IGNITION SYSTEM
J40RLCDE 1986	IGNITION SYSTEM
J40RLCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40RLCOB 1985	IGNITION SYSTEM
J40RLCRM 1984	IGNITION SYSTEM
J40RLCUD 1987	IGNITION SYSTEM
J40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40RLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40RLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40RLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40RLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40RLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TECCS 1988	IGNITION SYSTEM
J40TECDE 1986	IGNITION SYSTEM
J40TECEC 1989	IGNITION SYSTEM - ELECTRIC START
J40TECOB 1985	IGNITION SYSTEM
J40TECRM 1984	IGNITION SYSTEM
J40TECUD 1987	IGNITION SYSTEM

J40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TELCCS 1988	IGNITION SYSTEM
J40TELCDE 1986	IGNITION SYSTEM
J40TELCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40TELCOB 1985	IGNITION SYSTEM
J40TELCRM 1984	IGNITION SYSTEM
J40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TLCCS 1988	IGNITION SYSTEM
J40TLCDE 1986	IGNITION SYSTEM
J40TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40TLCUD 1987	IGNITION SYSTEM
J40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)



J40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TTLCCS 1988	IGNITION SYSTEM
J40TTLCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TTLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TTLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TTLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TTLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J45RCE 1989	IGNITION
J45RCEIA 1991	IGNITION SYSTEM
J45RCENM 1992	IGNITION SYSTEM - ELECTRIC
J45RCESR 1990	IGNITION
J45RCLE 1989	IGNITION
J45RCLEIA 1991	IGNITION SYSTEM
J45RCLENM 1992	IGNITION SYSTEM - ELECTRIC
J45RCLESR 1990	IGNITION
J45WMLE 1989	IGNITION
J45WMLEIA 1991	IGNITION SYSTEM
J45WMLLENM 1992	IGNITION SYSTEM - ELECTRIC
J45WMLCSR 1990	IGNITION
J48ESLCCC 1988	IGNITION SYSTEM
J48ESLCER 1989	IGNITION SYSTEM

J48ESLCUS 1987	IGNITION SYSTEM
J48ESLEIM 1991	IGNITION SYSTEM
J48ESLENB 1992	IGNITION SYSTEM
J48ESLESA 1990	IGNITION SYSTEM
J48ESLETE 1993	IGNITION SYSTEM
J50BECCS 1988	IGNITION SYSTEM
J50BECDE 1986	IGNITION SYSTEM
J50BECEC 1989	IGNITION SYSTEM - ELECTRIC START
J50BECIC 1981	IGNITION SYSTEM
J50BECNR 1982	IGNITION SYSTEM
J50BECOB 1985	IGNITION SYSTEM
J50BECRM 1984	IGNITION SYSTEM
J50BECTA 1983	IGNITION SYSTEM
J50BECUD 1987	IGNITION SYSTEM
J50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50BELCCS 1988	IGNITION SYSTEM
J50BELCDE 1986	IGNITION SYSTEM
J50BELCEC 1989	IGNITION SYSTEM - ELECTRIC START
J50BELCIC 1981	IGNITION SYSTEM
J50BELCNR 1982	IGNITION SYSTEM
J50BELCOB 1985	IGNITION SYSTEM
J50BELCRM 1984	IGNITION SYSTEM
J50BELCTA 1983	IGNITION SYSTEM
J50BELCUD 1987	IGNITION SYSTEM
J50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS

J50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50ECSR 1980	IGNITION SYSTEM
J50ELCSR 1980	IGNITION SYSTEM
J50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50JENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50JENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50JENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50JENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50JETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TELCCS 1988	IGNITION SYSTEM
J50TELCDE 1986	IGNITION SYSTEM
J50TELCEC 1989	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TELCOB 1985	IGNITION SYSTEM
J50TELCRM 1984	IGNITION SYSTEM
J50TELCCTA 1983	IGNITION SYSTEM
J50TELCUD 1987	IGNITION SYSTEM
J50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS

J50TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLCCS 1988	IGNITION SYSTEM
J50TLCDE 1986	IGNITION SYSTEM
J50TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
J50TLCOB 1985	IGNITION SYSTEM
J50TLCRM 1984	IGNITION SYSTEM
J50TLCUD 1987	IGNITION SYSTEM
J50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J55RCIM 1981	IGNITION SYSTEM
J55RLCIM 1981	IGNITION SYSTEM
J55RLCSA 1980	IGNITION SYSTEM
J55RWLE 1989	IGNITION
J55RWLEIA 1991	IGNITION SYSTEM
J55RWLENM 1992	IGNITION SYSTEM - ELECTRIC
J55RWLESR 1990	IGNITION
J60ECIA 1981	IGNITION SYSTEM
J60ECIH 1981	IGNITION SYSTEM
J60ECNM 1982	IGNITION SYSTEM
J60ECSR 1980	IGNITION SYSTEM
J60ECTB 1983	IGNITION SYSTEM
J60ELCIA 1981	IGNITION SYSTEM
J60ELCIH 1981	IGNITION SYSTEM

J60ELCNM 1982	IGNITION SYSTEM
J60ELCOD 1985	IGNITION SYSTEM
J60ELCRE 1984	IGNITION SYSTEM
J60ELCSR 1980	IGNITION SYSTEM
J60ELCTB 1983	IGNITION SYSTEM
J60TLCIA 1981	IGNITION SYSTEM
J60TLCIH 1981	IGNITION SYSTEM
J60TLCNM 1982	IGNITION SYSTEM
J60TLCOD 1985	IGNITION SYSTEM
J60TLCRE 1984	IGNITION SYSTEM
J60TLCTB 1983	IGNITION SYSTEM
SJ25TEEDA 1996	IGNITION
SJ25TEEUM 1997	IGNITION
SJ30EEDE 1996	IGNITION
SJ30TEEUD 1997	IGNITION
TE10ELCES 1989	IGNITION
TE10ELESC 1990	IGNITION
TE10RELEIR 1991	IGNITION
TE10RELENA 1992	IGNITION
TE10RELESC 1990	IGNITION
TE10RLCES 1989	IGNITION
TE10RLESC 1990	IGNITION
TE15RLCEC 1989	IGNITION
TE25ELCEB 1989	IGNITION
TE25ELEID 1991	IGNITION
TE25ELENS 1992	IGNITION
TE25ELESE 1990	IGNITION
TE25ELESF 1989	IGNITION
TE25ELETG 1993	IGNITION
TE30ELCED 1989	IGNITION
TE30ELESF 1989	IGNITION
TE30ELESS 1990	IGNITION
TE40ELCEC 1989	IGNITION SYSTEM - ELECTRIC START
TE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS

TE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
TE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
TE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TE40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
TE40TELESF 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE40TELESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE48ESLETE 1993	IGNITION SYSTEM
TE50TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
TE50TLESF 1989	IGNITION SYSTEM - ELECTRIC START
TE50TLESF 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE50TLESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ10ELCES 1989	IGNITION
TJ10ELESC 1990	IGNITION
TJ10RELEIR 1991	IGNITION
TJ10RELENA 1992	IGNITION
TJ10RELESC 1990	IGNITION
TJ10RLCES 1989	IGNITION
TJ10RLESC 1990	IGNITION
TJ15RLCEC 1989	IGNITION
TJ25ELCEB 1989	IGNITION
TJ25ELEID 1991	IGNITION
TJ25ELENS 1992	IGNITION
TJ25ELESE 1990	IGNITION
TJ25ELESF 1989	IGNITION
TJ25ELETB 1993	IGNITION
TJ30ELCED 1989	IGNITION

TJ30ELESF 1989	IGNITION
TJ30ELESS 1990	IGNITION
TJ40ELCEC 1989	IGNITION SYSTEM - ELECTRIC START
TJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
TJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
TJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TJ40ELESF 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ40ELESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
TJ40TELESF 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ40TELESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ48ESLETE 1993	IGNITION SYSTEM
TJ50TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
TJ50TLESF 1989	IGNITION SYSTEM - ELECTRIC START
TJ50TLESF 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ50TLESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE25ELEID 1991	IGNITION
VE25ELENS 1992	IGNITION
VE25ELESE 1990	IGNITION
VE25ELETG 1993	IGNITION
VE28ESLCCR 1988	IGNITION
VE28ESLCEA 1989	IGNITION
VE28ESLESM 1990	IGNITION
VE30EEIC 1991	IGNITION

VE30EENR 1992	IGNITION
VE30EESS 1990	IGNITION
VE30EETA 1993	IGNITION
VE30ELEIC 1991	IGNITION
VE30ELENR 1992	IGNITION
VE30ELESS 1990	IGNITION
VE30ELETA 1993	IGNITION
VE40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40EESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40EESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)



VE40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE48ESLCCC 1988	IGNITION SYSTEM
VE48ESLCER 1989	IGNITION SYSTEM
VE48ESLENB 1992	IGNITION SYSTEM
VE48ESLESA 1990	IGNITION SYSTEM
VE48ESLETE 1993	IGNITION SYSTEM
VE50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

VE50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ25ELEID 1991	IGNITION
VJ25ELENS 1992	IGNITION
VJ25ELESE 1990	IGNITION
VJ25ELETC 1993	IGNITION
VJ28ESLCCR 1988	IGNITION
VJ28ESLCEA 1989	IGNITION
VJ28ESLESM 1990	IGNITION
VJ30EEIC 1991	IGNITION

VJ30EENR 1992	IGNITION
VJ30EESS 1990	IGNITION
VJ30EETA 1993	IGNITION
VJ30ELEIC 1991	IGNITION
VJ30ELENR 1992	IGNITION
VJ30ELESS 1990	IGNITION
VJ30ELETA 1993	IGNITION
VJ40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40EESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40EESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)

VJ40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ48ESLCCC 1988	IGNITION SYSTEM
VJ48ESLCER 1989	IGNITION SYSTEM
VJ48ESLENB 1992	IGNITION SYSTEM
VJ48ESLESA 1990	IGNITION SYSTEM
VJ48ESLETE 1993	IGNITION SYSTEM
VJ50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

VJ50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY