

Where Used: Part Number 0582125

Model Name	Diagram
E100MLCSC 1980	IGNITION SYSTEM
E100TLCSC 1980	IGNITION SYSTEM
E100TXCSC 1980	IGNITION SYSTEM
E115MLCIH 1981	IGNITION SYSTEM
E115MLCIM 1981	IGNITION SYSTEM
E115MLCNB 1982	IGNITION SYSTEM
E115MLCRD 1984	IGNITION SYSTEM
E115MLCSA 1980	IGNITION SYSTEM
E115MLCTE 1983	IGNITION SYSTEM
E115TLCIH 1981	IGNITION SYSTEM
E115TLCIM 1981	IGNITION SYSTEM
E115TLCNB 1982	IGNITION SYSTEM
E115TLCRD 1984	IGNITION SYSTEM
E115TLCSA 1980	IGNITION SYSTEM
E115TLCTE 1983	IGNITION SYSTEM
E115TXCIH 1981	IGNITION SYSTEM
E115TXCIM 1981	IGNITION SYSTEM
E115TXCNB 1982	IGNITION SYSTEM
E115TXCRD 1984	IGNITION SYSTEM
E115TXCSA 1980	IGNITION SYSTEM
E115TXCTE 1983	IGNITION SYSTEM
E140MLCIH 1981	IGNITION SYSTEM
E140MLCIM 1981	IGNITION SYSTEM
E140MLCNB 1982	IGNITION SYSTEM
E140MLCSA 1980	IGNITION SYSTEM
E140MLCTE 1983	IGNITION SYSTEM
E140TLCRD 1984	IGNITION SYSTEM
E140TRLCIH 1981	IGNITION SYSTEM
E140TRLCIM 1981	IGNITION SYSTEM
E140TRLCNB 1982	IGNITION SYSTEM
E140TRLCSA 1980	IGNITION SYSTEM
E140TRLCTE 1983	IGNITION SYSTEM
E140TRXCIH 1981	IGNITION SYSTEM

E140TRXCIM 1981	IGNITION SYSTEM
E140TRXCNB 1982	IGNITION SYSTEM
E140TRXCSA 1980	IGNITION SYSTEM
E140TRXCTE 1983	IGNITION SYSTEM
E140TXCRD 1984	IGNITION SYSTEM
E85MLCSA 1980	IGNITION SYSTEM
E85STLCSA 1980	IGNITION SYSTEM
E85STXCSA 1980	IGNITION SYSTEM
E90MLCIH 1981	IGNITION SYSTEM
E90MLCIM 1981	IGNITION SYSTEM
E90MLCNB 1982	IGNITION SYSTEM
E90MLCRD 1984	IGNITION SYSTEM
E90MLCTE 1983	IGNITION SYSTEM
E90TLCIH 1981	IGNITION SYSTEM
E90TLCIM 1981	IGNITION SYSTEM
E90TLCNB 1982	IGNITION SYSTEM
E90TLCRD 1984	IGNITION SYSTEM
E90TLCTE 1983	IGNITION SYSTEM
E90TXCIH 1981	IGNITION SYSTEM
E90TXCIM 1981	IGNITION SYSTEM
E90TXCNB 1982	IGNITION SYSTEM
E90TXCRD 1984	IGNITION SYSTEM
E90TXCTE 1983	IGNITION SYSTEM
J100MLCSC 1980	IGNITION SYSTEM
J100TRLCSC 1980	IGNITION SYSTEM
J100TRXCSC 1980	IGNITION SYSTEM
J115MLCIH 1981	IGNITION SYSTEM
J115MLCIM 1981	IGNITION SYSTEM
J115MLCNB 1982	IGNITION SYSTEM
J115MLCRD 1984	IGNITION SYSTEM
J115MLCSA 1980	IGNITION SYSTEM
J115MLCTE 1983	IGNITION SYSTEM
J115TLCIH 1981	IGNITION SYSTEM
J115TLCIM 1981	IGNITION SYSTEM
J115TLCNB 1982	IGNITION SYSTEM

J115TLCRD 1984	IGNITION SYSTEM
J115TLCSA 1980	IGNITION SYSTEM
J115TLCTE 1983	IGNITION SYSTEM
J115TXCIH 1981	IGNITION SYSTEM
J115TXCIM 1981	IGNITION SYSTEM
J115TXCNB 1982	IGNITION SYSTEM
J115TXCRD 1984	IGNITION SYSTEM
J115TXCSA 1980	IGNITION SYSTEM
J115TXCTE 1983	IGNITION SYSTEM
J140MLCIH 1981	IGNITION SYSTEM
J140MLCIM 1981	IGNITION SYSTEM
J140MLCNB 1982	IGNITION SYSTEM
J140MLCSA 1980	IGNITION SYSTEM
J140MLCTE 1983	IGNITION SYSTEM
J140TLCIH 1981	IGNITION SYSTEM
J140TLCIM 1981	IGNITION SYSTEM
J140TLCNB 1982	IGNITION SYSTEM
J140TLCRD 1984	IGNITION SYSTEM
J140TLCSA 1980	IGNITION SYSTEM
J140TLCTE 1983	IGNITION SYSTEM
J140TXCIH 1981	IGNITION SYSTEM
J140TXCIM 1981	IGNITION SYSTEM
J140TXCNB 1982	IGNITION SYSTEM
J140TXCRD 1984	IGNITION SYSTEM
J140TXCSA 1980	IGNITION SYSTEM
J140TXCTE 1983	IGNITION SYSTEM
J85MLCSA 1980	IGNITION SYSTEM
J85TLCSA 1980	IGNITION SYSTEM
J85TXCSA 1980	IGNITION SYSTEM
J90MLCIH 1981	IGNITION SYSTEM
J90MLCIM 1981	IGNITION SYSTEM
J90MLCNB 1982	IGNITION SYSTEM
J90MLCRD 1984	IGNITION SYSTEM
J90MLCTE 1983	IGNITION SYSTEM
J90TLCIH 1981	IGNITION SYSTEM

J90TLCIM 1981	IGNITION SYSTEM
J90TLCNB 1982	IGNITION SYSTEM
J90TLCRD 1984	IGNITION SYSTEM
J90TLCTE 1983	IGNITION SYSTEM
J90TXCIH 1981	IGNITION SYSTEM
J90TXCIM 1981	IGNITION SYSTEM
J90TXCNB 1982	IGNITION SYSTEM
J90TXCRD 1984	IGNITION SYSTEM
J90TXCTE 1983	IGNITION SYSTEM