

Where Used: Part Number 0582453

Model Name	Diagram
E10ELCRA 1984	MAGNETO
E10ELCTC 1983	MAGNETO
E10RCRA 1984	MAGNETO
E10RCTC 1983	MAGNETO
E10RCTR 1983	MAGNETO
E10RLCRA 1984	MAGNETO
E10RLCTC 1983	MAGNETO
E10SELCRA 1984	MAGNETO
E10SELCTC 1983	MAGNETO
E15ECRM 1984	MAGNETO
E15ECTR 1983	MAGNETO
E15ELCRM 1984	MAGNETO
E15ELCTR 1983	MAGNETO
E15RCRM 1984	MAGNETO
E15RCTA 1983	MAGNETO
E15RCTR 1983	MAGNETO
E15RLCRM 1984	MAGNETO
E15RLCTA 1983	MAGNETO
E15RLCTR 1983	MAGNETO
E25ECSR 1984	IGNITION
E25ECTD 1983	MAGNETO
E25ELCRS 1984	IGNITION
E25ELCTD 1983	MAGNETO
E25RCRD 1984	IGNITION
E25RCTE 1983	MAGNETO
E25RLCRD 1984	IGNITION
E25RLCTE 1983	MAGNETO
E25TECRD 1984	IGNITION
E25TECTE 1983	MAGNETO
E25TELCRD 1984	IGNITION
E25TELCTE 1983	MAGNETO
E30ECRR 1984	IGNITION
E30ELCRR 1984	IGNITION

E35ECRR 1984	IGNITION
E35ECTS 1983	MAGNETO
E35ELCRR 1984	IGNITION
E35ELCTS 1983	MAGNETO
E35RCRR 1984	IGNITION
E35RCTS 1983	MAGNETO
E35RLCRR 1984	IGNITION
E35RLCTS 1983	MAGNETO
E35TELCRR 1984	IGNITION
E35TELCTS 1983	MAGNETO
E40ECRM 1984	IGNITION SYSTEM
E40ELCRM 1984	IGNITION SYSTEM
E40RCRM 1984	IGNITION SYSTEM
E40RLCRM 1984	IGNITION SYSTEM
E40TECRM 1984	IGNITION SYSTEM
E40TELCRM 1984	IGNITION SYSTEM
E50BECRM 1984	IGNITION SYSTEM
E50BECTA 1983	IGNITION SYSTEM
E50BELCRM 1984	IGNITION SYSTEM
E50BELCTA 1983	IGNITION SYSTEM
E50TELCRM 1984	IGNITION SYSTEM
E50TELCTA 1983	IGNITION SYSTEM
E50TLCRM 1984	IGNITION SYSTEM
E5RHCTA 1983	MAGNETO-4.5
E5RHCTA 1983	MAGNETO-7.5
E5RHLCTA 1983	MAGNETO-4.5
E5RHLCTA 1983	MAGNETO-7.5
E60ECTB 1983	IGNITION SYSTEM
E60ELCRE 1984	IGNITION SYSTEM
E60ELCTB 1983	IGNITION SYSTEM
E60TLCRE 1984	IGNITION SYSTEM
E60TLCTB 1983	IGNITION SYSTEM
E6RCRM 1984	MAGNETO - 6/8
E6RLCRM 1984	MAGNETO - 6/8
E6SLCRM 1984	MAGNETO - 6/8

E8RCRM 1984	MAGNETO - 6/8
E8RCTA 1983	MAGNETO-4.5
E8RCTA 1983	MAGNETO-7.5
E8RLCRM 1984	MAGNETO - 6/8
E8RLCTA 1983	MAGNETO-4.5
E8RLCTA 1983	MAGNETO-7.5
E8SRLCRM 1984	MAGNETO - 6/8
E8SRLCTA 1983	MAGNETO-4.5
E8SRLCTA 1983	MAGNETO-7.5
J10ELCRA 1984	MAGNETO
J10ELCTC 1983	MAGNETO
J10RCRA 1984	MAGNETO
J10RCTC 1983	MAGNETO
J10RCTR 1983	MAGNETO
J10RLCRA 1984	MAGNETO
J10RLCTC 1983	MAGNETO
J10RLCTR 1983	MAGNETO
J10SELCRA 1984	MAGNETO
J10SELCTC 1983	MAGNETO
J15ECRM 1984	MAGNETO
J15ECTR 1983	MAGNETO
J15ELCRM 1984	MAGNETO
J15ELCTR 1983	MAGNETO
J15RCRM 1984	MAGNETO
J15RCTA 1983	MAGNETO
J15RCTR 1983	MAGNETO
J15RLCRM 1984	MAGNETO
J15RLCTA 1983	MAGNETO
J15RLCTR 1983	MAGNETO
J25ECSR 1984	IGNITION
J25ECTD 1983	MAGNETO
J25ELCRS 1984	IGNITION
J25ELCTD 1983	MAGNETO
J25RCRD 1984	IGNITION
J25RCTE 1983	MAGNETO

J25RLCRD 1984	IGNITION
J25RLCTE 1983	MAGNETO
J25TECRD 1984	IGNITION
J25TECTE 1983	MAGNETO
J25TELCRD 1984	IGNITION
J25TELCTE 1983	MAGNETO
J30ECRR 1984	IGNITION
J30ELCRR 1984	IGNITION
J35ECRR 1984	IGNITION
J35ECTS 1983	MAGNETO
J35ELCRR 1984	IGNITION
J35ELCTS 1983	MAGNETO
J35RCRR 1984	IGNITION
J35RCTS 1983	MAGNETO
J35RLCRR 1984	IGNITION
J35RLCTS 1983	MAGNETO
J35TELCRR 1984	IGNITION
J35TELCTS 1983	MAGNETO
J40ECRM 1984	IGNITION SYSTEM
J40ELCRM 1984	IGNITION SYSTEM
J40RCRM 1984	IGNITION SYSTEM
J40RLCRM 1984	IGNITION SYSTEM
J40TECRM 1984	IGNITION SYSTEM
J40TELCRM 1984	IGNITION SYSTEM
J50BECRM 1984	IGNITION SYSTEM
J50BECTA 1983	IGNITION SYSTEM
J50BELCRM 1984	IGNITION SYSTEM
J50BELCTA 1983	IGNITION SYSTEM
J50TELCRM 1984	IGNITION SYSTEM
J50TELCTA 1983	IGNITION SYSTEM
J50TLCRM 1984	IGNITION SYSTEM
J5RHCTA 1983	MAGNETO-4.5
J5RHCTA 1983	MAGNETO-7.5
J5RHLCTA 1983	MAGNETO-4.5
J5RHLCTA 1983	MAGNETO-7.5

J60ECTB 1983	IGNITION SYSTEM
J60ELCRE 1984	IGNITION SYSTEM
J60ELCTB 1983	IGNITION SYSTEM
J60TLCRE 1984	IGNITION SYSTEM
J60TLCTB 1983	IGNITION SYSTEM
J6RCRM 1984	MAGNETO - 6/8
J6RLCRM 1984	MAGNETO - 6/8
J6SLCRM 1984	MAGNETO - 6/8
J8RCRM 1984	MAGNETO - 6/8
J8RCTA 1983	MAGNETO-4.5
J8RCTA 1983	MAGNETO-7.5
J8RLCRM 1984	MAGNETO - 6/8
J8RLCTA 1983	MAGNETO-4.5
J8RLCTA 1983	MAGNETO-7.5
J8SRLCRM 1984	MAGNETO - 6/8
J8SRLCTA 1983	MAGNETO-4.5
J8SRLCTA 1983	MAGNETO-7.5