

Where Used: Part Number 0584333

Model Name	Diagram
E10EEIR 1991	IGNITION
E10EENA 1992	IGNITION
E10ELEIR 1991	IGNITION
E10ELENA 1992	IGNITION
E10REIR 1991	IGNITION
E10RELEIR 1991	IGNITION
E10RELENA 1992	IGNITION
E10RENA 1992	IGNITION
E10RLEIR 1991	IGNITION
E10RLENA 1992	IGNITION
E10SELEIR 1991	IGNITION
E10SELENA 1992	IGNITION
E15EEIA 1991	IGNITION
E15EENM 1992	IGNITION
E15ELEIA 1991	IGNITION
E15ELENM 1992	IGNITION
E15REIA 1991	IGNITION
E15RELEIA 1991	IGNITION
E15RELENM 1992	IGNITION
E15RENM 1992	IGNITION
E15RLEIA 1991	IGNITION
E15RLENM 1992	IGNITION
E20CREIE 1991	IGNITION
E20CREND 1992	IGNITION
E20CRLEIE 1991	IGNITION
E20CRLEND 1992	IGNITION
E20EEIE 1991	IGNITION
E20EEND 1992	IGNITION
E20ELEIE 1991	IGNITION
E20ELEND 1992	IGNITION
E25EEID 1991	IGNITION
E25EENS 1992	IGNITION
E25ELEID 1991	IGNITION

E25ELEN 1992	IGNITION
E25REIE 1991	IGNITION
E25REND 1992	IGNITION
E25RLEIE 1991	IGNITION
E25RLEND 1992	IGNITION
E25RWEIM 1991	IGNITION
E25RWLEIM 1991	IGNITION
E25TEEIE 1991	IGNITION
E25TEEND 1992	IGNITION
E25TELEIE 1991	IGNITION
E25TELEND 1992	IGNITION
E28ESLEIB 1991	IGNITION
E28ESLENE 1992	IGNITION
E30EEIC 1991	IGNITION
E30EENR 1992	IGNITION
E30ELEIC 1991	IGNITION
E30ELENR 1992	IGNITION
E30REIC 1991	IGNITION
E30RENr 1992	IGNITION
E30RLEIC 1991	IGNITION
E30RLENr 1992	IGNITION
E30TEEIC 1991	IGNITION
E30TEENr 1992	IGNITION
E30TELEIC 1991	IGNITION
E30TELENr 1992	IGNITION
E35REIC 1991	IGNITION
E35RENr 1992	IGNITION
E35RLEIC 1991	IGNITION
E35RLENr 1992	IGNITION
E40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40EEIA 1991	IGNITION SYSTEM - ROPE START
E40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40EENJ 1992	IGNITION SYSTEM - ROPE START

E40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40EENM 1992	IGNITION SYSTEM - ROPE START
E40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40ELEIA 1991	IGNITION SYSTEM - ROPE START
E40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40ELENJ 1992	IGNITION SYSTEM - ROPE START
E40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40ELENM 1992	IGNITION SYSTEM - ROPE START
E40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40REIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40REIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40REIA 1991	IGNITION SYSTEM - ROPE START
E40RENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40RENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40RENM 1992	IGNITION SYSTEM - ROPE START
E40RETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40RLEIA 1991	IGNITION SYSTEM - ROPE START
E40RLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40RLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40RLENM 1992	IGNITION SYSTEM - ROPE START
E40RLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TEEIA 1991	IGNITION SYSTEM - ROPE START
E40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TEENJ 1992	IGNITION SYSTEM - ROPE START
E40TEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)

E40TEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TEENM 1992	IGNITION SYSTEM - ROPE START
E40TEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TELEIA 1991	IGNITION SYSTEM - ROPE START
E40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TELENJ 1992	IGNITION SYSTEM - ROPE START
E40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TELENM 1992	IGNITION SYSTEM - ROPE START
E40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TLEIA 1991	IGNITION SYSTEM - ROPE START
E40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TLENJ 1992	IGNITION SYSTEM - ROPE START
E40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TLENM 1992	IGNITION SYSTEM - ROPE START
E40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TTLEIA 1991	IGNITION SYSTEM - ROPE START
E40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TTLENM 1992	IGNITION SYSTEM - ROPE START
E40TTLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TTLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E45RCEIA 1991	IGNITION SYSTEM
E45RCENM 1992	IGNITION SYSTEM - ELECTRIC
E45RCLEIA 1991	IGNITION SYSTEM

E45RCLENM 1992	IGNITION SYSTEM - ELECTRIC
E45WMLEIA 1991	IGNITION SYSTEM
E45WMLENM 1992	IGNITION SYSTEM - ELECTRIC
E48ESLEIM 1991	IGNITION SYSTEM
E48ESLENB 1992	IGNITION SYSTEM
E48ESLETE 1993	IGNITION SYSTEM
E4RDHEIA 1991	IGNITION
E4RDHENM 1992	IGNITION
E4RDHETB 1993	IGNITION
E4RDHLEIA 1991	IGNITION
E4RDHLENM 1992	IGNITION
E4RDHLETB 1993	IGNITION
E50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50BEEIA 1991	IGNITION SYSTEM - ROPE START
E50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BEENJ 1992	IGNITION SYSTEM - ROPE START
E50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BEENM 1992	IGNITION SYSTEM - ROPE START
E50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50BELEIA 1991	IGNITION SYSTEM - ROPE START
E50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BELENJ 1992	IGNITION SYSTEM - ROPE START
E50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BELENM 1992	IGNITION SYSTEM - ROPE START
E50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50JEIA 1991	IGNITION SYSTEM - ROPE START

E50JENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50JENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50JENJ 1992	IGNITION SYSTEM - ROPE START
E50JENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50JENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50JENM 1992	IGNITION SYSTEM - ROPE START
E50JETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50RNLIB 1992	IGNITION SYSTEM
E50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TELEIA 1991	IGNITION SYSTEM - ROPE START
E50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50TELENM 1992	IGNITION SYSTEM - ROPE START
E50TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TLEIA 1991	IGNITION SYSTEM - ROPE START
E50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50TLENJ 1992	IGNITION SYSTEM - ROPE START
E50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50TLENM 1992	IGNITION SYSTEM - ROPE START
E50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E55RWLEIA 1991	IGNITION SYSTEM
E55RWLENM 1992	IGNITION SYSTEM - ELECTRIC
E6REIA 1991	IGNITION
E6RENM 1992	IGNITION
E6RLEIA 1991	IGNITION
E6RLENM 1992	IGNITION
E6SLEIA 1991	IGNITION
E6SLENM 1992	IGNITION
E8REIA 1991	IGNITION

E8RENM 1992	IGNITION
E8RLEIA 1991	IGNITION
E8RENM 1992	IGNITION
E8SRLEIA 1991	IGNITION
E8SRLENM 1992	IGNITION
J10EEIR 1991	IGNITION
J10EENA 1992	IGNITION
J10ELEIR 1991	IGNITION
J10ELENA 1992	IGNITION
J10REIR 1991	IGNITION
J10RELEIR 1991	IGNITION
J10RELENA 1992	IGNITION
J10RENA 1992	IGNITION
J10RLEIR 1991	IGNITION
J10RELENA 1992	IGNITION
J10SELEIR 1991	IGNITION
J10SELENA 1992	IGNITION
J15EEIA 1991	IGNITION
J15EENM 1992	IGNITION
J15ELEIA 1991	IGNITION
J15ELENM 1992	IGNITION
J15REIA 1991	IGNITION
J15RELEIA 1991	IGNITION
J15RELENM 1992	IGNITION
J15RENM 1992	IGNITION
J15RLEIA 1991	IGNITION
J15RLENM 1992	IGNITION
J20CREIE 1991	IGNITION
J20CREND 1992	IGNITION
J20CRLEIE 1991	IGNITION
J20CRLEND 1992	IGNITION
J20EEIE 1991	IGNITION
J20EEND 1992	IGNITION
J20ELEIE 1991	IGNITION
J20ELEND 1992	IGNITION

J25EEID 1991	IGNITION
J25EENS 1992	IGNITION
J25ELEID 1991	IGNITION
J25ELENS 1992	IGNITION
J25REIE 1991	IGNITION
J25REND 1992	IGNITION
J25RLEIE 1991	IGNITION
J25RLEND 1992	IGNITION
J25RWEIM 1991	IGNITION
J25RWLEIM 1991	IGNITION
J25TEEIE 1991	IGNITION
J25TEEND 1992	IGNITION
J25TELEIE 1991	IGNITION
J25TELEND 1992	IGNITION
J28ESLEIB 1991	IGNITION
J28ESLENE 1992	IGNITION
J30EEIC 1991	IGNITION
J30EENR 1992	IGNITION
J30ELEIC 1991	IGNITION
J30ELENR 1992	IGNITION
J30REIC 1991	IGNITION
J30RENr 1992	IGNITION
J30RLEIC 1991	IGNITION
J30RLENr 1992	IGNITION
J30TEEIC 1991	IGNITION
J30TEENr 1992	IGNITION
J30TELEIC 1991	IGNITION
J30TELENr 1992	IGNITION
J35REIC 1991	IGNITION
J35RENr 1992	IGNITION
J35RLEIC 1991	IGNITION
J35RLENr 1992	IGNITION
J40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40EEIA 1991	IGNITION SYSTEM - ROPE START

J40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40EENJ 1992	IGNITION SYSTEM - ROPE START
J40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40EENM 1992	IGNITION SYSTEM - ROPE START
J40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40ELEIA 1991	IGNITION SYSTEM - ROPE START
J40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40ELENJ 1992	IGNITION SYSTEM - ROPE START
J40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40ELENM 1992	IGNITION SYSTEM - ROPE START
J40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40REIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40REIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40REIA 1991	IGNITION SYSTEM - ROPE START
J40RENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40RENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40RENM 1992	IGNITION SYSTEM - ROPE START
J40RETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40RLEIA 1991	IGNITION SYSTEM - ROPE START
J40RLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40RLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40RLENM 1992	IGNITION SYSTEM - ROPE START
J40RLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TEEIA 1991	IGNITION SYSTEM - ROPE START
J40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)

J40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TEENJ 1992	IGNITION SYSTEM - ROPE START
J40TEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TEENM 1992	IGNITION SYSTEM - ROPE START
J40TEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TELEIA 1991	IGNITION SYSTEM - ROPE START
J40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TELENJ 1992	IGNITION SYSTEM - ROPE START
J40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TELENM 1992	IGNITION SYSTEM - ROPE START
J40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TLEIA 1991	IGNITION SYSTEM - ROPE START
J40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TLENJ 1992	IGNITION SYSTEM - ROPE START
J40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TLENM 1992	IGNITION SYSTEM - ROPE START
J40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TTLEIA 1991	IGNITION SYSTEM - ROPE START
J40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TTLENM 1992	IGNITION SYSTEM - ROPE START
J40TTLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TTLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

J45RCEIA 1991	IGNITION SYSTEM
J45RCENM 1992	IGNITION SYSTEM - ELECTRIC
J45RCLEIA 1991	IGNITION SYSTEM
J45RCLENM 1992	IGNITION SYSTEM - ELECTRIC
J45WMLEIA 1991	IGNITION SYSTEM
J45WMLENM 1992	IGNITION SYSTEM - ELECTRIC
J48ESLEIM 1991	IGNITION SYSTEM
J48ESLENB 1992	IGNITION SYSTEM
J48ESLETE 1993	IGNITION SYSTEM
J4RDHEIA 1991	IGNITION
J4RDHENM 1992	IGNITION
J4RDHETB 1993	IGNITION
J4RDHLEIA 1991	IGNITION
J4RDHLENM 1992	IGNITION
J4RDHLETB 1993	IGNITION
J50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50BEEIA 1991	IGNITION SYSTEM - ROPE START
J50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BEENJ 1992	IGNITION SYSTEM - ROPE START
J50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BEENM 1992	IGNITION SYSTEM - ROPE START
J50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50BELEIA 1991	IGNITION SYSTEM - ROPE START
J50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BELENJ 1992	IGNITION SYSTEM - ROPE START
J50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BELENM 1992	IGNITION SYSTEM - ROPE START
J50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

J50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50JEIA 1991	IGNITION SYSTEM - ROPE START
J50JENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50JENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50JENJ 1992	IGNITION SYSTEM - ROPE START
J50JENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50JENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50JENM 1992	IGNITION SYSTEM - ROPE START
J50JETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TELEIA 1991	IGNITION SYSTEM - ROPE START
J50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50TELENM 1992	IGNITION SYSTEM - ROPE START
J50TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TLEIA 1991	IGNITION SYSTEM - ROPE START
J50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50TLENJ 1992	IGNITION SYSTEM - ROPE START
J50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50TLENM 1992	IGNITION SYSTEM - ROPE START
J50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J55RWLEIA 1991	IGNITION SYSTEM
J55RWLENM 1992	IGNITION SYSTEM - ELECTRIC
J6REIA 1991	IGNITION
J6RENM 1992	IGNITION
J6RLEIA 1991	IGNITION
J6RLENM 1992	IGNITION
J6SLEIA 1991	IGNITION

J6SLENM 1992	IGNITION
J8REIA 1991	IGNITION
J8RENM 1992	IGNITION
J8RLEIA 1991	IGNITION
J8RLENM 1992	IGNITION
J8SRLEIA 1991	IGNITION
J8SRLENM 1992	IGNITION
TE10RELEIR 1991	IGNITION
TE10RELENA 1992	IGNITION
TE20CREND 1992	IGNITION
TE20CRLEIE 1991	IGNITION
TE20CRLEND 1992	IGNITION
TE25ELEID 1991	IGNITION
TE25ELENS 1992	IGNITION
TE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE40ELEIA 1991	IGNITION SYSTEM - ROPE START
TE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
TE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TE40ELENJ 1992	IGNITION SYSTEM - ROPE START
TE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
TE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TE40ELENM 1992	IGNITION SYSTEM - ROPE START
TE40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
TE48ESLETE 1993	IGNITION SYSTEM
TJ10RELEIR 1991	IGNITION
TJ10RELENA 1992	IGNITION
TJ20CREND 1992	IGNITION
TJ20CRLEIE 1991	IGNITION
TJ20CRLEND 1992	IGNITION
TJ25ELEID 1991	IGNITION
TJ25ELENS 1992	IGNITION
TJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40ELEIA 1991	IGNITION SYSTEM - ROPE START

TJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
TJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TJ40ELENJ 1992	IGNITION SYSTEM - ROPE START
TJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
TJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TJ40ELENM 1992	IGNITION SYSTEM - ROPE START
TJ40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
TJ48ESLETE 1993	IGNITION SYSTEM
VE25ELEID 1991	IGNITION
VE25ELENS 1992	IGNITION
VE25REIE 1991	IGNITION
VE30EEIC 1991	IGNITION
VE30EENR 1992	IGNITION
VE30ELEIC 1991	IGNITION
VE30ELENR 1992	IGNITION
VE40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40EEIA 1991	IGNITION SYSTEM - ROPE START
VE40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40EENJ 1992	IGNITION SYSTEM - ROPE START
VE40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40EENM 1992	IGNITION SYSTEM - ROPE START
VE40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40ELEIA 1991	IGNITION SYSTEM - ROPE START
VE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40ELENJ 1992	IGNITION SYSTEM - ROPE START
VE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40ELENM 1992	IGNITION SYSTEM - ROPE START
VE40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

VE40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40TELEIA 1991	IGNITION SYSTEM - ROPE START
VE40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TELENJ 1992	IGNITION SYSTEM - ROPE START
VE40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TELENM 1992	IGNITION SYSTEM - ROPE START
VE40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40TLEIA 1991	IGNITION SYSTEM - ROPE START
VE40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TLENJ 1992	IGNITION SYSTEM - ROPE START
VE40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TLENM 1992	IGNITION SYSTEM - ROPE START
VE40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE48ESLENB 1992	IGNITION SYSTEM
VE48ESLETE 1993	IGNITION SYSTEM
VE50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50BEEIA 1991	IGNITION SYSTEM - ROPE START
VE50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BEENJ 1992	IGNITION SYSTEM - ROPE START
VE50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BEENM 1992	IGNITION SYSTEM - ROPE START
VE50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS

VE50BELEIA 1991	IGNITION SYSTEM - ROPE START
VE50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BELENJ 1992	IGNITION SYSTEM - ROPE START
VE50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BELENM 1992	IGNITION SYSTEM - ROPE START
VE50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50TELENM 1992	IGNITION SYSTEM - ROPE START
VE50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50TLEIA 1991	IGNITION SYSTEM - ROPE START
VE50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50TLENJ 1992	IGNITION SYSTEM - ROPE START
VE50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50TLENM 1992	IGNITION SYSTEM - ROPE START
VE50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ25ELEID 1991	IGNITION
VJ25ELENS 1992	IGNITION
VJ25REIE 1991	IGNITION
VJ30EEIC 1991	IGNITION
VJ30EENR 1992	IGNITION
VJ30ELEIC 1991	IGNITION
VJ30ELENR 1992	IGNITION
VJ40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40EEIA 1991	IGNITION SYSTEM - ROPE START
VJ40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40EENJ 1992	IGNITION SYSTEM - ROPE START

VJ40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40EENM 1992	IGNITION SYSTEM - ROPE START
VJ40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40ELEIA 1991	IGNITION SYSTEM - ROPE START
VJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40ELENJ 1992	IGNITION SYSTEM - ROPE START
VJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40ELENM 1992	IGNITION SYSTEM - ROPE START
VJ40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40TELEIA 1991	IGNITION SYSTEM - ROPE START
VJ40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TELENJ 1992	IGNITION SYSTEM - ROPE START
VJ40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TELENM 1992	IGNITION SYSTEM - ROPE START
VJ40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40TLEIA 1991	IGNITION SYSTEM - ROPE START
VJ40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TLENJ 1992	IGNITION SYSTEM - ROPE START
VJ40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TLENM 1992	IGNITION SYSTEM - ROPE START
VJ40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

VJ48ESLENB 1992	IGNITION SYSTEM
VJ48ESLETE 1993	IGNITION SYSTEM
VJ50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BEEIA 1991	IGNITION SYSTEM - ROPE START
VJ50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BEENJ 1992	IGNITION SYSTEM - ROPE START
VJ50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BEENM 1992	IGNITION SYSTEM - ROPE START
VJ50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BELEIA 1991	IGNITION SYSTEM - ROPE START
VJ50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BELENJ 1992	IGNITION SYSTEM - ROPE START
VJ50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BELENM 1992	IGNITION SYSTEM - ROPE START
VJ50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50TELENM 1992	IGNITION SYSTEM - ROPE START
VJ50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50TLEIA 1991	IGNITION SYSTEM - ROPE START
VJ50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50TLENJ 1992	IGNITION SYSTEM - ROPE START
VJ50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50TLENM 1992	IGNITION SYSTEM - ROPE START
VJ50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

