

Where Used: Part Number 0584954

Model Name	Diagram
25/35HP (2 Stroke - 3 Cylinder)	AC LIGHTING KIT
9.9/15HP (4 Stroke - 305cc) 1995-2001	BATTERY CHARGING KIT
9.9/15HP (4 Stroke - 305cc) 1995-2001	TILLER ELECTRIC START KIT
9.9/15HP (4 Stroke - 305cc) 1995-2001	AC LIGHTING KIT
BE10FDLECM 1998	IGNITION -- ELECTRIC
BE10FDLECM 1998	IGNITION -- ROPE
BE10FDLEDR 1996	IGNITION - ELECTRIC START
BE10FDLEUA 1997	IGNITION - ELECTRIC
BE10FPXEDC 1996	IGNITION - ELECTRIC START
BE10FPXEUR 1997	IGNITION - ELECTRIC
BE10FREldr 1996	IGNITION - ELECTRIC START
BE10FRELUa 1997	IGNITION - ELECTRIC
BE15FAEDR 1996	IGNITION - ELECTRIC START
BE15FAEUa 1997	IGNITION - ELECTRIC
BE15FDLECM 1998	IGNITION -- ELECTRIC
BE15FDLECM 1998	IGNITION -- ROPE
BE15FDLEDR 1996	IGNITION - ELECTRIC START
BE15FDLEUA 1997	IGNITION - ELECTRIC
BE15FKEDR 1996	IGNITION - ELECTRIC START
BE15FKEUA 1997	IGNITION - ELECTRIC
BE15FREDR 1996	IGNITION - ELECTRIC START
BE15FRELEDR 1996	IGNITION - ELECTRIC START
BE15FRELUa 1997	IGNITION - ELECTRIC
BE15FREUA 1997	IGNITION - ELECTRIC
BE15FWECA 1998	IGNITION -- ELECTRIC
BE15FWECA 1998	IGNITION -- ROPE
BE15FWEDC 1996	IGNITION - ELECTRIC START
BE15FWEUR 1997	IGNITION - ELECTRIC
BE15FWLECA 1998	IGNITION -- ELECTRIC
BE15FWLECA 1998	IGNITION -- ROPE
BE15FWLEDC 1996	IGNITION - ELECTRIC START
BE15FWLEUR 1997	IGNITION - ELECTRIC
BE25ARECA 1998	IGNITION SYSTEM -- ROPE/AC

BE25AREDC 1996	IGNITION SYSTEM - ROPE & AC
BE25AREUR 1997	IGNITION SYSTEM - ROPE & AC
BE25ARLECA 1998	IGNITION SYSTEM -- ROPE/AC
BE25ARLEDC 1996	IGNITION SYSTEM - ROPE & AC
BE25ARLEUR 1997	IGNITION SYSTEM - ROPE & AC
BE25KECA 1998	IGNITION SYSTEM -- ROPE/AC
BE25KEDC 1996	IGNITION SYSTEM - ROPE & AC
BE25KEUR 1997	IGNITION SYSTEM - ROPE & AC
BE25KLECA 1998	IGNITION SYSTEM -- ROPE/AC
BE25KLEDC 1996	IGNITION SYSTEM - ROPE & AC
BE25KLEUR 1997	IGNITION SYSTEM - ROPE & AC
BE25QLECA 1998	IGNITION SYSTEM -- ROPE/AC
BE25QLEDC 1996	IGNITION SYSTEM - ROPE & AC
BE25QLEUR 1997	IGNITION SYSTEM - ROPE & AC
BE35ARECR 1998	IGNITION SYSTEM -- ROPE/AC
BE35AREDS 1996	IGNITION SYSTEM - ROPE & AC
BE35AREEA 1999	IGNITION SYSTEM -- R, RL
BE35AREUC 1997	IGNITION SYSTEM - ROPE & AC
BE35ARLECR 1998	IGNITION SYSTEM -- ROPE/AC
BE35ARLEDS 1996	IGNITION SYSTEM - ROPE & AC
BE35ARLEUC 1997	IGNITION SYSTEM - ROPE & AC
BE35ARSIB rope start, tiller, 15 in shaft, wht, n/a usa 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
BE35ARSSM 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - A, R, RL
BE35KECA 1998	IGNITION SYSTEM -- ROPE/AC
BE35KEDC 1996	IGNITION SYSTEM - ROPE & AC
BE35KEEM 1999	IGNITION SYSTEM -- R, RL
BE35KEUR 1997	IGNITION SYSTEM - ROPE & AC
BE35KLECA 1998	IGNITION SYSTEM -- ROPE/AC
BE35KLEDC 1996	IGNITION SYSTEM - ROPE & AC
BE35KLEUR 1997	IGNITION SYSTEM - ROPE & AC
BE35KSIE elec start, tiller, 15 in shaft, wht, n/a usa 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
BE35KSSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - A, R, RL
BE35QLECA 1998	IGNITION SYSTEM -- ROPE/AC
BE35QLEDC 1996	IGNITION SYSTEM - ROPE & AC

BE35QLEUR 1997	IGNITION SYSTEM - ROPE & AC
BJ10FDLECM 1998	IGNITION -- ELECTRIC
BJ10FDLECM 1998	IGNITION -- ROPE
BJ10FDLEDR 1996	IGNITION - ELECTRIC START
BJ10FDLEUA 1997	IGNITION - ELECTRIC
BJ10FPXEDC 1996	IGNITION - ELECTRIC START
BJ10FPXEUR 1997	IGNITION - ELECTRIC
BJ10FRELEDR 1996	IGNITION - ELECTRIC START
BJ10FRELUA 1997	IGNITION - ELECTRIC
BJ15FAEDR 1996	IGNITION - ELECTRIC START
BJ15FAEUA 1997	IGNITION - ELECTRIC
BJ15FDLECM 1998	IGNITION -- ELECTRIC
BJ15FDLECM 1998	IGNITION -- ROPE
BJ15FDLEDR 1996	IGNITION - ELECTRIC START
BJ15FDLEUA 1997	IGNITION - ELECTRIC
BJ15FKEDR 1996	IGNITION - ELECTRIC START
BJ15FKEUA 1997	IGNITION - ELECTRIC
BJ15FREDR 1996	IGNITION - ELECTRIC START
BJ15FRELEDR 1996	IGNITION - ELECTRIC START
BJ15FRELUA 1997	IGNITION - ELECTRIC
BJ15FREUA 1997	IGNITION - ELECTRIC
BJ15FWECA 1998	IGNITION -- ELECTRIC
BJ15FWECA 1998	IGNITION -- ROPE
BJ15FWEDC 1996	IGNITION - ELECTRIC START
BJ15FWEUR 1997	IGNITION - ELECTRIC
BJ15FWLECA 1998	IGNITION -- ELECTRIC
BJ15FWLECA 1998	IGNITION -- ROPE
BJ15FWLEDC 1996	IGNITION - ELECTRIC START
BJ15FWLEUR 1997	IGNITION - ELECTRIC
BJ25ARECA 1998	IGNITION SYSTEM -- ROPE/AC
BJ25AREDC 1996	IGNITION SYSTEM - ROPE & AC
BJ25AREUR 1997	IGNITION SYSTEM - ROPE & AC
BJ25ARLECA 1998	IGNITION SYSTEM -- ROPE/AC
BJ25ARLEDC 1996	IGNITION SYSTEM - ROPE & AC
BJ25ARLEUR 1997	IGNITION SYSTEM - ROPE & AC

BJ25KECA 1998	IGNITION SYSTEM -- ROPE/AC
BJ25KEDC 1996	IGNITION SYSTEM - ROPE & AC
BJ25KEUR 1997	IGNITION SYSTEM - ROPE & AC
BJ25KLECA 1998	IGNITION SYSTEM -- ROPE/AC
BJ25KLEDC 1996	IGNITION SYSTEM - ROPE & AC
BJ25KLEUR 1997	IGNITION SYSTEM - ROPE & AC
BJ25PL3EEM 1999	IGNITION SYSTEM -- R, RL
BJ25PL3SIE elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
BJ25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - A, R, RL
BJ25QLECA 1998	IGNITION SYSTEM -- ROPE/AC
BJ25QLEDC 1996	IGNITION SYSTEM - ROPE & AC
BJ25QLEUR 1997	IGNITION SYSTEM - ROPE & AC
BJ25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
BJ35ARECR 1998	IGNITION SYSTEM -- ROPE/AC
BJ35AREDS 1996	IGNITION SYSTEM - ROPE & AC
BJ35AREEA 1999	IGNITION SYSTEM -- R, RL
BJ35AREUC 1997	IGNITION SYSTEM - ROPE & AC
BJ35ARLECR 1998	IGNITION SYSTEM -- ROPE/AC
BJ35ARLEDS 1996	IGNITION SYSTEM - ROPE & AC
BJ35ARLEUC 1997	IGNITION SYSTEM - ROPE & AC
BJ35E3EEM 1999	IGNITION SYSTEM -- R, RL
BJ35E3SIE elec start, 15 in shaft, n/a usa 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
BJ35E3SSB 3 Cyl, Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - A, R, RL
BJ35EL3EEM 1999	IGNITION SYSTEM -- R, RL
BJ35EL3SIE elec start, 20 in shaft, wht, n/a usa 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
BJ35EL3SSB 3 Cyl, Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - A, R, RL
BJ35EV3SIE elec start, 15 in shaft, wht, n/a usa 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
BJ35EVL3SIE elec start, 20 in shaft, wht, n/a usa 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
BJ35KECA 1998	IGNITION SYSTEM -- ROPE/AC
BJ35KEDC 1996	IGNITION SYSTEM - ROPE & AC
BJ35KEEM 1999	IGNITION SYSTEM -- R, RL
BJ35KEUR 1997	IGNITION SYSTEM - ROPE & AC
BJ35KLECA 1998	IGNITION SYSTEM -- ROPE/AC
BJ35KLEDC 1996	IGNITION SYSTEM - ROPE & AC

BJ35KLEUR 1997	IGNITION SYSTEM - ROPE & AC
BJ35PL3EEM 1999	IGNITION SYSTEM -- R, RL
BJ35PL3SIE elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
BJ35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - A, R, RL
BJ35QLECA 1998	IGNITION SYSTEM -- ROPE/AC
BJ35QLEDC 1996	IGNITION SYSTEM - ROPE & AC
BJ35QLEUR 1997	IGNITION SYSTEM - ROPE & AC
BJ35VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
E10EBL4EEB 1999	IGNITION -- ROPE
E10EBL4EEB 1999	IGNITION -- ELECTRIC
E10EL4EEB 1999	IGNITION -- ROPE
E10EL4EEB 1999	IGNITION -- ELECTRIC
E10EL4SID 4-stroke, elec start, remote, 20 in shaft 2001	IGNITION - ROPE
E10EL4SID 4-stroke, elec start, remote, 20 in shaft 2001	IGNITION - ELECTRIC
E10EL4SSE 4-Stroke, Elec. Start, 20 IN shaft 2000	IGNITION - ROPE
E10EL4SSE 4-Stroke, Elec. Start, 20 IN shaft 2000	IGNITION - ELECTRIC
E10EVL4SIC 4-stroke, elec start, 20 in shaft, wht 2001	IGNITION - ROPE
E10EVL4SIC 4-stroke, elec start, 20 in shaft, wht 2001	IGNITION - ELECTRIC
E10EVL4SSS 4-Stroke, Elec. Start, 20 IN shaft, wht 2000	IGNITION - ROPE
E10EVL4SSS 4-Stroke, Elec. Start, 20 IN shaft, wht 2000	IGNITION - ELECTRIC
E10FEXECM 1998	IGNITION -- ELECTRIC
E10FEXECM 1998	IGNITION -- ROPE
E10FEXEDR 1996	IGNITION - ELECTRIC START
E10FEXEUA 1997	IGNITION - ELECTRIC
E10FRECM 1998	IGNITION -- ELECTRIC
E10FRECM 1998	IGNITION -- ROPE
E10FREDR 1996	IGNITION - ELECTRIC START
E10FRELECM 1998	IGNITION -- ELECTRIC
E10FRELECM 1998	IGNITION -- ROPE
E10FRELEDR 1996	IGNITION - ELECTRIC START
E10FRELEUA 1997	IGNITION - ELECTRIC
E10FREUA 1997	IGNITION - ELECTRIC
E10FRLECM 1998	IGNITION -- ELECTRIC
E10FRLECM 1998	IGNITION -- ROPE

E10FRLEDR 1996	IGNITION - ELECTRIC START
E10FRLEUA 1997	IGNITION - ELECTRIC
E10R4EEB 1999	IGNITION -- ROPE
E10R4EEB 1999	IGNITION -- ELECTRIC
E10R4SID 4-stroke, rope start, tiller, 15 in shaft 2001	IGNITION - ROPE
E10R4SID 4-stroke, rope start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
E10R4SSE 4-Stroke, Rope Start, Tiller, 15 IN shaft 2000	IGNITION - ROPE
E10R4SSE 4-Stroke, Rope Start, Tiller, 15 IN shaft 2000	IGNITION - ELECTRIC
E10RL4EEB 1999	IGNITION -- ROPE
E10RL4EEB 1999	IGNITION -- ELECTRIC
E10RL4SID 4-stroke, rope start, tiller, 20 in shaft 2001	IGNITION - ROPE
E10RL4SID 4-stroke, rope start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
E10RL4SSE 4-Stroke, Rope Start, Tiller, 20 IN shaft 2000	IGNITION - ROPE
E10RL4SSE 4-Stroke, Rope Start, Tiller, 20 IN shaft 2000	IGNITION - ELECTRIC
E10RV4SIC 4-stroke, rope start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
E10RV4SIC 4-stroke, rope start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
E10RV4SSS 4-Stroke, Rope Start, Tiller, 15 IN shaft, wht 2000	IGNITION - ROPE
E10RV4SSS 4-Stroke, Rope Start, Tiller, 15 IN shaft, wht 2000	IGNITION - ELECTRIC
E10RVL4SIC 4-stroke, rope start, tiller, 20 in shaft, wht 2001	IGNITION - ROPE
E10RVL4SIC 4-stroke, rope start, tiller, 20 in shaft, wht 2001	IGNITION - ELECTRIC
E10RVL4SSS 4-Stroke, Rope Start, Tiller, 20 IN shaft, wht 2000	IGNITION - ROPE
E10RVL4SSS 4-Stroke, Rope Start, Tiller, 20 IN shaft, wht 2000	IGNITION - ELECTRIC
E10TEX4EEB 1999	IGNITION -- ROPE
E10TEX4EEB 1999	IGNITION -- ELECTRIC
E10TEX4SID 4-stroke, elec start, tiller, 25 in shaft 2001	IGNITION - ROPE
E10TEX4SID 4-stroke, elec start, tiller, 25 in shaft 2001	IGNITION - ELECTRIC
E10TEX4SSE 4-Stroke, Elec. Start, Tiller, 25 IN shaft 2000	IGNITION - ROPE
E10TEX4SSE 4-Stroke, Elec. Start, Tiller, 25 IN shaft 2000	IGNITION - ELECTRIC
E10TVX4SIC 4-stroke, elec start, tiller, 25 in shaft, wht 2001	IGNITION - ROPE
E10TVX4SIC 4-stroke, elec start, tiller, 25 in shaft, wht 2001	IGNITION - ELECTRIC
E10TVX4SSS 4-Stroke, Elec. Start, Tiller, 25 IN shaft, wht 2000	IGNITION - ROPE
E10TVX4SSS 4-Stroke, Elec. Start, Tiller, 25 IN shaft, wht 2000	IGNITION - ELECTRIC
E15EBL4EEB 1999	IGNITION -- ROPE
E15EBL4EEB 1999	IGNITION -- ELECTRIC
E15EL4EEB 1999	IGNITION -- ROPE

E15EL4EEB 1999	IGNITION -- ELECTRIC
E15EL4SID 4-stroke, elec start, 20 in shaft 2001	IGNITION - ROPE
E15EL4SID 4-stroke, elec start, 20 in shaft 2001	IGNITION - ELECTRIC
E15EL4SSE 4-Stroke, Elec. Start, 20 IN shaft 2000	IGNITION - ROPE
E15EL4SSE 4-Stroke, Elec. Start, 20 IN shaft 2000	IGNITION - ELECTRIC
E15EVL4SIC 4-stroke, elec start, 20 in shaft, wht 2001	IGNITION - ROPE
E15EVL4SIC 4-stroke, elec start, 20 in shaft, wht 2001	IGNITION - ELECTRIC
E15EVL4SSS 4-Stroke, Elec. Start, 20 IN shaft, wht 2000	IGNITION - ROPE
E15EVL4SSS 4-Stroke, Elec. Start, 20 IN shaft, wht 2000	IGNITION - ELECTRIC
E15FKEDR 1996	IGNITION - ELECTRIC START
E15FKEUA 1997	IGNITION - ELECTRIC
E15FRECM 1998	IGNITION -- ELECTRIC
E15FRECM 1998	IGNITION -- ROPE
E15FREDR 1996	IGNITION - ELECTRIC START
E15FRELECM 1998	IGNITION -- ELECTRIC
E15FRELECM 1998	IGNITION -- ROPE
E15FRELEDR 1996	IGNITION - ELECTRIC START
E15FRELEUA 1997	IGNITION - ELECTRIC
E15FREUA 1997	IGNITION - ELECTRIC
E15FRLECM 1998	IGNITION -- ELECTRIC
E15FRLECM 1998	IGNITION -- ROPE
E15FRLEDR 1996	IGNITION - ELECTRIC START
E15FRLEUA 1997	IGNITION - ELECTRIC
E15R4EEB 1999	IGNITION -- ROPE
E15R4EEB 1999	IGNITION -- ELECTRIC
E15R4SID 4-stroke, rope start, 15 in shaft 2001	IGNITION - ROPE
E15R4SID 4-stroke, rope start, 15 in shaft 2001	IGNITION - ELECTRIC
E15R4SSE 4-Stroke, Rope Start, Tiller, 15 IN shaft 2000	IGNITION - ROPE
E15R4SSE 4-Stroke, Rope Start, Tiller, 15 IN shaft 2000	IGNITION - ELECTRIC
E15RB4EEB 1999	IGNITION -- ROPE
E15RB4EEB 1999	IGNITION -- ELECTRIC
E15RBL4EEB 1999	IGNITION -- ROPE
E15RBL4EEB 1999	IGNITION -- ELECTRIC
E15RL4EEB 1999	IGNITION -- ROPE
E15RL4EEB 1999	IGNITION -- ELECTRIC

E15RL4SID 4-stroke, rope start, 20 in shaft 2001	IGNITION - ROPE
E15RL4SID 4-stroke, rope start, 20 in shaft 2001	IGNITION - ELECTRIC
E15RL4SSE 4-Stroke, Rope Start, Tiller, 20 IN shaft 2000	IGNITION - ROPE
E15RL4SSE 4-Stroke, Rope Start, Tiller, 20 IN shaft 2000	IGNITION - ELECTRIC
E15RV4SIC 4-stroke,rope start, 15 in shaft, wht 2001	IGNITION - ROPE
E15RV4SIC 4-stroke,rope start, 15 in shaft, wht 2001	IGNITION - ELECTRIC
E15RV4SSS 4-Stroke, Rope Start, Tiller, 15 IN shaft, wht 2000	IGNITION - ROPE
E15RV4SSS 4-Stroke, Rope Start, Tiller, 15 IN shaft, wht 2000	IGNITION - ELECTRIC
E15RVL4SIC 4-stroke, elec start, 15 in shaft, wht 2001	IGNITION - ROPE
E15RVL4SIC 4-stroke, elec start, 15 in shaft, wht 2001	IGNITION - ELECTRIC
E15RVL4SSS 4-Stroke, Rope Start, Tiller, 20 IN shaft, wht 2000	IGNITION - ROPE
E15RVL4SSS 4-Stroke, Rope Start, Tiller, 20 IN shaft, wht 2000	IGNITION - ELECTRIC
E25KLECA 1998	IGNITION SYSTEM -- ROPE/AC
E25KLEDC 1996	IGNITION SYSTEM - ROPE & AC
E25KLEUR 1997	IGNITION SYSTEM - ROPE & AC
E25QLECA 1998	IGNITION SYSTEM -- ROPE/AC
E25QLEDC 1996	IGNITION SYSTEM - ROPE & AC
E25QLEUR 1997	IGNITION SYSTEM - ROPE & AC
E25RMECA 1998	IGNITION SYSTEM -- ROPE/AC
E25RMEDC 1996	IGNITION SYSTEM - ROPE & AC
E25RMEUR 1997	IGNITION SYSTEM - ROPE & AC
E25RMLECA 1998	IGNITION SYSTEM -- ROPE/AC
E25RMLEDC 1996	IGNITION SYSTEM - ROPE & AC
E25RMLEUR 1997	IGNITION SYSTEM - ROPE & AC
E25TKECA 1998	IGNITION SYSTEM -- ROPE/AC
E25TKEDC 1996	IGNITION SYSTEM - ROPE & AC
E25TKEUR 1997	IGNITION SYSTEM - ROPE & AC
E25TKLECA 1998	IGNITION SYSTEM -- ROPE/AC
E25TKLEDC 1996	IGNITION SYSTEM - ROPE & AC
E25TKLEUR 1997	IGNITION SYSTEM - ROPE & AC
E35KLECA 1998	IGNITION SYSTEM -- ROPE/AC
E35KLEDC 1996	IGNITION SYSTEM - ROPE & AC
E35KLEUR 1997	IGNITION SYSTEM - ROPE & AC
E35QLECA 1998	IGNITION SYSTEM -- ROPE/AC
E35QLEDC 1996	IGNITION SYSTEM - ROPE & AC

E35QLEUR 1997	IGNITION SYSTEM - ROPE & AC
E35RMLEDC 1996	IGNITION SYSTEM - ROPE & AC
E35RMLEUR 1997	IGNITION SYSTEM - ROPE & AC
E35TKLECA 1998	IGNITION SYSTEM -- ROPE/AC
E35TKLEDC 1996	IGNITION SYSTEM - ROPE & AC
E35TKLEUR 1997	IGNITION SYSTEM - ROPE & AC
ELECTRICAL 1995	AC LIGHTING KIT - 4-STROKE 9.9, 15 & 25, 35 (3-CYLINDER)
ELECTRICAL 1995	BATTERY CHARGE KIT - 4-STROKE 9.9/15
ELECTRICAL 1995	TILLER ELECTRIC START KIT - 4-STROKE 9.9, 15
ELECTRICAL 1996	AC LIGHTING KIT - 9.9, 15 (4-STROKE) & 25, 35 (3-CYLINDER)
ELECTRICAL 1996	BATTERY CHARGE KIT - 9.9, 15 (4-STROKE)
ELECTRICAL 1996	TILLER ELECTRIC START KIT - 9.9, 15 (4-STROKE)
ELECTRICAL 1997	AC LIGHTING KIT - 9.9, 15 (4-STROKE) & 25, 35 (3-CYLINDER)
ELECTRICAL 1997	BATTERY CHARGE KIT - 9.9, 15 (4-STROKE)
ELECTRICAL 1997	TILLER ELECTRIC START KIT - 9.9, 15 (4-STROKE)
ELECTRICAL 1998	AC LIGHTING KIT -- 9.9, 15 (4-STROKE) & 25, 35 (3-CYLINDER)
ELECTRICAL 1998	BATTERY CHARGE KIT -- 9.9, 15 (4-STROKE)
ELECTRICAL 1998	TILLER ELECTRIC START KIT -- 9.9, 15 (4-STROKE)
ELECTRICAL 1999	BATTERY CHARGE KIT -- 9.9, 15 (4-STROKE)
ELECTRICAL 1999	TILLER ELECTRIC START KIT -- 9.9, 15 (4-STROKE)
ELECTRICAL 2000	BATTERY CHARGE KIT - 9.9, 15 (4-STROKE)
ELECTRICAL 2000	TILLER ELECTRIC STARTING KIT - 9.9, 15 (4-STROKE)
HE35RMLEDC 1996	IGNITION SYSTEM - ROPE & AC
HE35RMLEUR 1997	IGNITION SYSTEM - ROPE & AC
HJ35RMLEDC 1996	IGNITION SYSTEM - ROPE & AC
HJ35RMLEUR 1997	IGNITION SYSTEM - ROPE & AC
J10FEXECM 1998	IGNITION -- ELECTRIC
J10FEXECM 1998	IGNITION -- ROPE
J10FEXEDR 1996	IGNITION - ELECTRIC START
J10FEXEUA 1997	IGNITION - ELECTRIC
J10FRECM 1998	IGNITION -- ELECTRIC
J10FRECM 1998	IGNITION -- ROPE
J10FREDR 1996	IGNITION - ELECTRIC START

J10FRELECM 1998	IGNITION -- ELECTRIC
J10FRELECM 1998	IGNITION -- ROPE
J10FRELEDR 1996	IGNITION - ELECTRIC START
J10FRELEUA 1997	IGNITION - ELECTRIC
J10FREUA 1997	IGNITION - ELECTRIC
J10FRLECM 1998	IGNITION -- ELECTRIC
J10FRLECM 1998	IGNITION -- ROPE
J10FRLEDR 1996	IGNITION - ELECTRIC START
J10FRLEUA 1997	IGNITION - ELECTRIC
J15FKEDR 1996	IGNITION - ELECTRIC START
J15FKEUA 1997	IGNITION - ELECTRIC
J15FRECM 1998	IGNITION -- ELECTRIC
J15FRECM 1998	IGNITION -- ROPE
J15FREDR 1996	IGNITION - ELECTRIC START
J15FRELECM 1998	IGNITION -- ELECTRIC
J15FRELECM 1998	IGNITION -- ROPE
J15FRELEDR 1996	IGNITION - ELECTRIC START
J15FRELEUA 1997	IGNITION - ELECTRIC
J15FREUA 1997	IGNITION - ELECTRIC
J15FRLECM 1998	IGNITION -- ELECTRIC
J15FRLECM 1998	IGNITION -- ROPE
J15FRLEDR 1996	IGNITION - ELECTRIC START
J15FRLEUA 1997	IGNITION - ELECTRIC
J25KLECA 1998	IGNITION SYSTEM -- ROPE/AC
J25KLEDC 1996	IGNITION SYSTEM - ROPE & AC
J25KLEUR 1997	IGNITION SYSTEM - ROPE & AC
J25PL3EEM 1999	IGNITION SYSTEM -- R, RL
J25PL3SIE elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
J25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM - A, R, RL
J25QLECA 1998	IGNITION SYSTEM -- ROPE/AC
J25QLEDC 1996	IGNITION SYSTEM - ROPE & AC
J25QLEUR 1997	IGNITION SYSTEM - ROPE & AC
J25R3EEM 1999	IGNITION SYSTEM -- R, RL
J25R3SIE rope start, tiller, 15 in shaft 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
J25R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM - A, R, RL

J25RL3EEM 1999	IGNITION SYSTEM -- R, RL
J25RL3SIE rope start, tiller, 20 in shaft 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
J25RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - A, R, RL
J25RMECA 1998	IGNITION SYSTEM -- ROPE/AC
J25RMEDC 1996	IGNITION SYSTEM - ROPE & AC
J25RMEUR 1997	IGNITION SYSTEM - ROPE & AC
J25RMLECA 1998	IGNITION SYSTEM -- ROPE/AC
J25RMLEDC 1996	IGNITION SYSTEM - ROPE & AC
J25RMLEUR 1997	IGNITION SYSTEM - ROPE & AC
J25RV3SIE rope start, tiller, 15 in shaft, wht, n/a usa 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
J25RVL3SIE rope start, tiller, 20 in shaft, wht 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
J25TEL3EEM 1999	IGNITION SYSTEM -- R, RL
J25TEL3SIE elec start, tiller, 20 in shaft 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
J25TEL3SSB 3 Cyl, Elec. Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - A, R, RL
J25TKECA 1998	IGNITION SYSTEM -- ROPE/AC
J25TKEDC 1996	IGNITION SYSTEM - ROPE & AC
J25TKEUR 1997	IGNITION SYSTEM - ROPE & AC
J25TKLECA 1998	IGNITION SYSTEM -- ROPE/AC
J25TKLEDC 1996	IGNITION SYSTEM - ROPE & AC
J25TKLEUR 1997	IGNITION SYSTEM - ROPE & AC
J25TVL3SIE elec start, tiller, 20 in shaft, wht 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
J25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
J35E3EEM 1999	IGNITION SYSTEM -- R, RL
J35EL3EEM 1999	IGNITION SYSTEM -- R, RL
J35KLECA 1998	IGNITION SYSTEM -- ROPE/AC
J35KLEDC 1996	IGNITION SYSTEM - ROPE & AC
J35KLEUR 1997	IGNITION SYSTEM - ROPE & AC
J35PL3EEM 1999	IGNITION SYSTEM -- R, RL
J35PL3SIE elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
J35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM - A, R, RL
J35QLECA 1998	IGNITION SYSTEM -- ROPE/AC
J35QLEDC 1996	IGNITION SYSTEM - ROPE & AC
J35QLEUR 1997	IGNITION SYSTEM - ROPE & AC
J35R3EEM 1999	IGNITION SYSTEM -- R, RL
J35R3SIE rope start, tiller, 15 in shaft 2001	IGNITION SYSTEM - A, R,RL,RV,RVL

J35R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM - A, R, RL
J35RL3EEM 1999	IGNITION SYSTEM -- R, RL
J35RL3SIE rope start, tiller, 20 in shaft 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
J35RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - A, R, RL
J35RMLEDC 1996	IGNITION SYSTEM - ROPE & AC
J35RMLEUR 1997	IGNITION SYSTEM - ROPE & AC
J35RV3SIE rope start, 15 in shaft, wht 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
J35RVL3SIE rope start, 20 in shaft, wht 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
J35TEL3EEM 1999	IGNITION SYSTEM -- R, RL
J35TEL3SIE elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
J35TEL3SSB 3 Cyl, Elec. Start, TNT, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - A, R, RL
J35TKLECA 1998	IGNITION SYSTEM -- ROPE/AC
J35TKLEDC 1996	IGNITION SYSTEM - ROPE & AC
J35TKLEUR 1997	IGNITION SYSTEM - ROPE & AC
J35TVL3SIE elec start, tiller, 20 in shaft, wht 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
J35VL3SIE elec start, TNT, 20 in shaft, wht 2001	IGNITION SYSTEM - A, R,RL,RV,RVL
L10FRELECM 1998	IGNITION -- ELECTRIC
L10FRELECM 1998	IGNITION -- ROPE
L10FRELEDR 1996	IGNITION - ELECTRIC START
L10FRELEUA 1997	IGNITION - ELECTRIC
SE35RWECs 1998	IGNITION SYSTEM
SE35RWLECS 1998	IGNITION SYSTEM
SJ35RWECs 1998	IGNITION SYSTEM
SJ35RWLECS 1998	IGNITION SYSTEM