

Where Used: Part Number 0585146

Model Name	Diagram
40/50HP (2 Stroke)	POWER TRIM/TILT KIT (Early Style)
65HP (2 Stroke - 3 CYLINDER)	POWER TRIM/TILT ELECTRICAL - 65 MODELS
BE115TLEDA 1996	POWER TRIM/TILT ELECTRICAL
BE130TLECE 1998	IGNITION SYSTEM
BE130TLEDM 1996	IGNITION SYSTEM
BE130TLEUB 1997	IGNITION SYSTEM
BE25ARECA 1998	POWER TRIM/TILT ELECTRICAL
BE25AREDC 1996	POWER TRIM/TILT ELECTRICAL
BE25AREUR 1997	POWER TRIM/TILT ELECTRICAL
BE25ARLECA 1998	POWER TRIM/TILT ELECTRICAL
BE25ARLEDC 1996	POWER TRIM/TILT ELECTRICAL
BE25ARLEUR 1997	POWER TRIM/TILT ELECTRICAL
BE25KECA 1998	POWER TRIM/TILT ELECTRICAL
BE25KEDC 1996	POWER TRIM/TILT ELECTRICAL
BE25KEUR 1997	POWER TRIM/TILT ELECTRICAL
BE25KLECA 1998	POWER TRIM/TILT ELECTRICAL
BE25KLEDC 1996	POWER TRIM/TILT ELECTRICAL
BE25KLEUR 1997	POWER TRIM/TILT ELECTRICAL
BE25QLECA 1998	POWER TRIM/TILT ELECTRICAL
BE25QLEDC 1996	POWER TRIM/TILT ELECTRICAL
BE25QLEUR 1997	POWER TRIM/TILT ELECTRICAL
BE35ARECR 1998	POWER TRIM/TILT ELECTRICAL
BE35AREDS 1996	POWER TRIM/TILT ELECTRICAL
BE35AREEA 1999	POWER TRIM/TILT ELECTRICAL
BE35AREUC 1997	POWER TRIM/TILT ELECTRICAL
BE35ARLECR 1998	POWER TRIM/TILT ELECTRICAL
BE35ARLEDS 1996	POWER TRIM/TILT ELECTRICAL
BE35ARLEUC 1997	POWER TRIM/TILT ELECTRICAL
BE35ARSIB rope start, tiller, 15 in shaft, wht, n/a usa 2001	POWER TRIM/TILT ELECTRICAL
BE35ARSSM 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	POWER TRIM AND TILT - ELECTRICAL
BE35KECA 1998	POWER TRIM/TILT ELECTRICAL
BE35KEDC 1996	POWER TRIM/TILT ELECTRICAL
BE35KEEM 1999	POWER TRIM/TILT ELECTRICAL

BE35KEUR 1997	POWER TRIM/TILT ELECTRICAL
BE35KLECA 1998	POWER TRIM/TILT ELECTRICAL
BE35KLEDC 1996	POWER TRIM/TILT ELECTRICAL
BE35KLEUR 1997	POWER TRIM/TILT ELECTRICAL
BE35KSIE elec start, tiller, 15 in shaft, wht, n/a usa 2001	POWER TRIM/TILT ELECTRICAL
BE35KSSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	POWER TRIM AND TILT - ELECTRICAL
BE35QLECA 1998	POWER TRIM/TILT ELECTRICAL
BE35QLEDC 1996	POWER TRIM/TILT ELECTRICAL
BE35QLEUR 1997	POWER TRIM/TILT ELECTRICAL
BE40EECR 1998	LOWER ENGINE COVER
BE40EEUC 1997	LOWER ENGINE COVER
BE40ELECR 1998	LOWER ENGINE COVER
BE40ELEUC 1997	LOWER ENGINE COVER
BE40TLECR 1998	LOWER ENGINE COVER
BE40TLEUC 1997	LOWER ENGINE COVER
BE50DTLEDC 1996	POWER TRIM/TILT ELECTRICAL
BE50DTLEDC 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
BE50DTLEUR 1997	POWER TRIM/TILT ELECTRICAL
BE50ESECC 1998	LOWER ENGINE COVER
BE50RLECR 1998	LOWER ENGINE COVER
BE50RLEUC 1997	LOWER ENGINE COVER
BE50TLECR 1998	LOWER ENGINE COVER
BE50TLEUC 1997	LOWER ENGINE COVER
BE50TSLECC 1998	LOWER ENGINE COVER
BE50TSLEUS 1997	LOWER ENGINE COVER
BE60ELEDR 1996	POWER TRIM/TILT ELECTRICAL
BE60ELEDR 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
BE60ELEUA 1997	POWER TRIM/TILT ELECTRICAL
BE60TLECM 1998	POWER TRIM/TILT ELECTRICAL
BE60TLEDR 1996	POWER TRIM/TILT ELECTRICAL
BE60TLEDR 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
BE60TLEUA 1997	POWER TRIM/TILT ELECTRICAL
BE70ELECB 1998	POWER TRIM/TILT ELECTRICAL
BE70ELEDA 1996	POWER TRIM/TILT ELECTRICAL
BE70ELEDA 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY

BE70ELEUM 1997	POWER TRIM/TILT ELECTRICAL
BE70TLECB 1998	POWER TRIM/TILT ELECTRICAL
BE70TLEDA 1996	POWER TRIM/TILT ELECTRICAL
BE70TLEDA 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
BE70TLEUM 1997	POWER TRIM/TILT ELECTRICAL
BE90TLEDA 1996	POWER TRIM/TILT ELECTRICAL
BJ115TLEDA 1996	POWER TRIM/TILT ELECTRICAL
BJ130PLEED 1999	IGNITION SYSTEM
BJ130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM
BJ130PXEDD 1999	IGNITION SYSTEM
BJ130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	IGNITION SYSTEM
BJ130TLECE 1998	IGNITION SYSTEM
BJ130TLEDM 1996	IGNITION SYSTEM
BJ130TLEUB 1997	IGNITION SYSTEM
BJ135PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	IGNITION
BJ135VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	IGNITION
BJ25ARECA 1998	POWER TRIM/TILT ELECTRICAL
BJ25AREDC 1996	POWER TRIM/TILT ELECTRICAL
BJ25AREUR 1997	POWER TRIM/TILT ELECTRICAL
BJ25ARLECA 1998	POWER TRIM/TILT ELECTRICAL
BJ25ARLEDC 1996	POWER TRIM/TILT ELECTRICAL
BJ25ARLEUR 1997	POWER TRIM/TILT ELECTRICAL
BJ25KECA 1998	POWER TRIM/TILT ELECTRICAL
BJ25KEDC 1996	POWER TRIM/TILT ELECTRICAL
BJ25KEUR 1997	POWER TRIM/TILT ELECTRICAL
BJ25KLECA 1998	POWER TRIM/TILT ELECTRICAL
BJ25KLEDC 1996	POWER TRIM/TILT ELECTRICAL
BJ25KLEUR 1997	POWER TRIM/TILT ELECTRICAL
BJ25PL3EEM 1999	POWER TRIM/TILT ELECTRICAL
BJ25PL3SIE elec start, TNT, 20 in shaft 2001	POWER TRIM/TILT ELECTRICAL
BJ25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	POWER TRIM AND TILT - ELECTRICAL
BJ25QLECA 1998	POWER TRIM/TILT ELECTRICAL
BJ25QLEDC 1996	POWER TRIM/TILT ELECTRICAL
BJ25QLEUR 1997	POWER TRIM/TILT ELECTRICAL
BJ25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	POWER TRIM/TILT ELECTRICAL

BJ35ARECR 1998	POWER TRIM/TILT ELECTRICAL
BJ35AREDS 1996	POWER TRIM/TILT ELECTRICAL
BJ35AREEA 1999	POWER TRIM/TILT ELECTRICAL
BJ35AREUC 1997	POWER TRIM/TILT ELECTRICAL
BJ35ARLECR 1998	POWER TRIM/TILT ELECTRICAL
BJ35ARLEDS 1996	POWER TRIM/TILT ELECTRICAL
BJ35ARLEUC 1997	POWER TRIM/TILT ELECTRICAL
BJ35E3EEM 1999	POWER TRIM/TILT ELECTRICAL
BJ35E3SIE elec start, 15 in shaft, n/a usa 2001	POWER TRIM/TILT ELECTRICAL
BJ35E3SSB 3 Cyl, Elec. Start, 15 IN. shaft, N/A USA 2000	POWER TRIM AND TILT - ELECTRICAL
BJ35EL3EEM 1999	POWER TRIM/TILT ELECTRICAL
BJ35EL3SIE elec start, 20 in shaft, wht, n/a usa 2001	POWER TRIM/TILT ELECTRICAL
BJ35EL3SSB 3 Cyl, Elec. Start, 20 IN. shaft, N/A USA 2000	POWER TRIM AND TILT - ELECTRICAL
BJ35EV3SIE elec start, 15 in shaft, wht, n/a usa 2001	POWER TRIM/TILT ELECTRICAL
BJ35EVL3SIE elec start, 20 in shaft, wht, n/a usa 2001	POWER TRIM/TILT ELECTRICAL
BJ35KECA 1998	POWER TRIM/TILT ELECTRICAL
BJ35KEDC 1996	POWER TRIM/TILT ELECTRICAL
BJ35KEEM 1999	POWER TRIM/TILT ELECTRICAL
BJ35KEUR 1997	POWER TRIM/TILT ELECTRICAL
BJ35KLECA 1998	POWER TRIM/TILT ELECTRICAL
BJ35KLEDC 1996	POWER TRIM/TILT ELECTRICAL
BJ35KLEUR 1997	POWER TRIM/TILT ELECTRICAL
BJ35PL3EEM 1999	POWER TRIM/TILT ELECTRICAL
BJ35PL3SIE elec start, TNT, 20 in shaft 2001	POWER TRIM/TILT ELECTRICAL
BJ35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	POWER TRIM AND TILT - ELECTRICAL
BJ35QLECA 1998	POWER TRIM/TILT ELECTRICAL
BJ35QLEDC 1996	POWER TRIM/TILT ELECTRICAL
BJ35QLEUR 1997	POWER TRIM/TILT ELECTRICAL
BJ35VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	POWER TRIM/TILT ELECTRICAL
BJ40EECR 1998	LOWER ENGINE COVER
BJ40EEEA 1999	LOWER ENGINE COVER
BJ40EEEA 1999	REMOTE TILT SWITCH KIT -- 40TPL ONLY
BJ40EEUC 1997	LOWER ENGINE COVER
BJ40ELECR 1998	LOWER ENGINE COVER
BJ40ELEEA 1999	LOWER ENGINE COVER

BJ40ELEEA 1999	REMOTE TILT SWITCH KIT -- 40TPL ONLY
BJ40ELEUC 1997	LOWER ENGINE COVER
BJ40ELSIF elec start, 20 in shaft, n/a usa 2001	LOWER ENGINE COVER
BJ40ELSIF elec start, 20 in shaft, n/a usa 2001	REMOTE TILT SWITCH KIT - 40 TPL ONLY
BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000	LOWER ENGINE COVER
BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000	REMOTE TILT SWITCH KIT - 40 TPL ONLY
BJ40ESIF elec start, 15 in shaft, n/a usa 2001	LOWER ENGINE COVER
BJ40ESIF elec start, 15 in shaft, n/a usa 2001	REMOTE TILT SWITCH KIT - 40 TPL ONLY
BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000	LOWER ENGINE COVER
BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000	REMOTE TILT SWITCH KIT - 40 TPL ONLY
BJ40PLEEA 1999	LOWER ENGINE COVER
BJ40PLEEA 1999	REMOTE TILT SWITCH KIT -- 40TPL ONLY
BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	LOWER ENGINE COVER
BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	REMOTE TILT SWITCH KIT - 40 TPL ONLY
BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000	LOWER ENGINE COVER
BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000	REMOTE TILT SWITCH KIT - 40 TPL ONLY
BJ40TLECR 1998	LOWER ENGINE COVER
BJ40TLEUC 1997	LOWER ENGINE COVER
BJ50DTLEDC 1996	POWER TRIM/TILT ELECTRICAL
BJ50DTLEDC 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
BJ50DTLEUR 1997	POWER TRIM/TILT ELECTRICAL
BJ50EEER 1999	LOWER ENGINE COVER
BJ50EEER 1999	REMOTE TILT SWITCH KIT -- 40TPL ONLY
BJ50ELEER 1999	LOWER ENGINE COVER
BJ50ELEER 1999	REMOTE TILT SWITCH KIT -- 40TPL ONLY
BJ50ELSIF elec start, 20 in shaft, n/a usa 2001	LOWER ENGINE COVER
BJ50ELSIF elec start, 20 in shaft, n/a usa 2001	REMOTE TILT SWITCH KIT - 40 TPL ONLY
BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000	LOWER ENGINE COVER
BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000	REMOTE TILT SWITCH KIT - 40 TPL ONLY
BJ50ESECC 1998	LOWER ENGINE COVER
BJ50ESIF elec start, 15 in shaft, n/a usa 2001	LOWER ENGINE COVER
BJ50ESIF elec start, 15 in shaft, n/a usa 2001	REMOTE TILT SWITCH KIT - 40 TPL ONLY
BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000	LOWER ENGINE COVER
BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000	REMOTE TILT SWITCH KIT - 40 TPL ONLY
BJ50PLEEA 1999	LOWER ENGINE COVER

BJ50PLEEA 1999	REMOTE TILT SWITCH KIT -- 40TPL ONLY
BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	LOWER ENGINE COVER
BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	REMOTE TILT SWITCH KIT - 40 TPL ONLY
BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000	LOWER ENGINE COVER
BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000	REMOTE TILT SWITCH KIT - 40 TPL ONLY
BJ50RLECR 1998	LOWER ENGINE COVER
BJ50RLEEA 1999	LOWER ENGINE COVER
BJ50RLEEA 1999	REMOTE TILT SWITCH KIT -- 40TPL ONLY
BJ50RLEUC 1997	LOWER ENGINE COVER
BJ50RLSIF elec start, 20 in shaft, n/a usa 2001	LOWER ENGINE COVER
BJ50RLSIF elec start, 20 in shaft, n/a usa 2001	REMOTE TILT SWITCH KIT - 40 TPL ONLY
BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000	LOWER ENGINE COVER
BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000	REMOTE TILT SWITCH KIT - 40 TPL ONLY
BJ50TLECR 1998	LOWER ENGINE COVER
BJ50TLEUC 1997	LOWER ENGINE COVER
BJ50TSLECC 1998	LOWER ENGINE COVER
BJ50TSLEUS 1997	LOWER ENGINE COVER
BJ60ELEDR 1996	POWER TRIM/TILT ELECTRICAL
BJ60ELEDR 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
BJ60ELEUA 1997	POWER TRIM/TILT ELECTRICAL
BJ60TLECM 1998	POWER TRIM/TILT ELECTRICAL
BJ60TLEDR 1996	POWER TRIM/TILT ELECTRICAL
BJ60TLEDR 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
BJ60TLEUA 1997	POWER TRIM/TILT ELECTRICAL
BJ70ELECB 1998	POWER TRIM/TILT ELECTRICAL
BJ70ELEDA 1996	POWER TRIM/TILT ELECTRICAL
BJ70ELEDA 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
BJ70ELEUM 1997	POWER TRIM/TILT ELECTRICAL
BJ70PLEEE 1999	POWER TRIM/TILT ELECTRICAL
BJ70PLSIS elec start, TNT, 20 in shaft, n/a usa 2001	POWER TRIM/TILT ELECTRICAL
BJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	POWER TRIM/TILT ELECTRICAL
BJ70TLECB 1998	POWER TRIM/TILT ELECTRICAL
BJ70TLEDA 1996	POWER TRIM/TILT ELECTRICAL
BJ70TLEDA 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
BJ70TLEUM 1997	POWER TRIM/TILT ELECTRICAL

BJ90TLEDA 1996	POWER TRIM/TILT ELECTRICAL
E100WTLEDR 1996	POWER TRIM/TILT ELECTRICAL
E100WTLEUA 1997	POWER TRIM/TILT ELECTRICAL
E100WTXEDR 1996	POWER TRIM/TILT ELECTRICAL
E100WTXEUA 1997	POWER TRIM/TILT ELECTRICAL
E112TSLEDR 1996	POWER TRIM/TILT ELECTRICAL
E112TSXEDR 1996	POWER TRIM/TILT ELECTRICAL
E115ELEOC 1995	IGNITION SYSTEM
E115GLEOC 1995	IGNITION SYSTEM
E115JLEDA 1996	POWER TRIM/TILT ELECTRICAL
E115JLEUM 1997	POWER TRIM/TILT ELECTRICAL
E115SLEOC 1995	IGNITION SYSTEM
E115SXEOC 1995	IGNITION SYSTEM
E115TLEDA 1996	POWER TRIM/TILT ELECTRICAL
E115TSLECM 1998	POWER TRIM/TILT ELECTRICAL
E115TSLEUA 1997	POWER TRIM/TILT ELECTRICAL
E115TSXECM 1998	POWER TRIM/TILT ELECTRICAL
E115TSXEUA 1997	POWER TRIM/TILT ELECTRICAL
E115TXADA 1996	POWER TRIM/TILT ELECTRICAL
E130TLECE 1998	IGNITION SYSTEM
E130TLEDM 1996	IGNITION SYSTEM
E130TLEUB 1997	IGNITION SYSTEM
E130TXACB 1998	IGNITION SYSTEM
E130TXADA 1996	IGNITION SYSTEM
E130TXAUM 1997	IGNITION SYSTEM
E25KLECA 1998	POWER TRIM/TILT ELECTRICAL
E25KLEDC 1996	POWER TRIM/TILT ELECTRICAL
E25KLEUR 1997	POWER TRIM/TILT ELECTRICAL
E25QLECA 1998	POWER TRIM/TILT ELECTRICAL
E25QLEDC 1996	POWER TRIM/TILT ELECTRICAL
E25QLEUR 1997	POWER TRIM/TILT ELECTRICAL
E25RMECA 1998	POWER TRIM/TILT ELECTRICAL
E25RMEDC 1996	POWER TRIM/TILT ELECTRICAL
E25RMEUR 1997	POWER TRIM/TILT ELECTRICAL
E25RMLECA 1998	POWER TRIM/TILT ELECTRICAL

E25RMLEDC 1996	POWER TRIM/TILT ELECTRICAL
E25RMLEUR 1997	POWER TRIM/TILT ELECTRICAL
E25TKECA 1998	POWER TRIM/TILT ELECTRICAL
E25TKEDC 1996	POWER TRIM/TILT ELECTRICAL
E25TKEUR 1997	POWER TRIM/TILT ELECTRICAL
E25TKLECA 1998	POWER TRIM/TILT ELECTRICAL
E25TKLEDC 1996	POWER TRIM/TILT ELECTRICAL
E25TKLEUR 1997	POWER TRIM/TILT ELECTRICAL
E35KLECA 1998	POWER TRIM/TILT ELECTRICAL
E35KLEDC 1996	POWER TRIM/TILT ELECTRICAL
E35KLEUR 1997	POWER TRIM/TILT ELECTRICAL
E35QLECA 1998	POWER TRIM/TILT ELECTRICAL
E35QLEDC 1996	POWER TRIM/TILT ELECTRICAL
E35QLEUR 1997	POWER TRIM/TILT ELECTRICAL
E35RMLEDC 1996	POWER TRIM/TILT ELECTRICAL
E35RMLEUR 1997	POWER TRIM/TILT ELECTRICAL
E35TKLECA 1998	POWER TRIM/TILT ELECTRICAL
E35TKLEDC 1996	POWER TRIM/TILT ELECTRICAL
E35TKLEUR 1997	POWER TRIM/TILT ELECTRICAL
E40ELECR 1998	LOWER ENGINE COVER
E40ELEUC 1997	LOWER ENGINE COVER
E40RECR 1998	LOWER ENGINE COVER
E40REUC 1997	LOWER ENGINE COVER
E40RLECR 1998	LOWER ENGINE COVER
E40RLEUC 1997	LOWER ENGINE COVER
E40TEECR 1998	LOWER ENGINE COVER
E40TEEUC 1997	LOWER ENGINE COVER
E40TELECR 1998	LOWER ENGINE COVER
E40TELEUC 1997	LOWER ENGINE COVER
E40TLECR 1998	LOWER ENGINE COVER
E40TLEUC 1997	LOWER ENGINE COVER
E40TTLECR 1998	LOWER ENGINE COVER
E40TTLEUC 1997	LOWER ENGINE COVER
E50DTLECA 1998	POWER TRIM/TILT ELECTRICAL
E50DTLEDC 1996	POWER TRIM/TILT ELECTRICAL

E50DTLEDC 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
E50DTLEUR 1997	POWER TRIM/TILT ELECTRICAL
E50ELED 1996	POWER TRIM/TILT ELECTRICAL
E50ELED 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
E50ELEUR 1997	POWER TRIM/TILT ELECTRICAL
E50ESLECC 1998	LOWER ENGINE COVER
E50ESLEUR 1997	LOWER ENGINE COVER
E50JEUC 1997	LOWER ENGINE COVER
E50TLECR 1998	LOWER ENGINE COVER
E50TLEUC 1997	LOWER ENGINE COVER
E50TSLECC 1998	LOWER ENGINE COVER
E50TSLEUS 1997	LOWER ENGINE COVER
E50TTLECA 1998	LOWER ENGINE COVER
E50TTLECA 1998	REMOTE TILT SWITCH KIT
E50TTLEUR 1997	LOWER ENGINE COVER
E50TTLEUR 1997	REMOTE TILT SWITCH KIT
E60ELEDR 1996	POWER TRIM/TILT ELECTRICAL
E60ELEDR 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
E60ELEUA 1997	POWER TRIM/TILT ELECTRICAL
E60TLECM 1998	POWER TRIM/TILT ELECTRICAL
E60TLEDR 1996	POWER TRIM/TILT ELECTRICAL
E60TLEDR 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
E60TLEUA 1997	POWER TRIM/TILT ELECTRICAL
E60TTLECM 1998	LOWER ENGINE COVER
E60TTLECM 1998	REMOTE TILT SWITCH KIT
E60TTLEUA 1997	LOWER ENGINE COVER
E60TTLEUA 1997	REMOTE TILT SWITCH KIT
E70TLECB 1998	POWER TRIM/TILT ELECTRICAL
E70TLEDA 1996	POWER TRIM/TILT ELECTRICAL
E70TLEDA 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
E70TLEUM 1997	POWER TRIM/TILT ELECTRICAL
E88MSLEDC 1996	POWER TRIM/TILT ELECTRICAL
E88TSLEDR 1996	POWER TRIM/TILT ELECTRICAL
E90ELEOC 1995	IGNITION SYSTEM
E90EXEOC 1995	IGNITION SYSTEM

E90SLEOC 1995	IGNITION SYSTEM
E90TLEDA 1996	POWER TRIM/TILT ELECTRICAL
E90TSLECM 1998	POWER TRIM/TILT ELECTRICAL
E90TSLEUA 1997	POWER TRIM/TILT ELECTRICAL
HE115TXADA 1996	POWER TRIM/TILT ELECTRICAL
HE130CXADA 1996	IGNITION SYSTEM
HE130XAUM 1997	IGNITION SYSTEM
HE130TXACB 1998	IGNITION SYSTEM
HE130TXADA 1996	IGNITION SYSTEM
HE130XAUM 1997	IGNITION SYSTEM
HE35RMLEDC 1996	POWER TRIM/TILT ELECTRICAL
HE35RMLEUR 1997	POWER TRIM/TILT ELECTRICAL
HE40REUC 1997	LOWER ENGINE COVER
HE40REUC 1997	LOWER ENGINE COVER
HE70TXEDA 1996	POWER TRIM/TILT ELECTRICAL
HE70TXEDA 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
HE70TXEUM 1997	POWER TRIM/TILT ELECTRICAL
HE88MSLEDC 1996	POWER TRIM/TILT ELECTRICAL
HE90MLEDA 1996	POWER TRIM/TILT ELECTRICAL
HE90TXADA 1996	POWER TRIM/TILT ELECTRICAL
HJ115TXADA 1996	POWER TRIM/TILT ELECTRICAL
HJ130CXADA 1996	IGNITION SYSTEM
HJ130XAUM 1997	IGNITION SYSTEM
HJ130TXACB 1998	IGNITION SYSTEM
HJ130TXADA 1996	IGNITION SYSTEM
HJ130XAUM 1997	IGNITION SYSTEM
HJ35RMLEDC 1996	POWER TRIM/TILT ELECTRICAL
HJ35RMLEUR 1997	POWER TRIM/TILT ELECTRICAL
HJ40REUC 1997	LOWER ENGINE COVER
HJ40REUC 1997	LOWER ENGINE COVER
HJ70TXEDA 1996	POWER TRIM/TILT ELECTRICAL
HJ70TXEDA 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
HJ70TXEUM 1997	POWER TRIM/TILT ELECTRICAL
HJ88MSLEDC 1996	POWER TRIM/TILT ELECTRICAL
HJ90MLEDA 1996	POWER TRIM/TILT ELECTRICAL

HJ90TXADA 1996	POWER TRIM/TILT ELECTRICAL
J100WTLEDR 1996	POWER TRIM/TILT ELECTRICAL
J100WTLEUA 1997	POWER TRIM/TILT ELECTRICAL
J100WTXEDR 1996	POWER TRIM/TILT ELECTRICAL
J100WTXEUA 1997	POWER TRIM/TILT ELECTRICAL
J112TSLEDR 1996	POWER TRIM/TILT ELECTRICAL
J112TSXEDR 1996	POWER TRIM/TILT ELECTRICAL
J115ELEOC 1995	IGNITION SYSTEM
J115GLEOC 1995	IGNITION SYSTEM
J115JLEDA 1996	POWER TRIM/TILT ELECTRICAL
J115JLEUM 1997	POWER TRIM/TILT ELECTRICAL
J115SLEOC 1995	IGNITION SYSTEM
J115SXEOC 1995	IGNITION SYSTEM
J115TLEDA 1996	POWER TRIM/TILT ELECTRICAL
J115TSLECM 1998	POWER TRIM/TILT ELECTRICAL
J115TSLEUA 1997	POWER TRIM/TILT ELECTRICAL
J115TSXECM 1998	POWER TRIM/TILT ELECTRICAL
J115TSXEUA 1997	POWER TRIM/TILT ELECTRICAL
J115TXADA 1996	POWER TRIM/TILT ELECTRICAL
J130PLEED 1999	IGNITION SYSTEM
J130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM
J130PXEEED 1999	IGNITION SYSTEM
J130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	IGNITION SYSTEM
J130TLECE 1998	IGNITION SYSTEM
J130TLEDM 1996	IGNITION SYSTEM
J130TLEUB 1997	IGNITION SYSTEM
J130TXACB 1998	IGNITION SYSTEM
J130TXADA 1996	IGNITION SYSTEM
J130TXAUM 1997	IGNITION SYSTEM
J130VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	IGNITION SYSTEM
J135PLSIF elec start, TNT, 20 in shaft 2001	IGNITION
J135VLSIF elec start, TNT, 20 in shaft, wht 2001	IGNITION
J135VXSIF elec start, TNT, 25 in shaft, wht 2001	IGNITION
J25KLECA 1998	POWER TRIM/TILT ELECTRICAL
J25KLEDC 1996	POWER TRIM/TILT ELECTRICAL

J25KLEUR 1997	POWER TRIM/TILT ELECTRICAL
J25PL3EEM 1999	POWER TRIM/TILT ELECTRICAL
J25PL3SIE elec start, TNT, 20 in shaft 2001	POWER TRIM/TILT ELECTRICAL
J25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000	POWER TRIM AND TILT - ELECTRICAL
J25QLECA 1998	POWER TRIM/TILT ELECTRICAL
J25QLEDC 1996	POWER TRIM/TILT ELECTRICAL
J25QLEUR 1997	POWER TRIM/TILT ELECTRICAL
J25R3EEM 1999	POWER TRIM/TILT ELECTRICAL
J25R3SIE rope start, tiller, 15 in shaft 2001	POWER TRIM/TILT ELECTRICAL
J25R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000	POWER TRIM AND TILT - ELECTRICAL
J25RL3EEM 1999	POWER TRIM/TILT ELECTRICAL
J25RL3SIE rope start, tiller, 20 in shaft 2001	POWER TRIM/TILT ELECTRICAL
J25RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000	POWER TRIM AND TILT - ELECTRICAL
J25RMECA 1998	POWER TRIM/TILT ELECTRICAL
J25RMEDC 1996	POWER TRIM/TILT ELECTRICAL
J25RMEUR 1997	POWER TRIM/TILT ELECTRICAL
J25RMLECA 1998	POWER TRIM/TILT ELECTRICAL
J25RMLEDC 1996	POWER TRIM/TILT ELECTRICAL
J25RMLEUR 1997	POWER TRIM/TILT ELECTRICAL
J25RV3SIE rope start, tiller, 15 in shaft, wht, n/a usa 2001	POWER TRIM/TILT ELECTRICAL
J25RVL3SIE rope start, tiller, 20 in shaft, wht 2001	POWER TRIM/TILT ELECTRICAL
J25TEL3EEM 1999	POWER TRIM/TILT ELECTRICAL
J25TEL3SIE elec start, tiller, 20 in shaft 2001	POWER TRIM/TILT ELECTRICAL
J25TEL3SSB 3 Cyl, Elec. Start, Tiller, 20 IN. shaft 2000	POWER TRIM AND TILT - ELECTRICAL
J25TKECA 1998	POWER TRIM/TILT ELECTRICAL
J25TKEDC 1996	POWER TRIM/TILT ELECTRICAL
J25TKEUR 1997	POWER TRIM/TILT ELECTRICAL
J25TKLECA 1998	POWER TRIM/TILT ELECTRICAL
J25TKLEDC 1996	POWER TRIM/TILT ELECTRICAL
J25TKLEUR 1997	POWER TRIM/TILT ELECTRICAL
J25TVL3SIE elec start, tiller, 20 in shaft, wht 2001	POWER TRIM/TILT ELECTRICAL
J25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	POWER TRIM/TILT ELECTRICAL
J35E3EEM 1999	POWER TRIM/TILT ELECTRICAL
J35EL3EEM 1999	POWER TRIM/TILT ELECTRICAL
J35KLECA 1998	POWER TRIM/TILT ELECTRICAL

J35KLEDC 1996	POWER TRIM/TILT ELECTRICAL
J35KLEUR 1997	POWER TRIM/TILT ELECTRICAL
J35PL3EEM 1999	POWER TRIM/TILT ELECTRICAL
J35PL3SIE elec start, TNT, 20 in shaft 2001	POWER TRIM/TILT ELECTRICAL
J35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000	POWER TRIM AND TILT - ELECTRICAL
J35QLECA 1998	POWER TRIM/TILT ELECTRICAL
J35QLEDC 1996	POWER TRIM/TILT ELECTRICAL
J35QLEUR 1997	POWER TRIM/TILT ELECTRICAL
J35R3EEM 1999	POWER TRIM/TILT ELECTRICAL
J35R3SIE rope start, tiller, 15 in shaft 2001	POWER TRIM/TILT ELECTRICAL
J35R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000	POWER TRIM AND TILT - ELECTRICAL
J35RL3EEM 1999	POWER TRIM/TILT ELECTRICAL
J35RL3SIE rope start, tiller, 20 in shaft 2001	POWER TRIM/TILT ELECTRICAL
J35RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000	POWER TRIM AND TILT - ELECTRICAL
J35RMLEDC 1996	POWER TRIM/TILT ELECTRICAL
J35RMLEUR 1997	POWER TRIM/TILT ELECTRICAL
J35RV3SIE rope start, 15 in shaft, wht 2001	POWER TRIM/TILT ELECTRICAL
J35RVL3SIE rope start, 20 in shaft, wht 2001	POWER TRIM/TILT ELECTRICAL
J35TEL3EEM 1999	POWER TRIM/TILT ELECTRICAL
J35TEL3SIE elec start, TNT, 20 in shaft 2001	POWER TRIM/TILT ELECTRICAL
J35TEL3SSB 3 Cyl, Elec. Start, TNT, Tiller, 20 IN. shaft 2000	POWER TRIM AND TILT - ELECTRICAL
J35TKLECA 1998	POWER TRIM/TILT ELECTRICAL
J35TKLEDC 1996	POWER TRIM/TILT ELECTRICAL
J35TKLEUR 1997	POWER TRIM/TILT ELECTRICAL
J35TVL3SIE elec start, tiller, 20 in shaft, wht 2001	POWER TRIM/TILT ELECTRICAL
J35VL3SIE elec start, TNT, 20 in shaft, wht 2001	POWER TRIM/TILT ELECTRICAL
J40ELECR 1998	LOWER ENGINE COVER
J40ELEUC 1997	LOWER ENGINE COVER
J40JPLEEC 1999	POWER TRIM/TILT ELECTRICAL
J40JPLSIA jet drive,elec start, TNT, 20 in shaft 2001	POWER TRIM/TILT ELECTRICAL
J40JPLSSR Jet Drive, Elec Start, TNT, 20 IN. shaft 2000	POWER TRIM/TILT ELECTRICAL
J40JVLSIA jet drive,elec start, TNT, 20 in shaft, wht 2001	POWER TRIM/TILT ELECTRICAL
J40PLEEA 1999	LOWER ENGINE COVER
J40PLEEA 1999	REMOTE TILT SWITCH KIT -- 40TPL ONLY
J40PLSIF elec start, TNT, 20 in shaft 2001	LOWER ENGINE COVER

J40PLSIF elec start, TNT, 20 in shaft 2001	REMOTE TILT SWITCH KIT - 40 TPL ONLY
J40PLSNF - FR	21-3_CAPOT MOTEUR INFÉRIEUR
J40PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	LOWER ENGINE COVER
J40PLSOC	LOWER ENGINE COVER
J40PLSOC - FR	21-3_CAPOT MOTEUR INFÉRIEUR
J40PLSRS	LOWER ENGINE COVER
J40PLSRS - FR	21-3_CAPOT MOTEUR INFÉRIEUR
J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000	LOWER ENGINE COVER
J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000	REMOTE TILT SWITCH KIT - 40 TPL ONLY
J40PLSTD	LOWER ENGINE COVER
J40PLSTD - FR	21-3_CAPOT MOTEUR INFÉRIEUR
J40RECR 1998	LOWER ENGINE COVER
J40REEA 1999	LOWER ENGINE COVER
J40REEA 1999	REMOTE TILT SWITCH KIT -- 40TPL ONLY
J40REUC 1997	LOWER ENGINE COVER
J40RLECR 1998	LOWER ENGINE COVER
J40RLEEA 1999	LOWER ENGINE COVER
J40RLEEA 1999	REMOTE TILT SWITCH KIT -- 40TPL ONLY
J40RLEUC 1997	LOWER ENGINE COVER
J40RLSIF rope start, 20 in shaft 2001	LOWER ENGINE COVER
J40RLSIF rope start, 20 in shaft 2001	REMOTE TILT SWITCH KIT - 40 TPL ONLY
J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000	LOWER ENGINE COVER
J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000	REMOTE TILT SWITCH KIT - 40 TPL ONLY
J40RSIF rope start, 15 in shaft 2001	LOWER ENGINE COVER
J40RSIF rope start, 15 in shaft 2001	REMOTE TILT SWITCH KIT - 40 TPL ONLY
J40RSSM Rope Start, Tiller, 15 IN. shaft 2000	LOWER ENGINE COVER
J40RSSM Rope Start, Tiller, 15 IN. shaft 2000	REMOTE TILT SWITCH KIT - 40 TPL ONLY
J40TEECR 1998	LOWER ENGINE COVER
J40TEEUC 1997	LOWER ENGINE COVER
J40TELECR 1998	LOWER ENGINE COVER
J40TELEUC 1997	LOWER ENGINE COVER
J40TLECR 1998	LOWER ENGINE COVER
J40TLEUC 1997	LOWER ENGINE COVER
J40TPLEEA 1999	LOWER ENGINE COVER
J40TPLEEA 1999	REMOTE TILT SWITCH KIT -- 40TPL ONLY

J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001	LOWER ENGINE COVER
J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001	REMOTE TILT SWITCH KIT - 40 TPL ONLY
J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	LOWER ENGINE COVER
J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	REMOTE TILT SWITCH KIT - 40 TPL ONLY
J40TTLECR 1998	LOWER ENGINE COVER
J40TTLEUC 1997	LOWER ENGINE COVER
J50DTLECA 1998	POWER TRIM/TILT ELECTRICAL
J50DTLEDC 1996	POWER TRIM/TILT ELECTRICAL
J50DTLEDC 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
J50DTLEUR 1997	POWER TRIM/TILT ELECTRICAL
J50ELED 1996	POWER TRIM/TILT ELECTRICAL
J50ELED 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
J50ELEER 1999	LOWER ENGINE COVER
J50ELEER 1999	REMOTE TILT SWITCH KIT -- 40TPL ONLY
J50ELEUR 1997	POWER TRIM/TILT ELECTRICAL
J50ELSIF elec start, 20 in shaft 2001	LOWER ENGINE COVER
J50ELSIF elec start, 20 in shaft 2001	REMOTE TILT SWITCH KIT - 40 TPL ONLY
J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000	LOWER ENGINE COVER
J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000	REMOTE TILT SWITCH KIT - 40 TPL ONLY
J50ESLECC 1998	LOWER ENGINE COVER
J50ESLEUR 1997	LOWER ENGINE COVER
J50JEUC 1997	LOWER ENGINE COVER
J50PLEEA 1999	LOWER ENGINE COVER
J50PLEEA 1999	REMOTE TILT SWITCH KIT -- 40TPL ONLY
J50PLSIF elec start, TNT, 20 in shaft 2001	LOWER ENGINE COVER
J50PLSIF elec start, TNT, 20 in shaft 2001	REMOTE TILT SWITCH KIT - 40 TPL ONLY
J50PLSNF - FR	21-3_CAPOT MOTEUR INFÉRIEUR
J50PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	LOWER ENGINE COVER
J50PLSOC	LOWER ENGINE COVER
J50PLSOC - FR	21-3_CAPOT MOTEUR INFÉRIEUR
J50PLSRS	LOWER ENGINE COVER
J50PLSRS - FR	21-3_CAPOT MOTEUR INFÉRIEUR
J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	LOWER ENGINE COVER
J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	REMOTE TILT SWITCH KIT - 40 TPL ONLY
J50PLSTD	LOWER ENGINE COVER

J50PLSTD - FR	21-3_CAPOT MOTEUR INFÉRIEUR
J50TLECR 1998	LOWER ENGINE COVER
J50TLEUC 1997	LOWER ENGINE COVER
J50TSLECC 1998	LOWER ENGINE COVER
J50TSLEUS 1997	LOWER ENGINE COVER
J50TTLECA 1998	LOWER ENGINE COVER
J50TTLECA 1998	REMOTE TILT SWITCH KIT
J50TTLEUR 1997	LOWER ENGINE COVER
J50TTLEUR 1997	REMOTE TILT SWITCH KIT
J60ELEDR 1996	POWER TRIM/TILT ELECTRICAL
J60ELEDR 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
J60ELEUA 1997	POWER TRIM/TILT ELECTRICAL
J60PLEEB 1999	POWER TRIM/TILT ELECTRICAL
J60PLSID elec start, TNT, 20 in shaft 2001	POWER TRIM/TILT ELECTRICAL
J60PLSSE Elec Start, TNT, 20 IN. shaft 2000	POWER TRIM/TILT ELECTRICAL
J60TLECM 1998	POWER TRIM/TILT ELECTRICAL
J60TLEDR 1996	POWER TRIM/TILT ELECTRICAL
J60TLEDR 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
J60TLEUA 1997	POWER TRIM/TILT ELECTRICAL
J60TTLECM 1998	LOWER ENGINE COVER
J60TTLECM 1998	REMOTE TILT SWITCH KIT
J60TTLEUA 1997	LOWER ENGINE COVER
J60TTLEUA 1997	REMOTE TILT SWITCH KIT
J60VLSID elec start, TNT, 20 in shaft, wht 2001	POWER TRIM/TILT ELECTRICAL
J70PLEEE 1999	POWER TRIM/TILT ELECTRICAL
J70PLSIS elec start, TNT, 20 in shaft 2001	POWER TRIM/TILT ELECTRICAL
J70PLSSD Elec Start, TNT, 20 IN. shaft 2000	POWER TRIM/TILT ELECTRICAL
J70TLECB 1998	POWER TRIM/TILT ELECTRICAL
J70TLEDA 1996	POWER TRIM/TILT ELECTRICAL
J70TLEDA 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
J70TLEUM 1997	POWER TRIM/TILT ELECTRICAL
J70VLSIS elec start, TNT, 20 in shaft 2001	POWER TRIM/TILT ELECTRICAL
J88MSLEDC 1996	POWER TRIM/TILT ELECTRICAL
J88TSLEDR 1996	POWER TRIM/TILT ELECTRICAL
J90ELEOC 1995	IGNITION SYSTEM

J90EXEOC 1995	IGNITION SYSTEM
J90SLEOC 1995	IGNITION SYSTEM
J90TLEDA 1996	POWER TRIM/TILT ELECTRICAL
J90TSLECM 1998	POWER TRIM/TILT ELECTRICAL
J90TSLEUA 1997	POWER TRIM/TILT ELECTRICAL
L115GLEOS 1995	IGNITION SYSTEM
POWER TRIM & TILT	REMOTE TILT SWITCH KIT
POWER TRIM/TILT 1997	POWER TRIM/TILT ELECTRICAL - 50, 60, 70 MODELS
POWER TRIM/TILT 1997	REMOTE TILT SWITCH KIT P/N 174835
POWER TRIM/TILT 1998	POWER TRIM/TILT ELECTRICAL -- 65, 70 MODELS
POWER TRIM/TILT 1998	POWER TRIM/TILT KIT -- 40 & 50 MODELS
POWER TRIM/TILT 1998	REMOTE TILT SWITCH KIT P/N 174835
POWER TRIM/TILT 1999	POWER TRIM/TILT KIT -- 40 & 50 MODELS
POWER TRIM/TILT 1999	POWER TRIM/TILT ELECTRICAL -- 65 MODELS
POWER TRIM/TILT 1999	REMOTE TILT SWITCH KIT (1)
POWER TRIM_TILT 2000	POWER TRIM/TILT KIT - 40 & 50 MODELS
POWER TRIM_TILT 2000	POWER TRIM/TILT ELECTRICAL - 65 MODELS - Z
POWER TRIM_TILT 2000	REMOTE TILT SWITCH KIT
RJ130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM
RJ130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	IGNITION SYSTEM
RJ130VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	IGNITION SYSTEM
RJ135PLSIF elec start, TNT, 20 in shaft 2001	IGNITION
RJ135VXSIF elec start, TNT, 20 in shaft, wht 2001	IGNITION
RJ50ELSIF elec start, TNT, 20 in shaft 2001	LOWER ENGINE COVER
RJ50ELSIF elec start, TNT, 20 in shaft 2001	REMOTE TILT SWITCH KIT - 40 TPL ONLY
RJ70PLSIS elec start, TNT, 20 in shaft 2001	POWER TRIM/TILT ELECTRICAL
RJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	POWER TRIM/TILT ELECTRICAL
SE100WMPLM 1996	POWER TRIM/TILT ELECTRICAL
SE100WMPLZ 1997	POWER TRIM/TILT ELECTRICAL
SE100WTPLM 1996	POWER TRIM/TILT ELECTRICAL
SE100WTPLZ 1997	POWER TRIM/TILT ELECTRICAL
SE125WTPLJ 1997	IGNITION SYSTEM
SE125WTPLN 1998	IGNITION SYSTEM
SE125WTPXJ 1997	IGNITION SYSTEM

SE125WTPXN 1998	IGNITION SYSTEM
SJ100WMPLM 1996	POWER TRIM/TILT ELECTRICAL
SJ100WMPLZ 1997	POWER TRIM/TILT ELECTRICAL
SJ100WTPLM 1996	POWER TRIM/TILT ELECTRICAL
SJ100WTPLZ 1997	POWER TRIM/TILT ELECTRICAL
SJ125WTPLJ 1997	IGNITION SYSTEM
SJ125WTPLN 1998	IGNITION SYSTEM
SJ125WTPXJ 1997	IGNITION SYSTEM
SJ125WTPXN 1998	IGNITION SYSTEM
SJ130CXADA 1996	IGNITION SYSTEM
SJ130TLEDM 1996	IGNITION SYSTEM
SJ130TXADA 1996	IGNITION SYSTEM
SJ60TLEDR 1996	POWER TRIM/TILT ELECTRICAL
SJ60TLEDR 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
SJ70TLEDA 1996	POWER TRIM/TILT ELECTRICAL
SJ70TLEDA 1996	POWER TRIM/TILT ELECTRICAL - E70RNLIB ONLY
X50ESLECC 1998	LOWER ENGINE COVER
XE112TSLEDR 1996	POWER TRIM/TILT ELECTRICAL
XE112TSXEDR 1996	POWER TRIM/TILT ELECTRICAL
XE115HLECM 1998	POWER TRIM/TILT ELECTRICAL
XE115HLEUA 1997	POWER TRIM/TILT ELECTRICAL
XE115HXECM 1998	POWER TRIM/TILT ELECTRICAL
XE115HXEUA 1997	POWER TRIM/TILT ELECTRICAL
XE88TSLEDR 1996	POWER TRIM/TILT ELECTRICAL
XE90TSLECM 1998	POWER TRIM/TILT ELECTRICAL
XE90TSLEUA 1997	POWER TRIM/TILT ELECTRICAL
XJ112TSLEDR 1996	POWER TRIM/TILT ELECTRICAL
XJ112TSXEDR 1996	POWER TRIM/TILT ELECTRICAL
XJ115HLECM 1998	POWER TRIM/TILT ELECTRICAL
XJ115HLEUA 1997	POWER TRIM/TILT ELECTRICAL
XJ115HXECM 1998	POWER TRIM/TILT ELECTRICAL
XJ115HXEUA 1997	POWER TRIM/TILT ELECTRICAL
XJ88TSLEDR 1996	POWER TRIM/TILT ELECTRICAL
XJ90TSLECM 1998	POWER TRIM/TILT ELECTRICAL
XJ90TSLEUA 1997	POWER TRIM/TILT ELECTRICAL

