

Where Used: Part Number 0585195

Model Name	Diagram
115JEEOB 1995	IGNITION SYSTEM
115JEERA 1994	IGNITION SYSTEM
115TJEDB 1996	IGNITION SYSTEM
115TJEOA 1995	IGNITION SYSTEM
115TJEUC 1997	IGNITION SYSTEM
90JEEOB 1995	IGNITION SYSTEM
90JEERA 1994	IGNITION SYSTEM
BE115TLEDA 1996	IGNITION SYSTEM
BE90TLEDA 1996	IGNITION SYSTEM
BJ115TLEDA 1996	IGNITION SYSTEM
BJ90TLEDA 1996	IGNITION SYSTEM
E100WTLEDR 1996	IGNITION SYSTEM
E100WTLEOC 1995	IGNITION SYSTEM
E100WTLEUA 1997	IGNITION SYSTEM
E100WTXEDR 1996	IGNITION SYSTEM
E100WTXEOC 1995	IGNITION SYSTEM
E100WTXEUA 1997	IGNITION SYSTEM
E112TSLEDR 1996	IGNITION SYSTEM
E112TSLEOC 1995	IGNITION SYSTEM
E112TSXEDR 1996	IGNITION SYSTEM
E112TSXEOC 1995	IGNITION SYSTEM
E115JLEDA 1996	IGNITION SYSTEM
E115JLEOR 1995	IGNITION SYSTEM
E115JLEUM 1997	IGNITION SYSTEM
E115MLEOR 1995	IGNITION SYSTEM
E115TLEDA 1996	IGNITION SYSTEM
E115TLEOR 1995	IGNITION SYSTEM
E115TSLECM 1998	IGNITION SYSTEM
E115TSLEUA 1997	IGNITION SYSTEM
E115TSXECM 1998	IGNITION SYSTEM
E115TSXEUA 1997	IGNITION SYSTEM
E115TXADA 1996	IGNITION SYSTEM
E115TXAOR 1995	IGNITION SYSTEM

E88MSLEDC 1996	IGNITION SYSTEM
E88MSLEOS 1995	IGNITION SYSTEM
E88TSLEDR 1996	IGNITION SYSTEM
E88TSLEOC 1995	IGNITION SYSTEM
E90JLEOR 1995	IGNITION SYSTEM
E90MLEOR 1995	IGNITION SYSTEM
E90TLEDA 1996	IGNITION SYSTEM
E90TLEOR 1995	IGNITION SYSTEM
E90TSLECM 1998	IGNITION SYSTEM
E90TSLEUA 1997	IGNITION SYSTEM
HE115TXADA 1996	IGNITION SYSTEM
HE88MSLEDC 1996	IGNITION SYSTEM
HE90MLEDA 1996	IGNITION SYSTEM
HE90TXADA 1996	IGNITION SYSTEM
HJ115TXADA 1996	IGNITION SYSTEM
HJ88MSLEDC 1996	IGNITION SYSTEM
HJ90MLEDA 1996	IGNITION SYSTEM
HJ90TXADA 1996	IGNITION SYSTEM
J100WTLEDR 1996	IGNITION SYSTEM
J100WTLEOC 1995	IGNITION SYSTEM
J100WTLEUA 1997	IGNITION SYSTEM
J100WTXEDR 1996	IGNITION SYSTEM
J100WTXEOC 1995	IGNITION SYSTEM
J100WTXEUA 1997	IGNITION SYSTEM
J112TSLEDR 1996	IGNITION SYSTEM
J112TSLEOC 1995	IGNITION SYSTEM
J112TSXEDR 1996	IGNITION SYSTEM
J112TSXEOC 1995	IGNITION SYSTEM
J115JLEDA 1996	IGNITION SYSTEM
J115JLEOR 1995	IGNITION SYSTEM
J115JLEUM 1997	IGNITION SYSTEM
J115MLEOR 1995	IGNITION SYSTEM
J115TLEDA 1996	IGNITION SYSTEM
J115TLEOR 1995	IGNITION SYSTEM
J115TSLECM 1998	IGNITION SYSTEM

J115TSLEUA 1997	IGNITION SYSTEM
J115TSXECM 1998	IGNITION SYSTEM
J115TSXEUA 1997	IGNITION SYSTEM
J115TXADA 1996	IGNITION SYSTEM
J115TXAOR 1995	IGNITION SYSTEM
J88MSLEDC 1996	IGNITION SYSTEM
J88MSLEOS 1995	IGNITION SYSTEM
J88TSLEDR 1996	IGNITION SYSTEM
J88TSLEOC 1995	IGNITION SYSTEM
J90JLEOR 1995	IGNITION SYSTEM
J90MLEOR 1995	IGNITION SYSTEM
J90TLEDA 1996	IGNITION SYSTEM
J90TLEOR 1995	IGNITION SYSTEM
J90TSLECM 1998	IGNITION SYSTEM
J90TSLEUA 1997	IGNITION SYSTEM
SE100WMPLM 1996	IGNITION SYSTEM
SE100WMPLZ 1997	IGNITION SYSTEM
SE100WTPLM 1996	IGNITION SYSTEM
SE100WTPLZ 1997	IGNITION SYSTEM
SJ100WMPLM 1996	IGNITION SYSTEM
SJ100WMPLZ 1997	IGNITION SYSTEM
SJ100WTPLM 1996	IGNITION SYSTEM
SJ100WTPLZ 1997	IGNITION SYSTEM
XE112TSLEDR 1996	IGNITION SYSTEM
XE112TSLEOC 1995	IGNITION SYSTEM
XE112TSXEDR 1996	IGNITION SYSTEM
XE112TSXEOC 1995	IGNITION SYSTEM
XE115HLECM 1998	IGNITION SYSTEM
XE115HLEUA 1997	IGNITION SYSTEM
XE115HXECM 1998	IGNITION SYSTEM
XE115HXEUA 1997	IGNITION SYSTEM
XE88TSLEDR 1996	IGNITION SYSTEM
XE88TSLEOC 1995	IGNITION SYSTEM
XE90TSLECM 1998	IGNITION SYSTEM
XE90TSLEUA 1997	IGNITION SYSTEM

XJ112TSLEDR 1996	IGNITION SYSTEM
XJ112TSLEOC 1995	IGNITION SYSTEM
XJ112TSXEDR 1996	IGNITION SYSTEM
XJ112TSXEOC 1995	IGNITION SYSTEM
XJ115HLECM 1998	IGNITION SYSTEM
XJ115HLEUA 1997	IGNITION SYSTEM
XJ115HXECM 1998	IGNITION SYSTEM
XJ115HXEUA 1997	IGNITION SYSTEM
XJ88TSLEDR 1996	IGNITION SYSTEM
XJ88TSLEOC 1995	IGNITION SYSTEM
XJ90TSLECM 1998	IGNITION SYSTEM
XJ90TSLEUA 1997	IGNITION SYSTEM