

Where Used: Part Number 0586101

Model Name	Diagram
40/50HP (2 Stroke)	ELECTRIC START KIT (1993-Current models w/CD II Ignition)
40HP Rope 45-55HP Comm (2 Stroke) 1992-2001	TILLER ELECTRIC START KIT - 40, 55
65HP (2 Stroke - 3 CYLINDER)	TILLER ELECTRIC START KIT - 65 MODELS
BE40EECR 1998	ELECTRIC STARTER & SOLENOID
BE40EEDS 1996	ELECTRIC STARTER & SOLENOID
BE40EEUC 1997	ELECTRIC STARTER & SOLENOID
BE40ELECR 1998	ELECTRIC STARTER & SOLENOID
BE40ELEDs 1996	ELECTRIC STARTER & SOLENOID
BE40ELEUC 1997	ELECTRIC STARTER & SOLENOID
BE40TLECR 1998	ELECTRIC STARTER & SOLENOID
BE40TLEDs 1996	ELECTRIC STARTER & SOLENOID
BE40TLEUC 1997	ELECTRIC STARTER & SOLENOID
BE50BEEDs 1996	ELECTRIC STARTER & SOLENOID
BE50BELEDs 1996	ELECTRIC STARTER & SOLENOID
BE50DTLEDC 1996	ELECTRIC STARTER
BE50DTLEUR 1997	ELECTRIC STARTER
BE50ESECC 1998	ELECTRIC STARTER & SOLENOID
BE50RLECR 1998	ELECTRIC STARTER & SOLENOID
BE50RLEUC 1997	ELECTRIC STARTER & SOLENOID
BE50TLECR 1998	ELECTRIC STARTER & SOLENOID
BE50TLEDs 1996	ELECTRIC STARTER & SOLENOID
BE50TLEUC 1997	ELECTRIC STARTER & SOLENOID
BE50TSLECC 1998	ELECTRIC STARTER & SOLENOID
BE50TSLEUS 1997	ELECTRIC STARTER & SOLENOID
BE60ELEDR 1996	ELECTRIC STARTER
BE60ELEUA 1997	ELECTRIC STARTER
BE60TLECM 1998	ELECTRIC STARTER
BE60TLEDR 1996	ELECTRIC STARTER
BE60TLEUA 1997	ELECTRIC STARTER
BE70ELECB 1998	ELECTRIC STARTER
BE70ELEDa 1996	ELECTRIC STARTER
BE70ELEUM 1997	ELECTRIC STARTER
BE70TLECB 1998	ELECTRIC STARTER

BE70TLEDA 1996	ELECTRIC STARTER
BE70TLEUM 1997	ELECTRIC STARTER
BJ40EECR 1998	ELECTRIC STARTER & SOLENOID
BJ40EEDS 1996	ELECTRIC STARTER & SOLENOID
BJ40EEEE 1999	ELECTRIC STARTER & SOLENOID
BJ40EEUC 1997	ELECTRIC STARTER & SOLENOID
BJ40ELECR 1998	ELECTRIC STARTER & SOLENOID
BJ40ELEDS 1996	ELECTRIC STARTER & SOLENOID
BJ40ELEEA 1999	ELECTRIC STARTER & SOLENOID
BJ40ELEUC 1997	ELECTRIC STARTER & SOLENOID
BJ40ELSIF elec start, 20 in shaft, n/a usa 2001	ELECTRIC STARTER & SOLENOID
BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000	ELECTRIC STARTER & SOLENOID
BJ40ESIF elec start, 15 in shaft, n/a usa 2001	ELECTRIC STARTER & SOLENOID
BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000	ELECTRIC STARTER & SOLENOID
BJ40PLEEA 1999	ELECTRIC STARTER & SOLENOID
BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	ELECTRIC STARTER & SOLENOID
BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000	ELECTRIC STARTER & SOLENOID
BJ40TLECR 1998	ELECTRIC STARTER & SOLENOID
BJ40TLEDS 1996	ELECTRIC STARTER & SOLENOID
BJ40TLEUC 1997	ELECTRIC STARTER & SOLENOID
BJ50BEEDS 1996	ELECTRIC STARTER & SOLENOID
BJ50BELEDS 1996	ELECTRIC STARTER & SOLENOID
BJ50DTLEDC 1996	ELECTRIC STARTER
BJ50DTLEUR 1997	ELECTRIC STARTER
BJ50EEER 1999	ELECTRIC STARTER & SOLENOID
BJ50ELEER 1999	ELECTRIC STARTER & SOLENOID
BJ50ELSIF elec start, 20 in shaft, n/a usa 2001	ELECTRIC STARTER & SOLENOID
BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000	ELECTRIC STARTER & SOLENOID
BJ50ESECC 1998	ELECTRIC STARTER & SOLENOID
BJ50ESIF elec start, 15 in shaft, n/a usa 2001	ELECTRIC STARTER & SOLENOID
BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000	ELECTRIC STARTER & SOLENOID
BJ50PLEEA 1999	ELECTRIC STARTER & SOLENOID
BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	ELECTRIC STARTER & SOLENOID
BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000	ELECTRIC STARTER & SOLENOID
BJ50RLECR 1998	ELECTRIC STARTER & SOLENOID

BJ50RLEEA 1999	ELECTRIC STARTER & SOLENOID
BJ50RLEUC 1997	ELECTRIC STARTER & SOLENOID
BJ50RLSIF elec start, 20 in shaft, n/a usa 2001	ELECTRIC STARTER & SOLENOID
BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000	ELECTRIC STARTER & SOLENOID
BJ50TLECR 1998	ELECTRIC STARTER & SOLENOID
BJ50TLEDS 1996	ELECTRIC STARTER & SOLENOID
BJ50TLEUC 1997	ELECTRIC STARTER & SOLENOID
BJ50TSLECC 1998	ELECTRIC STARTER & SOLENOID
BJ50TSLEUS 1997	ELECTRIC STARTER & SOLENOID
BJ60ELEDR 1996	ELECTRIC STARTER
BJ60ELEUA 1997	ELECTRIC STARTER
BJ60TLECM 1998	ELECTRIC STARTER
BJ60TLEDR 1996	ELECTRIC STARTER
BJ60TLEUA 1997	ELECTRIC STARTER
BJ70ELECB 1998	ELECTRIC STARTER
BJ70ELEDA 1996	ELECTRIC STARTER
BJ70ELEUM 1997	ELECTRIC STARTER
BJ70PLEEE 1999	ELECTRIC STARTER
BJ70PLSIS elec start, TNT, 20 in shaft, n/a usa 2001	ELECTRIC STARTER
BJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	ELECTRIC STARTER
BJ70TLECB 1998	ELECTRIC STARTER
BJ70TLEDA 1996	ELECTRIC STARTER
BJ70TLEUM 1997	ELECTRIC STARTER
E40ELECR 1998	ELECTRIC STARTER & SOLENOID
E40ELEDS 1996	ELECTRIC STARTER & SOLENOID
E40ELEUC 1997	ELECTRIC STARTER & SOLENOID
E40RECR 1998	ELECTRIC STARTER & SOLENOID
E40REDS 1996	ELECTRIC STARTER & SOLENOID
E40REUC 1997	ELECTRIC STARTER & SOLENOID
E40RLECR 1998	ELECTRIC STARTER & SOLENOID
E40RLEDS 1996	ELECTRIC STARTER & SOLENOID
E40RLEUC 1997	ELECTRIC STARTER & SOLENOID
E40TEECR 1998	ELECTRIC STARTER & SOLENOID
E40TEEDS 1996	ELECTRIC STARTER & SOLENOID
E40TEEUC 1997	ELECTRIC STARTER & SOLENOID

E40TELECR 1998	ELECTRIC STARTER & SOLENOID
E40TELEDS 1996	ELECTRIC STARTER & SOLENOID
E40TELEUC 1997	ELECTRIC STARTER & SOLENOID
E40TLECR 1998	ELECTRIC STARTER & SOLENOID
E40TLEDS 1996	ELECTRIC STARTER & SOLENOID
E40TLEUC 1997	ELECTRIC STARTER & SOLENOID
E40TTLECR 1998	ELECTRIC STARTER & SOLENOID
E40TTLEDS 1996	ELECTRIC STARTER & SOLENOID
E40TTLEUC 1997	ELECTRIC STARTER & SOLENOID
E48ESLEDC 1996	ELECTRIC STARTER & SOLENOID
E50DTLECA 1998	ELECTRIC STARTER
E50DTLEDC 1996	ELECTRIC STARTER
E50DTLEUR 1997	ELECTRIC STARTER
E50ELED 1996	ELECTRIC STARTER
E50ELEUR 1997	ELECTRIC STARTER
E50ESLECC 1998	ELECTRIC STARTER & SOLENOID
E50ESLEUR 1997	ELECTRIC STARTER & SOLENOID
E50JEDS 1996	ELECTRIC STARTER & SOLENOID
E50JEUC 1997	ELECTRIC STARTER & SOLENOID
E50TLECR 1998	ELECTRIC STARTER & SOLENOID
E50TLEDS 1996	ELECTRIC STARTER & SOLENOID
E50TLEUC 1997	ELECTRIC STARTER & SOLENOID
E50TSLECC 1998	ELECTRIC STARTER & SOLENOID
E50TSLEUS 1997	ELECTRIC STARTER & SOLENOID
E50TTLECA 1998	ELECTRIC STARTER
E50TTLEDC 1996	ELECTRIC STARTER
E50TTLEUR 1997	ELECTRIC STARTER
E60ELEDR 1996	ELECTRIC STARTER
E60ELEUA 1997	ELECTRIC STARTER
E60TLECM 1998	ELECTRIC STARTER
E60TLEDR 1996	ELECTRIC STARTER
E60TLEUA 1997	ELECTRIC STARTER
E60TTLECM 1998	ELECTRIC STARTER
E60TTLEDR 1996	ELECTRIC STARTER
E60TTLEUA 1997	ELECTRIC STARTER

E65WELEES 1999	ELECTRIC STARTER
E65WELSIR Commercial, elec start, 20 in shaft 2001	ELECTRIC STARTER
E65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	ELECTRIC STARTER
E70TLECB 1998	ELECTRIC STARTER
E70TLEDA 1996	ELECTRIC STARTER
E70TLEUM 1997	ELECTRIC STARTER
ELECTRICAL	ELECTRIC START KIT - 40,50 HP (Johnson 2-Stroke)
ELECTRICAL 1996	TILLER ELECTRIC STARTING KIT - 40, 50
ELECTRICAL 1996	TILLER ELECTRIC STARTING KIT - 45, 55
ELECTRICAL 1997	TILLER ELECTRIC STARTING KIT - 40, 50
ELECTRICAL 1997	TILLER ELECTRIC STARTING KIT - 45, 55
ELECTRICAL 1998	TILLER ELECTRIC STARTING KIT -- 40, 50
ELECTRICAL 1998	TILLER ELECTRIC STARTING KIT -- 45, 55
ELECTRICAL 1998	TILLER ELECTRIC START KIT -- 65 MODELS
ELECTRICAL 1999	TILLER ELECTRIC STARTING KIT -- 40, 50
ELECTRICAL 1999	TILLER ELECTRIC STARTING KIT -- 40, 55
ELECTRICAL 1999	TILLER ELECTRIC START KIT -- 65 MODELS
ELECTRICAL 2000	TILLER ELECTRIC STARTING KIT - 40, 50
ELECTRICAL 2000	TILLER ELECTRIC STARTING KIT - 40, 55
ELECTRICAL 2000	TILLER ELECTRIC START KIT - 65 MODELS
HE40REDS 1996	ELECTRIC STARTER & SOLENOID
HE40REUC 1997	ELECTRIC STARTER & SOLENOID
HE40RLEDS 1996	ELECTRIC STARTER & SOLENOID
HE40RLEUC 1997	ELECTRIC STARTER & SOLENOID
HE55WMLM 1996	ELECTRIC STARTER & SOLENOID
HE55WMLZ 1997	ELECTRIC STARTER & SOLENOID
HE70TXEDA 1996	ELECTRIC STARTER
HE70TXEUM 1997	ELECTRIC STARTER
HJ40REDS 1996	ELECTRIC STARTER & SOLENOID
HJ40REUC 1997	ELECTRIC STARTER & SOLENOID
HJ40RLEDS 1996	ELECTRIC STARTER & SOLENOID
HJ40RLEUC 1997	ELECTRIC STARTER & SOLENOID
HJ55WMLM 1996	ELECTRIC STARTER & SOLENOID
HJ55WMLZ 1997	ELECTRIC STARTER & SOLENOID
HJ70TXEDA 1996	ELECTRIC STARTER

HJ70TXEUM 1997	ELECTRIC STARTER
J40ELECR 1998	ELECTRIC STARTER & SOLENOID
J40ELED 1996	ELECTRIC STARTER & SOLENOID
J40ELEUC 1997	ELECTRIC STARTER & SOLENOID
J40JPLEEC 1999	ELECTRIC STARTER
J40JPLSIA jet drive,elec start, TNT, 20 in shaft 2001	ELECTRIC STARTER
J40JPLSSR Jet Drive, Elec Start, TNT, 20 IN. shaft 2000	ELECTRIC STARTER
J40JVLZIA jet drive,elec start, TNT, 20 in shaft, wht 2001	ELECTRIC STARTER
J40PLEEA 1999	ELECTRIC STARTER & SOLENOID
J40PLSIF elec start, TNT, 20 in shaft 2001	ELECTRIC STARTER & SOLENOID
J40PLSNF - FR	22-1_MOTEUR DE DÉMARREUR
J40PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	STARTER MOTOR
J40PLSOC	STARTER MOTOR
J40PLSOC - FR	22-1_MOTEUR DE DÉMARREUR
J40PLSRS	STARTER MOTOR
J40PLSRS - FR	22-1_MOTEUR DE DÉMARREUR
J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000	ELECTRIC STARTER & SOLENOID
J40PLSTD	STARTER MOTOR
J40PLSTD - FR	22-1_MOTEUR DE DÉMARREUR
J40RECR 1998	ELECTRIC STARTER & SOLENOID
J40REDS 1996	ELECTRIC STARTER & SOLENOID
J40REEA 1999	ELECTRIC STARTER & SOLENOID
J40REUC 1997	ELECTRIC STARTER & SOLENOID
J40RLECR 1998	ELECTRIC STARTER & SOLENOID
J40RLED 1996	ELECTRIC STARTER & SOLENOID
J40RLEEA 1999	ELECTRIC STARTER & SOLENOID
J40RLEUC 1997	ELECTRIC STARTER & SOLENOID
J40RLSIF rope start, 20 in shaft 2001	ELECTRIC STARTER & SOLENOID
J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000	ELECTRIC STARTER & SOLENOID
J40RSIF rope start, 15 in shaft 2001	ELECTRIC STARTER & SOLENOID
J40RSSM Rope Start, Tiller, 15 IN. shaft 2000	ELECTRIC STARTER & SOLENOID
J40TEECR 1998	ELECTRIC STARTER & SOLENOID
J40TEEDS 1996	ELECTRIC STARTER & SOLENOID
J40TEUC 1997	ELECTRIC STARTER & SOLENOID
J40TELECR 1998	ELECTRIC STARTER & SOLENOID

J40TELEDS 1996	ELECTRIC STARTER & SOLENOID
J40TELEUC 1997	ELECTRIC STARTER & SOLENOID
J40TLECR 1998	ELECTRIC STARTER & SOLENOID
J40TLEDS 1996	ELECTRIC STARTER & SOLENOID
J40TLEUC 1997	ELECTRIC STARTER & SOLENOID
J40TPLEEA 1999	ELECTRIC STARTER & SOLENOID
J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001	ELECTRIC STARTER & SOLENOID
J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	ELECTRIC STARTER & SOLENOID
J40TTLECR 1998	ELECTRIC STARTER & SOLENOID
J40TTLEDS 1996	ELECTRIC STARTER & SOLENOID
J40TTLEUC 1997	ELECTRIC STARTER & SOLENOID
J48ESLEDC 1996	ELECTRIC STARTER & SOLENOID
J50DTLECA 1998	ELECTRIC STARTER
J50DTLEDC 1996	ELECTRIC STARTER
J50DTLEUR 1997	ELECTRIC STARTER
J50ELED 1996	ELECTRIC STARTER
J50ELEER 1999	ELECTRIC STARTER & SOLENOID
J50ELEUR 1997	ELECTRIC STARTER
J50ELSIF elec start, 20 in shaft 2001	ELECTRIC STARTER & SOLENOID
J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000	ELECTRIC STARTER & SOLENOID
J50ESLECC 1998	ELECTRIC STARTER & SOLENOID
J50ESLEUR 1997	ELECTRIC STARTER & SOLENOID
J50JEDS 1996	ELECTRIC STARTER & SOLENOID
J50JEUC 1997	ELECTRIC STARTER & SOLENOID
J50PLEEA 1999	ELECTRIC STARTER & SOLENOID
J50PLSIF elec start, TNT, 20 in shaft 2001	ELECTRIC STARTER & SOLENOID
J50PLSNF - FR	22-1_MOTEUR DE DÉMARREUR
J50PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	STARTER MOTOR
J50PLSOC	STARTER MOTOR
J50PLSOC - FR	22-1_MOTEUR DE DÉMARREUR
J50PLSRS	STARTER MOTOR
J50PLSRS - FR	22-1_MOTEUR DE DÉMARREUR
J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	ELECTRIC STARTER & SOLENOID
J50PLSTD	STARTER MOTOR
J50PLSTD - FR	22-1_MOTEUR DE DÉMARREUR

J50TLECR 1998	ELECTRIC STARTER & SOLENOID
J50TLEDS 1996	ELECTRIC STARTER & SOLENOID
J50TLEUC 1997	ELECTRIC STARTER & SOLENOID
J50TSLECC 1998	ELECTRIC STARTER & SOLENOID
J50TSLEUS 1997	ELECTRIC STARTER & SOLENOID
J50TTLECA 1998	ELECTRIC STARTER
J50TTLEDC 1996	ELECTRIC STARTER
J50TTLEUR 1997	ELECTRIC STARTER
J60ELEDR 1996	ELECTRIC STARTER
J60ELEUA 1997	ELECTRIC STARTER
J60PLEEB 1999	ELECTRIC STARTER
J60PLSID elec start, TNT, 20 in shaft 2001	ELECTRIC STARTER
J60PLSSE Elec Start, TNT, 20 IN. shaft 2000	ELECTRIC STARTER
J60TLECM 1998	ELECTRIC STARTER
J60TLEDR 1996	ELECTRIC STARTER
J60TLEUA 1997	ELECTRIC STARTER
J60TTLECM 1998	ELECTRIC STARTER
J60TTLEDR 1996	ELECTRIC STARTER
J60TTLEUA 1997	ELECTRIC STARTER
J60VLSID elec start, TNT, 20 in shaft, wht 2001	ELECTRIC STARTER
J65WELEES 1999	ELECTRIC STARTER
J65WELSIR Commercial, elec start, 20 in shaft 2001	ELECTRIC STARTER
J65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	ELECTRIC STARTER
J70PLEEE 1999	ELECTRIC STARTER
J70PLSIS elec start, TNT, 20 in shaft 2001	ELECTRIC STARTER
J70PLSSD Elec Start, TNT, 20 IN. shaft 2000	ELECTRIC STARTER
J70TLECB 1998	ELECTRIC STARTER
J70TLEDA 1996	ELECTRIC STARTER
J70TLEUM 1997	ELECTRIC STARTER
J70VLSIS elec start, TNT, 20 in shaft 2001	ELECTRIC STARTER
RJ50ELSIF elec start, TNT, 20 in shaft 2001	ELECTRIC STARTER & SOLENOID
RJ70PLSIS elec start, TNT, 20 in shaft 2001	ELECTRIC STARTER
RJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	ELECTRIC STARTER
SE50TLEDS 1996	ELECTRIC STARTER & SOLENOID
SE65WMLD 1998	ELECTRIC STARTER

SE65WMLM 1996	ELECTRIC STARTER
SE65WMLZ2 1997	ELECTRIC STARTER
SE65WMYD 1998	ELECTRIC STARTER
SE65WMYM 1996	ELECTRIC STARTER
SE65WMYZ2 1997	ELECTRIC STARTER
SJ40EEDS 1996	ELECTRIC STARTER & SOLENOID
SJ40REDS 1996	ELECTRIC STARTER & SOLENOID
SJ40RLEDS 1996	ELECTRIC STARTER & SOLENOID
SJ60TLEDR 1996	ELECTRIC STARTER
SJ65WMLD 1998	ELECTRIC STARTER
SJ65WMLM 1996	ELECTRIC STARTER
SJ65WMLZ2 1997	ELECTRIC STARTER
SJ65WMYD 1998	ELECTRIC STARTER
SJ65WMYM 1996	ELECTRIC STARTER
SJ65WMYZ2 1997	ELECTRIC STARTER
SJ70TLEDA 1996	ELECTRIC STARTER
X50ESLECC 1998	ELECTRIC STARTER & SOLENOID