

Where Used: Part Number 0587275

Model Name	Diagram
B30MRLAFA	02-5_IGNITION COIL
B30MRLAFB	02-5_IGNITION COIL
B30MRLAFC	02-5_IGNITION COIL
B30MRLAFD	02-5_IGNITION COIL
E15HPGLAFA	02-5_IGNITION COIL
E15HPGLAFB	02-5_IGNITION COIL
E15HPGLAFC	02-5_IGNITION COIL
E15HPGLAFD	02-5_IGNITION COIL
E15HPGXAFA	02-5_IGNITION COIL
E15HPGXAFB	02-5_IGNITION COIL
E15HPGX AFC	02-5_IGNITION COIL
E15HPGXAFD	02-5_IGNITION COIL
E15HPSLAFA	02-5_IGNITION COIL
E15HPSLAFB	02-5_IGNITION COIL
E15HPSLAFC	02-5_IGNITION COIL
E15HPSLAFD	02-5_IGNITION COIL
E15HPSXAFA	02-5_IGNITION COIL
E15HPSXAFB	02-5_IGNITION COIL
E15HPSX AFC	02-5_IGNITION COIL
E15HPSXAFD	02-5_IGNITION COIL
E15HTGLAFA	02-5_IGNITION COIL
E15HTGLAFB	02-5_IGNITION COIL
E15HTGLAFC	02-5_IGNITION COIL
E15HTGLAFD	02-5_IGNITION COIL
E15HTGX AFA	02-5_IGNITION COIL
E15HTGXAFB	02-5_IGNITION COIL
E15HTGX AFC	02-5_IGNITION COIL
E15HTGXAFD	02-5_IGNITION COIL
E15HTSLAFA	02-5_IGNITION COIL
E15HTSLAFB	02-5_IGNITION COIL
E15HTSLAFC	02-5_IGNITION COIL
E15HTSLAFD	02-5_IGNITION COIL
E15HTSX AFA	02-5_IGNITION COIL

E15HTSXAFB	02-5_IGNITION COIL
E15HTSX AFC	02-5_IGNITION COIL
E15HTSXAFD	02-5_IGNITION COIL
E25DGELAFB	02-5_IGNITION COIL
E25DGTEAFB	02-5_IGNITION COIL
E25DGTEAFC	02-5_IGNITION COIL
E25DGTEAFD	02-5_IGNITION COIL
E25DGT LAFB	02-5_IGNITION COIL
E25DGT L AFC	02-5_IGNITION COIL
E25DGT L AFD	02-5_IGNITION COIL
E25DPGLAFB	02-5_IGNITION COIL
E25DPGL AFC	02-5_IGNITION COIL
E25DPGL AFD	02-5_IGNITION COIL
E25DPSLAFB	02-5_IGNITION COIL
E25DPSL AFC	02-5_IGNITION COIL
E25DPSL AFD	02-5_IGNITION COIL
E25DRGAFB	02-5_IGNITION COIL
E25DRG AFC	02-5_IGNITION COIL
E25DRG AFD	02-5_IGNITION COIL
E25DRGLAFB	02-5_IGNITION COIL
E25DRGL AFC	02-5_IGNITION COIL
E25DRGL AFD	02-5_IGNITION COIL
E25DRSAFB	02-5_IGNITION COIL
E25DRSAFC	02-5_IGNITION COIL
E25DRSAFD	02-5_IGNITION COIL
E25DRSLAFB	02-5_IGNITION COIL
E25DRSL AFC	02-5_IGNITION COIL
E25DRSL AFD	02-5_IGNITION COIL
E25DTSLAFB	02-5_IGNITION COIL
E25DTSL AFC	02-5_IGNITION COIL
E25DTSL AFD	02-5_IGNITION COIL
E25GTE LAFB	02-5_IGNITION COIL
E25GTE L AFC	02-5_IGNITION COIL
E25GTE L AFD	02-5_IGNITION COIL
E25TESLAFB	02-5_IGNITION COIL

E30DGELAFB	02-5_IGNITION COIL
E30DGTLAFB	02-5_IGNITION COIL
E30DGTLAFB	02-5_IGNITION COIL
E30DGTLAFD	02-5_IGNITION COIL
E30DPGLAFB	02-5_IGNITION COIL
E30DPGLAFB	02-5_IGNITION COIL
E30DPGLAFD	02-5_IGNITION COIL
E30DPSLAFB	02-5_IGNITION COIL
E30DPSLAFB	02-5_IGNITION COIL
E30DPSLAFD	02-5_IGNITION COIL
E30DRGAFB	02-5_IGNITION COIL
E30DRGAFB	02-5_IGNITION COIL
E30DRGAFD	02-5_IGNITION COIL
E30DRGLAFB	02-5_IGNITION COIL
E30DRGLAFB	02-5_IGNITION COIL
E30DRGLAFD	02-5_IGNITION COIL
E30DRSAFB	02-5_IGNITION COIL
E30DRSAFB	02-5_IGNITION COIL
E30DRSAFD	02-5_IGNITION COIL
E30DRSLAFB	02-5_IGNITION COIL
E30DRSLAFB	02-5_IGNITION COIL
E30DRSLAFD	02-5_IGNITION COIL
E30DTSLAFB	02-5_IGNITION COIL
E30DTSLAFB	02-5_IGNITION COIL
E30DTSLAFD	02-5_IGNITION COIL
E30GTELAFB	02-5_IGNITION COIL
E30GTELAFB	02-5_IGNITION COIL
E30GTELAFD	02-5_IGNITION COIL
E30MALAFA	02-5_IGNITION COIL
E30MALAFB	02-5_IGNITION COIL
E30MALAFB	02-5_IGNITION COIL
E30MALAFD	02-5_IGNITION COIL
E30MRLAFA	02-5_IGNITION COIL
E30MRLAFB	02-5_IGNITION COIL
E30MRLAFB	02-5_IGNITION COIL
E30MRLAFD	02-5_IGNITION COIL

E30MRLAFD	02-5_IGNITION COIL
E30TESLAFB	02-5_IGNITION COIL
E60DPJLAFB	02-5_IGNITION COIL
E60DPJLAFD	02-5_IGNITION COIL
E60DPJLAFF	02-5_IGNITION COIL
E60DPJLAFC	02-5_IGNITION COIL
E60DPJLAFG	02-5_IGNITION COIL
E60HGLAFC	02-5_IGNITION COIL
E60HGLAFD	02-5_IGNITION COIL
E60HGLAFF	02-5_IGNITION COIL
E60HGLAFG	02-5_IGNITION COIL
E60HGXAFC	02-5_IGNITION COIL
E60HGXAFF	02-5_IGNITION COIL
E60HGXAFC	02-5_IGNITION COIL
E60HGXAFC	02-5_IGNITION COIL
E60HGXAFC	02-5_IGNITION COIL
E60HGXAFC	02-5_IGNITION COIL
E60HGXAFC	02-5_IGNITION COIL
E60HGXAFC	02-5_IGNITION COIL
E60HSLAFD	02-5_IGNITION COIL
E60HSLAFF	02-5_IGNITION COIL
E60HSLAFG	02-5_IGNITION COIL
E65GLAFA	02-5_IGNITION COIL
E65GLAFB	02-5_IGNITION COIL
E65GLAFC	02-5_IGNITION COIL
E65GNLAFA	02-5_IGNITION COIL
E65GNLAFB	02-5_IGNITION COIL
E65GNLAFC	02-5_IGNITION COIL
E65SLAFA	02-5_IGNITION COIL
E65SLAFB	02-5_IGNITION COIL
E65SLAFC	02-5_IGNITION COIL
E65SNLAFA	02-5_IGNITION COIL
E65SNLAFB	02-5_IGNITION COIL
E65SNLAFC	02-5_IGNITION COIL
E75DPGLAFA	02-5_IGNITION COIL
E75DPGLAFB	02-5_IGNITION COIL
E75DPGLAFC	02-5_IGNITION COIL
E75DPGLAFD	02-5_IGNITION COIL
E75DPGLAFF	02-5_IGNITION COIL



E90GNLAFB	02-5_IGNITION COIL
E90GNL AFC	02-5_IGNITION COIL
E90GNLAFD	02-5_IGNITION COIL
E90GNL A FF	02-5_IGNITION COIL
E90GNL A FG	02-5_IGNITION COIL
E90SLAFA	02-5_IGNITION COIL
E90SLA FB	02-5_IGNITION COIL
E90SLA FC	02-5_IGNITION COIL
E90SNL A FA	02-5_IGNITION COIL
E90SNL A FB	02-5_IGNITION COIL
E90SNL A FC	02-5_IGNITION COIL
E90SNL A FD	02-5_IGNITION COIL
E90SNL A FF	02-5_IGNITION COIL
E90SNL A FG	02-5_IGNITION COIL