

Where Used: Part Number 0582926

Model Name	Diagram
20/35HP	BATTERY CHARGING KIT
40/50HP (2 Stroke)	ELECTRIC START KIT (1993-Current models w/CD II Ignition)
40HP Rope 45-55HP Comm (2 Stroke) 1992-2001	TILLER ELECTRIC START KIT - 40, 55
BE20SEECB 1998	IGNITION
BE20SEEDA 1996	IGNITION
BE20SEEUM 1997	IGNITION
BE20SELECB 1998	IGNITION
BE20SELEDA 1996	IGNITION
BE20SELEUM 1997	IGNITION
BE25EECE 1998	IGNITION
BE25EEDM 1996	IGNITION
BE25EEUB 1997	IGNITION
BE25ELECE 1998	IGNITION
BE25ELEDM 1996	IGNITION
BE25ELEUB 1997	IGNITION
BE25EREDC 1996	IGNITION
BE25ERLEDC 1996	IGNITION
BE30ECS 1998	IGNITION
BE30EEDE 1996	IGNITION
BE30EEUD 1997	IGNITION
BE30ELECS 1998	IGNITION
BE30ELEDE 1996	IGNITION
BE30ELEUD 1997	IGNITION
BJ20SEECB 1998	IGNITION
BJ20SEEDA 1996	IGNITION
BJ20SEEUM 1997	IGNITION
BJ20SELECB 1998	IGNITION
BJ20SELEDA 1996	IGNITION
BJ20SELEUM 1997	IGNITION
BJ25EECE 1998	IGNITION
BJ25EEDM 1996	IGNITION
BJ25EEED 1999	IGNITION
BJ25EEEN 1999	IGNITION

BJ25EEUB 1997	IGNITION
BJ25ELECE 1998	IGNITION
BJ25ELEDM 1996	IGNITION
BJ25ELEED 1999	IGNITION
BJ25ELEEN 1999	IGNITION
BJ25ELEUB 1997	IGNITION
BJ25ELSIC elec start, remote, 20 in shaft, n/a usa 2001	IGNITION
BJ25ELSSS Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION
BJ25EREDC 1996	IGNITION
BJ25ERLEDC 1996	IGNITION
BJ25ESIC elec start, remote, 15 in shaft, n/a usa 2001	IGNITION
BJ25ESSS Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION
BJ25EVSIC elec start, remote, 20 in shaft, wht, n/a usa 2001	IGNITION
BJ25EVSIC elec start, remote, 15 in shaft, wht, n/a usa 2001	IGNITION
BJ30EECS 1998	IGNITION
BJ30EEDE 1996	IGNITION
BJ30EEEC 1999	IGNITION
BJ30EEEN 1999	IGNITION
BJ30EEUD 1997	IGNITION
BJ30ELECS 1998	IGNITION
BJ30ELEDE 1996	IGNITION
BJ30ELEEC 1999	IGNITION
BJ30ELEEN 1999	IGNITION
BJ30ELEUD 1997	IGNITION
BJ30ELSIA elec start, remote, 20 in shaft, n/a usa 2001	IGNITION
BJ30ELSSR Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION
BJ30ESIA elec start, remote, 15 in shaft, n/a usa 2001	IGNITION
BJ30ESSR Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION
BJ30EVSIA elec start, remote, 20 in shaft, wht, n/a usa 2001	IGNITION
BJ30EVSIA elec start, remote, 15 in shaft, wht, n/a usa 2001	IGNITION
E10ECCD 1988	IGNITION
E10ECDB 1986	IGNITION
E10ECOM 1985	IGNITION
E10ECUE 1987	IGNITION
E10ELCCD 1988	IGNITION

E10ELCDB 1986	IGNITION
E10ELCOM 1985	IGNITION
E10ELCUE 1987	IGNITION
E10RCCD 1988	IGNITION
E10RCDB 1986	IGNITION
E10RCOM 1985	IGNITION
E10RCUE 1987	IGNITION
E10RLCCD 1988	IGNITION
E10RLCDB 1986	IGNITION
E10RLCOM 1985	IGNITION
E10RLCUE 1987	IGNITION
E10SELCCD 1988	IGNITION
E10SELCDB 1986	IGNITION
E10SELCOM 1985	IGNITION
E10SELCUE 1987	IGNITION
E15ECCS 1988	IGNITION
E15ECDE 1986	IGNITION
E15ECOB 1985	IGNITION
E15ECUD 1987	IGNITION
E15ELCCS 1988	IGNITION
E15ELCDE 1986	IGNITION
E15ELCOB 1985	IGNITION
E15ELCUD 1987	IGNITION
E15RCCS 1988	IGNITION
E15RCDE 1986	IGNITION
E15RCOB 1985	IGNITION
E15RCUD 1987	IGNITION
E15RLCCS 1988	IGNITION
E15RLCDE 1986	IGNITION
E15RLCOB 1985	IGNITION
E15RLCUD 1987	IGNITION
E20CRCCA 1988	IGNITION
E20CRCDC 1986	IGNITION
E20CRCOS 1985	IGNITION
E20CRLCCA 1988	IGNITION

E20CRLCDC 1986	IGNITION
E20CRLCOS 1985	IGNITION
E20ECCA 1988	IGNITION
E20ECDC 1986	IGNITION
E20ECOS 1985	IGNITION
E20EEOR 1995	IGNITION
E20EERC 1994	IGNITION
E20EETS 1993	IGNITION
E20ELCCA 1988	IGNITION
E20ELCDC 1986	IGNITION
E20ELCOS 1985	IGNITION
E20ELEOR 1995	IGNITION
E20ELERC 1994	IGNITION
E20ELETs 1993	IGNITION
E20TECDC 1986	IGNITION
E25ECCM 1988	IGNITION
E25ECDR 1986	IGNITION
E25ECOC 1985	IGNITION
E25EECE 1998	IGNITION
E25EEDM 1996	IGNITION
E25EEOA 1995	IGNITION
E25EERR 1994	IGNITION
E25EETC 1993	IGNITION
E25EEUB 1997	IGNITION
E25ELCCM 1988	IGNITION
E25ELCDR 1986	IGNITION
E25ELCOC 1985	IGNITION
E25ELECE 1998	IGNITION
E25ELEDM 1996	IGNITION
E25ELEOA 1995	IGNITION
E25ELERR 1994	IGNITION
E25ELETc 1993	IGNITION
E25ELEUB 1997	IGNITION
E25RCCA 1988	IGNITION
E25RCDC 1986	IGNITION

E25RCOS 1985	IGNITION
E25RLCCA 1988	IGNITION
E25RLCDC 1986	IGNITION
E25RLCOS 1985	IGNITION
E25TECCA 1988	IGNITION
E25TECDC 1986	IGNITION
E25TECOS 1985	IGNITION
E25TEECB 1998	IGNITION
E25TEEDA 1996	IGNITION
E25TEEOR 1995	IGNITION
E25TEERC 1994	IGNITION
E25TEETS 1993	IGNITION
E25TEEUM 1997	IGNITION
E25TELCCA 1988	IGNITION
E25TELCDC 1986	IGNITION
E25TELCOS 1985	IGNITION
E25TELECB 1998	IGNITION
E25TELEDA 1996	IGNITION
E25TELEOR 1995	IGNITION
E25TELETS 1993	IGNITION
E25TELEUM 1997	IGNITION
E28ELCDS 1986	MAGNETO
E28ESLCCR 1988	IGNITION
E28ESLEDR 1996	IGNITION
E28ESLEOC 1995	IGNITION
E28ESLERS 1994	IGNITION
E28ESLETD 1993	IGNITION
E30ECCE 1988	IGNITION
E30ECDM 1986	IGNITION
E30EECS 1998	IGNITION
E30EEDE 1996	IGNITION
E30EEOB 1995	IGNITION
E30EERM 1994	IGNITION
E30EETA 1993	IGNITION
E30EEUD 1997	IGNITION

E30ELCCE 1988	IGNITION
E30ELCDM 1986	IGNITION
E30ELECS 1998	IGNITION
E30ELEDE 1996	IGNITION
E30ELEOB 1995	IGNITION
E30ELERM 1994	IGNITION
E30ELETA 1993	IGNITION
E30ELEUD 1997	IGNITION
E30RCCE 1988	IGNITION
E30RCDM 1986	IGNITION
E30RLCCE 1988	IGNITION
E30RLCDM 1986	IGNITION
E30TECCE 1988	IGNITION
E30TECDM 1986	IGNITION
E30TEECS 1998	IGNITION
E30TEEDE 1996	IGNITION
E30TEEOB 1995	IGNITION
E30TEERM 1994	IGNITION
E30TEETA 1993	IGNITION
E30TEEUD 1997	IGNITION
E30TELCCE 1988	IGNITION
E30TELCDM 1986	IGNITION
E30TELECB 1998	IGNITION
E30TELEDE 1996	IGNITION
E30TELEOB 1995	IGNITION
E30TELERM 1994	IGNITION
E30TELETA 1993	IGNITION
E30TELEUD 1997	IGNITION
E35AELCDE 1986	IGNITION SYSTEM
E35ARLCDE 1986	IGNITION SYSTEM
E35RCCE 1988	IGNITION
E35RCDM 1986	IGNITION
E35RLCCE 1988	IGNITION
E35RLCDM 1986	IGNITION
E40AELCCS 1988	IGNITION SYSTEM

E40ARLCCS 1988	IGNITION SYSTEM
E40ATLCCS 1988	IGNITION SYSTEM
E40ECCS 1988	IGNITION SYSTEM
E40ECDE 1986	IGNITION SYSTEM
E40ECOB 1985	IGNITION SYSTEM
E40ECRM 1984	IGNITION SYSTEM
E40EEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40EERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40ELCCS 1988	IGNITION SYSTEM
E40ELCDE 1986	IGNITION SYSTEM
E40ELCOB 1985	IGNITION SYSTEM
E40ELCRM 1984	IGNITION SYSTEM
E40ELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40ELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RCCS 1988	IGNITION SYSTEM
E40RCDE 1986	IGNITION SYSTEM
E40RCOB 1985	IGNITION SYSTEM
E40RCRM 1984	IGNITION SYSTEM
E40REOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40RERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RLCCS 1988	IGNITION SYSTEM
E40RLCDE 1986	IGNITION SYSTEM
E40RLCOB 1985	IGNITION SYSTEM
E40RLCRM 1984	IGNITION SYSTEM
E40RLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40RLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TECCS 1988	IGNITION SYSTEM
E40TECDE 1986	IGNITION SYSTEM
E40TECOB 1985	IGNITION SYSTEM
E40TECRM 1984	IGNITION SYSTEM
E40TEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY

E40TEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TELCCS 1988	IGNITION SYSTEM
E40TELCDE 1986	IGNITION SYSTEM
E40TELCOB 1985	IGNITION SYSTEM
E40TELCRM 1984	IGNITION SYSTEM
E40TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TLCCS 1988	IGNITION SYSTEM
E40TLCDE 1986	IGNITION SYSTEM
E40TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TTLCCS 1988	IGNITION SYSTEM
E40TTLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TTLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E48ESLCCC 1988	IGNITION SYSTEM
E48ESLEDC 1996	IGNITION SYSTEM
E48ESLEOS 1995	IGNITION SYSTEM
E48ESLERD 1994	IGNITION SYSTEM
E50BECCS 1988	IGNITION SYSTEM
E50BECDE 1986	IGNITION SYSTEM
E50BECOB 1985	IGNITION SYSTEM
E50BEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50BEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50BELCCS 1988	IGNITION SYSTEM
E50BELCDE 1986	IGNITION SYSTEM
E50BELCOB 1985	IGNITION SYSTEM
E50BELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50BELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50JEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY

E50JERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TELCCS 1988	IGNITION SYSTEM
E50TELCDE 1986	IGNITION SYSTEM
E50TELCOB 1985	IGNITION SYSTEM
E50TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLCCS 1988	IGNITION SYSTEM
E50TLCDE 1986	IGNITION SYSTEM
E50TLCOB 1985	IGNITION SYSTEM
E50TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E60ELCOD 1985	IGNITION SYSTEM
E60TLCOD 1985	IGNITION SYSTEM
ELECTRICAL	BATTERY CHARGING KIT - 25,30 HP (2-Stroke)
ELECTRICAL	ELECTRIC START KIT - 40,50 HP (Johnson 2-Stroke)
ELECTRICAL 1985	BATTERY CHARGING KIT 9.9, 15, 20, 25, 30, 35
ELECTRICAL 1985	ELECTRIC STARTING KIT 40,45,55
ELECTRICAL 1986	BATTERY CHARGING KIT 9.9, 15, 20, 25, 30, 35
ELECTRICAL 1986	ELECTRIC STARTING KIT 40,45,55
ELECTRICAL 1987	BATTERY CHARGING KIT 9.9, 15, 20, 25, 30, 35
ELECTRICAL 1987	ELECTRIC STARTING KIT 40,45,55
ELECTRICAL 1988	BATTERY CHARGING KIT 9.9, 15, 20, 25, 30, 35
ELECTRICAL 1988	ELECTRIC STARTING KIT 40,45,55
ELECTRICAL 1989	ELECTRIC STARTING KIT 45, 55 COMMERCIALS
ELECTRICAL 1992	BATTERY CHARGING KIT - 10 & 25 COMMERCIAL
ELECTRICAL 1992	ELECTRIC STARTING KIT 40,45,55
ELECTRICAL 1993	BATTERY CHARGING KIT - 20, 25, 30
ELECTRICAL 1993	ELECTRIC STARTING KIT - 45/55
ELECTRICAL 1994	BATTERY CHARGING KIT - 20, 25, 30
ELECTRICAL 1994	ELECTRIC STARTING KIT - 45/55
ELECTRICAL 1995	BATTERY CHARGING KIT - 20, 25, 30 (2-CYLINDER)
ELECTRICAL 1995	TILLER ELECTRIC STARTING KIT - 45/55
ELECTRICAL 1996	BATTERY CHARGING KIT - 20, 25, 30 (2-CYLINDER)

ELECTRICAL 1996	TILLER ELECTRIC STARTING KIT - 40, 50
ELECTRICAL 1996	TILLER ELECTRIC STARTING KIT - 45, 55
ELECTRICAL 1997	BATTERY CHARGING KIT - 20, 25, 30 (2-CYLINDER)
ELECTRICAL 1997	TILLER ELECTRIC STARTING KIT - 40, 50
ELECTRICAL 1997	TILLER ELECTRIC STARTING KIT - 45, 55
ELECTRICAL 1998	BATTERY CHARGING KIT -- 20, 25, 30 (2-CYLINDER)
ELECTRICAL 1998	TILLER ELECTRIC STARTING KIT -- 40, 50
ELECTRICAL 1998	TILLER ELECTRIC STARTING KIT -- 45, 55
ELECTRICAL 1999	BATTERY CHARGING KIT -- 20, 25, 30 (2-CYLINDER)
ELECTRICAL 1999	TILLER ELECTRIC STARTING KIT -- 40, 50
ELECTRICAL 1999	TILLER ELECTRIC STARTING KIT -- 40, 55
ELECTRICAL 2000	BATTERY CHARGING KIT - 20, 25, 30 (2-CYLINDER)
ELECTRICAL 2000	TILLER ELECTRIC STARTING KIT - 40, 50
ELECTRICAL 2000	TILLER ELECTRIC STARTING KIT - 40, 55
HE25TELEDA 1996	IGNITION
HE55WMLM 1996	IGNITION SYSTEM
HE55WMLZ 1997	IGNITION SYSTEM
HJ25TELEDA 1996	IGNITION
HJ55WMLM 1996	IGNITION SYSTEM
HJ55WMLZ 1997	IGNITION SYSTEM
J10ECCD 1988	IGNITION
J10ECDB 1986	IGNITION
J10ECOM 1985	IGNITION
J10ECUE 1987	IGNITION
J10ELCCD 1988	IGNITION
J10ELCDB 1986	IGNITION
J10ELCOM 1985	IGNITION
J10ELCUE 1987	IGNITION
J10RCCD 1988	IGNITION
J10RCDB 1986	IGNITION
J10RCOM 1985	IGNITION
J10RCUE 1987	IGNITION
J10RLCCD 1988	IGNITION
J10RLCDB 1986	IGNITION
J10RLCOM 1985	IGNITION

J10RLCUE 1987	IGNITION
J10SELCCD 1988	IGNITION
J10SELCDB 1986	IGNITION
J10SELCOM 1985	IGNITION
J10SELCUE 1987	IGNITION
J15ECCS 1988	IGNITION
J15ECDE 1986	IGNITION
J15ECOB 1985	IGNITION
J15ECUD 1987	IGNITION
J15ELCCS 1988	IGNITION
J15ELCDE 1986	IGNITION
J15ELCOB 1985	IGNITION
J15ELCUD 1987	IGNITION
J15RCCS 1988	IGNITION
J15RCDE 1986	IGNITION
J15RCOB 1985	IGNITION
J15RCUD 1987	IGNITION
J15RLCCS 1988	IGNITION
J15RLCDE 1986	IGNITION
J15RLCOB 1985	IGNITION
J15RLCUD 1987	IGNITION
J20CRCCA 1988	IGNITION
J20CRCDC 1986	IGNITION
J20CRCOS 1985	IGNITION
J20CRLCCA 1988	IGNITION
J20CRLCDC 1986	IGNITION
J20CRLCOS 1985	IGNITION
J20ECCA 1988	IGNITION
J20ECDC 1986	IGNITION
J20ECOS 1985	IGNITION
J20EEOR 1995	IGNITION
J20EERC 1994	IGNITION
J20EETS 1993	IGNITION
J20ELCCA 1988	IGNITION
J20ELCDC 1986	IGNITION

J20ELCOS 1985	IGNITION
J20ELEOR 1995	IGNITION
J20ELERC 1994	IGNITION
J20ELETs 1993	IGNITION
J20TECDC 1986	IGNITION
J25ECCM 1988	IGNITION
J25ECDR 1986	IGNITION
J25ECOC 1985	IGNITION
J25EECE 1998	IGNITION
J25EEDM 1996	IGNITION
J25EEED 1999	IGNITION
J25EEEN 1999	IGNITION
J25EEOA 1995	IGNITION
J25EERR 1994	IGNITION
J25EETC 1993	IGNITION
J25EEUB 1997	IGNITION
J25ELCCM 1988	IGNITION
J25ELCDR 1986	IGNITION
J25ELCOC 1985	IGNITION
J25ELECE 1998	IGNITION
J25ELEDM 1996	IGNITION
J25ELEED 1999	IGNITION
J25ELEEN 1999	IGNITION
J25ELEOA 1995	IGNITION
J25ELERR 1994	IGNITION
J25ELETC 1993	IGNITION
J25ELEUB 1997	IGNITION
J25ELSIC elec start, remote, 20 in shaft 2001	IGNITION
J25ELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSNF Electric start, Carb, White, Remote, 20 in., 4 Amp Alt 2002	IGNITION
J25ELSOB	IGNITION
J25ELSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSRM	IGNITION
J25ELSRM - FR	22-5_SYSTÈME D'ALLUMAGE

J25ELSSS Elec. Start, 20 IN. shaft 2000	IGNITION
J25ELSTA	IGNITION
J25ELSTA - FR	22-5_SYSTÈME D'ALLUMAGE
J25ESIC elec start, remote, 15 in shaft 2001	IGNITION
J25ESSS Elec. Start, 15 IN. shaft 2000	IGNITION
J25EVSIC elec start, remote, 120 in shaft, wht 2001	IGNITION
J25EVSIC elec start, remote, 15 in shaft, wht 2001	IGNITION
J25GTESOC	IGNITION
J25GTESOC - FR	22-5_SYSTÈME D'ALLUMAGE
J25GTESRS	IGNITION
J25GTESRS - FR	22-5_SYSTÈME D'ALLUMAGE
J25RCCA 1988	IGNITION
J25RCDC 1986	IGNITION
J25RCOS 1985	IGNITION
J25RLCCA 1988	IGNITION
J25RLCDC 1986	IGNITION
J25RLCOS 1985	IGNITION
J25TECCA 1988	IGNITION
J25TECDC 1986	IGNITION
J25TECOS 1985	IGNITION
J25TEECB 1998	IGNITION
J25TEEDA 1996	IGNITION
J25TEEEE 1999	IGNITION
J25TEEEN 1999	IGNITION
J25TEEOR 1995	IGNITION
J25TEERC 1994	IGNITION
J25TEETS 1993	IGNITION
J25TEEUM 1997	IGNITION
J25TELCCA 1988	IGNITION
J25TELCDC 1986	IGNITION
J25TELCOS 1985	IGNITION
J25TELECB 1998	IGNITION
J25TELEDA 1996	IGNITION
J25TELEEE 1999	IGNITION
J25TELEEN 1999	IGNITION

J25TELEOR 1995	IGNITION
J25TELERC	IGNITION
J25TELETS 1993	IGNITION
J25TELEUM 1997	IGNITION
J25TELSIS elec start, tiller, 20 in shaft 2001	IGNITION
J25TELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSNF Electric strart, White, Tiller, 20 in., 4 Amp Alt 2002	IGNITION
J25TELSOM	IGNITION
J25TELSOM - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSRA	IGNITION
J25TELSRA - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSSD Elec. Start, Tiller, 20 IN. shaft 2000	IGNITION
J25TELSTR	IGNITION
J25TELSTR - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESIS elec start, tiller, 15 in shaft 2001	IGNITION
J25TESNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESNF Electric strart, White, Tiller,15 in. shaft, 4 Amp Alt 2002	IGNITION
J25TESOM	IGNITION
J25TESOM - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESRA	IGNITION
J25TESRA - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESSD Elec. Start, Tiller, 15 IN. shaft 2000	IGNITION
J25TESTR	IGNITION
J25TESTR - FR	22-5_SYSTÈME D'ALLUMAGE
J25TVLSIS elec start, tiller, 20 in shaft 2001	IGNITION
J25TVSIS elec start, tiller, 15 in shaft 2001	IGNITION
J28ELCDS 1986	MAGNETO
J28ESLCCR 1988	IGNITION
J28ESLEDR 1996	IGNITION
J28ESLEOC 1995	IGNITION
J28ESLERS 1994	IGNITION
J28ESLETD 1993	IGNITION
J30ECCE 1988	IGNITION
J30ECDM 1986	IGNITION

J30EECS 1998	IGNITION
J30EEDE 1996	IGNITION
J30EEEC 1999	IGNITION
J30EEEN 1999	IGNITION
J30EEOB 1995	IGNITION
J30EERM 1994	IGNITION
J30EETA 1993	IGNITION
J30EEUD 1997	IGNITION
J30ELCCE 1988	IGNITION
J30ELCDM 1986	IGNITION
J30ELECS 1998	IGNITION
J30ELEDE 1996	IGNITION
J30ELEEC 1999	IGNITION
J30ELEEN 1999	IGNITION
J30ELEOB 1995	IGNITION
J30ELERM 1994	IGNITION
J30ELETA 1993	IGNITION
J30ELEUD 1997	IGNITION
J30ELSIA elec start, remote, 20 in shaft 2001	IGNITION
J30ELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSNF Electric start, Carb, White, Remote, 20 in., 4 Amp Alt, 2002	IGNITION
J30ELSOD	IGNITION
J30ELSOD - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSRE	IGNITION
J30ELSRE - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSSR Elec. Start, 20 IN. shaft 2000	IGNITION
J30ELSTB	IGNITION
J30ELSTB - FR	22-5_SYSTÈME D'ALLUMAGE
J30ESIA elec start, remote, 15 in shaft 2001	IGNITION
J30ESSR Elec. Start, 15 IN. shaft 2000	IGNITION
J30EVLSIA elec start, remote, 20 in shaft, wht 2001	IGNITION
J30RCCE 1988	IGNITION
J30RCDM 1986	IGNITION
J30RLCCE 1988	IGNITION

J30RLCDM 1986	IGNITION
J30TECCE 1988	IGNITION
J30TECDM 1986	IGNITION
J30TEECS 1998	IGNITION
J30TEEDE 1996	IGNITION
J30TEEOB 1995	IGNITION
J30TEERM 1994	IGNITION
J30TEETA 1993	IGNITION
J30TEEUD 1997	IGNITION
J30TELCCE 1988	IGNITION
J30TELCDM 1986	IGNITION
J30TELECS 1998	IGNITION
J30TELEDE 1996	IGNITION
J30TELEOB 1995	IGNITION
J30TELERM 1994	IGNITION
J30TELETA 1993	IGNITION
J30TELEUD 1997	IGNITION
J35AELCDE 1986	IGNITION SYSTEM
J35ARLCDE 1986	IGNITION SYSTEM
J35RCCE 1988	IGNITION
J35RCDM 1986	IGNITION
J35RLCCE 1988	IGNITION
J35RLCDM 1986	IGNITION
J40AELCCS 1988	IGNITION SYSTEM
J40ARLCCS 1988	IGNITION SYSTEM
J40ATLCCS 1988	IGNITION SYSTEM
J40ECCS 1988	IGNITION SYSTEM
J40ECDE 1986	IGNITION SYSTEM
J40ECOB 1985	IGNITION SYSTEM
J40ECRM 1984	IGNITION SYSTEM
J40EEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40EERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40ELCCS 1988	IGNITION SYSTEM
J40ELCDE 1986	IGNITION SYSTEM

J40ELCOB 1985	IGNITION SYSTEM
J40ELCRM 1984	IGNITION SYSTEM
J40ELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40ELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40RCCS 1988	IGNITION SYSTEM
J40RCDE 1986	IGNITION SYSTEM
J40RCOB 1985	IGNITION SYSTEM
J40RCRM 1984	IGNITION SYSTEM
J40REOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40RERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40RLCCS 1988	IGNITION SYSTEM
J40RLCDE 1986	IGNITION SYSTEM
J40RLCOB 1985	IGNITION SYSTEM
J40RLCRM 1984	IGNITION SYSTEM
J40RLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40RLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TECCS 1988	IGNITION SYSTEM
J40TECDE 1986	IGNITION SYSTEM
J40TECOB 1985	IGNITION SYSTEM
J40TECRM 1984	IGNITION SYSTEM
J40TEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TELCCS 1988	IGNITION SYSTEM
J40TELCDE 1986	IGNITION SYSTEM
J40TELCOB 1985	IGNITION SYSTEM
J40TELCRM 1984	IGNITION SYSTEM
J40TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TLCCS 1988	IGNITION SYSTEM
J40TLCDE 1986	IGNITION SYSTEM

J40TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TTLCCS 1988	IGNITION SYSTEM
J40TTLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TTLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J48ESLCCC 1988	IGNITION SYSTEM
J48ESLEDC 1996	IGNITION SYSTEM
J48ESLEOS 1995	IGNITION SYSTEM
J48ESLERD 1994	IGNITION SYSTEM
J50BECCS 1988	IGNITION SYSTEM
J50BECDE 1986	IGNITION SYSTEM
J50BECOB 1985	IGNITION SYSTEM
J50BEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50BEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50BELCCS 1988	IGNITION SYSTEM
J50BELCDE 1986	IGNITION SYSTEM
J50BELCOB 1985	IGNITION SYSTEM
J50BELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50BELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50JEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50JERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TELCCS 1988	IGNITION SYSTEM
J50TELCDE 1986	IGNITION SYSTEM
J50TELCOB 1985	IGNITION SYSTEM
J50TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLCCS 1988	IGNITION SYSTEM
J50TLCDE 1986	IGNITION SYSTEM
J50TLCOB 1985	IGNITION SYSTEM

J50TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J60ELCOD 1985	IGNITION SYSTEM
J60TLCOD 1985	IGNITION SYSTEM
SJ25TEEDA 1996	IGNITION
SJ25TEEUM 1997	IGNITION
SJ30EEDE 1996	IGNITION
SJ30TEEUD 1997	IGNITION
TE25ELET 1993	IGNITION
TJ25ELET 1993	IGNITION
VE25ELET 1993	IGNITION
VE28ESLCCR 1988	IGNITION
VE30EETA 1993	IGNITION
VE30EETA 1993	IGNITION
VE48ESLCCC 1988	IGNITION SYSTEM
VJ25ELET 1993	IGNITION
VJ28ESLCCR 1988	IGNITION
VJ30EETA 1993	IGNITION
VJ30EETA 1993	IGNITION
VJ48ESLCCC 1988	IGNITION SYSTEM