

Where Used: Part Number 0772727

Model Name	Diagram
BE30BASSR Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	PAINT
BE35ARSSM 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	PAINT
BE35KSSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	PAINT
BJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	PAINT
BJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	PAINT
BJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	PAINT
BJ130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	PAINT
BJ130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	PAINT
BJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	PAINT
BJ175PXSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000	PAINT
BJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	PAINT
BJ200CXSSC Elec. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	PAINT
BJ200PLSSC Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	PAINT
BJ200PXSSC Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	PAINT
BJ200VCSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	PAINT
BJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	PAINT
BJ225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	PAINT
BJ225PLSSR Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	PAINT
BJ225PXSSR Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	PAINT
BJ225VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	PAINT
BJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	PAINT
BJ25ELSSS Elec. Start, 20 IN. shaft, N/A USA 2000	PAINT
BJ25ESSS Elec. Start, 15 IN. shaft, N/A USA 2000	PAINT
BJ25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	PAINT
BJ30ELSSR Elec. Start, 20 IN. shaft, N/A USA 2000	PAINT
BJ30ESSR Elec. Start, 15 IN. shaft, N/A USA 2000	PAINT
BJ35E3SSB 3 Cyl, Elec. Start, 15 IN. shaft, N/A USA 2000	PAINT
BJ35EL3SSB 3 Cyl, Elec. Start, 20 IN. shaft, N/A USA 2000	PAINT
BJ35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	PAINT
BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000	PAINT
BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000	PAINT
BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000	PAINT
BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000	PAINT

BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000	PAINT
BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000	PAINT
BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000	PAINT
BJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	PAINT
BJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	PAINT
BJ90PXSS ELEC. Start, TNT, 25 IN. shaft, N/A USA 2000	PAINT
BJ90VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	PAINT
E100WPLSSR Commercial, Elec. Start, TNT, 20 IN. shaft 2000	PAINT
E100WPXSSR Commercial, Elec. Start, TNT, 25 IN. shaft 2000	PAINT
E105WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	PAINT
E105WPLSSC Commercial, Elec. Start, TNT, 20 IN. shaft 2000	PAINT
E105WPXSSC Commercial, Elec. Start, TNT, 25 IN. shaft 2000	PAINT
E105WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	PAINT
E105WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	PAINT
E150WPLSSC Commercial, Elec Start, TNT, 20 IN. shaft 2000	PAINT
E15WRLSSC Commercial, Rope Start, Tiller, 20 IN shaft 2000	PAINT
E15WRSSC Commercial, Rope Start, Tiller, 15 IN shaft 2000	PAINT
E200WPXSSC Commercial, Elec Start, TNT, 25 IN shaft 2000	PAINT
E25WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	PAINT
E25WRSSC Commercial, Rope Start, 15 IN. shaft 2000	PAINT
E2WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	PAINT
E3ROSSR Rope Start, Tiller, 15 in. shaft, N/A USA 2000	PAINT
E3WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	PAINT
E40WRLSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	PAINT
E40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	PAINT
E40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	PAINT
E55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	PAINT
E55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	PAINT
E55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	PAINT
E65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	PAINT
E8DRSSM Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	PAINT
E8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
E8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J100WPLSSR Commercial, Elec. Start, TNT, 20 IN. shaft 2000	PAINT
J100WPXSSR Commercial, Elec. Start, TNT, 25 IN. shaft 2000	PAINT

J105WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	PAINT
J105WPLSSC Commercial, Elec. Start, TNT, 20 IN. shaft 2000	PAINT
J105WPXSSC Commercial, Elec. Start, TNT, 25 IN. shaft 2000	PAINT
J105WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	PAINT
J105WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	PAINT
J10ELSSA Electric Start, 15 IN. shaft 2000	PAINT
J10EVLSSS Electric Start, 20 IN. shaft, wht 2000	PAINT
J10RGTSSS Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	PAINT
J10RLGTSSS Rope Start, Tiller, 20 IN. shaft, N/A USA 2000	PAINT
J10RLSSA Rope Start, Tiller, 20 IN. shaft 2000	PAINT
J10RSSA Rope Start, Tiller, 15 IN. shaft 2000	PAINT
J10RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	PAINT
J10RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	PAINT
J10TEGSSS Electric Start, Tiller, 15 IN. shaft, N/A USA 2000	PAINT
J10TELSSA Electric Start, Tiller, 20 IN. shaft 2000	PAINT
J10TESSA Electric Start, Tiller, 15 IN. shaft 2000	PAINT
J115JPLSSR Jet Drive, Elec. Start, TNT, 20 IN. shaft 2000	PAINT
J115PLSSB Elec. Start, TNT, 20 IN. shaft 2000	PAINT
J115PXSSB Elec. Start, TNT, 25 IN. shaft 2000	PAINT
J115SPLSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000	PAINT
J115VLSSS Elec. Start, 20 IN. shaft, wht 2000	PAINT
J115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, 2000	PAINT
J130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	PAINT
J130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	PAINT
J130VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	PAINT
J150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	PAINT
J150JPLSSC Jet Drive, Elec. Start, TNT, 20 IN. shaft 2000	PAINT
J150MXSSD Military, Elec. Start, TNT, 25 IN. shaft 2000	PAINT
J150PLSSC Military, Elec. Start, TNT, 20 IN. shaft 2000	PAINT
J150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	PAINT
J150SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	PAINT
J150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	PAINT
J150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	PAINT
J150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	PAINT
J150WPLSSC Commercial, Elec Start, TNT, 20 IN. shaft 2000	PAINT

J15ELSSM Electric Start, 20 IN. shaft 2000	PAINT
J15EVLSSS Electric Start, 20 IN. shaft, wht 2000	PAINT
J15RLSSM Rope Start, Tiller, 20 IN. shaft 2000	PAINT
J15RSSM Rope Start, Tiller, 15 IN. shaft 2000	PAINT
J15RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	PAINT
J15RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	PAINT
J15TELSSM Electric Start, Tiller, 20 IN. shaft 2000	PAINT
J15TESSM Electric Start, Tiller, 15 IN. shaft 2000	PAINT
J15WRLSSC Commercial, Rope Start, Tiller, 20 IN shaft 2000	PAINT
J15WRSSC Commercial, Rope Start, Tiller, 15 IN shaft 2000	PAINT
J175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	PAINT
J175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	PAINT
J175PXSSC Elec. Start, TNT, 25 IN. shaft, wht 2000	PAINT
J175SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	PAINT
J175VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	PAINT
J175VLSSS Elec. Start, TNT, 20 IN. shaft, wht 2000	PAINT
J175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	PAINT
J200CXSSS Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000	PAINT
J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	PAINT
J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	PAINT
J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	PAINT
J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	PAINT
J200WPXSSC Commercial, Elec Start, TNT, 25 IN shaft 2000	PAINT
J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	PAINT
J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	PAINT
J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	PAINT
J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	PAINT
J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	PAINT
J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	PAINT
J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	PAINT
J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	PAINT
J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	PAINT
J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000	PAINT
J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000	PAINT
J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	PAINT

J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	PAINT
J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	PAINT
J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	PAINT
J25ELSSS Elec. Start, 20 IN. shaft 2000	PAINT
J25ESSS Elec. Start, 15 IN. shaft 2000	PAINT
J25JRSSB Jet Drive,Rope Start, Tiller, 20 IN. shaft 2000	PAINT
J25JRTSSS Jet Drive, Rope Start, Tiller, 15 IN. shaft 2000	PAINT
J25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000	PAINT
J25R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000	PAINT
J25RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000	PAINT
J25RLSSE Rope Start, Tiller, 20 IN. shaft 2000	PAINT
J25RSSE Rope Start, Tiller, 15 IN. shaft 2000	PAINT
J25TEL3SSB 3 Cyl, Elec. Start, Tiller, 20 IN. shaft 2000	PAINT
J25WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	PAINT
J25WRSSC Commercial, Rope Start, 15 IN. shaft 2000	PAINT
J2RTSSR Rope Start, Tiller, 15 in. shaft 2000	PAINT
J2WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	PAINT
J30ELSSR Elec. Start, 20 IN. shaft 2000	PAINT
J30ESSR Elec. Start, 15 IN. shaft 2000	PAINT
J30JRSSB Jet Drive, Rope Start, Tiller, 15 IN. shaft 2000	PAINT
J30RLSSR Rope Start, Tiller, 20 IN. shaft 2000	PAINT
J30RSSR Rope Start, Tiller, 15 IN. shaft 2000	PAINT
J35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000	PAINT
J35R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000	PAINT
J35RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000	PAINT
J35TEL3SSB 3 Cyl, Elec. Start, TNT, Tiller, 20 IN. shaft 2000	PAINT
J3RTLSSR Rope Start, Tiller, 20 in. shaft 2000	PAINT
J3RTSSR Rope Start, Tiller, 15 in. shaft 2000	PAINT
J3WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	PAINT
J40JPLSSR Jet Drive, Elec Start, TNT, 20 IN. shaft 2000	PAINT
J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000	PAINT
J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000	PAINT
J40RSSM Rope Start, Tiller, 15 IN. shaft 2000	PAINT
J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	PAINT
J40WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	PAINT

J40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	PAINT
J40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	PAINT
J4RLSSM Rope Start, Tiller, 20 IN. shaft 2000	PAINT
J4RSSM Rope Start, Tiller, 15 IN. shaft 2000	PAINT
J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000	PAINT
J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	PAINT
J55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	PAINT
J55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	PAINT
J55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	PAINT
J60PLSSE Elec Start, TNT, 20 IN. shaft 2000	PAINT
J65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	PAINT
J6RLSSM Rope Start, Tiller, 20 IN. shaft 2000	PAINT
J6RSSM Rope Start, Tiller, 15 IN. shaft 2000	PAINT
J70PLSSD Elec Start, TNT, 20 IN. shaft 2000	PAINT
J8RLSSB Rope Start, Tiller, 20 IN. shaft 2000	PAINT
J8RSSB Rope Start, Tiller, 15 IN. shaft 2000	PAINT
J8RXSSB Rope Start, Tiller, 25 IN. shaft 2000	PAINT
J8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J90PLSSE Elec. Start, TNT, 20 IN. shaft 2000	PAINT
J90SPLSSC Elec. Start, TNT, 20 IN. shaft, wht 2000	PAINT
J90VLSSC Elec. Start, TNT, 20 IN. shaft, wht 2000	PAINT
RJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	PAINT
RJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	PAINT
RJ115VLSSB Elec. Start, 20 IN. shaft, wht, N/A USA 2000	PAINT
RJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	PAINT
RJ130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	PAINT
RJ130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	PAINT
RJ130VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	PAINT
RJ150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	PAINT
RJ150PLSSC Elec. Start, TNT, 20 IN. shaft 2000	PAINT
RJ150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	PAINT
RJ150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	PAINT
RJ150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	PAINT
RJ150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	PAINT

RJ175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	PAINT
RJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	PAINT
RJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	PAINT
RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	PAINT
RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	PAINT
RJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	PAINT
RJ225CXSSS Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	PAINT
RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	PAINT
RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	PAINT
RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	PAINT
RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	PAINT
RJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	PAINT
RJ250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	PAINT
RJ250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	PAINT
RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	PAINT
RJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	PAINT
RJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	PAINT
RJ90VLSSS Elec. Start, 20 IN. shaft, wht, N/A USA 2000	PAINT
SE15BASSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	PAINT
SE25RDSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	PAINT
SJ15RTSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	PAINT
SJ25RTSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	PAINT