

Where Used: Part Number 0377230

Model Name	Diagram
40002A 1970	GEARCASE GROUP
40003A 1970	GEARCASE GROUP
40052A 1970	GEARCASE GROUP
40053A 1970	GEARCASE GROUP
40072A 1970	GEARCASE GROUP ELECTRIC SHIFT
40073A 1970	GEARCASE GROUP ELECTRIC SHIFT
40802A 1968	GEARCASE GROUP
40802D 1968	GEARCASE GROUP
40802S 1968	GEARCASE GROUP
40803A 1968	GEARCASE GROUP
40803D 1968	GEARCASE GROUP
40803S 1968	GEARCASE GROUP
40852A 1968	GEARCASE GROUP ELECTRIC START
40852C 1968	GEARCASE GROUP ELECTRIC START
40852D 1968	GEARCASE GROUP ELECTRIC START
40852S 1968	GEARCASE GROUP ELECTRIC START
40853A 1968	GEARCASE GROUP ELECTRIC START
40853C 1968	GEARCASE GROUP ELECTRIC START
40853D 1968	GEARCASE GROUP ELECTRIC START
40853S 1968	GEARCASE GROUP ELECTRIC START
40872A 1968	GEARCASE GROUP ELECTRIC SHIFT
40872C 1968	GEARCASE GROUP ELECTRIC SHIFT
40872D 1968	GEARCASE GROUP ELECTRIC SHIFT
40873A 1968	GEARCASE GROUP ELECTRIC SHIFT
40873C 1968	GEARCASE GROUP ELECTRIC SHIFT
40873D 1968	GEARCASE GROUP ELECTRIC SHIFT
40902R 1969	GEARCASE GROUP
40903R 1969	GEARCASE GROUP
40952R 1969	GEARCASE GROUP
40953R 1969	GEARCASE GROUP
40972R 1969	GEARCASE GROUP ELECTRIC SHIFT
40973R 1969	GEARCASE GROUP ELECTRIC SHIFT
40E69R 1969	GEARCASE GROUP ELECTRIC START

40E70A 1970	GEARCASE GROUP
40EL69R 1969	GEARCASE GROUP ELECTRIC START
40EL70A 1970	GEARCASE GROUP
40ES69R 1969	GEARCASE GROUP ELECTRIC SHIFT
40ES70A 1970	GEARCASE GROUP ELECTRIC SHIFT
40ESL69R 1969	GEARCASE GROUP ELECTRIC SHIFT
40ESL70A 1970	GEARCASE GROUP ELECTRIC SHIFT
40R70A 1970	GEARCASE GROUP
40RL70A 1970	GEARCASE GROUP
50172S 1971	GEARCASE
50173S 1971	GEARCASE
50202C 1972	GEARCASE 50 HP MANUAL START
50202C 1972	GEARCASE ELECTRIC START
50203C 1972	GEARCASE 50 HP MANUAL START
50203C 1972	GEARCASE ELECTRIC START
50272C 1972	GEARCASE 50 HP MANUAL START
50272C 1972	GEARCASE ELECTRIC START
50273C 1972	GEARCASE 50 HP MANUAL START
50273C 1972	GEARCASE ELECTRIC START
50302R 1973	GEARCASE MANUAL START
50302R 1973	GEARCASE ELECTRIC START
50303R 1973	GEARCASE MANUAL START
50303R 1973	GEARCASE ELECTRIC START
50372R 1973	GEARCASE MANUAL START
50372R 1973	GEARCASE ELECTRIC START
50373R 1973	GEARCASE MANUAL START
50373R 1973	GEARCASE ELECTRIC START
50442M 1974	GEARCASE
50443M 1974	GEARCASE
50472M 1974	GEARCASE
50473M 1974	GEARCASE
50542B 1975	GEARCASE
50543B 1975	GEARCASE
50572B 1975	GEARCASE
50573B 1975	GEARCASE

50ES71S 1971	GEARCASE
50ES72C 1972	GEARCASE 50 HP MANUAL START
50ES72C 1972	GEARCASE ELECTRIC START
50ES73R 1973	GEARCASE MANUAL START
50ES73R 1973	GEARCASE ELECTRIC START
50ES74M 1974	GEARCASE
50ES75B 1975	GEARCASE
50ESL71S 1971	GEARCASE
50ESL72C 1972	GEARCASE 50 HP MANUAL START
50ESL72C 1972	GEARCASE ELECTRIC START
50ESL73R 1973	GEARCASE MANUAL START
50ESL73R 1973	GEARCASE ELECTRIC START
50ESL74M 1974	GEARCASE
50ESL75B 1975	GEARCASE
50R72C 1972	GEARCASE 50 HP MANUAL START
50R72C 1972	GEARCASE ELECTRIC START
50R73R 1973	GEARCASE MANUAL START
50R73R 1973	GEARCASE ELECTRIC START
50RL72C 1972	GEARCASE 50 HP MANUAL START
50RL72C 1972	GEARCASE ELECTRIC START
50RL73R 1973	GEARCASE MANUAL START
50RL73R 1973	GEARCASE ELECTRIC START
55642E 1976	GEARCASE
55643E 1976	GEARCASE
55672E 1976	GEARCASE
55673E 1976	GEARCASE
55772D 1977	GEARCASE
55773D 1977	GEARCASE
55874S 1978	GEARCASE
55875S 1978	GEARCASE
55E76E 1976	GEARCASE
55E77D 1977	GEARCASE
55E78S 1978	GEARCASE
55EL76E 1976	GEARCASE
55EL77D 1977	GEARCASE

55EL78S 1978	GEARCASE
MISCELLANEOUS 1972	CHROME PUMP KITS 50 HP
MISCELLANEOUS 1973	CHROME PUMP KITS 50 HP
MISCELLANEOUS 1974	CHROME PUMP KITS 50 HP
MISCELLANEOUS 1975	CHROME PUMP KITS 50 HP
MISCELLANEOUS 1976	CHROME PUMP KITS 55 H.P.
MISCELLANEOUS 1977	CHROME PUMP KITS 55 HP
RD-30A 1968	GEARCASE GROUP
RD-30D 1968	GEARCASE GROUP
RD-30S 1968	GEARCASE GROUP
RDL-30A 1968	GEARCASE GROUP
RDL-30D 1968	GEARCASE GROUP
RDL-30S 1968	GEARCASE GROUP
RDS-30A 1968	GEARCASE GROUP
RDS-30C 1968	GEARCASE GROUP
RDS-30D 1968	GEARCASE GROUP
RDS-30S 1968	GEARCASE GROUP
RDSL-30A 1968	GEARCASE GROUP
RDSL-30C 1968	GEARCASE GROUP
RDSL-30D 1968	GEARCASE GROUP
RDSL-30S 1968	GEARCASE GROUP
RK-30A 1968	GEARCASE GROUP ELECTRIC SHIFT
RK-30C 1968	GEARCASE GROUP ELECTRIC SHIFT
RK-30D 1968	GEARCASE GROUP ELECTRIC SHIFT
RKL-30A 1968	GEARCASE GROUP ELECTRIC SHIFT
RKL-30C 1968	GEARCASE GROUP ELECTRIC SHIFT
RKL-30D 1968	GEARCASE GROUP ELECTRIC SHIFT