

Where Used: Part Number 0912937

Model Name	Diagram
302BMRAMH 1992	HEAD & ROCKER ARM
302BMRAMK 1992	HEAD & ROCKER ARM
302BMRJVB 1993	HEAD & ROCKER ARM
302BMRPWR 1990	HEAD & ROCKER ARM
302BMRPWS 1990	HEAD & ROCKER ARM
302BMRRGD 1991	HEAD & ROCKER ARM
302BPRPWR 1990	HEAD & ROCKER ARM
302BPRPWS 1990	HEAD & ROCKER ARM
302CMLPWR 1990	HEAD & ROCKER ARM
302CMLPWS 1990	HEAD & ROCKER ARM
302CMRAMH 1992	HEAD & ROCKER ARM
302CMRAMK 1992	HEAD & ROCKER ARM
302CMRJVB 1993	HEAD & ROCKER ARM
302CMRPWR 1990	HEAD & ROCKER ARM
302CMRPWS 1990	HEAD & ROCKER ARM
302CMRRGD 1991	HEAD & ROCKER ARM
302CPRAMH 1992	HEAD & ROCKER ARM
302CPRAMK 1992	HEAD & ROCKER ARM
302CPRJVB 1993	HEAD & ROCKER ARM
302CPRPWR 1990	HEAD & ROCKER ARM
302CPRPWS 1990	HEAD & ROCKER ARM
302CPRRGD 1991	HEAD & ROCKER ARM
460AMLMD 1989	CYLINDER HEAD
460APRMED 1989	CYLINDER HEAD
754APEPWS 1990	CYLINDER HEAD
754APFTC 1987	CYLINDER HEAD
754APSRC 1987	CYLINDER HEAD
754BMLGDP 1988	CYLINDER HEAD
754BPFTC 1987	CYLINDER HEAD
754BPRGDP 1988	CYLINDER HEAD
754BPSRC 1987	CYLINDER HEAD