



Aerator pump for baitwell/livewell tanks

It can be fixed to the tank by means of a suction cup. Fitted with aerator hose to be fixed with suction cups to the tank sides. Packed in blisters.

Code	V	Flow l/min	Current draw A	Head m
16.163.00	12	22	1	3



TMC aerator pump for livewell/baitwell tanks

Designed for mounting inside the tank by means of 3 suction pads. It connects at 12 volts.

Code	V	Flow l/min
16.452.43	12	15.8


ATTWOOD thru-hull scoop strainer



Code 16.388.61

Sea inlet with filter to match a pump with a 19 mm (3/4") hose connection.

ATTWOOD strainer



Code 16.388.50

Only a filter to be applied externally to the pump 16.411.01/02/03/04, 16.161.01/02/03/04 when mounted directly on the transom.


ATTWOOD spray head



Spray head to connect to aeration pumps. Flow rate adjustable as desired.

Code	For pipe Ø mm	For pumps
16.412.53	19	16.411.xx; 16.160.xx; 16.161.xx

TMC electric aerator pump for livewell tanks



Code 16.201.00

Bulkhead mounting, powered by 2 x D batteries, 100% watertight.