





Spring locks



▲ 38.180.01



Spring lock for hatches and cabinet doors


Press the push-button to **lock** it and is then **aligned**, press the button to **open** and to release the cabinet doors making a knob grip at the same time; 2-screw mounting click and ring nut from the outside with a hole of Ø size 26 mm; **nylon** casing, **stainless steel** springs.

Code	Version
38.180.01	Simple nylon ratchet
38.180.02	simple nylon ratchet with lateral anti-vibration stoppers

Minimum flange required 5 mm. **Attention: ratchet, only. Knob and ring nut art. 38.181.xx to be ordered separately.**




▲ 38.180.02




▲ 38.180.02

Knob with chromed brass ring


To pair with spring latch 38.180.01/02.




▲ 38.181.01



▲ 38.181.02




▲ 38.181.03



▲ 38.181.00


Knob with polished painted brass ring



To pair with spring latch 38.180.01/02.

Code	For hatches up to mm
38.181.04	13
38.181.05	16
38.181.06	19
38.181.07	23


Knob with pearl chromed brass ring



To pair with spring latch 38.180.01/02.

Code	For hatches up to mm
38.181.11	16
38.181.12	19

Knob with chromed brass ring



To pair with spring latch 38.180.01/02.

Code	For hatches up to mm
38.181.20	16
38.181.21	19
38.181.22	23



L shape stop plates

for pawl series: 38.180.01/02 and 38.182.01/04.

Code	Material
38.183.05	Chromed brass