



Sticks and trapeze handles

OSCULATI



Telescopic tiller extensions

in **anodized aluminum** with elastomer joint, "Soft" handle


Code	Tube Ø mm	Handgrip Ø mm	Length cm
60.668.00	17 - 20	25	66 - 120
60.668.01	17 - 20	25	93 - 173



Stick rudder bar

Made of **black anodized aluminium**, fitted with elastomer swivel and "golf" handgrip.

Code	Ø mm	Length cm
60.511.00	16	61
60.511.11	16	76
60.511.12	16	91



▲ E: Measurement of the maximum and minimum extension of the stick. \$L\$: Measurement of the distance from the hook attachment point (Y) to the hinge attachment point of the stick on the bar (X).

Stick Friend

Adjustable in length in an easy and precise way. It includes two important functions: 1) it is a sturdy tiller that extends with precision - 2) it is a manual self-steering; it has the same function of the handwheel locking the wheel steering. When locked in its place it holds the tiller in the desired position, it can be easily adjusted by turning the handle and sliding the tiller up to new position. Leaving the handle, "Friend" will lock it in that position. Coming back to traditional stick steering is easy and intuitive: rise it from its bracket to disengage. Useful when needing to leave the tiller when sailing, or when at mooring/anchor to lock the tiller.

Handle		Extensible mm	Boat L measure
A	B		
-	60.663.02	585/821	670/760
60.664.00	60.663.00	642/935	760/870
60.664.01	60.663.01	750/1043	870/980



Plastic joint for stick



Code	Description
60.050.04	Removable joint for elastomer stick, suitable for pipe Ø 13 mm inner part
60.050.05	Adaptable base for tube size 25/32 mm, external
60.050.06	Reduction bushing for pipe Ø mm 17 inner side



Flexible tiller extension fitting

Made of **nylon and neoprene**, allows easy removal of the tiller extension if necessary.

Code	For internal pipe Ø mm
60.237.60	16